

**Digitized Automation for a Changing World** 

# Delta IP55 Fan and Pump Drive CFP2000 Series User Manual





### Copyright notice

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

### **Limitation of Liability**

The contents of this user manual are only for the use of the products manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following: (i) this product will meet your needs or expectations; (ii) the information contained in the product is current and correct; (iii) the product does not infringe any rights of any other person. You shall bear your own risk to use this product.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, indirect, incidental, special, derivative or consequential damages (including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contains special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.

(Original instructions)



- ☑ Disconnect AC input power before connecting any wiring to the AC motor drive.
- ☑ Turn OFF the AC motor drive power before doing any wiring. A charge with hazardous voltages may remain in the DC bus capacitors even after the power has been turned off for a short time. Do not touch the internal circuits and components before the POWER LED (behind the digital keypad) is OFF.
- ☑ There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. Please do not touch these components or the circuit boards before taking anti-static measures.
- ✓ Never reassemble internal components or wiring.
- ☑ Ground the AC motor drive using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed.
- ☑ Do NOT install the AC motor drive in a place subjected to high temperature, direct sunlight and inflammables.



- ☑ Never connect the AC motor drive output terminals U/T1, V/T2 and W/T3 directly to the AC mains circuit power supply.
- After finishing the wiring of the AC motor drive, check if U/T1, V/T2, and W/T3 are short-circuited to ground with a multimeter. Do NOT power the drive if short circuits occur. Eliminate the short circuits before the drive is powered.
- ☑ The rated voltage of power system to install motor drives is listed below. Ensure that the installation voltage is in the correct range when installing a motor drive.
  - 1. For 230V models, the range is between 170–264 V.
  - 2. For 460V models, the range is between 323–528 V.
  - 3. For 575V models, the range is between 446–660 V.
- ☑ Refer to the table below for short circuit rating:

Model (Power)	Short circuit rating
230V / 460V	100 kA
575V (2-50 HP)	5 kA
575V (60-125 HP)	10 kA

- ☑ Only qualified persons are allowed to install, wire and maintain the AC motor drives.
- ☑ Even if the three-phase AC motor is stopped, a charge with hazardous voltages may still remain in the main circuit terminals of the AC motor drive.
- ☑ The performance of electrolytic capacitor will degrade if it is not charged for a long time. It is recommended to charge the drive which is stored in no charge condition every 2 years for 3–4 hours to restore the performance of electrolytic capacitor in the motor drive. NOTE: When power up the motor drive, use adjustable AC power source (ex. AC autotransformer) to charge the drive at 70%–80% of rated voltage for 30 minutes (do not run the motor drive). Then charge the drive at 100% of rated voltage

- for an hour (do not run the motor drive). By doing these, restore the performance of electrolytic capacitor before starting to run the motor drive. Do NOT run the motor drive at 100% rated voltage right away.
- ☑ Pay attention to the following precautions when transporting and installing this package (including wooden crate and wood stave)
  - 1. If you need to deworm the wooden crate, do NOT use fumigation or you will damage the drive. Any damage to the drive caused by using fumigation voids the warranty.
  - 2. Use other methods, such as heat treatment or any other non-fumigation treatment, to deworm the wood packaging material.
  - 3. If you use heat treatment to deworm, leave the packaging materials in an environment of over 56°C for a minimum of thirty minutes.
- ☑ Connect the drive to a three-phase three-wire or three-phase four-wire Wye system to comply with UL standards.
- ☑ If the motor drive generates leakage current over AC 3.5 mA or over DC 10 mA on a grounding conductor, compliance with local grounding regulations or EN 61800-5-1 standard is the minimum requirement for grounding.
- ☑ The CFP2000 drives are designed for Industrial application. The non-linear load generates harmonic current, when you use a CFP2000 drive in a public low-voltage distribution network (such as power supply in a residential building), install suppression devices (for example, one-to-one transformer or input AC reactor) to suppress the possible interferences caused by the harmonic current. Contact Delta for more information.

### NOTE:

- In the figures in this manual, the cover or safety shield is disassembled only when explaining the details of the product. During operation, install the top cover and wiring correctly according to the provisions. Refer to the operation descriptions in the manual to ensure safety.
- 2. The figures in this instruction are only for reference and may be slightly different depending on your model, but it will not affect your customer rights.
- 3. The content of this manual may be revised without prior notice. Consult our distributors or download the latest version at <a href="http://www.deltaww.com/iadownload">http://www.deltaww.com/iadownload</a> acmotordrive

# **Table of Contents**

Chapter 1 Introduction	1
1-1 Nameplate Information	2
1-2 Model Name	3
1-3 Serial Number	3
1-4 Apply After-sales Service by Mobile Device	4
1-5 RFI Jumper	5
1-6 Dimensions	13
1-7 Digital Keypad	28
Chapter 2 Installation	29
2-1 Mounting Clearance	30
2-2 Airflow and Power Dissipation	33
Chapter 3 Unpacking	35
3-1 Unpacking	36
3-2 The Lifting Hook	40
3-3 Weight	42
Chapter 4 Wiring	43
4-1 System Wiring Diagram	45
4-2 Wiring	46
4-3 Wiring Plate Diagram	49
4-4 Basic Waterproof Component Wiring Diagram	50
Chapter 5 Main Circuit Terminals	53
5-1 Main Circuit Diagram	56
5-2 Specifications of Main Circuit Terminals	57
Chapter 6 Control Terminals	75
6-1 Remove the Cover for Wiring	78
6-2 Specifications of Control Terminal	81
6-3 Remove the Terminal Block	84
Chapter 7 Optional Accessories	85
7-1 Brake Resistors and Brake Units Used in AC Motor Drives	86
7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker	93
7-3 Fuse Specification Chart	96
7-4 AC Reactor	98
7-5 Zero Phase Reactors	135
7-6 EMC Filter	136
7-7 Panel Mounting (MKC-KPPK)	
7-8 Fan Kit	144
7-9 USB/RS-485 Communication Interface IFD6530	
Chapter 8 Option Cards	161
8-1 Option Card Installation	162

8-2 EMC-D42A Extension card for 4-point digital input / 2-point digital input	170
8-3 EMC-D611A Extension card for 6-point digital input (110 V <sub>AC</sub> input voltage)	170
8-4 EMC-R6AA Relay output extension card (6-point N.O. output contact)	171
8-5 EMC-BPS01 +24V power card	171
8-6 EMC-A22A – Extension card for 2-point analog input / 2-point analog output	172
8-7 CMC-PD01 – Communication card, PROFIBUS DP	174
8-8 CMC-DN01 – Communication card, DeviceNet	176
8-9 CMC-EIP01 / CMC-EIP02 – Communication card, EtherNet/IP	179
8-10 CMC-PN01 – Communication card, PROFINET	183
8-11 eZVFD – Communication card, BACnet Ethernet/BACnet IP	187
8-12 EMC-COP01 – Communication card, CANopen	191
8-13 Delta Standard Fieldbus Cables	193
Chapter 9 Specification	195
9-1 230V Models	196
9-2 460V Models	198
9-3 575V Models	200
9-4 General Specifications	202
9-5 Environment for Operation, Storage and Transportation	203
9-6 Operation Noise Level	204
9-7 Specifications for Operation Temperature and Protection Level	205
9-7 Derating Curve for Ambient Temperature, Altitude and Carrier Frequency	206
9-8 Efficiency Curve	210
Chapter 10 Digital Keypad	213
10-1 Descriptions of Digital Keypad	214
10-2 Function of Digital Keypad KPC-CC01	217
10-3 TPEditor Installation Instruction	239
10-4 Fault Code Description of Digital Keypad KPC-CC01	248
10-5 Unsupported Functions when using TPEditor with the KPC-CC01	255
Chapter 11 Summary of Parameter Settings	257
Chapter 12 Description of Parameter Settings	311
12-1 Description of Parameter Settings	312
00 Drive Parameters	312
01 Basic Parameters	329
02 Digital Input / Output Parameter	343
03 Analog Input / Output Parameter	367
04 Multi-Step Speed Parameters	393
05 Motor Parameters	397
06 Protection Parameters	405
07 Special Parameters	441
08 High-function PID Parameters	459
09 Communication Parameters	471
10 Sensorless Motor Control Parameters	481

11 Advanced Parameters (applied to 230V / 460V models)	489
12 Pump Parameters	497
13 Application Parameters by Industry	517
14 Extension Card Parameters	521
12-2 Adjustment & Application	525
Chapter 13 Warning Codes	549
Chapter 14 Fault Codes and Descriptions	643
Chapter 15 CANopen Overview	737
15-1 CANopen Overview	739
15-2 Wiring for CANopen	742
15-3 CANopen Communication Interface Description	743
15-5 CANopen Fault Codes	758
15-6 CANopen LED Function	766
Chapter 16 PLC Function Applications	767
16-1 PLC Summary	768
16-2 Notes before PLC Use	769
16-3 Turn On	771
16-4 Basic Principles of PLC Ladder Diagrams	781
16-5 Various PLC Device Functions	793
16-6 Introduction to the Command Window	809
16-7 Error Display and Handling	904
16-8 CANopen Master Control Applications	905
16-9 Explanation of Various PLC Speed Mode Controls	918
16-10 Internal Communications Main Node Control	920
16-11 Modbus Remote IO Control Applications (use MODRW)	924
16-12 Calendar Functions	931
Chapter 17 Introduction to BACnet	933
17-1 About BACnet	934
17-2 CFP2000 BACnet-Object and Property	934
17-3 Steps to setup the Parameters about BACnet in CFP2000	940
17-4 BACnet Protocol Implementation Conformance Statement	942
Chapter 18 Safe Torque Off Function	949
18-1 The Drive Safety Function Failure Rate	950
18-2 Safe Torque Off Terminal Function Description	951
18-3 Wiring Diagram	952
18-4 Parameter	955
18-5 Operating Sequence Description	956
18-6 New Error Code for STO Function	958
Appendix A. Modbus Protocol	959
A-1 Code Description	960
A-2 Data Format	960
A-3 Communication Protocol	961

Α	ppendix B. Revision History	.977
	71 0 Exception (Cosponed	.010
	A-5 Exception Response	976
	A-4 Address List	.966

Issued Edition: 00

Firmware Version: V1.09 (Refer to Parameter 00-06 on the product to get the firmware version.)

Issued Date: 2025/08

# **Chapter 1 Introduction**

- 1-1 Nameplate Information
- 1-2 Model Name
- 1-3 Serial Number
- 1-4 Apply After-sales Service by Mobile Device
- 1-5 RFI Jumper
- 1-6 Dimensions
- 1-7 Digital Keypad

After receiving the AC motor drive, check for the following:

- 1. Inspect the unit after unpacking to ensure that it was not damaged during shipment. Make sure that the part number printed on the package matches the part number indicated on the nameplate.
- 2. Make sure that the mains voltage is within the range indicated on the nameplate. Install the AC motor drive according to the instructions in this manual.
- 3. Before applying power, make sure that all devices, including mains power, motor, control board and digital keypad, are connected correctly.
- 4. When wiring the AC motor drive, make sure that the wiring of input terminals "R/L1, S/L2, T/L3" and output terminals "U/T1, V/T2, W/T3" are correct to prevent damage to the drive.
- 5. When power is applied, use the digital keypad (KPC-CC01) to select the language and set parameters. When executing a trial run, begin with a low speed and then gradually increase the speed to the desired speed.

### 1-1 Nameplate Information






Figure 1-1

### 1-2 Model Name



### 1-3 Serial Number



### 1-4 Apply After-sales Service by Mobile Device

### 1-4-1 Location of Service Link Label

### Frame A-D

Service link label (Service Label) is pasted on the area as the drawing below shows:




Figure 1-2

### 1-4-2 Service Link Label



Figure 1-3

### Scan QR Code to apply

- 1. Find the QR code sticker (as shown above).
- 2. Use a smartphone to run a QR Code reader APP.
- Point your camera at the QR Code. Hold your camera steady until the QR code comes into focus.
- 4. Access the Delta After-sales Service website.
- 5. Fill your information into the column marked with an orange star.
- 6. Enter the CAPTCHA and click "Submit" to complete the application.

### Cannot find the QR Code?


- 1. Open a web browser on your computer or smart phone.
- 2. Enter <a href="https://service.deltaww.com/us/Repair/Request?type=IA">https://service.deltaww.com/us/Repair/Request?type=IA</a> in browser bar and press the Enter key.
- 3. Fill your information into the columns marked with an orange star.
- 4. Enter the CAPTCHA and click "Submit" to complete the application.


### 1-5 RFI Jumper

- 1. The drive contains Varistor / MOVs that are connected from phase-to-phase and from phase-to-ground to prevent the drive from unexpected stop or damage caused by mains surges or voltage spikes. Because the Varistors / MOVs from phase-to-ground are connected to ground with the RFI jumper, removing the RFI jumper disables the protection.
- 2. In the models with a built-in EMC filter, the RFI jumper connects the filer capacitors to ground to form a return path for high frequency noise in order to isolate the noise from contaminating the mains power. Removing the RFI jumper strongly reduces the effect of the built-in EMC filter. Although a single drive complies with the international standards for leakage current, an installation with several drives with built-in EMC filter can trigger the RCD. Removing the RFI jumper helps, but the EMC performance of each drive would be no longer guaranteed.

Frame A

By switching the position of the RFI jumper to control ON / OFF.








Figure 1-4

Frame B

By switching the position of the RFI jumper to control ON / OFF.




Figure 1-5

Frame C

By switching the position of the RFI jumper to control ON / OFF.






Figure 1-6

By switching the position of the RFI jumper to control ON / OFF.








Figure 1-7

Frame D

By switching the position of the RFI jumper to control ON / OFF.




Figure 1-8

### Remove the built-in EMC Filter

In some specific power system, the shunt capacitors might cause damage to the motor drive or electrically charge the enclosure to cause electrical shock. Because of this, follow these recommendations for jumper / screw installation of these three power systems:

Jumper / Screw	TN-S System	Corner Grounded TN	TT System	IT System	
RFI-1	Keep (Default)	Remove	Remove	Remove	
RFI-2	Keep (Default)	Remove	Remove	Remove	Table

1-1

### NOTE:

- 1. If any of the RFIs is removed, the EMC effect is affected.
- 2. Use a LCB (leakage circuit breaker) designed for the motor drive. If an LCB has tripped, remove the RFI-2 (jumper / screw) or contact an authorized Delta dealer near you.
- 3. Grounding Systems:

The international standard IEC60364 distinguishes three different grounding system categories, using the two-letter codes TN, TT and IT.

- The first letter indicates the grounding type for the power supply equipment (generator or transformer).
  - T: Connect one or more points on the power supply directly to the same grounding point.
  - I: Do not connect to ground (isolated) or connect to ground with high impedance.
- The **second letter** indicates the connection between ground and the power supply equipment.
  - T: Connected directly to ground. This grounding point is separated from other grounding points in the power supply.
  - N: Connected to ground by the conductor that is provided by the power supply system

### Isolating main power from ground

When the power distribution system for the drive is a floating ground system (IT Systems) or an asymmetric ground system (Corner Grounded TN Systems), you must remove the RFI Jumper. Voltage of any phase to the ground for either system may be larger than the voltage specifications of the drive's builtin surge absorber and common-mode capacitance. In this case, connecting RFI jumper to the ground may cause damage to the drive.

Important points regarding ground connection:

- ☑ To ensure the safety of personnel, proper operation, and to reduce electromagnetic radiation, you must properly ground the motor and drive during installation.
- ☑ The diameter of the grounding cables must comply with the local safety regulations.
- ☑ You must connect the shielded calbe to the motor drive's ground to meet safety regulations.
- ☑ Only use the shielded cables as the ground for equipment when the aforementioned points are met.
- ☑ When installing multiple drives, do not connect the grounds of the drives in series but connect each drive to ground. The following pictures show the correct and wrong ways to connect the grounds.




Figure 1-9 Figure 1-10

Pay particular attention to the following points:

- ☑ Do not remove the RFI jumper while the power is on.
- ☑ Removing the RFI jumper also cuts the capacitor conductivity of the surge absorber to ground and the built-in EMC filter capacitors. Compliance with the EMC specifications is no longer guaranteed.
- ☑ Do not remove the RFI jumper if the mains power is a symmetrical grounded power system in order to maintain the efficiency for EMC circuit.
- ☑ Remove the RFI jumper when conducting high voltage tests. When conducting a high voltage test to the entire facility, disconnect the mains power and the motor if the leakage current is too high.

### Floating Ground System (IT Systems)

A floating ground system is also called an IT system, an ungrounded system, or a high impedance / resistance (greater than 30  $\Omega$ ) grounded system.

- ☑ Remove the RFI jumper to disconnect the ground cable from the internal filter capacitor and surge absorber.
- ☑ In situations where EMC is required, check for excess electromagnetic radiation affecting nearby low-voltage circuits. In some situations, the adapter and cable naturally provide enough suppression. If in doubt, install an extra electrostatic shielded cable on the power supply side between the main circuit and the control terminals to increase shielding.
- ☑ Do not install an external RFI / EMC filter. The external EMC filter passes through a filter capacitors and connects power input to the ground. This is very dangerous and damages the motor drive.

### Asymmetric Ground System (Corner Grounded TN Systems)

Caution: Do not remove the RFI jumper while power to the input terminal of the drive is ON. In the following four situations, you must remove the RFI jumper. This is to prevent the system from grounding through the RFI and filter capacitors and damaging the drive.

# You must remove the RFI jumper for an asymmetric ground system 1. Grounding at a corner in a triangle configuration L1 Configuration 2. Grounding at a midpoint in a polygonal configuration Configuration L1 Figure 1-11 3. No stable neutral grounding in a three-phase autotransformer configuration L1 L2 L2 L3 Figure 1-12

In the following situation, you can use the RFI jumper for a symmetrical grounding power system.

L3-





Figure 1-13

L3

### 1-6 Dimensions

### Frame A

A-1: VFD007FP2EA-52, VFD015FP2EA-52, VFD022FP2EA-52, VFD037FP2EA-52, VFD055FP2EA-52, VFD007FP4EA-52, VFD015FP4EA-52, VFD022FP4EA-52, VFD037FP4EA-52, VFD040FP4EA-52, VFD055FP4EA-52, VFD075FP4EA-52, VFD015FP5EA-52, VFD022FP5EA-52, VFD037FP5EA-52, VFD055FP5EA-52, VFD075FP5EA-52






Figure 1-15

Frame	W	W1	Н	H1	D	D1	S1	Ø1	Ø2	Ø3
A-1	161.0 (6.34)	135.0 (5.31)	366.4 (14.43)	356.0 (14.02)	-	199.0 (7.83)	6.5 (0.26)	25.4 (1.00)	20.3 (0.80)	20.3 (0.80)

Table 1-2

### Frame A

A-2: VFD007FP2EA-52S, VFD015FP2EA-52S, VFD022FP2EA-52S, VFD037FP2EA-52S, VFD055FP2EA-52S, VFD007FP4EA-52S, VFD015FP4EA-52S, VFD037FP4EA-52S, VFD037FP4EA-52S, VFD037FP4EA-52S, VFD015FP5EA-52S, VFD022FP5EA-52S, VFD037FP5EA-52S, VFD055FP5EA-52S, VFD075FP5EA-52S, V





Figure 1-16

										`
Frame	W	W1	Н	H1	D	D1	S1	Ø1	Ø2	Ø3
A-2	161.0 (6.34)	135.0 (5.31)	366.4 (14.43)	356.0 (14.02)	244.0 (9.61)	199.0 (7.83)	6.5 (0.26)	25.4 (1.00)	20.3 (0.80)	20.3 (0.80)

Table 1-3

### Frame A

A-3: VFD007FP2EA-41, VFD015FP2EA-41, VFD022FP2EA-41, VFD037FP2EA-41, VFD055FP2EA-41, VFD007FP4EA-41, VFD015FP4EA-41, VFD022FP4EA-41, VFD037FP4EA-41, VFD040FP4EA-41, VFD055FP4EA-41, VFD075FP4EA-41, VFD015FP5EA-41, VFD022FP5EA-41, VFD037FP5EA-41, VFD055FP5EA-41, VFD075FP5EA-41







Figure 1-17

										•
Frame	W	W1	Н	H1	D	D1	S1	Ø1	Ø2	Ø3
A-3	161.0 (6.34)	135.0 (5.31)	366.4 (14.43)	356.0 (14.02)	_	199.0 (7.83)	6.5 (0.26)	28.0 (1.10)	22.0 (0.87)	_

Table 1-4

### Frame B

B-1: VFD075FP2EA-52, VFD110FP2EA-52, VFD110FP4EA-52, VFD150FP4EA-52, VFD185FP4EA-52, VFD1220FP4EA-52, VFD110FP5EA-52, VFD150FP5EA-52, VFD185FP5EA-52







Figure 1-18

Frame	W	W1	Н	H1	D	D1	S1	Ø1	Ø2	Ø3
B-1	216.0 (8.50)	181.0 (7.13)	491.4 (19.35)	479.0 (18.86)	-	229.0 (9.02)	8.5 (0.33)	41.0 (1.61)	25.4 (1.00)	20.3 (0.80)

Table 1-5

### Frame B

B-2: VFD075FP2EA-52S, VFD110FP2EA-52S, VFD110FP4EA-52S, VFD150FP4EA-52S, VFD185FP4EA-52S, VFD220FP4EA-52S, VFD110FP5EA-52S, VFD150FP5EA-52S, VFD185FP5EA-52S







Figure 1-19

Frame	W	W1	Н	H1	D	D1	S1	Ø1	Ø2	Ø3
B-2	216.0 (8.50)	181.0 (7.13)	491.4 (19.35)	479.0 (18.86)	274.0 (10.79)	229.0 (9.02)	8.5 (0.33)	41.0 (1.61)	25.4 (1.00)	20.3 (0.80)

Table 1-6

### Frame B

B-3: VFD075FP2EA-41, VFD110FP2EA-41, VFD110FP4EA-41, VFD150FP4EA-41, VFD185FP4EA-41, VFD1220FP4EA-41, VFD110FP5EA-41, VFD150FP5EA-41, VFD185FP5EA-41






Figure 1-20

Frame	W	W1	Н	H1	D	D1	S1	Ø1	Ø2	Ø3
B-3	216.0 (8.50)	181.0 (7.13)	491.4 (19.35)	479.0 (18.86)	-	229.0 (9.02)	8.5 (0.33)	41.8 (1.65)	28.0 (1.10)	22.0 (0.87)

Table 1-7

### Frame C

C-1: VFD150FP2EA-52, VFD185FP2EA-52, VFD300FP4EA-52, VFD370FP4EA-52, VFD220FP5EA-52, VFD300FP5EA-52, VFD370FP5EA-52




Figure 1-21

							=
Frame	W	W1	W2	Н	H1	H2	D
C-1	282.0 (11.10)	231.0 (9.09)	271.0 (10.67)	630.0 (24.8)	611.0 (24.06)	602.5 (23.72)	265.0 (10.43)
Frame	D1	S1	S2	Ø1	Ø2	Ø3	Ø4
C-1	27.8 (1.09)	9.0 (0.35)	16.0 (0.63)	51.0 (2.01)	41.0 (1.61)	25.4 (1.00)	20.3 (0.80)

Table 1-8

### Frame C

C-2: VFD150FP2EA-52S, VFD185FP2EA-52S, VFD220FP5EA-52S, VFD300FP4EA-52S, VFD370FP4EA-52S, VFD370FP5EA-52S




Figure 1-22

							•	(
Frame	W	W1	W2	Н	H1	H2	D	D1
C-2	282.0 (11.10)	231.0 (9.09)	271.0 (10.67)	630.0 (24.8)	611.0 (24.06)	602.5 (23.72)	310.0 (12.20)	265.0 (10.43)
Frame	D2	S1	S2	Ø1	Ø2	Ø3	Ø4	
C-2	27.8 (1.09)	9.0 (0.35)	16.0 (0.63)	51.0 (2.01)	41.0 (1.61)	25.4 (1.00)	20.3 (0.80)	

Table 1-9

### Frame C

C-3: VFD150FP2EA-41, VFD185FP2EA-41, VFD300FP4EA-41, VFD370FP4EA-41, VFD220FP5EA-41, VFD300FP5EA-41, VFD370FP5EA-41




Figure 1-23

							· · · · · · · · · · · · · · · · · · ·
Frame	W	W1	W2	Н	H1	H2	D
C-3	282.0 (11.10)	231.0 (9.09)	271.0 (10.67)	630.0 (24.80)	611.0 (24.06)	602.5 (23.72)	265.0 (10.43)
Frame	D1	S1	S2	Ø1	Ø2	Ø3	Ø4
C-3	27.8 (1.09)	9.0 (0.35)	16.0 (0.63)	51.0 (2.01)	34.0 (1.34)	28.0 (1.10)	22.0 (0.87)

Table 1-10

D0-1: VFD220FP2EA-52, VFD300FP2EA-52, VFD450FP4EA-52, VFD550FP4EA-52, VFD450FP5EA-52, VFD550FP5EA-52




Figure 1-24

							`
Frame	W	W1	Н	H1	H2	D	D1
D0-1	308.0 (12.13)	272.0 (10.71)	680.0 (26.77)	651.0 (25.63)	622.0 (24.49)	307.0 (12.09)	17.0 (0.67)
Frame	S1	S2	Ø1	Ø2	Ø3	Ø4	
D0-1	13.0 (0.51)	18.0 (0.71)	51.0 (2.01)	41.0 (1.61)	25.4 (1.00)	20.3 (0.80)	

Table 1-11

D0-2: VFD220FP2EA-52S, VFD300FP2EA-52S, VFD450FP4EA-52S, VFD550FP4EA-52S, VFD450FP5EA-52S, VFD550FP5EA-52S




Figure 1-25

Frame	W	W1	Н	H1	H2	D	D1
D0-2	308.0 (12.13)	272.0 (10.71)	680.0 (26.77)	651.0 (25.63)	622.0 (24.49)	352.0 (13.86)	307.0 (12.09)
Frame	D2	S1	S2	Ø1	Ø2	Ø3	Ø4
D0-2	17.0 (0.67)	13.0 (0.51)	18.0 (0.71)	51.0 (2.01)	41.0 (1.61)	25.4 (1.00)	20.3 (0.80)

Table 1-12

D0-3: VFD220FP2EA-41, VFD300FP2EA-41, VFD450FP4EA-41, VFD550FP4EA-41, VFD450FP5EA-41, VFD550FP5EA-41




Figure 1-26

Frame	W	W1	Н	H1	H2	D	D1
D0-3	308.0 (12.13)	272.0 (10.71)	680.0 (26.77)	651.0 (25.63)	622.0 (24.49)	307.0 (12.09)	17.0 (0.67)
Frame	S1	S2	Ø1	Ø2	Ø3	Ø4	
D0-3	13.0 (0.51)	18.0 (0.71)	51.0 (2.01)	44.0 (1.73)	28.0 (1.10)	22.0 (0.87)	

Table 1-13

# D-1: VFD370FP2EA-52, VFD450FP2EA-52, VFD750FP4EA-52, VFD900FP4EA-52, VFD750FP5EA-52, VFD900FP5EA-52




Figure 1-27

Frame	W	W1	Н	H1	H2	D	D1
D-1	370.0 (14.57)	334.0 (13.15)	770.0 (30.31)	739.0 (29.09)	707.0 (27.83)	335.0 (13.19)	17.0 (0.67)
Frame	S1	S2	Ø1	Ø2	Ø3	Ø4	
D-1	13.0 (0.51)	18.0 (0.71)	64.0 (2.52)	51.0 (2.01)	25.4 (1.00)	20.3 (0.80)	

Table 1-14

D-2: VFD370FP2EA-52S, VFD450FP2EA-52S, VFD750FP4EA-52S, VFD900FP4EA-52S, VFD750FP5EA-52S, VFD900FP5EA-52S




Figure 1-28

Frame	W	W1	Н	H1	H2	D	D1
D-2	370.0	334.0	770.0	739.0	707.0	380.0	335.0
	(14.57)	(13.15)	(30.31)	(29.09)	(27.83)	(14.96)	(13.19)
Frame	D2	S1	S2	Ø1	Ø2	Ø3	Ø4
D-2	17.0	13.0	18.0	64.0	51.0	25.4	20.3
	(0.67)	(0.51)	(0.71)	(2.52)	(2.01)	(1.00)	(0.80)

Table 1-15

D-3: VFD370FP2EA-41, VFD450FP2EA-41, VFD750FP4EA-41, VFD900FP4EA-41, VFD750FP5EA-41, VFD900FP5EA-41




Figure 1-29

Frame	W	W1	Н	H1	H2	D	D1
D-3	370.0 (14.57)	334.0 (13.15)	770.0 (30.31)	739.0 (29.09)	707.0 (27.83)	335.0 (13.19)	17.0 (0.67)
Frame	S1	S2	Ø1	Ø2	Ø3	Ø4	
D-3	13.0 (0.51)	18.0 (0.71)	62.0 (2.44)	28.0 (1.10)	22.0 (0.87)	-	

Table 1-16

# 1-7 Digital Keypad

KPC-CC01




Figure 1-30


# Chapter 2 Installation

- 2-1 Mounting Clearance
- 2-2 Airflow and Power Dissipation

## 2-1 Mounting Clearance

- ☑ Prevent fiber particles, scraps of paper, shredded wood, sawdust, metal particles, etc. from adhering to the heat sink
- ☐ Install the AC motor drive in a metal cabinet (IP41 models). When installing one drive below another one, use a metal separator between the AC motor drives to prevent mutual heating and to prevent the risk of fire accident.
- ☐ Install the AC motor drive in Pollution Degree 2 environments only:
- ✓ Normally only nonconductive pollution occurs, and temporary conductivity caused by condensation is expected.


The appearances shown in the following figures are for reference only. The actual motor drives may look different.



Multiple drives side-by-side vertical installation (Frame A–D)

#### Ta: Frame A-D

When installing one AC motor drive below another one (top-bottom installation), use a metal separator between the drives to prevent mutual heating. The temperature measured at the fan's inflow side must be lower than the temperature measured at the operation side. If the fan's inflow temperature is higher, use a thicker or larger size of metal separator. Operation temperature is the temperature measured at 50 mm away from the fan's inflow side (as shown in the figure below). (Ta=50°C)



## Minimum mounting clearance

Frame	A (mm)	B (mm)	C (mm)	D (mm)
A–B	60	15	-	-
C–D	100	25	-	-

NOTE: Table 2-1

The minimum mounting clearances A–D stated in the table above apply to AC motor drives installation. Failing to follow the minimum mounting clearances may cause the fan to malfunction and heat dissipation problems.

	VFD007FP2EA-41, VFD007FP2EA-52, VFD007FP2EA-52S,
	VFD015FP2EA-41, VFD015FP2EA-52, VFD015FP2EA-52S,
	VFD022FP2EA-41, VFD022FP2EA-52, VFD022FP2EA-52S,
	VFD037FP2EA-41, VFD037FP2EA-52, VFD037FP2EA-52S,
	VFD055FP2EA-41, VFD055FP2EA-52, VFD055FP2EA-52S,
	VFD007FP4EA-41, VFD007FP4EA-52, VFD007FP4EA-52S,
	VFD015FP4EA-41, VFD015FP4EA-52, VFD015FP4EA-52S,
	VFD022FP4EA-41, VFD022FP4EA-52, VFD022FP4EA-52S,
Frame A	VFD037FP4EA-41, VFD037FP4EA-52, VFD037FP4EA-52S,
	VFD040FP4EA-41, VFD040FP4EA-52, VFD040FP4EA-52S,
	VFD055FP4EA-41, VFD055FP4EA-52, VFD055FP4EA-52S,
	VFD075FP4EA-41, VFD075FP4EA-52, VFD075FP4EA-52S,
	VFD015FP5EA-41, VFD015FP5EA-52, VFD015FP5EA-52S,
	VFD022FP5EA-41, VFD022FP5EA-52, VFD022FP5EA-52S,
	VFD037FP5EA-41, VFD037FP5EA-52, VFD037FP5EA-52S,
	VFD055FP5EA-41, VFD055FP5EA-52, VFD055FP5EA-52S,
	VFD075FP5EA-41, VFD075FP5EA-52, VFD075FP5EA-52S
	VFD075FP2EA-41, VFD075FP2EA-52, VFD075FP2EA-52S,
	VFD110FP2EA-41, VFD110FP2EA-52, VFD110FP2EA-52S,
	VFD110FP4EA-41, VFD110FP4EA-52, VFD110FP4EA-52S,
	VFD150FP4EA-41, VFD150FP4EA-52, VFD150FP4EA-52S,
Frame B	VFD185FP4EA-41, VFD185FP4EA-52, VFD185FP4EA-52S,
	VFD220FP4EA-41, VFD220FP4EA-52, VFD220FP4EA-52S,
	VFD110FP5EA-41, VFD110FP5EA-52, VFD110FP5EA-52S,
	VFD150FP5EA-41, VFD150FP5EA-52, VFD150FP5EA-52S,
	VFD185FP5EA-41, VFD185FP5EA-52, VFD185FP5EA-52S
	VFD150FP2EA-41, VFD150FP2EA-52, VFD150FP2EA-52S,
	VFD185FP2EA-41, VFD185FP2EA-52, VFD185FP2EA-52S,
	VFD300FP4EA-41, VFD300FP4EA-52, VFD300FP4EA-52S,
Frame C	VFD370FP4EA-41, VFD370FP4EA-52, VFD370FP4EA-52S,
	VFD220FP5EA-41, VFD220FP5EA-52, VFD220FP5EA-52S,
	VFD300FP5EA-41, VFD300FP5EA-52, VFD300FP5EA-52S,
	VFD370FP5EA-41, VFD370FP5EA-52, VFD370FP5EA-52S
<u></u>	

	VFD220FP2EA-41, VFD220FP2EA-52, VFD220FP2EA-52S,
	VFD300FP2EA-41, VFD300FP2EA-52, VFD300FP2EA-52S,
Every DO	VFD450FP4EA-41, VFD450FP4EA-52, VFD450FP4EA-52S,
Frame D0	VFD550FP4EA-41, VFD550FP4EA-52, VFD550FP4EA-52S,
	VFD450FP5EA-41, VFD450FP5EA-52, VFD450FP5EA-52S,
	VFD550FP5EA-41, VFD550FP5EA-52, VFD550FP5EA-52S
	VFD370FP2EA-41, VFD370FP2EA-52, VFD370FP2EA-52S,
	VFD450FP2EA-41, VFD450FP2EA-52, VFD450FP2EA-52S,
	VFD750FP4EA-41, VFD750FP4EA-52, VFD750FP4EA-52S,
Frame D	VFD900FP4EA-41, VFD900FP4EA-52, VFD900FP4EA-52S
	VFD750FP5EA-41, VFD750FP5EA-52, VFD750FP5EA-52S,
	VFD900FP5EA-41, VFD900FP5EA-52, VFD900FP5EA-52S

Table 2-2




Figure 2-4

#### NOTE:

- 1. The mounting clearance stated in the figure is for installing the drive in an open area. To install the drive in a confined space (such as cabinet or electric box), follow the following rules:
  - (1) Keep the minimum mounting clearances.
  - (2) Install a ventilation equipment or an air conditioner to keep surrounding temperature lower than operation temperature.
  - (3) Refer to parameter setting and set up Pr.00-16, Pr.00-17 and Pr.06-55.
- 2. Table 2-3 below shows the heat dissipation and the required air volume when installing a single drive in a confined space. When installing multiple drives, the required air volume shall be multiplied by the number of the drives.
- 3. See Table 2-3 below (Airflow Rate for Cooling) for ventilation equipment design and selection.
- 4. See Table 2-3 below (Power Dissipation for AC Motor Drive) for air conditioner design and selection.
- 5. Different control mode affects the derating. See Pr.06-55 for more information.
- 6. See Section 9-6 for ambient temperature derating curve and derating curves under different control modes.

# 2-2 Airflow and Power Dissipation

	Airflow	Rate for Coo	ling	Power Dissipation for AC Motor Drive			
Model No.	Flov	w Rate (cfm)		Power Dissipation (watt)			
	External	Internal	Total	Loss External	Internal	Total	
VFD007FP2EA-41/-52/-52S	-	14	14	34	23	57	
VFD015FP2EA-41/-52/-52S	-	14	14	52	25	77	
VFD022FP2EA-41/-52/-52S	34	14	48	70	28	98	
VFD037FP2EA-41/-52/-52S	34	14	48	115	30	145	
VFD055FP2EA-41/-52/-52S	34	14	48	171	33	204	
VFD075FP2EA-41/-52/-52S	88	14	102	242	40	282	
VFD110FP2EA-41/-52/-52S	88	14	102	375	45	420	
VFD150FP2EA-41/-52/-52S	200	29	229	467	70	537	
VFD185FP2EA-41/-52/-52S	200	29	229	553	76	629	
VFD220FP2EA-41/-52/-52S	285	29	314	738	82	820	
VFD300FP2EA-41/-52/-52S	285	29	314	894	85	979	
VFD370FP2EA-41/-52/-52S	330	29	359	1017	114	1131	
VFD450FP2EA-41/-52/-52S	330	29	359	1296	123	1419	
VFD007FP4EA-41/-52/-52S	-	14	14	32	20	52	
VFD015FP4EA-41/-52/-52S	-	14	14	43	21	64	
VFD022FP4EA-41/-52/-52S	34	14	48	74	25	99	
VFD037FP4EA-41/-52/-52S	34	14	48	92	26	118	
VFD040FP4EA-41/-52/-52S	34	14	48	113	26	139	
VFD055FP4EA-41/-52/-52S	34	14	48	139	27	166	
VFD075FP4EA-41/-52/-52S	34	14	48	195	29	224	
VFD110FP4EA-41/-52/-52S	88	14	102	240	34	274	
VFD150FP4EA-41/-52/-52S	88	14	102	309	38	347	
VFD185FP4EA-41/-52/-52S	88	14	102	353	39	392	
VFD220FP4EA-41/-52/-52S	88	14	102	449	47	496	
VFD300FP4EA-41/-52/-52S	200	29	229	618	84	702	
VFD370FP4EA-41/-52/-52S	200	29	229	726	87	813	
VFD450FP4EA-41/-52/-52S	285	29	314	864	82	946	
VFD550FP4EA-41/-52/-52S	285	29	314	1068	84	1152	
VFD750FP4EA-41/-52/-52S	330	29	359	1407	111	1518	
VFD900FP4EA-41/-52/-52S	330	29	359	1623	114	1737	
VFD015FP5EA-41/-52/-52S	-	14	14	40	18	58	
VFD022FP5EA-41/-52/-52S	34	14	48	55	21	76	
VFD037FP5EA-41/-52/-52S	34	14	48	75	24	99	
VFD055FP5EA-41/-52/-52S	34	14	48	109	28	137	
VFD075FP5EA-41/-52/-52S	34	14	48	133	29	162	
VFD110FP5EA-41/-52/-52S	88	14	102	207	32	239	

#### Chapter 2 Installation | CFP2000

	Airflow	Rate for Cool	ling	Power Dissipation for AC Motor Drive			
Model No.	Flov	w Rate (cfm)		Power	Dissipation (	watt)	
	External	Internal	Total	Loss External	Internal	Total	
VFD150FP5EA-41/-52/-52S	88	14	102	274	36	310	
VFD185FP5EA-41/-52/-52S	88	14	102	392	39	431	
VFD220FP5EA-41/-52/-52S	200	29	229	360	41	401	
VFD300FP5EA-41/-52/-52S	200	29	229	455	45	500	
VFD370FP5EA-41/-52/-52S	200	29	229	605	60	665	
VFD450FP5EA-41/-52/-52S	285	29	314	774	72	846	
VFD550FP5EA-41/-52/-52S	285	29	314	1036	75	1111	
VFD750FP5EA-41/-52/-52S	330	29	359	1207	84	1291	
VFD900FP5EA-41/-52/-52S	330	29	359	1481	102	1583	

#### NOTE:

- 1. The required airflow shown in the table is for installing single drive in a confined space.
- When installing multiple drives, the required air volume should be the required air volume for single drive X the number of the drives.

#### NOTE:

- The heat dissipation shown in the table is for installing single drive in a confined space.
- When installing multiple drives, volume of heat dissipation should be the heat dissipated for single drive X the number of the drives.
- Heat dissipation for each model is calculated by rated voltage, current and default carrier.

**NOTE:** For information of heat dissipation and installed environment, refer to Chapter 5 < Precautions for Heat Dissipation and Environment Conditions > of Application manual for C2000, CP2000, CH2000 Series.

Table 2-3

 $\underline{\text{https://downloadcenter.deltaww.com/downloadCenterCounter.aspx?DID=5333\&DocPath=1\&hl=en-US}$ 

# Chapter 3 Unpacking

- 3-1 Unpacking
- 3-2 The Lifting Hook
- 3-3 Weight

#### Chapter 3 Unpacking | CFP2000

The AC motor drive should be kept in the shipping carton or crate before installation. In order to retain the warranty coverage, the AC motor drive should be stored properly when it is not to be used for an extended period of time.

# 3-1 Unpacking

Follow these steps to unpack the AC motor drive:

### Frame D0

VFD200FP2EA-41/-52/-52S, VFD300FP2EA-41/-52/-52S, VFD450FP4EA-41/-52/-52S, VFD550FP4EA-41/-52/-52S, VFD450FP5EA-41/-52/-52S, VFD550FP5EA-41/-52/-52S

1. Remove the 4 clips by slotted screwdriver.




Figure 3-1

2. Remove the cover of wood box and then take out the EPE tray and user manual.




Figure 3-2




Figure 3-4

### Frame D

VFD370FP2EA-41/-52/-52S, VFD450FP2EA-41/-52/-52S, VFD750FP4EA-41/-52/-52S, VFD750FP5EA-41/-52/-52S, VFD900FP4EA-41/-52/-52S, VFD900FP5EA-41/-52/-52S

1. Remove the 6 clips by slotted screwdriver.





Figure 3-5

2. Remove the cover of wood box and then take out the EPE tray and user manual.






Figure 3-8

# **3-2 The Lifting Hook**

The arrows indicate the location of the lifting holes, as shown in figure below:

Frame D0 Frame D




Figure 3-9




Figure 3-10

Ensure the lifting hook properly goes through the lifting hole, as shown in the following diagram.




Figure 3-11




Figure 3-12

Ensure the angle between the lifting holes and the lifting device is within the specification, as shown in the following figure.




Figure 3-14

# 3-3 Weight

Frame VFDXXXFP2EA-41, VFDXXXFP2EA-52 VFDXXXFP4EA-52S VFDXXXFP4EA-52S VFDXXXFP4EA-52S VFDXXXFP5EA-52S VFDXXFP5EA-52S VFDXX			
VFDXXXFP5EA-41, VFDXXXFP5EA-52  41.5 kg (91.4 lbs.)  41.7 kg (91.9 lbs.)  Figure 3-15  Figure 3-16  59.0 kg (130.0 lbs.)  Figure 3-16		VFDXXXFP2EA-41, VFDXXXFP2EA-52	VFDXXXFP2EA-52S
Figure 3-15  Figure 3-15  Figure 3-16  59.0 kg (130.0 lbs.)  Figure 3-16  Figure 3-	Frame	VFDXXXFP4EA-41, VFDXXXFP4EA-52	VFDXXXFP4EA-52S
D0  Figure 3-15  Figure 3-16  59.0 kg (130.0 lbs.)  Figure 3-16  60.2 kg (132.6 lbs.)		VFDXXXFP5EA-41, VFDXXXFP5EA-52	VFDXXXFP5EA-52S
Figure 3-15  Figure 3-16  59.0 kg (130.0 lbs.)  60.2 kg (132.6 lbs.)		41.5 kg (91.4 lbs.)	41.7 kg (91.9 lbs.)
59.0 kg (130.0 lbs.)  60.2 kg (132.6 lbs.)	D0		<b>_</b> _
		Figure 3-15	Figure 3-16
		59.0 kg (130.0 lbs.)	60.2 kg (132.6 lbs.)
I I Eiguro 2 17 I Eiguro 2 10	D	Figure 3-17	Figure 3-18

# **Chapter 4 Wiring**

- 4-1 System Wiring Diagram
- 4-2 Wiring
- 4-3 Wiring Plate Diagram
- 4-4 Basic Waterproof Component Wiring Diagram

#### Chapter 4 Wiring | CFP2000

 $\checkmark$ 

After removing the front cover, verify if the power and control terminals are clearly noted. Read following precautions to avoid wiring mistakes.



- Turn off the AC motor drive power before doing any wiring. A charge with hazardous voltages may remain in the DC bus capacitors even after the power has been turned off for a short time. Measure the remaining voltage with a DC voltmeter before doing any wiring. For your safety, do not start wiring before the voltage drops to a safe level (less than 25  $V_{DC}$ ). Installing wiring with a residual voltage may cause personal injury, sparks and a short circuit.
- Only qualified personnel familiar with AC motor drives are allowed to perform installation, wiring and commissioning. Make sure the power is turned off before wiring to prevent electric shock.
- ☑ Make sure that power is only applied to the R/L1, S/L2 and T/L3 terminals. Failure to comply may result in damage to the equipment. The voltage and current must be in the range indicated on the nameplate (refer to Section 1-1 Nameplate Information for details).
- All units must be grounded directly to a common ground terminal to prevent damage from a lightning strike or electric shock and reduce noise interference.
- ☑ Tighten the screws of the main circuit terminals to prevent sparks caused by screws loosened due to vibration.



- ☐ For your safety, choose wires that comply with local regulation when wiring
- ☑ Check following items after finishing the wiring:
  - 1. Are all connections correct?
    - 2. Are there any loose wires?
    - 3. Are there any short-circuits between the terminals or to ground?

# **4-1 System Wiring Diagram**




Figure 4-1

### NOTE:

Refer to Section 4-2 Wiring Diagram for detailed wiring information.

Power input terminal	Supply power according to the rated power specifications indicated in the user manual (refer to Chapter 9 Specification).
NFB or fuse	There may be a large inrush current during power on. Refer to Section 7-2 NFB to select a suitable NFB or Section 7-3 Fuse Specification Chart.
Magnetic contactor	Switching the power ON / OFF on the primary side of the electromagnetic contactor can turn the drive ON / OFF, but frequent switching can cause machine failure. Do not switch ON / OFF more than once an hour.  Do not use the magnetic contactor as the power switch for the drive; doing so shortens the life of the drive.  Refer to Section 7-2 Magnetic Contactor / Air Circuit Breaker to select the electromagnetic contactor that meets your requirement.
AC reactor (input terminal)	When the main power capacity is > 500 kVA, or when it switches into the phase capacitor, the instantaneous peak voltage and current generated may destroy the internal circuit of the drive.  It is recommended that you install an input side AC reactor in the drive. This also improves the power factor and reduces power harmonics. The wiring distance should be within 10 m. Refer to Section 7-4 AC/DC Reactor for details.
Zero-phase reactor	Used to reduce radiated interference, especially in environments with audio devices, and reduce input and output side interference.  The effective range is AM band to 10 MHz.  Refer to Section 7-5 Zero Phase Reactor for details.
EMC filter	Can be used to reduce electromagnetic interference.  Refer to Section 7-6 EMC Filter for details.
Brake module & Brake resistor	Used to shorten the deceleration time of the motor.  Refer to Section 7-1 Brake Resistors and Brake
(BR)	Units Used in AC Motor Drives for details.  The motor cable length affects the size of the
AC reactor (output terminal)	reflected wave on the motor end. It is recommended that you install an AC output reactor when the motor wiring length exceeds the value listed in Section 7-4.

Table 4-1

## 4-2 Wiring

Wiring Diagram for 460V / 575V Frame A-C




Figure 4-2

\*1. Refer to Section 7-1 for brake units and resistor selection.




Figure 4-3

\*1. Refer to Section 7-1 for brake units and resistor selection.

#### Wiring Diagram for Frame A-D

Input: 3-phase power







Figure 4-4

## 4-2-1 SINK (NPN) / SOURCE (PNP) Mode



# 4-3 Wiring Plate Diagram





# 4-4 Basic Waterproof Component Wiring Diagram

#### Frame A




Figure 4-12

#### Frame B




Figure 4-13

### Frame C/D0




Figure 4-14

#### Chapter 4 Wiring | CFP2000

#### Frame D




Figure 4-15

# **Chapter 5 Main Circuit Terminals**

- 5-1 Main Circuit Diagram
- 5-2 Specifications of Main Circuit Terminals



- ☑ Tighten the screws in the main circuit terminal to prevent sparks caused by screws loosened due to vibration.
- ☑ If necessary, use an inductive filter only at the motor output terminals U/T1, V/T2, W/T3 of the AC motor drive. DO NOT use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance), unless approved by Delta.
- ☑ DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- ☑ DO NOT short circuit [+1, -], [+2, -], [+1/DC+, -/DC-] or connect brake resistor directly to any of them to prevent damage to the drive or to the brake resistors.
- ☑ Ensure proper insulation of the main circuit wiring in accordance with the relevant safety regulations.




#### Main input power terminals

- Do not connect three-phase model to single-phase power. R/L1, S/L2 and T/L3 have no phase-sequence requirement, they can be connected in any sequence.
- Add a magnetic contactor (MC) to the power input wiring to cut off power quickly and reduce malfunction when the AC motor drive protection function activates. Both ends of the MC should have an R-C surge absorber.
- ☑ Use voltage and current within the specification in Chapter 09. Refer to Chapter 09 Specifications for details.
- ☑ When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200 mA or above and not less than 0.1-second operation time to avoid nuisance tripping.
- ☑ Use shielded wire or conduit for the power wiring and ground the two ends of the shielded wire or conduit.
- ☑ Do NOT run and stop AC motor drives by turning the power ON and OFF. Run and stop the AC motor drives by sending RUN and STOP command through the control terminals or the keypad. If you still need to run and stop AC motor drives by turning the power ON and OFF, do so no more often than ONCE per hour.
- ☑ To comply with UL standards, connect the drive to a three-phase three-wire or three-phase four-wire Wye system type of mains power system.


### Output terminals of the main circuit

- ☑ Use well-insulated motor, suitable for inverter operation.
- When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3 respectively, the motor will rotate counterclockwise (as viewed on the shaft end of the motor, refer to the pointed direction in the figure below) upon a forward operation command is received. To permanently reverse the direction of motor rotation, switch over any of the two motor leads.



#### Terminals for connecting DC reactor, external brake resistor and DC circuit

☑ Install an external brake resistor for applications in frequent deceleration to stop, short deceleration time (such as high frequency operation and heavy load operation), too low braking torque, or increased braking torque.



- ☑ The external brake resistor of Frame A, B and C should connect to the terminals (B1, B2) of AC motor drives.
- For those models without built-in brake resistor, connect external brake unit and brake resistor (both of them are optional) to increase brake torque.
- ☑ When the terminals +1/DC+ and -/DC- are not used, leave the terminals open.
- ☑ DC+ and DC- are connected by common DC bus, refer to Section 5-1 (Main Circuit Terminal) for the wiring terminal specification and the wire gauge information.
- ☑ Refer to the VFDB manual for more information on wire gauge when installing the brake unit.

# 5-1 Main Circuit Diagram

Wiring diagram for frame A-C of 460V / 575V models

Input: 3-phase power




Figure 5-3

Wiring diagram for frame D0-D of 460V / 575V models and frame A-D of 230V models

Input: 3-phase power




Figure 5-4

<sup>\*1</sup> Refer to Section 7-1 for brake units and resistors selection.

Terminals	Descriptions					
R/L1, S/L2, T/L3	AC line input terminals three-phase					
U/T1, V/T2, W/T3	C drive output terminals for connecting three-phase induction motor					
	Connections for brake module (VFDB series)					
+1/DC+, -/DC-	≤ 37 kW, built-in brake module)					
	Common DC bus					
B1, B2	Connections for brake resistor (optional)					
D1, D2	(≤ 37 kW, built-in brake module)					
	Ground connection; comply with local regulations.					

Table 5-1

# **5-2 Specifications of Main Circuit Terminals**

- Use the specified ring lug for main circuit terminal wiring. See figure 5-5 and figure 5-6 for ring lug specifications. For other types of wiring use the wires that comply with the local regulations.
- After crimping the wire to the ring lug (must be UL approved), UL and CSA approved recognized component (YDPU2/8), install heat shrink tube rated at a minimum of 600 V<sub>AC</sub> insulation over the live part. Refer to figure 5-6 below.




Figure 5-5

Figure 5-6

### **Terminal Specification**

The part number of the ring lugs (produced by K.S. Terminals Inc.) in the table below are for reference only. You can buy the ring lugs of your choice to match with different frame sizes.

Unit: mm

Frame	AWG*1	Kit P/N	A (MAX)	B (MAX)	C (MIN)	D (MAX)	d2 (MIN)	E (MIN)	F (MIN)	W (MAX)	t (MAX)
Α	12/4 mm <sup>2</sup>	RNBS5-4	12.1	3.6	6.1	5.6	4.3	7.0	6.1	7.3	1.0
	10/6 mm <sup>2</sup>	RNBS5-4	12.1	3.0	0.1	5.	4.5	7.0	0.1	7.5	1.0
В	8/10 mm <sup>2</sup>	RNBM8-5	23.8	6.0	13.3	9.0	5.3	11.0	13.3	12.0	1.5
Ь	6/16 mm <sup>2</sup>	RNB14-5	23.0	0.0	13.3	9.0	5.5	11.0	13.3	12.0	1.5
	6	RNB14-8							12.0*2	22.0	2.5
С	4	RNB22-8	40.0	10.0	10.0	15.0	.0 8.3	13.0			
	2	RNBS38-8									
	6	RNB14-8					23.0 8.3	13.0	14.0*3	24.0	4.5
	4	SQNBS22-8									
D0	2	SQNBS38-8	40.0	11.0	10.0	23.0					
	1	SQNBS60-8									
	1/0	SQNBS60-8									
	2	RNBL38-8									
	1/0	1/0 RNB60-8									
D	2/0	RNB70-8	50.0	16.0	10.0	27.0	8.3	13.0	14.0	28.0	6.0
	3/0	RNB80-8									
	4/0	SQNBS100-8									

NOTE: Table 5-2

<sup>\*1:</sup> AWG: Refer to the following tables for the wire size specification for models in each frame.

<sup>\*2:</sup> F(MAX) = 15.5

<sup>\*3:</sup> F(MAX) = 16-5

### Frame A-1 / A-3




Figure 5-7

- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD055FP2EA-41, VFD055FP2EA-52 models: if you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.

	I						
	Main Circuit Terminals:			Terminals:			
	R/L1, S/L	R/L1, S/L2, T/L3, U/T1, V/T2, W/T3,			DC-, DC+,		
Model Name		B1, B2	)		DO-, DO · ,		
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and	
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)	
VFD007FP2EA-41		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD007FP2EA-52		(12 AWG)		(12 AWG)	(12 AWG)		
VFD015FP2EA-41		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD015FP2EA-52		(12 AWG)	M4	(12 AWG)	(12 AWG)		
VFD022FP2EA-41	6 mm <sup>2</sup>	4 mm <sup>2</sup>	18 kg-cm	4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD022FP2EA-52	(10 AWG)	(12 AWG)	(15.6 lb-in.)	(12 AWG)	(12 AWG)		
VFD037FP2EA-41		6 mm <sup>2</sup>	(1.77 Nm)	6 mm <sup>2</sup>	6 mm <sup>2</sup>		
VFD037FP2EA-52		(10 AWG)		(10 AWG)	(10 AWG)	M4	
VFD055FP2EA-41		6 mm <sup>2</sup>		6 mm <sup>2</sup>	6 mm <sup>2</sup>	18 kg-cm	
VFD055FP2EA-52		(10 AWG)		(10 AWG)	(10 AWG)	(15.6 lb-in.)	
VFD007FP4EA-41		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>	(1.77 Nm)	
VFD007FP4EA-52		(12 AWG)		(12 AWG)	(12 AWG)		
VFD015FP4EA-41		4 mm <sup>2</sup>	M3.5	4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD015FP4EA-52	4 mm <sup>2</sup>	(12 AWG)	10 kg-cm	(12 AWG)	(12 AWG)		
VFD022FP4EA-41	(12 AWG)	4 mm <sup>2</sup>	(8.7 lb-in.)	4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD022FP4EA-52		(12 AWG)	(0.98 Nm)	(12 AWG)	(12 AWG)		
VFD037FP4EA-41		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD037FP4EA-52		(12 AWG)		(12 AWG)	(12 AWG)		

## Chapter 5 Main Circuit Terminals | CFP2000

	Main Circuit Terminals: R/L1, S/L2, T/L3, U/T1, V/T2, W/T3,			Terminals: DC-, DC+,		
Model Name		B1, B2			DC-, DC+,	
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD040FP4EA-41		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>	
VFD040FP4EA-52		(12 AWG)	M4	(12 AWG)	(12 AWG)	
VFD055FP4EA-41	6 mm <sup>2</sup>	6 mm <sup>2</sup>	18 kg-cm	6 mm <sup>2</sup>	6 mm <sup>2</sup>	
VFD055FP4EA-52	(10 AWG)	(10 AWG)	(15.6 lb-in.)	(10 AWG)	(10 AWG)	
VFD075FP4EA-41		6 mm <sup>2</sup>	(1.77 Nm)	6 mm <sup>2</sup>	6 mm <sup>2</sup>	
VFD075FP4EA-52		(10 AWG)		(10 AWG)	(10 AWG)	
VFD015FP5EA-41		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>	M4
VFD015FP5EA-52		(12 AWG)		(12 AWG)	(12 AWG)	18 kg-cm
VFD022FP5EA-41	4 mm <sup>2</sup>	4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>	(15.6 lb-in.)
VFD022FP5EA-52	(12 AWG)	(12 AWG)	M4	(12 AWG)	(12 AWG)	(1.77 Nm)
VFD037FP5EA-41		4 mm <sup>2</sup>	10 kg-cm	4 mm <sup>2</sup>	4 mm <sup>2</sup>	
VFD037FP5EA-52		(12 AWG)	(8.7 lb-in.)	(12 AWG)	(12 AWG)	
VFD055FP5EA-41		4 mm <sup>2</sup>	(0.98 Nm)	4 mm <sup>2</sup>	4 mm <sup>2</sup>	
VFD055FP5EA-52	6 mm <sup>2</sup>	(12 AWG)		(12 AWG)	(12 AWG)	
VFD075FP5EA-41	(10 AWG)	4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>	
VFD075FP5EA-52		(12 AWG)		(12 AWG)	(12 AWG)	

Table 5-3

### Frame A-2




Figure 5-8

- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD055FP2EA-52S models: if you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based
  on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do
  not reduce the wire gauge when using high-temperature resistant wire.

	M	ain Circuit Ter	minals:		Terminals	3.	
Madal Naws		1, V/T2, W/T		DC-, DC+, ⊕			
Model Name	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and	
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)	
VFD007FP2EA-52S		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD007FF2EA-323		(12 AWG)		(12 AWG)	(12 AWG)		
VFD015FP2EA-52S		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD015FF2EA-525		(12 AWG)	M4	(12 AWG)	(12 AWG)		
VFD022FP2EA-52S	6 mm <sup>2</sup>	4 mm <sup>2</sup>	18 kg-cm	4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD022FF2EA-323	(10 AWG)	(12 AWG)	(15.6 lb-in.)	(12 AWG)	(12 AWG)		
VFD037FP2EA-52S		6 mm <sup>2</sup>	(1.77 Nm)	6 mm <sup>2</sup>	6 mm <sup>2</sup>		
VFD03/FF2EA-323		(10 AWG)		(10 AWG)	(10 AWG)	M4	
VFD055FP2EA-52S		6 mm <sup>2</sup>		6 mm <sup>2</sup>	6 mm <sup>2</sup>	18 kg-cm	
VFD033FF2EA-323		(10 AWG)		(10 AWG)	(10 AWG)	(15.6 lb-in.)	
VFD007FP4EA-52S		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>	(1.77 Nm)	
VFD007FF4EA-323		(12 AWG)		(12 AWG)	(12 AWG)		
VFD015FP4EA-52S		4 mm <sup>2</sup>	M3.5	4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD015FF4EA-525	4 mm <sup>2</sup>	(12 AWG)	10 kg-cm	(12 AWG)	(12 AWG)		
VFD022FP4EA-52S	(12 AWG)	4 mm <sup>2</sup>	(8.7 lb-in.)	4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD022FF4EA-323		(12 AWG)	(0.98 Nm)	(12 AWG)	(12 AWG)		
VFD037FP4EA-52S		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>		
VFD03/FF4EA-323		(12 AWG)		(12 AWG)	(12 AWG)		

	Main Circuit Terminals:			Terminals:		
Model Name	U/T1, V/T2, W/T3, B1, B2			DC-, DC+, 🕀		
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD040FP4EA-52S		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>	
		(12 AWG)	M4	(12 AWG)	(12 AWG)	
VFD055FP4EA-52S	6 mm <sup>2</sup>	6 mm <sup>2</sup>	18 kg-cm	6 mm <sup>2</sup>	6 mm <sup>2</sup>	
	(10 AWG)	(10 AWG)	(15.6 lb-in.)	(10 AWG)	(10 AWG)	
\/FD075FD4F4_500		6 mm <sup>2</sup>	(1.77 Nm)	6 mm <sup>2</sup>	6 mm <sup>2</sup>	
VFD075FP4EA-52S		(10 AWG)		(10 AWG)	(10 AWG)	
VFD015FP5EA-52S		4 mm <sup>2</sup>		4 mm <sup>2</sup>	4 mm <sup>2</sup>	M4
		(12 AWG)	M3.5	(12 AWG)	(12 AWG)	18 kg-cm
VFD022FP5EA-52S	4 mm <sup>2</sup>	4 mm <sup>2</sup>	10 kg-cm	4 mm <sup>2</sup>	4 mm <sup>2</sup>	(15.6 lb-in.)
	(12 AWG)	(12 AWG)	(8.7 lb-in.)	(12 AWG)	(12 AWG)	(1.77 Nm)
VFD037FP5EA-52S		4 mm <sup>2</sup>	(0.98 Nm)	4 mm <sup>2</sup>	4 mm <sup>2</sup>	
		(12 AWG)		(12 AWG)	(12 AWG)	
VFD055FP5EA-52S		4 mm <sup>2</sup>	M4	4 mm <sup>2</sup>	4 mm <sup>2</sup>	
	6 mm <sup>2</sup>	(12 AWG)	18 kg-cm	(12 AWG)	(12 AWG)	
VFD075FP5EA-52S	(10 AWG)	4 mm <sup>2</sup>	(15.6 lb-in.)	4 mm <sup>2</sup>	4 mm <sup>2</sup>	]
	_	(12 AWG)	(1.77 Nm)	(12 AWG)	(12 AWG)	

Table 5-4

	Main Circuit Terminals:							
Model Name	R/L1, S/L2, T/L3 (Stranded wire use only)							
Woder Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)					
VFD007FP2EA-52S	6 mm <sup>2</sup> (10 AWG)	4 mm <sup>2</sup> (12 AWG)						
VFD015FP2EA-52S		4 mm <sup>2</sup> (12 AWG)						
VFD022FP2EA-52S		4 mm <sup>2</sup> (12 AWG)						
VFD037FP2EA-52S		6 mm <sup>2</sup> (10 AWG)						
VFD055FP2EA-52S		6 mm <sup>2</sup> (10 AWG)						
VFD007FP4EA-52S		4 mm <sup>2</sup> (12 AWG)						
VFD015FP4EA-52S		4 mm <sup>2</sup> (12 AWG)						
VFD022FP4EA-52S		4 mm <sup>2</sup> (12 AWG)	8 kg-cm					
VFD037FP4EA-52S		4 mm <sup>2</sup> (12 AWG)	(6.9 lb-in)					
VFD040FP4EA-52S		4 mm <sup>2</sup> (12 AWG)	(0.78 Nm)					
VFD055FP4EA-52S		6 mm <sup>2</sup> (10 AWG)						
VFD075FP4EA-52S		6 mm <sup>2</sup> (10 AWG)						
VFD015FP5EA-52S		4 mm <sup>2</sup> (12 AWG)						
VFD022FP5EA-52S		4 mm <sup>2</sup> (12 AWG)						
VFD037FP5EA-52S		4 mm <sup>2</sup> (12 AWG)						
VFD055FP5EA-52S		4 mm <sup>2</sup> (12 AWG)						
VFD075FP5EA-52S		4 mm <sup>2</sup> (12 AWG)	]					

Table 5-5

### Frame B-1 / B-3




Figure 5-9

- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD110FP2EA-41, VFD110FP2EA-52 models: if you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD220FP4EA-41, VFD220FP4EA-52 models: if you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.

	Main Circuit Terminals: R/L1, S/L2, T/L3, U/T1, V/T2, W/T3,			Terminals:		
Model Name	DC-, DC+, B1, B2					
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD075FP2EA-41		16 mm <sup>2</sup>		16 mm <sup>2</sup>	16 mm <sup>2</sup>	
VFD075FP2EA-52		(6 AWG)		(6 AWG)	(6 AWG)	
VFD110FP2EA-41		16 mm <sup>2</sup>		16 mm <sup>2</sup>	16 mm <sup>2</sup>	
VFD110FP2EA-52		(6 AWG)		(6 AWG)	(6 AWG)	
VFD110FP4EA-41		10 mm <sup>2</sup>		10 mm <sup>2</sup>	10 mm <sup>2</sup>	
VFD110FP4EA-52		(8 AWG)		(8 AWG)	(8 AWG)	
VFD150FP4EA-41		16 mm <sup>2</sup>		16 mm <sup>2</sup>	16 mm <sup>2</sup>	
VFD150FP4EA-52		(6 AWG)	M5	(6 AWG)	(6 AWG)	M5
VFD185FP4EA-41	16 mm <sup>2</sup>	16 mm <sup>2</sup>	25 kg-cm	16 mm <sup>2</sup>	16 mm <sup>2</sup>	25 kg-cm
VFD185FP4EA-52	(6 AWG)	(6 AWG)	(21.7 lb-in.)	(6 AWG)	(6 AWG)	(21.7 lb-in.)
VFD220FP4EA-41		16 mm <sup>2</sup>	(2.45 Nm)	16 mm <sup>2</sup>	16 mm <sup>2</sup>	(2.45 Nm)
VFD220FP4EA-52		(6 AWG)		(6 AWG)	(6 AWG)	
VFD110FP5EA-41		10 mm <sup>2</sup>		10 mm <sup>2</sup>	10 mm <sup>2</sup>	
VFD110FP5EA-52		(8 AWG)		(8 AWG)	(8 AWG)	
VFD150FP5EA-41		10 mm <sup>2</sup>	]	10 mm <sup>2</sup>	10 mm <sup>2</sup>	
VFD150FP5EA-52		(8 AWG)		(8 AWG)	(8 AWG)	
VFD185FP5EA-41		10 mm <sup>2</sup>	]	10 mm <sup>2</sup>	10 mm <sup>2</sup>	
VFD185FP5EA-52		(8 AWG)		(8 AWG)	(8 AWG)	

Table 5-6

## Frame B-2




Figure 5-10

- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD110FP2EA-52S models: if you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD220FP4EA-52S models: if you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.

	Main Circuit Terminals:			Terminals:		
Model Name	U/T1, V/T2, W/T3, DC-, DC+, B1, B2			<b>=</b>		
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD075FP2EA-52S		16 mm <sup>2</sup>		16 mm <sup>2</sup>	16 mm <sup>2</sup>	
		(6 AWG)		(6 AWG)	(6 AWG)	
VFD110FP2EA-52S		16 mm <sup>2</sup>		16 mm <sup>2</sup>	16 mm <sup>2</sup>	
		(6 AWG)		(6 AWG)	(6 AWG)	
VFD110FP4EA-52S		10 mm <sup>2</sup>		10 mm <sup>2</sup>	10 mm <sup>2</sup>	
		(8 AWG)		(8 AWG)	(8 AWG)	
VFD150FP4EA-52S	16 mm <sup>2</sup> (6 AWG)	16 mm <sup>2</sup>		16 mm <sup>2</sup>	16 mm <sup>2</sup>	
		(6 AWG)	M5	(6 AWG)	(6 AWG)	M5
VFD185FP4EA-52S		16 mm <sup>2</sup>	25 kg-cm	16 mm <sup>2</sup>	16 mm <sup>2</sup>	25 kg-cm
VFD183FP4EA-328		(6 AWG)	(21.7 lb-in.)	(6 AWG)	(6 AWG)	(21.7 lb-in.)
VFD220FP4EA-52S		16 mm <sup>2</sup>	(2.45 Nm)	16 mm <sup>2</sup>	16 mm <sup>2</sup>	(2.45 Nm)
		(6 AWG)		(6 AWG)	(6 AWG)	
VFD110FP5EA-52S		10 mm <sup>2</sup>		10 mm <sup>2</sup>	10 mm <sup>2</sup>	
		(8 AWG)		(8 AWG)	(8 AWG)	
VFD150FP5EA-52S		10 mm <sup>2</sup>		10 mm <sup>2</sup>	10 mm <sup>2</sup>	
		(8 AWG)		(8 AWG)	(8 AWG)	
VFD185FP5EA-52S		10 mm <sup>2</sup>		10 mm <sup>2</sup>	10 mm <sup>2</sup>	
		(8 AWG)		(8 AWG)	(8 AWG)	

Table 5-7

# Chapter 5 Main Circuit Terminals | CFP2000

	Main Circuit Terminals: R/L1, S/L2, T/L3 (stranded wire use only)				
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)		
VFD075FP2EA-52S		16 mm² (6 AWG)			
VFD110FP2EA-52S		16 mm <sup>2</sup> (6 AWG)			
VFD110FP4EA-52S	16 mm² (6 AWG)	10 mm <sup>2</sup> (8 AWG)			
VFD150FP4EA-52S		16 mm <sup>2</sup> (6 AWG)	21 kg-cm		
VFD185FP4EA-52S		16 mm <sup>2</sup> (6 AWG)	(18.2 lb-in.)		
VFD220FP4EA-52S		16 mm <sup>2</sup> (6 AWG)	(2.06 Nm)		
VFD110FP5EA-52S		10 mm <sup>2</sup> (8 AWG)			
VFD150FP5EA-52S		10 mm <sup>2</sup> (8 AWG)			
VFD185FP5EA-52S		10 mm <sup>2</sup> (8 AWG)			

Table 5-8

# Frame C-1 / C-3




Figure 5-11

- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD185FP2EA-41, VFD185FP2EA-52, VFD370FP4EA-41, and VFD370FP4EA-52 models: if you install at Ta 45°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based
  on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do
  not reduce the wire gauge when using high-temperature resistant wire.

Model Name	Main Circuit Terminals: R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, DC+, DC-, B1, B2			Terminal:		
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD150FP2EA-41		35 mm <sup>2</sup>		35 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD150FP2EA-52		(2 AWG)		(2 AWG)	(6 AWG)	
VFD185FP2EA-41		35 mm <sup>2</sup>		35 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD185FP2EA-52		(2 AWG)		(2 AWG)	(6 AWG)	
VFD300FP4EA-41		35 mm <sup>2</sup>		35 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD300FP4EA-52		(3 AWG)	M8	(3 AWG)	(6 AWG)	M8
VFD370FP4EA-41	35 mm <sup>2</sup>	35 mm <sup>2</sup>	81.6 kg-cm	35 mm <sup>2</sup>	35 mm <sup>2</sup>	81.6 kg-cm
VFD370FP4EA-52	(2 AWG)	(2 AWG)	(70.8 lb-in.)	(2 AWG)	(6 AWG)	(70.8 lb-in.)
VFD220FP5EA-41		16 mm <sup>2</sup>	(8.00 Nm)	16 mm <sup>2</sup>	35 mm <sup>2</sup>	(8.00 Nm)
VFD220FP5EA-52		(6 AWG)		(6 AWG)	(6 AWG)	
VFD300FP5EA-41		25 mm <sup>2</sup>		25 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD300FP5EA-52		(4 AWG)		(4 AWG)	(6 AWG)	
VFD370FP5EA-41		35 mm <sup>2</sup>		35 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD370FP5EA-52		(3 AWG)		(3 AWG)	(6 AWG)	

Table 5-9

#### Frame C-2




Figure 5-12

- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD185FP2EA-52S, VFD370FP4EA-52S models: if you install at Ta 45°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.

		ain Circuit Te	rminals: -, DC+, B1, B2	Terminals:		
Model Name						
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD150FP2EA-52S		35 mm <sup>2</sup>		35 mm <sup>2</sup>	35 mm <sup>2</sup>	
VI D 1301 F 2LA-323		(2 AWG)		(2 AWG)	(6 AWG)	
VFD185FP2EA-52S		35 mm <sup>2</sup>		35 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD100FP2EA-026		(2 AWG)		(2 AWG)	(6 AWG)	
VFD300FP4EA-52S		35 mm <sup>2</sup>		35 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD300FF4EA-323		(3 AWG)	M8	(3 AWG)	(6 AWG)	M8
VFD370FP4EA-52S	35 mm <sup>2</sup>	35 mm <sup>2</sup>	81.6 kg-cm	35 mm <sup>2</sup>	35 mm <sup>2</sup>	81.6 kg-cm
VFD3/UFP4EA-323	(2 AWG)	(2 AWG)	(70.8 lb-in.)	(2 AWG)	(6 AWG)	(70.8 lb-in.)
VFD220FP5EA-52S		16 mm <sup>2</sup>	(8.00 Nm)	16 mm <sup>2</sup>	35 mm <sup>2</sup>	(8.00 Nm)
VFD220FF3EA-323		(6 AWG)		(6 AWG)	(6 AWG)	
VFD300FP5EA-52S		25 mm <sup>2</sup>		25 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD300FF3EA-323		(4 AWG)		(4 AWG)	(6 AWG)	]
VFD370FP5EA-52S		35 mm <sup>2</sup>		35 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD370FF3EA-323		(3 AWG)		(3 AWG)	(6 AWG)	

Table 5-10

# Chapter 5 Main Circuit Terminals | CFP2000

	Main Circuit Terminals: R/L1, S/L2, T/L3 (stranded wire use only)					
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)			
VFD150FP2EA-52S		35 mm <sup>2</sup> (2 AWG)				
VFD185FP2EA-52S		35 mm <sup>2</sup> (2 AWG)				
VFD300FP4EA-52S		35 mm <sup>2</sup> (3 AWG)	21 kg-cm			
VFD370FP4EA-52S	33.6 mm <sup>2</sup>	35 mm <sup>2</sup> (2 AWG)	(18.2 lb-in)			
VFD220FP5EA-52S	(2 AWG)	16 mm <sup>2</sup> (6 AWG)	(2.06 Nm)			
VFD300FP5EA-52S		25 mm <sup>2</sup> (4 AWG)				
VFD370FP5EA-52S		35 mm <sup>2</sup> (3 AWG)				

Table 5-11

#### Frame D0-1 / D0-3




Figure 5-13

- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD300FP2EA-41, VFD300FP2EA-52, VFD450FP4EA-41, and VFD450FP4EA-52 models: if you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD550FP4EA-41 and VFD550FP4EA-52 models: if you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based
  on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do
  not reduce the wire gauge when using high-temperature resistant wire.

Model Name	Main Circuit Terminals: R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, DC+, DC-				Termin	al:
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD220FP2EA-41		50 mm <sup>2</sup>		50 mm <sup>2</sup>	25 mm <sup>2</sup>	
VFD220FP2EA-52		(1/0 AWG)		(1/0 AWG)	(4 AWG)	
VFD300FP2EA-41		50 mm <sup>2</sup>		50 mm <sup>2</sup>	25 mm <sup>2</sup>	
VFD300FP2EA-52		(1/0 AWG)		(1/0 AWG)	(4 AWG)	
VFD450FP4EA-41		50 mm <sup>2</sup>	M8	50 mm <sup>2</sup>	25 mm <sup>2</sup>	M8
VFD450FP4EA-52	50 mm <sup>2</sup>	(1 AWG)	180 kg-cm	(1 AWG)	(4 AWG)	180 kg-cm
VFD550FP4EA-41	(1/0 AWG)	50 mm <sup>2</sup>	(156.2 lb-in.)	50 mm <sup>2</sup>	25 mm <sup>2</sup>	(156.2 lb-in.)
VFD550FP4EA-52		(1/0 AWG)	(17.65 Nm)	(1/0 AWG)	(4 AWG)	(17.65 Nm)
VFD450FP5EA-41		35 mm <sup>2</sup>		35 mm <sup>2</sup>	$35 \text{ mm}^2$	
VFD450FP5EA-52		(2 AWG)		(2 AWG)	(2 AWG)	
VFD550FP5EA-41		50 mm <sup>2</sup>		50 mm <sup>2</sup>	16 mm <sup>2</sup>	
VFD550FP5EA-52		(1/0 AWG)		(1/0 AWG)	(6 AWG)	

Table 5-12

# Frame D0-2




Figure 5-14

- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD300FP2EA-52S and VFD450FP4EA-52S models: if you install at Ta 40°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD550FP4EA-52S: if you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using high-temperature resistant wire.

	Ma	ain Circuit Ter	minals:	Terminal:		
Madal Nama	U/T1	V/T2, W/T3,	DC-, DC+	<del>-</del>		
Model Name	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD220FP2EA-52S		50 mm <sup>2</sup>		50 mm <sup>2</sup>	25 mm <sup>2</sup>	
VFD220FF2EA-525		(1/0 AWG)		(1/0 AWG)	(4 AWG)	
VFD300FP2EA-52S		50 mm <sup>2</sup>		50 mm <sup>2</sup>	25 mm <sup>2</sup>	
VFD300FF2EA-323		(1/0 AWG)		(1/0 AWG)	(4 AWG)	
VFD450FP4EA-52S		50 mm <sup>2</sup>	M8	50 mm <sup>2</sup>	25 mm <sup>2</sup>	M8
VFD450FF4EA-525	50 mm <sup>2</sup>	(1 AWG)	180 kg-cm	(1 AWG)	(4 AWG)	180 kg-cm
VFD550FP4EA-52S	(1/0 AWG)	50 mm <sup>2</sup>	(156.2 lb-in.)	50 mm <sup>2</sup>	25 mm <sup>2</sup>	(156.2 lb-in.)
VFD000FF4EA-020		(1/0 AWG)	(17.65 Nm)	(1/0 AWG)	(4 AWG)	(17.65 Nm)
VFD450FP5EA-52S		35 mm <sup>2</sup>		$35 \text{ mm}^2$	16 mm <sup>2</sup>	
VFD450FP5EA-525		(2 AWG)		(2 AWG)	(6 AWG)	
VEDEEOEDEEA 500		50 mm <sup>2</sup>		50 mm <sup>2</sup>	25 mm <sup>2</sup>	
VFD550FP5EA-52S		(1/0 AWG)		(1/0 AWG)	(4 AWG)	


Table 5-13

# Chapter 5 Main Circuit Terminals | CFP2000

	Main Circuit Terminals R/L1, S/L2, T/L3 (Stranded wire use only)				
Model Name	Max. Wire Gauge Min. Wire Gauge		Screw Spec. and Torque (±10%)		
VFD220FP2EA-52S		50 mm <sup>2</sup> (1/0 AWG)			
VFD300FP2EA-52S		50 mm <sup>2</sup> (1/0 AWG)	M8		
VFD450FP4EA-52S	50 mm <sup>2</sup>	50 mm <sup>2</sup> (1/0 AWG)	63 kg-cm		
VFD550FP4EA-52S	(1/0 AWG)	50 mm <sup>2</sup> (1/0 AWG)	(55.0 lb-in.)		
VFD450FP5EA-52S		35 mm <sup>2</sup> (2 AWG)	(6.20 Nm)		
VFD550FP5EA-52S		50 mm <sup>2</sup> (1/0 AWG)			

Table 5-14

#### Frame D-1 / D-3




- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD370FP2EA-41, VFD370FP2EA-52 models: if you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD750FP4EA-41, VFD750FP4EA-52 models: if you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD450FP2EA-41, VFD450FP2EA-52, VFD900FP4EA-41, and VFD900FP4EA-52 models: if you install at Ta 30°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based
  on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do
  not reduce the wire gauge when using high-temperature resistant wire.

		ain Circuit Te		Terminal:		
	R/L1, S/I		1, V/T2, W/T3,		<u>_</u>	
Model Name		DC+, DC	;-		T	
	Max. Wire	Min. Wire	Screw Spec. and	Max. Wire	Min. Wire	Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD370FP2EA-41		120 mm <sup>2</sup>		120 mm <sup>2</sup>	70 mm <sup>2</sup>	
VFD370FP2EA-52		(4/0 AWG)		(4/0 AWG)	(2/0 AWG)	
VFD450FP2EA-41		120 mm <sup>2</sup>		120 mm <sup>2</sup>	70 mm <sup>2</sup>	
VFD450FP2EA-52		(4/0 AWG)		(4/0 AWG)	(2/0 AWG)	
VFD750FP4EA-41		95 mm <sup>2</sup>	M8	95 mm <sup>2</sup>	50 mm <sup>2</sup>	M8
VFD750FP4EA-52	120 mm <sup>2</sup>	(3/0 AWG)	180 kg-cm	(3/0 AWG)	(1/0 AWG)	180 kg-cm
VFD900FP4EA-41	(4/0 AWG)	120 mm <sup>2</sup>	(156.2 lb-in.)	120 mm <sup>2</sup>	70 mm <sup>2</sup>	(156.2 lb-in.)
VFD900FP4EA-52		(4/0 AWG)	(17.65 Nm)	(4/0 AWG)	(2/0 AWG)	(17.65 Nm)
VFD750FP5EA-41		70 mm <sup>2</sup>		70 mm <sup>2</sup>	35 mm <sup>2</sup>	
VFD750FP5EA-52		(2/0 AWG)		(2/0 AWG)	(2 AWG)	
VFD900FP5EA-41		120 mm <sup>2</sup>		120 mm <sup>2</sup>	70 mm <sup>2</sup>	
VFD900FP5EA-52		(4/0 AWG)		(4/0 AWG)	(2/0 AWG)	

Table 5-15

#### Frame D-2



- Figure 5-16
- If you install at Ta 50°C environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD370FP2EA-52S models: if you install at Ta 45°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD750FP4EA-52S models: if you install at Ta 35°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- For VFD450FP2EA-52S, VFD900FP4EA-52S models: if you install at Ta 30°C above environment, use copper wires that have a voltage rating of 600V and are temperature resistance to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based
  on temperature resistance of 75°C, in accordance with UL requirements and recommendations. Do
  not reduce the wire gauge when using high-temperature resistant wire.

	Main Circuit Terminals: U/T1, V/T2, W/T3, DC-, DC+			Terminals:		
Model Name	Max. Wire	Min. Wire	Screw Spec. and			Screw Spec. and
	Gauge	Gauge	Torque (±10%)	Gauge	Gauge	Torque (±10%)
VFD370FP2EA-52S		120 mm <sup>2</sup>		120 mm <sup>2</sup>	70 mm <sup>2</sup>	
VFD370FP2EA-323		(4/0 AWG)		(4/0 AWG)	(2/0 AWG)	
VFD450FP2EA-52S		120 mm <sup>2</sup>		120 mm <sup>2</sup>	70 mm <sup>2</sup>	
VFD450FF2EA-525		(4/0 AWG)		(4/0 AWG)	(2/0 AWG)	
VFD750FP4EA-52S		95 mm²	M8	95 mm <sup>2</sup>	50 mm <sup>2</sup>	M8
VFD/30FF4EA-323	120 mm <sup>2</sup>	(3/0 AWG)	180 kg-cm	(3/0 AWG)	(1/0 AWG)	180 kg-cm
VFD900FP4EA-52S	(4/0 AWG)	120 mm <sup>2</sup>	(156.2 lb-in.)	120 mm <sup>2</sup>	70 mm <sup>2</sup>	(156.2 lb-in.)
VFD900FF4EA-323		(4/0 AWG)	(17.65 Nm)	(4/0 AWG)	(2/0 AWG)	(17.65 Nm)
VFD750FP5EA-52S		70 mm <sup>2</sup>		70 mm <sup>2</sup>	35 mm²	
VFD/30FF3EA-323		(2/0 AWG)		(2/0 AWG)	(2 AWG)	
VED000EDEE		120 mm <sup>2</sup>		120 mm <sup>2</sup>	70 mm <sup>2</sup>	
VFD900FP5EA-52S		(4/0 AWG)		(4/0 AWG)	(2/0 AWG)	

Table 5-16

# Chapter 5 Main Circuit Terminals | CFP2000

Maddana	Main Circuit Terminals: R/L1, S/L2, T/L3 (Stranded wire use only)					
Model Name	Max. Wire Gauge Min. Wire Gauge		Screw Spec. and Torque (±10%)			
VFD370FP2EA-52S		120 mm <sup>2</sup> (4/0 AWG)				
VFD450FP2EA-52S		120 mm <sup>2</sup> (4/0 AWG)	M8			
VFD750FP4EA-52S	120 mm <sup>2</sup>	95 mm <sup>2</sup> (3/0 AWG)	63 kg-cm			
VFD900FP4EA-52S	(4/0 AWG)	120 mm <sup>2</sup> (4/0 AWG)	(55.0 lb-in.)			
VFD750FP5EA-52S		70 mm <sup>2</sup> (2/0 AWG)	(6.20 Nm)			
VFD900FP5EA-52S		120 mm <sup>2</sup> (4/0 AWG)				

Table 5-17

[This page is intentionally left blank]


# **Chapter 6 Control Terminals**

- 6-1 Remove the Cover for Wiring
- 6-2 Specifications of Control Terminal
- 6-3 Remove the Terminal Block




#### Analog input terminals (AVI1, AVI2, ACI, ACM)

- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (< 20 m) with proper grounding. If the noise is inductive, connecting the shield to the ACM terminal can reduce interference.
- ☑ Use twisted-pair wire for weak analog signals.
- ☑ If the analog input signals are affected by noise from the AC motor drive, connect a capacitor and a ferrite core as shown in Figure 6-1.



#### Contact input terminals (FWD, REV, MI1-MI8, COM)

☑ The "COM" terminal is a common terminal of the photo-coupler in all the wiring methods.



☑ When the photo-coupler uses the internal power supply, the switch connection for Sink and Source modes shows as Figure 6-2 and Figure 6-3:

MI-DCM: Sink mode
MI-+24V: Source mode

☑ When the photo-coupler uses the external power supply, remove the short-circuit cable between +24V and COM terminals. The switch connection for Sink and Source modes shows as Figure 6-4 and Figure 6-5:

The "+" of 24V connecting to COM: Sink mode
The "-" of 24V connecting to COM: Source mode

# 6-1 Remove the Cover for Wiring

Remove the top cover before wiring the multi-function input and output terminals.

NOTE: The drive appearances shown in the figures are for reference only, a real drive may look different.

#### Frame A & B

Applicable models:

VFD007FP2EA-41/-52/-52S, VFD015FP2EA-41/-52/-52S, VFD022FP2EA-41/-52/-52S,

VFD037FP2EA-41/-52/-52S, VFD055FP2EA-41/-52/-52S, VFD075FP2EA-41/-52/-52S,

VFD110FP2EA-41/-52/-52S, VFD007FP4EA-41/-52/-52S, VFD015FP4EA-41/-52/-52S,

VFD022FP4EA-41/-52/-52S, VFD037FP4EA-41/-52/-52S, VFD040FP4EA-41/-52/-52S,

WFD055FP4EA-41/-52/-52S, VFD075FP4EA-41/-52/-52S, VFD110FP4EA-41/-52/-52S,

VFD150FP4EA-41/-52/-52S, VFD185FP4EA-41/-52/-52S, VFD220FP4EA-41/-52/-52S,


VFD015FP5EA-41/-52/-52S, VFD022FP5EA-41/-52/-52S, VFD037FP5EA-41/-52/-52S,

VFD055FP5EA-41/-52/-52S, VFD075FP5EA-41/-52/-52S, VFD110FP5EA-41/-52/-52S,

VFD150FP5EA-41/-52/-52S, VFD185FP5EA-41/-52/52S

Screw torque: 14–16 kg-cm / (12.2–13.9 lb-in.) / (1.4–1.6 Nm)

- 1) Remove the keypad. (As shown in Figure 6-7)
- 2) Loosen the screws and press the tabs on both sides to remove the cover. (As shown in Figure 6-8)




#### Frame C

Applicable models:

VFD150FP2EA-41/-52/-52S, VFD185FP2EA-41/-52/-52S, VFD300FP4EA-41/-52/-52S, VFD370FP4EA-41/-52/-52S, VFD220FP5EA-41/-52/-52S, VFD300FP5EA-41/-52/-52S, VFD370FP5EA-41/-52/-52S

Screw torque: 12–16 kg-cm / (10.4–13.9 lb-in.) / (1.2–1.6 Nm)

- 1) Remove the keypad. (As shown in Figure 6-10)
- 2) Loosen the screws and press the tabs on both sides to remove the cover. (As shown in Figure 6-11)



#### Frame D0


Applicable models:

VFD220FP2EA-41/-52/-52S, VFD300FP2EA-41/-52/-52S, VFD450FP4EA-41/-52/-52S,

VFD550FP4EA-41/-52/-52S, VFD450FP5EA-41/-52/-52S, VFD550FP4EA-41/-52/-52S

Screw torque: 14-16 kg-cm / (12.1-13.9 lb-in.) / (1.4-1.6 Nm)

- 1) Remove the keypad. (As shown in Figure 6-13)
- 2) Loosen the screws and press the tabs on both sides to remove the cover. (As shown in Figure 6-14)



#### Frame D


Applicable models:

VFD370FP2EA-41/-52/-52S, VFD450FP2EA-41/-52/-52S, VFD750FP4EA-41/-52/-52S,

VFD900FP4EA-41/-52/-52S, VFD750FP5EA-41/-52/-52S, VFD900FP5EA-41/-52/-52S

Screw torque: 14–16 kg-cm / (12.1–13.9 lb-in.) / (1.4–1.6 Nm)

- 1) Remove the keypad. (As shown in Figure 6-16)
- 2) Loosen the screw and press the tabs on both sides to remove the cover. (As shown in Figure 6-17)



# **6-2 Specifications of Control Terminal**




Figure 6-18

Terminal Function	Group	Conductor	Stripping Length (mm)	Max. wire Gauge	Min. wire Gauge	Torque (±10%)					
Delev		Solid	4 5			5 kg-cm					
Relay	A	Strand	4–5			(4.3 lb-in.) (0.49 Nm)					
Control	(n)	Solid		1.5 mm <sup>2</sup>	0.2 mm <sup>2</sup>	8 kg-cm					
board	B	Strand	6.7	(16 AWG)	(26 AWG)	(6.9 lb-in.) (0.78 Nm)					
Control	Solid Solid	Solid	6–7	6-7	6-7	6-7			0-7		2 kg-cm
board	C	Strand				(1.7 lb-in.) (0.20 Nm)					

Table 6-1

#### Wiring precautions:

- In the figure above, the default for STO1, STO2, +24V and SCM1, SCM2, DCM are short circuit. The +24V from section © of above figure is for STO only, and cannot be used for other purposes. The default for +24V-COM is short circuit and SINK mode (NPN); refer to Chapter 4 Wiring for more detail.
- Tighten the wiring with slotted screwdriver:
  - (A) (B) is 3.5 mm (wide)  $\times$  0.6 mm (thick); (C) is 2.5 mm (wide)  $\times$  0.4 mm (thick)
- When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.

Terminals	Terminal Function	Default (NPN mode)
+24V	Digital control signal common (Source)	+24V ± 5% 200 mA
COM	Digital control signal common (Sink)	Common for multi-function input terminals
		FWD-DCM:
FWD	Forward-Stop command	ON: Forward running
		OFF: Deceleration to stop
		REV-DCM:
REV	Reverse-Stop command	ON: Reverse running
		OFF: Deceleration to stop

Terminals	Terminal Function	Default (NPN mode)		
MI1   MI8	Multi-function input 1–8	Refer to Pr.02-01–02-08 to program the multifunction inputs MI1–MI8.  Source Mode  ON: the activation voltage $\geq$ 11 V <sub>DC</sub> OFF: cut-off current voltage $\leq$ 5 V <sub>DC</sub> Sink Mode  ON: the activation voltage $\leq$ 13 V <sub>DC</sub> OFF: cut-off current voltage $\geq$ 19 V <sub>DC</sub> The internal resistance is 3.6 k $\Omega$ .		
DCM	Digital frequency signal common	Digital frequency signal common		
RA1	Multi-function relay output 1 (N.O.) a	Resistive Load: 3A (N.O.) / 3A (N.C.) 250 V <sub>AC</sub> 5A (N.O.) / 3A (N.C.) 30 V <sub>DC</sub>		
RB1	Multi-function relay output 1 (N.C.) b	Inductive Load (COS 0.4): 1.2A (N.O) / 1.2A (N.C.) 250 V <sub>AC</sub>		
RC1	Multi-function relay common	Various kinds of monitor signals output, e.g. operation, frequency reached, overload indication, etc.		
RA2	Multi-function relay output 2 (N.O.) a	Resistive Load: 3A (N.O.) / 250 V <sub>AC</sub>		
RC2	Multi-function relay common	5A (N.O.) / 30 V <sub>DC</sub> Inductive Load (COS 0.4):		
RA3	Multi-function relay output 3 (N.O.) a	1.2A (N.O.) / 250 V <sub>AC</sub> Various kinds of monitor signals output, e.g.		
RC3	Multi-function relay common	operation, frequency reached, overload indication, etc.		
+10V	Potentiometer power supply	Analog frequency setting: +10 V <sub>DC</sub> 20 mA		
AVI1	Analog voltage input  AVI1 circuit  +10V  AVI1  AVI1  AVI1  Figure 6-19	Impedance: 20 kΩ Range: 0–20 mA / 4–20 mA / 0–10 V = 0–Max. Output Frequency (Pr.01-00) AVI1 switch, default is 0–10 V		
ACI	Analog current input  ACI ACI circuit  ACI ACI CIRCII  ACI ACI CIRCUIT  ACI ACI CIRCII  ACI ACI CIRCII  ACI ACI CIRCII  ACI ACI CIRCUIT  ACI ACI CIRCUIT  ACI A	Impedance: 250 Ω Range: 0–20 mA / 4–20 mA / 0–10 V = 0–Max. Output Frequency (Pr.01-00) ACI Switch, default is 4–20 mA		

Terminals	Terminal Function	Default (NPN mode)				
	Auxiliary analog voltage					
	input					
AVI2	AVI2 circuit  AVI2 circuit  AVI2  AVI2  AVI2  ACM  Internal circuit Figure 6-21	Impedance: $20 \text{ k}\Omega$ Range: $0$ – $10 \text{ V}_{DC}$ = $0$ –Max. Output Frequency (Pr.01-00)				
	Multi-function analog	0.40 V May output ourrent 2 mA May load 5 kO				
AFM1	voltage output	0–10 V Max. output current 2 mA, Max. load 5 kΩ 0–20 mA Max. load 500 $\Omega$				
ALIVIT	AFM1					
		Output current: 20 mA max.				
	ACM	Resolution: 0–10 V corresponds to Max. operation frequency				
AFM2	AFM2	Range: 0–10 V → 4–20 mA				
7 (1 1 1 1 2	Figure 6-22	AFM1 / AFM2 Switch, default is 0–10 V				
ACM	Analog Signal Common	Common for analog terminals				
STO1	Default setting is shorted					
SCM1	Power removal safety function for EN	ISO 13849 and IEC 61508				
STO2	When STO1-SCM1; STO2-SCM2 is a	activated, the voltage of STO1–SCM1 / STO2–				
SCMO	SCM2 must be ≥ 11 V <sub>DC</sub> , the internal r	esistance for STO1–SCM1 / STO2–SCM2 is 3.6 k $\Omega$				
SCM2	NOTE: Refer to Chapter 18 Safe Torq	ue Off Function.				
SG+	Modbus RS-485					
SG-	NOTE: Refer to Chapter 12 DESCRIPTION OF PARAMETER SETTINGS Group 09					
SGND	Communication Parameters for more	information.				
RJ45	PIN 1, 2, 7, 8 : Reserved PIN 3,	6: SGND				
KJ45	PIN 4: SG- PIN 5:	SG+				

NOTE: Wire size of analog control signals: 0.75 mm<sup>2</sup> (18 AWG) with shielded wire.

Table 6-2

# 6-3 Remove the Terminal Block

1. Loosen the screws by screwdriver. (As shown in figure below). Screw torque: 6–8 kg-cm / (5.2–6.9 lb-in.) / (0.59–0.78 Nm)




Figure 6-23

2. Remove the control board by pulling it out for a distance 6–8 cm (as 1 in the figure) then lift the control board upward (as 2 in the figure).




Figure 6-24

# **Chapter 7 Optional Accessories**

- 7-1 Brake Resistors and Brake Units Used in AC Motor Drives
- 7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker
- 7-3 Fuse Specification Chart
- 7-4 AC Reactor
- 7-5 Zero Phase Reactors
- 7-6 EMC Filter
- 7-7 Panel Mounting (MKC-KPPK)
- 7-8 Fan Kit
- 7-9 USB/RS-485 Communication Interface IFD6530

The optional accessories listed in this chapter are available upon request. Installing additional accessories to your drive can substantially improve the drive's performance. Select accessories according to your needs or contact your local distributor for suggestion.

# 7-1 Brake Resistors and Brake Units Used in AC Motor Drives

#### 230V Model

		cable tor		125%Braking Torque / 10%ED*1						Max. Br	Max. Braking Torque*2			
Model Name			Braking	Brake Brake Resistor Serie Braking Unit Each Brake Unit*			Resistor Value Spec.	Total Braking	Min.	Max. Total	Peak			
	HP kW	kW	Torque (kg-m)	VFDB*4	P/N	Q'ty	Usage	for Each AC Motor Drive	Current (A)	Resistor Value (Ω)	Braking Current (A)	Power (kW)		
VFD007FP2EA	1	0.7	0.5	2015	BR080W200	1	-	80W 200Ω	1.9	63.3	6.0	2.3		
VFD015FP2EA	2	1.5	0.5	2015	BR080W200	1	-	80W 200Ω	1.9	63.3	6.0	2.3		
VFD022FP2EA	3	2.2	1	2015	BR200W091	1	-	200W 91Ω	4.2	47.5	8.0	3.0		
VFD037FP2EA	5	3.7	1.5	2015	BR300W070	1	-	300W 70Ω	5.4	38	10.0	3.8		
VFD055FP2EA	7.5	5.5	2.5	2015	BR400W040	1	-	400W 40Ω	9.5	19	20.0	7.6		
VFD075FP2EA	10	7.5	2.7	2015	BR1K0W020	1	-	1000W 20Ω	19	14.6	26.0	9.9		
VFD110FP2EA	15	11	3.7	2015	BR1K0W020	1	-	1000W 20Ω	19	14.6	26.0	9.9		
VFD150FP2EA	20	15	5.1	2015	BR1K5W013	1	-	1500W 13Ω	29	11.6	32.8	12.4		
VFD185FP2EA	25	18	7.4	2022	BR1K0W4P3	2	2 in series	2000W 8.6Ω	44	9.6	39.6	15.0		
VFD220FP2EA	30	22	10.2	2022	BR1K0W4P3	2	2 in series	2000W 8.6Ω	44	6.4	59.4	22.6		
VFD300FP2EA	40	30	12.2	2015*2	BR1K5W3P3	2	2 in series	6000W 3.3Ω	58	5.8	65.5	24.9		
VFD370FP2EA	50	37	14.9	2015*2	BR1K0W5P1	2	2 in series	4000W 5.1Ω	75	4.8	79.2	30.1		
VFD450FP2EA	60	45	20.3	2022*2	BR1K2W3P9	2	2 in series	4800W 3.9Ω	97	3.2	118.8	45.1		

Table 7-1

		cable otor			125%Brakin	g Toı	que 10%	ED*1		Max. Braking Torque*2		
Model Name	Model Name HP kW		Braking	Brake Unit	Brake Resis Each Br			Resistor Value Spec.	Total Braking	Min.	Max. Total	Peak
			Torque (kg-m) VFDB*4	P/N	Q'ty	Usage	for Each AC Motor Drive	Current (A)	Resistor Value (Ω)	Braking Current (A)		
VFD007FP4EA	1	0.75	0.5	-	BR080W750	1	-	80W750Ω	1	190.0	4	3.0
VFD015FP4EA	2	1.5	0.5	-	BR080W750	1	-	80W750Ω	1	190.0	4	3.0
VFD022FP4EA	3	2.2	1.0	-	BR200W360	1	-	200W360Ω	2.1	126.7	6	4.6
VFD037FP4EA	5	3.7	1.5	-	BR300W250	1	-	300W250Ω	3	108.6	7	5.3
VFD040FP4EA	5	4.0	2.5	-	BR400W150	1	-	400W150Ω	5.1	84.4	9	6.8
VFD055FP4EA	7.5	5.5	2.7	-	BR1K0W075	1	-	1000W75Ω	10.2	54.3	14	10.6
VFD075FP4EA	10	7.5	3.7	-	BR1K0W075	1	-	1000W75Ω	10.2	54.3	14	10.6
VFD110FP4EA	15	11	5.1	-	BR1K0W075	1	-	1000W75Ω	10.2	47.5	16	12.2
VFD150FP4EA	20	15	7.4	-	BR1K5W043	1	-	1500W43Ω	17.6	42.2	18	13.7
VFD185FP4EA	25	18	10.2	-	BR1K0W016	2	2 in series	2000W32Ω	24	26.2	29	22.0
VFD220FP4EA	30	22	12.2	-	BR1K0W016	2	2 in series	2000W32Ω	24	23.0	33	25.1
VFD300FP4EA	40	30	14.9	-	BR1K5W013	2	2 in series	3000W26Ω	29	23.0	33	25.1
VFD370FP4EA	50	37	20.3	ı	BR1K0W016	4	2 parallel, 2 in series	4000W16Ω	47.5	14.1	54	41.0
VFD450FP4EA	60	45	25	4045*1	BR1K2W015	4	2 parallel, 2 in series	4800W15Ω	50	12.7	60	45.6
VFD550FP4EA	75	55	30.5	4045*1	BR1K5W013	4	2 parallel, 2 in series	6000W13Ω	59	12.7	60	45.6
VFD750FP4EA	100	75	37.2	4030*2	BR1K0W5P1	4	4 in series	8000W10.2Ω	76	9.5	80	60.8
VFD900FP4EA	125	90	50.8	4045*2	BR1K2W015	4	2 parallel, 2 in series	9600W7.5Ω	100	6.3	120	91.2

Table 7-2

#### 575V Model

		cable otor			125%Brakin	ng Toi	rque / 10%E	D*1		Max. Braking Torque*2		
Model Name		Brakin		Brake Unit	Brake Resis Each Br			Resistor Value Spec.	Total Braking	Min.	Max. Total	Peak
	HP		Torque (kg-m)	VFDB*4	P/N	Q'ty	Usage	for Each AC Motor Drive	Current (A)	Resistor Value (Ω)	Braking Current (A)	
VFD015FP5EA	2	1.5	0.5	-	BR300W400	1	-	300W 400Ω	2.2	164.3	5.4	4.9
VFD022FP5EA	3	2.2	1	1	BR200W360	1	•	200W 360Ω	2.5	164.3	5.4	4.9
VFD037FP5EA	5	3.7	1.5	ı	BR300W250	1	•	300W 250Ω	3.6	87.6	10.2	9.1
VFD055FP5EA	7.5	5.5	2.7	-	BR750W140	1	-	750W 140Ω	6.4	52.6	17.0	15.2
VFD075FP5EA	10	7.5	3.7	ı	BR1K1W091	1	•	1100W 91Ω	9.8	52.6	17.0	15.2
VFD110FP5EA	15	11	5.1	-	BR1K0W075	1	-	1000W 75Ω	11.9	37.6	23.8	21.3
VFD150FP5EA	20	15	7.4	-	BR1K0W025	2	2 in series	2000W 50Ω	17.9	33.7	26.6	23.8
VFD185FP5EA	25	18.5	10.2	-	BR1K2W015	3	3 in series	3600W 45Ω	19.9	23.0	38.9	34.8
VFD220FP5EA	30	22.5	12.2	-	BR1K5W012	3	3 in series	4500W 36Ω	24.9	18.4	48.6	43.5
VFD300FP5EA	40	30	14.9	-	BR1K5W013	2	2 in series	3000W 26Ω	34.4	18.4	48.6	43.5
VFD370FP5EA	50	37	20.3	-	BR1K1W091	4	4 parallel	4000W 23Ω	38.9	12.3	73.0	65.3
VFD450FP5EA	60	45	25	5055	BR2250W020	4	2 parallel, 2 in series	9000W 20Ω	44.8	15.2	58.9	52.7
VFD550FP5EA	75	55	30.5	5055*2	BR1K0W9P5	3	3 in series	6000W 14.3Ω	62.6	7.6	117.8	105.4
VFD750FP5EA	100	75	37.2	5055*2	BR1K0W5P8	4	4 in series	8000W 11.6Ω	77.2	7.6	117.8	105.4
VFD900FP5EA	125	90	50.8	5055*2	BR1K5W3P3	5	5 in series	15000W 8.3Ω	107.8	7.6	117.8	105.4

Table 7-3

#### NOTE:

- \*1: Calculation for 125% brake torque: (kW) × 125% × 0.8; where 0.8 is the motor efficiency.

  Since there is a resistor power consumption limit, the longest operation time for 10% ED is 10 seconds (ON: 10 seconds / OFF: 90 seconds).
- \*2: See Chapter 7 "Brake Module and Brake Resistors" in the application manual for "Operation Duration & ED" vs. "Braking Current".
- \*3: To dissipate heat, mount resistors of 400 W or lower to a frame to keep the surface temperature below 250°C. Fix a resistor of 1000 W or higher to a surface to keep the surface temperature below 350°C. (If the surface temperature is higher than the temperature limit, install extra cooling or increase the size of the resistor.)
- \*4: The calculation of the brake resistor is based on a four-pole motor (1800 rpm). See VFDB series Braking Module Instruction for more details on brake resistor.

#### NOTE:

- 1. Specification and Appearances of Brake Resistors
  - (1) Wire wound resistors: For 1000W and above, see the following appearance of wire wound resistor (Figure 7-1) and its model and specification comparison table (Table 7-2) for details.




Figure 7-1

Model and Specification Comparison Table of Wire Wound Resistors:

Unit: mm

Model	Α	В	С	D	Е	F	G	Н	ØI	ØJ	K	L
BR1K0W4P3												
BR1K0W5P1												
BR1K0W016												
BR1K0W020												
BR1K0W075												
BR1K2W3P9	470±10	445±5	48±0.2	9.1±0.1	390±3	98±5	47±5	15±1	55±5	8.1±0.1	21±0.2	8±1
BR1K2W015												
BR1K5W3P3												
BR1K5W012												
BR1K5W013												
BR1K5W043												

Table 7-4

(2) Aluminum housed resistors: For below 1000W, see the following appearance of aluminum-housed resistor (Figure 7-2) and its model and specification comparison table (Table 7-3) for details.




Figure 7-2

Model and Specification Comparison Table of Aluminum Housed Resistors:

Unit: mm


Model	L1	L2	L3	W	Н	А	L
BR080W200	140.12	105.10	100±1	40+0 F	20+0 F		200±20
BR080W750	140±2	125±2	100±1	40±0.5	20±0.5	5.3±0.5	
BR200W091	165±2	150±2	125±1		30±0.5		
BR200W360	10012	150±2	12311				
BR300W070	045+0	215±2 200±2	175±1	60±0.5			
BR300W250	Z10±Z	200±2	1/311				
BR400W040	265±2	050.0 005.4					
BR400W150	200±2	250±2	225±1				

Table 7-5


#### 2. How to install brake resistors?

- (1) Clearance around brake resistors (See Figure 7-3–7-8)
- The side clearance around the brake resistor should be over 150 mm.
- The top clearance above the brake resistor should be over 500 mm.
- The clearance between two brake resistors should be at least 150 mm.

#### Single brake resistor




#### Multiple brake resistor



#### (2) Installation limits

Both horizontal and vertical mounting is safe if there is sufficient clearance and the brake resistor is installed in the correct position. Note the following:

- Do NOT install brake resistors on another brake resistor or above any hot air source.
   (Do NOT mount as shown in Figure 7-9)
- When mounting vertically, the cable connection should not be on the top of the brake resistor.
   (Do NOT mount as shown in Figure 7-10)






Figure 7-9

Figure 7-10

Select the resistance value, power and brake usage (ED %) according to Delta rules.
 100%





Figure 7-11

 $ED\% = T1 / T0 \times 100(\%)$ 

#### Explanation:

Brake usage ED (%) is the amount of time needed for the brake unit and brake resistor to dissipate heat generated by braking. When the brake resistor heats up, the resistance increases with temperature, and braking torque decreases accordingly.

For safety, install a thermal overload relay between the brake unit and the brake resistor in conjunction with the magnetic contactor (MC) at the drive mains input for additional protection. The thermal overload relay protects the brake resistor from overheat damage due to frequent or continuous braking. Under such circumstances, turn off the power to prevent damage to the brake resistor, brake unit and the drive. NOTE: Never use it to disconnect the brake resistor.



- When AC Drive is equipped with a DC reactor, please read user manual for the correct wiring for the brake unit input circuit +(P).
- DO NOT connect input circuit -(N) to the neutral point of the power system.

Figure 7-12

- 4. Any damage to the drive or other equipment caused by using brake resistors and brake modules that are not provided by Delta voids the warranty.
- 5. Consider environmental safety factors when installing the brake resistors. If you use the minimum resistance value, consult your local dealers for the power calculation.
- 6. When using more than two brake units, the equivalent resistor value of the parallel brake unit cannot be less than the value in the column "Min. Resistor Value (Ω)". Install the brake unit vertically and leaves 150 mm (5.91 in.) of heat dissipation space on the top and the bottom of the brake unit. Read the wiring information in the brake unit instruction sheet thoroughly prior to operation. Visit the following links to get the instruction sheets for the wiring in the brake unit:
  - VFDB2015 / 2022 / 4030 / 4045 / 5055 Braking Modules Instruction Sheet
     https://downloadcenter.deltaww.com/downloadCenterCounter.aspx?DID=47611&DocPath=1&hl=en-US
  - VFDB4110 / 4160 / 4185 Braking Modules Instruction Sheet
     <a href="https://downloadcenter.deltaww.com/downloadCenterCounter.aspx?DID=47614&DocPath=1&hl=en-US">https://downloadcenter.deltaww.com/downloadCenterCounter.aspx?DID=47614&DocPath=1&hl=en-US</a>
  - VFDB6055 / 6110 / 6160 / 6200 Braking Modules Instruction Sheet
     https://downloadcenter.deltaww.com/downloadCenterCounter.aspx?DID=8592&DocPath=1&hl=en-US
- 7. The selection tables are for normal use. If the AC motor drive requires frequent braking, increase the Watts by two to three times.
- 8. Thermal Overload Relay (TOR), for 230V / 460V / 575V models:

Thermal overload relay selection is based on its overload capacity. A standard braking capacity of the CFP2000 is 10%ED (Tripping time = 10 sec.). As shown in the figure below, a 460V, 110 kW CFP2000 requires the thermal relay to take 260% overload capacity for 10 seconds (hot starting) and the braking current is 126 A. In this case, select a thermal overload relay rated at 50 A. The specification of each thermal relay may vary among different manufacturers. Carefully read the specification before using it.




Figure 7-13

# 7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker

Magnetic Contactor (MC) and Air Circuit Breaker (ACB)

It is recommended the surrounding temperature for MC should be  $\geq$  60°C and that for ACB should be  $\geq$  50°C. In the meanwhile, consider temperature derating for components with ON/OFF switch in accordance with the ambient temperature of the on-site distribution panel.

#### 230V Model

Frame	Model	Light Duty	Light Duty	MC/ACB Selection
		Output Current (A)	Input Current (A)	(A)
	VFD007FP2EA-41/-52/-52S	5	5	9
	VFD015FP2EA-41/-52/-52S	7.5	7.5	13
Α	VFD022FP2EA-41/-52/-52S	10	10	18
	VFD037FP2EA-41/-52/-52S	15	15	32
	VFD055FP2EA-41/-52/-52S	21	21	40
В	VFD075FP2EA-41/-52/-52S	31	31	55
В	VFD110FP2EA-41/-52/-52S	46	46	75
	VFD150FP2EA-41/-52/-52S	61	61	105
С	VFD185FP2EA-41/-52/-52S	75	75	130
D0	VFD220FP2EA-41/-52/-52S	90	90	150
D0	VFD300FP2EA-41/-52/-52S	105	105	185
7	VFD370FP2EA-41/-52/-52S	146	146	265
D	VFD450FP2EA-41/-52/-52S	180	180	330

Table 7-6

Eromo	Model	Light Duty Output	Light Duty Input	MC/ACB Selection
Frame	Model	Current (A)	Current (A)	(A)
	VFD007FP4EA-41/-52/-52S	3	3	7
	VFD015FP4EA-41/-52/-52S	4.2	4.2	7
	VFD022FP4EA-41/-52/-52S	5.5	5.5	9
Α	VFD037FP4EA-41/-52/-52S	8.5	8.5	18
	VFD040FP4EA-41/-52/-52S	10.5	10.5	18
	VFD055FP4EA-41/-52/-52S	13	13	22
	VFD075FP4EA-41/-52/-52S	18	18	32
	VFD110FP4EA-41/-52/-52S	24	24	40
Р	VFD150FP4EA-41/-52/-52S	32	32	50
В	VFD185FP4EA-41/-52/-52S	38	38	65
	VFD220FP4EA-41/-52/-52S	45	45	75
С	VFD300FP4EA-41/-52/-52S	60	60	105
C	VFD370FP4EA-41/-52/-52S	73	73	130
DO	VFD450FP4EA-41/-52/-52S	91	91	150
D0	VFD550FP4EA-41/-52/-52S	110	110	185
	VFD750FP4EA-41/-52/-52S	150	150	265
D	VFD900FP4EA-41/-52/-52S	180	180	330

Table 7-7

#### 575V Model

Frame	Model	Light Duty Output Current (A)	Light Duty Input Current (A)	MC/ACB Selection (A)
	VFD015FP5EA-41/-52/-52S	3	3	5
	VFD022FP5EA-41/-52/-52S	4.3	4.3	9
Α	VFD037FP5EA-41/-52/-52S	6.7	6.7	18
	VFD055FP5EA-41/-52/-52S	9.9	9.9	18
	VFD075FP5EA-41/-52/-52S	12.1	12.1	23
	VFD110FP5EA-41/-52/-52S	18.7	18.7	35
В	VFD150FP5EA-41/-52/-52S	24.2	24.2	45
	VFD185FP5EA-41/-52/-52S	30	30	60
	VFD220FP5EA-41/-52/-52S	36	36	60
С	VFD300FP5EA-41/-52/-52S	45	45	120
	VFD370FP5EA-41/-52/-52S	54	54	120
D0	VFD450FP5EA-41/-52/-52S	67	67	120
DU	VFD550FP5EA-41/-52/-52S	86	86	150
D	VFD750FP5EA-41/-52/-52S	104	104	185
D -	VFD900FP5EA-41/-52/-52S	125	125	225

Table 7-8

# Non-fuse Circuit Breaker

Comply with the UL standard: Per UL 508, paragraph 45.8.4, part a.

The rated current of the non-fuse circuit breaker should be 1.6–2.6 times the drive's rated input current.

# 230V Model

Model	Breaker Rated Input Recommended Current (A)				
VFD007FP2EA-41/-52/-52S	8				
VFD015FP2EA-41/-52/-52S	12				
VFD022FP2EA-41/-52/-52S	15				
VFD037FP2EA-41/-52/-52S	25				
VFD055FP2EA-41/-52/-52S	35				
VFD075FP2EA-41/-52/-52S	50				
VFD110FP2EA-41/-52/-52S	80				
VFD150FP2EA-41/-52/-52S	100				
VFD185FP2EA-41/-52/-52S	125				
VFD220FP2EA-41/-52/-52S	150				
VFD300FP2EA-41/-52/-52S	175				
VFD370FP2EA-41/-52/-52S	225				
VFD450FP2EA-41/-52/-52S	300				

Table 7-9

# 460V Model

Model	Breaker Rated Input Recommended Current (A)
VFD007FP4EA-41/-52/-52S	6
VFD015FP4EA-41/-52/-52S	6
VFD022FP4EA-41/-52/-52S	10
VFD037FP4EA-41/-52/-52S	15
VFD040FP4EA-41/-52/-52S	15
VFD055FP4EA-41/-52/-52S	20
VFD075FP4EA-41/-52/-52S	25
VFD110FP4EA-41/-52/-52S	35
VFD150FP4EA-41/-52/-52S	50
VFD185FP4EA-41/-52/-52S	60
VFD220FP4EA-41/-52/-52S	60
VFD300FP4EA-41/-52/-52S	90
VFD370FP4EA-41/-52/-52S	100
VFD450FP4EA-41/-52/-52S	125
VFD550FP4EA-41/-52/-52S	150
VFD750FP4EA-41/-52/-52S	200
VFD900FP4EA-41/-52/-52S	250

Table 7-10

Model	Breaker Rated Input Recommended Current (A)					
VFD015FP5EA-41/-52/-52S	6					
VFD022FP5EA-41/-52/-52S	10					
VFD037FP5EA-41/-52/-52S	15					
VFD055FP5EA-41/-52/-52S	20					
VFD075FP5EA-41/-52/-52S	25					
VFD110FP5EA-41/-52/-52S	30					
VFD150FP5EA-41/-52/-52S	40					
VFD185FP5EA-41/-52/-52S	50					
VFD220FP5EA-41/-52/-52S	60					
VFD300FP5EA-41/-52/-52S	75					
VFD370FP5EA-41/-52/-52S	90					
VFD450FP5EA-41/-52/-52S	110					
VFD550FP5EA-41/-52/-52S	150					
VFD750FP5EA-41/-52/-52S	175					
VFD900FP5EA-41/-52/-52S	200					

Table 7-11

# 7-3 Fuse Specification Chart

- ☑ Fuse specifications lower than the table below are allowed.
- ☑ For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code (NEC) and any applicable local codes. Use UL classified fuses to fulfill this requirement."
- For installation in Canada, branch circuit protection must be provided in accordance with Canadian Electrical Code and any applicable provincial codes. Use UL classified fuses to fulfill this requirement."

#### 230V Model

Model Name	Input Cu	rrent I (A)	Line Fuse		
Model Name	Light Duty Normal Duty		I (A)	Bussmann P/N	
VFD007FP2EA-41/-52/-52S	5	3	8	JJS-8	
VFD015FP2EA-41/-52/-52S	7.5	5	12	JJS-12	
VFD022FP2EA-41/-52/-52S	10	8	15	JJS-15	
VFD037FP2EA-41/-52/-52S	15	11	25	JJS-25	
VFD055FP2EA-41/-52/-52S	21	17	35	JJS-35	
VFD075FP2EA-41/-52/-52S	31	25	50	JJS-50	
VFD110FP2EA-41/-52/-52S	46	33	80	JJS-80	
VFD150FP2EA-41/-52/-52S	61	49	100	JJS-100	
VFD185FP2EA-41/-52/-52S	75	65	125	JJS-125	
VFD220FP2EA-41/-52/-52S	90	75	150	JJS-150	
VFD300FP2EA-41/-52/-52S	105	90	175	JJS-175	
VFD370FP2EA-41/-52/-52S	146	120	225	JJS-225	
VFD450FP2EA-41/-52/-52S	180	146	300	JJS-300	

Table 7-12

Madal Nama	Input Cu	rrent I (A)	Line Fuse		
Model Name	Light Duty	Normal Duty	I (A)	Bussmann P/N	
VFD007FP4EA-41/-52/-52S	3.0	1.7	6	JJS-6	
VFD015FP4EA-41/-52/-52S	4.2	3	6	JJS-6	
VFD022FP4EA-41/-52/-52S	5.5	4	10	JJS-10	
VFD037FP4EA-41/-52/-52S	8.5	6	15	JJS-15	
VFD040FP4EA-41/-52/-52S	10.5	9	15	JJS-15	
VFD055FP4EA-41/-52/-52S	13	10.5	20	JJS-20	
VFD075FP4EA-41/-52/-52S	18	12	25	JJS-25	
VFD110FP4EA-41/-52/-52S	24	18	35	JJS-35	
VFD150FP4EA-41/-52/-52S	32	24	50	JJS-50	
VFD185FP4EA-41/-52/-52S	38	32	60	JJS-60	
VFD220FP4EA-41/-52/-52S	45	38	60	JJS-60	

# Chapter 7 Optional Accessories | CFP2000

Model Name	Input Cui	rrent I (A)	Line Fuse		
Woder Name	Light Duty Normal Duty		I (A)	Bussmann P/N	
VFD300FP4EA-41/-52/-52S	60	45	90	JJS-90	
VFD370FP4EA-41/-52/-52S	73	60	100	JJS-100	
VFD450FP4EA-41/-52/-52S	91	73	125	JJS-125	
VFD550FP4EA-41/-52/-52S	110	91	150	JJS-150	
VFD750FP4EA-41/-52/-52S	150	110	200	JJS-200	
VFD900FP4EA-41/-52/-52S	180	150	250	JJS-250	

Table 7-13

Model Name	Input Cui	rent I (A)	Line Fuse		
Model Name	Light Duty	Normal Duty	I (A)	Bussmann P/N	
VFD015FP5EA-41/-52/-52S	3	2.5	6	JJS-6	
VFD022FP5EA-41/52/-52S	4.3	3.6	10	JJS-10	
VFD037FP5EA-41/-52/-52S	6.7	5.5	15	JJS-15	
VFD055FP5EA-41/-52/-52S	9.9	8.2	20	JJS-20	
VFD075FP5EA-41/-52/-52S	12.1	10	25	JJS-25	
VFD110FP5EA-41/-52/-52S	18.7	15.5	30	JJS-30	
VFD150FP5EA-41/-52/-52S	24.2	20	40	JJS-40	
VFD185FP5EA-41/-52/-52S	30	24	50	JJS-50	
VFD220FP5EA-41/-52/-52S	36	30	60	JJS-60	
VFD300FP5EA-41/-52/-52S	45	36	75	JJS-75	
VFD370FP5EA-41/-52/-52S	54	45	90	JJS-90	
VFD450FP5EA-41/-52/-52S	67	54	110	JJS-110	
VFD550FP5EA-41/-52/-52S	86	67	150	JJS-150	
VFD750FP5EA-41/-52/-52S	104	86	175	JJS-175	
VFD900FP5EA-41/-52/-52S	125	104	200	JJS-200	

Table 7-14

#### 7-4 AC Reactor

#### 7-4-1 AC Input Reactor

Installing an AC reactor on the input side of an AC motor drive can increase line impedance, improve power factor, reduce input current, and reduce interference generated from the motor drive. It also reduces momentary voltage surges or abnormal current spikes. For example, when the main power capacity is higher than 500 kVA, or when using a switching capacitor bank, momentary voltage and current spike may damage the AC motor drive's internal circuit. An AC reactor on the input side of the AC motor drive protects it by suppressing surges.

#### Installation

Install an AC input reactor in series with the mains power to the three input phases R, S & T as shown below:




Figure 7-14 Wiring an AC input reactor

Following table shows the standard AC reactors specification of Delta CFP2000:

#### 200-230V / 50-60 Hz, Light Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD007FP2EA-41/-52 / VFD007FP2EA-52S	0.75	1	5	6	2.536	4.227	Yes	DR005A0254	1.2	21
VFD015FP2EA-41/-52 / VFD015FP2EA-52S	1.5	2	7.5	9	1.585	2.642	Yes	DR008A0159	1.7	37
VFD022FP2EA-41/-52 / VFD022FP2EA-52S	2.2	3	10	12	1.152	1.92	Yes	DR011A0115	2.5	38
VFD037FP2EA-41/-52 / VFD037FP2EA-52S	3.7	5	15	18	0.746	1.243	Yes	DR017AP746	3.2	40
VFD055FP2EA-41/-52 / VFD055FP2EA-52S	5.5	7.5	21	25.2	0.507	0.845	Yes	DR025AP507	3.8	61
VFD075FP2EA-41/-52 / VFD075FP2EA-52S	7.5	10	31	37.2	0.38	0.633	Yes	DR033AP320	4.5	60
VFD110FP2EA-41/-52 / VFD110FP2EA-52S	11	15	46	55.2	0.26	0.433	Yes	DR049AP215	6.5	70
VFD150FP2EA-41/-52 VFD150FP2EA-52S	15	20	61	73.2	0.196	0.327	Yes	DR065AP162	8.5	83
VFD185FP2EA-41/-52 / VFD185FP2EA-52S	18.5	25	75	90	0.169	0.282	Yes	DR075AP170	10	150
VFD220FP2EA-41/-52 / VFD200FP2EA-52S	22	30	90	108	0.141	0.235	Yes	DR090AP141	11.5	120

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD300FP2EA-41/-52 / VFD300FP2EA-52S	30	40	105	126	0.12	0.2	Yes	DR105AP106	11.8	150
VFD370FP2EA-41/-52 / VFD370FP2EA-52S	37	50	146	175.2	0.087	0.145	Yes	DR146AP087	22	110
VFD450FP2EA-41/-52 / VFD450FP2EA-52S	45	60	180	216	0.07	0.117	Yes	DR180AP070	26	120

**NOTE:** The above heat dissipation is calculated based on AC reactor's rated current, the actual dissipation varies with the operation current.

Table 7-15

# 200-230V / 50-60 Hz, Normal Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD007FP2EA-41/-52 / VFD007FP2EA-52S	0.75	1	4.6	7.36	2.536	4.227	Yes	DR005A0254	1.2	21
VFD015FP2EA-41/-52 / VFD015FP2EA-52S	1.5	2	5	8	2.536	4.227	Yes	DR005A0254	1.2	21
VFD022FP2EA-41/-52 / VFD022FP2EA-52S	2.2	3	8	12.8	1.585	2.642	Yes	DR008A0159	1.7	37
VFD037FP2EA-41/-52 / VFD037FP2EA-52S	3.7	5	11	17.6	1.152	1.92	Yes	DR011A0115	2.5	38
VFD055FP2EA-41/-52 / VFD055FP2EA-52S	5.5	7.5	17	27.2	0.746	1.243	Yes	DR017AP746	3.2	40
VFD075FP2EA-41/-52 / VFD075FP2EA-52S	7.5	10	25	40	0.507	0.845	Yes	DR025AP507	3.8	61
VFD110FP2EA-41/-52 / VFD110FP2EA-52S	11	15	33	52.8	0.38	0.633	Yes	DR033AP320	4.5	60
VFD150FP2EA-41/-52 / VFD150FP2EA-52S	15	20	49	78.4	0.26	0.433	Yes	DR049AP215	6.5	70
VFD185FP2EA-41/-52 / VFD185FP2EA-52S	18.5	25	65	104	0.196	0.327	Yes	DR065AP162	8.5	83
VFD220FP2EA-41/-52 / VFD220FP2EA-52S	22	30	75	120	0.169	0.282	Yes	DR075AP170	10	150
VFD300FP2EA-41/-52 / VFD300FP2EA-52S	30	40	90	144	0.141	0.235	Yes	DR090AP141	11.5	120
VFD370FP2EA-41/-52 / VFD370FP2EA-52S	37	50	120	192	0.12	0.2	Yes	DR105AP106	11.8	150
VFD450FP2EA-41/-52 / VFD450FP2EA-52S	45	60	146	233.6	0.087	0.145	Yes	DR146AP087	22	110

**NOTE:** The above heat dissipation is calculated based on AC reactor's rated current; the actual dissipation varies with the operation current.

Table 7-16

# 380V-460V / 50-60 Hz, Light Duty

	, _	.9	J 41.5							
Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC reactor	Input AC Reactor Delta part #	Weight (kg)	Heat Dissipation (W)
VFD007FP4EA-41/-52 / VFD007FP4EA-52S	0.75	1	3	3.9	8.102	13.502	Yes	DR003A0810	1.5	20
VFD015FP4EA-41/-52 / VFD015FP4EA-52S	1.5	2	4.2	5.46	6.077	10.127	Yes	DR004A0607	1.8	21
VFD022FP4EA-41/-52 / VFD022FP4EA-52S	2.2	3	5.5	7.15	4.05	6.752	Yes	DR006A0405	2.8	31
VFD037FP4EA-41/-52 / VFD037FP4EA-52S	3.7	5	8.5	11.05	2.7	4.501	Yes	DR009A0270	3.5	40
VFD040FP4EA-41/-52 / VFD040FP4EA-52S	4	5	10.5	13.65	2.315	3.858	Yes	DR010A0231	4.5	50
VFD055FP4EA-41/-52 / VFD055FP4EA-52S	5.5	7.5	13	16.9	2.025	3.375	Yes	DR012A0202	4.8	50

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC reactor	Input AC Reactor Delta part #	Weight (kg)	Heat Dissipation (W)
VFD075FP4EA-41/-52 / VFD075FP4EA-52S	7.5	10	18	23.4	1.174	1.957	Yes	DR018A0117	5.3	54
VFD110FP4EA-41/-52 / VFD110FP4EA-52S	11	15	24	31.2	0.881	1.468	Yes	DR024AP881	5.8	60
VFD150FP4EA-41/-52 / VFD150FP4EA-52S	15	20	32	41.6	0.66	1.101	Yes	DR032AP660	9	80
VFD185FP4EA-41/-52 / VFD185FP4EA-52S	18.5	25	38	49.4	0.639	1.066	Yes	DR038AP639	9.5	85
VFD220FP4EA-41/-52 / VFD220FP4EA-52S	22	30	45	58.5	0.541	0.9	Yes	DR045AP541	10.5	95
VFD300FP4EA-41/-52 / VFD300FP4EA-52S	30	40	60	78	0.405	0.675	Yes	DR060AP405	11.5	100
VFD370FP4EA-41/-52 / VFD370FP4EA-52S	37	50	73	94.9	0.334	0.555	Yes	DR073AP334	25	115
VFD450FP4EA-41/-52 / VFD450FP4EA-52S	45	60	91	118.3	0.267	0.445	Yes	DR091AP267	25	130
VFD550FP4EA-41/-52 / VFD550FP4EA-52S	55	75	110	143	0.221	0.368	Yes	DR110AP221	28	150
VFD750FP4EA-41/-52 / VFD750FP4EA-52S	75	100	150	195	0.162	0.27	Yes	DR150AP162	35	170
VFD900FP4EA-41/-52 / VFD900FP4EA-52S	90	125	180	234	0.135	0.225	Yes	DR180AP135	42	190

**NOTE:** The above heat dissipation is calculated based on AC reactor's rated current; the actual dissipation varies with the operation current.

Table 7-17

#### 380V-460V / 50-60 Hz, Normal Duty

	12, Normal Buty									
Model	kW HP		Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta part #	Weight (kg)	Heat Dissipation (W)
VFD007FP4EA-41/-52 / VFD007FP4EA-52S	0.75	1	2.8	2.72	13.344	22.241	Yes	DR003A0810*1	1.5	20
VFD015FP4EA-41/-52 / VFD015FP4EA-52S	1.5	2	3	4.8	8.102	13.502	Yes	DR003A0810	1.5	20
VFD022FP4EA-41/-52 / VFD022FP4EA-52S	2.2	3	4	6.4	6.077	10.127	Yes	DR004A0607	1.8	21
VFD037FP4EA-41/-52 / VFD037FP4EA-52S	3.7	5	6	9.6	4.05	6.752	Yes	DR006A0405	2.8	31
VFD040FP4EA-41/-52 / VFD040FP4EA-52S	4	5	9	14.4	2.7	4.501	Yes	DR009A0270	3.5	40
VFD055FP4EA-41/-52 / VFD055FP4EA-52S	5.5	7.5	10.5	16.8	2.315	3.858	Yes	DR010A0231	4.5	50
VFD075FP4EA-41/-52 / VFD075FP4EA-52S	7.5	10	12	19.2	2.025	3.375	Yes	DR012A0202	4.8	50
VFD110FP4EA-41/-52 / VFD110FP4EA-52S	11	15	18	28.8	1.174	1.957	Yes	DR018A0117	5.3	54
VFD150FP4EA-41/-52 / VFD150FP4EA-52S	15	20	24	38.4	0.881	1.468	Yes	DR024AP881	5.8	60
VFD185FP4EA-41/-52 / VFD185FP4EA-52S	18.5	25	32	51.2	0.66	1.101	Yes	DR032AP660	9	80
VFD220FP4EA-41/-52 / VFD220FP4EA-52S	22	30	38	60.8	0.639	1.066	Yes	DR038AP639	9.5	85
VFD300FP4EA-41/-52 / VFD300FP4EA-52S	30	40	45	72	0.541	0.9	Yes	DR045AP541	10.5	95
VFD370FP4EA-41/-52 / VFD370FP4EA-52S	37	50	60	96	0.405	0.675	Yes	DR060AP405	11.5	100
VFD450FP4EA-41/-52 / VFD450FP4EA-52S	45	60	73	116.8	0.334	0.555	Yes	DR073AP334	25	115
VFD550FP4EA-41/-52 / VFD550FP4EA-52S	55	75	91	145.6	0.267	0.445	Yes	DR091AP267	25	130

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta part #	Weight (kg)	Heat Dissipation (W)
VFD750FP4EA-41/-52 / VFD750FP4EA-52S	75	100	110	176	0.221	0.368	Yes	DR110AP221	28	150
VFD900FP4EA-41/-52 / VFD900FP4EA-52S	90	125	150	240	0.162	0.27	Yes	DR150AP162	35	170

NOTE: Table 7-18

- \*1: The inductance value for the above applications of Delta's reactors will be closer, but less than 3%.
- 2: The above heat dissipation is calculated based on AC reactor's rated current; the actual dissipation varies with the operation current.

#### 575V-600V / 50-60 Hz, Light Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta part #	Heat Dissipation (W)
VFD015FP5EA-41/-52 / VFD015FP5EA-52S	1.5	2	2.5	4	19.10	19.10	Yes	N/A	N/A
VFD022FP5EA-41/-52 / VFD022FP5EA-52S	2.2	3	3.6	6	13.26	13.26	Yes	N/A	N/A
VFD037FP5EA-41/-52 / VFD037FP5EA-52S	3.7	5	5.5	9	8.68	8.68	Yes	N/A	N/A
VFD055FP5EA-41/-52 / VFD055FP5EA-52S	5.5	5	8.2	13	5.82	5.82	Yes	N/A	N/A
VFD075FP5EA-41/-52 / VFD075FP5EA-52S	7.5	7.5	10	16	4.77	4.77	Yes	N/A	N/A
VFD110FP5EA-41/-52 / VFD110FP5EA-52S	11	10	15.5	25	3.08	3.08	Yes	N/A	N/A
VFD150FP5EA-41/-52 / VFD150FP5EA-52S	15	15	20	32	2.39	2.39	Yes	N/A	N/A
VFD185FP5EA-41/-52 / VFD185FP5EA-52S	18.5	25	30	38	1.99	1.99	Yes	N/A	N/A
VFD220FP5EA-41/-52 / VFD220FP5EA-52S	22	30	36	38	1.59	1.59	Yes	N/A	N/A
VFD300FP5EA-41/-52 / VFD300FP5EA-52S	30	40	45	48	1.33	1.33	Yes	N/A	N/A
VFD370FP5EA-41/-52 / VFD370FP5EA-52S	37	50	54	58	1.06	1.06	Yes	N/A	N/A
VFD450FP5EA-41/-52 / VFD450FP5EA-52S	45	60	67	72	0.88	0.88	Yes	N/A	N/A
VFD550FP5EA-41/-52 / VFD550FP5EA-52S	55	75	86	86	0.71	0.71	Yes	N/A	N/A
VFD750FP5EA-41/-52 / VFD750FP5EA-52S	75	100	104	107	0.56	0.56	Yes	N/A	N/A
VFD900FP5EA-41/-52 / VFD900FP5EA-52S	90	125	128	138	0.46	0.46	Yes	N/A	N/A

Table 7-19

#### 575V-600V / 50-60 Hz, Normal Duty

· · · · · · · · · · · · · · · · · · ·									
Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta part #	Heat Dissipation (W)
VFD015FP5EA-41/-52 / VFD015FP5EA-52S	1.5	2	3	4	15.92	26.53	Yes	N/A	N/A
VFD022FP5EA-41/-52 / VFD022FP5EA-52S	2.2	3	4.3	5	11.10	18.51	Yes	N/A	N/A
VFD037FP5EA-41/-52 / VFD037FP5EA-52S	3.7	5	6.7	8	7.13	11.88	Yes	N/A	N/A
VFD055FP5EA-41/-52 / VFD055FP5EA-52S	5.5	5	9.9	12	4.82	8.04	Yes	N/A	N/A

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta part #	Heat Dissipation (W)
VFD075FP5EA-41/-52 / VFD075FP5EA-52S	7.5	7.5	12.1	15	3.95	6.58	Yes	N/A	N/A
VFD110FP5EA-41/-52 / VFD110FP5EA-52S	11	10	18.7	22	2.55	4.26	Yes	N/A	N/A
VFD150FP5EA-41/-52 / VFD150FP5EA-52S	15	15	24.2	29	1.97	3.29	Yes	N/A	N/A
VFD185FP5EA-41/-52 / VFD185FP5EA-52S	18.5	25	24	36	1.59	2.65	Yes	N/A	N/A
VFD220FP5EA-41/-52 / VFD220FP5EA-52S	22	30	30	36	1.33	2.21	Yes	N/A	N/A
VFD300FP5EA-41/-52 / VFD300FP5EA-52S	30	40	36	43	1.06	1.77	Yes	N/A	N/A
VFD370FP5EA-41/-52 / VFD370FP5EA-52S	37	50	45	54	0.88	1.47	Yes	N/A	N/A
VFD450FP5EA-41/-52 / VFD450FP5EA-52S	45	60	54	65	0.71	1.19	Yes	N/A	N/A
VFD550FP5EA-41/-52 / VFD550FP5EA-52S	55	75	67	80	0.56	0.93	Yes	N/A	N/A
VFD750FP5EA-41/-52 / VFD750FP5EA-52S	75	100	86	103	0.46	0.77	Yes	N/A	N/A
VFD900FP5EA-41/-52 / VFD900FP5EA-52S	90	125	104	125	0.37	0.62	Yes	N/A	N/A

## AC input reactor dimensions and specification:




Figure 7-15

Unit: mm

Input AC Reactor Delta Part #	А	В	С	D1*D2	Е	G1	G2	PE D
DR005A0254	100	115	65	6*9	45	60	40	M4
DR008A0159	100	115	65	6*9	45	60	40	M4
DR011A0115	130	135	95	6*12	60	80.5	60	M4
DR017AP746	130	135	100	6*12	65	80.5	60	M4

Table 7-21




Figure 7-16

Unit: mm

Input AC Reactor Delta Part #	Α	В	С	D1*D2	H	G1	G2	PE D
DR025AP215	130	195	100	6*12	65	80.5	60	M4
DR033AP163	130	195	100	6*12	65	80.5	60	M4
DR049AP163	160	200	125	6*12	90	107	75	M4

Table 7-22




Figure 7-17

Unit: mm

Input AC Reactor Delta Part #	Dimensions
DR065AP162	Refer to the diagram above

Table 7-23




Figure 7-18

Input AC Reactor Delta Part #	Dimensions
DR075AP170	Refer to the diagram above

Table 7-24




Figure 7-19

Input AC Reactor Delta Part #	Dimensions
DR090AP141	Refer to the diagram above

Table 7-25




Figure 7-20

Input AC Reactor Delta Part #	Dimensions
DR105AP106	Refer to the diagram above

Table 7-26




Figure 7-21

Input AC Reactor Delta Part #	Dimensions
DR146AP087	Refer to the diagram above

Table 7-27




Figure 7-22

Input AC Reactor Delta Part #	Dimensions
DR180AP070	Refer to the diagram above

Table 7-28




Figure 7-23

Input AC Reactor Delta Part #	Α	В	С	D1*D2	Н	G1	G2	PE D
DR003A0810	100	125	65	6*9	43	60	40	M4
DR004A0607	100	125	65	6*9	43	60	40	M4
DR006A0405	130	135	95	6*12	60	80.5	60	M4
DR009A0270	160	160	105	6*12	75	107	75	M4
DR010A0231	160	160	115	6*12	90	107	75	M4
DR012A0202	160	160	115	6*12	90	107	75	M4
DR018A0117	160	160	115	6*12	90	107	75	M4




Figure 7-24

Input AC Reactor Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR024AP881	160	175	115	6*12	90	107	75	M4
DR032AP660	195	200	145	6*12	115	122	85	M6
DR038AP639	190	200	145	6*12	115	122	85	M6
DR045AP541	190	200	145	6*12	115	122	85	M6

Table 7-30




Figure 7-25

Input AC Reactor Delta Part #	Dimensions
DR060AP405	Refer to the diagram above

Table 7-31




Figure 7-26

Input AC Reactor Delta Part #	А	A1	В	B1	B2	С	D	D1*D2	Е	C1	G1	G2	Н
DR073AP334	228	240	215	40	170	133	8.5	7*13	152	75	176	200	97
DR091AP267	228	240	245	40	195	133	8.8	7*13	152	90	176	200	97
DR110AP221	228	240	245	40	195	138	8.5	7*13	152	75	176	200	102

Table 7-32




Figure 7-27

Input AC Reactor Delta Part #	Α	A1	В	В1	B2	С	C1	D	D1*D2	F	G1	G2	Н	M*T
DR150AP162	240	250	245	40	200	151	105	9	11*18	160	190	220	125	20*3
DR180AP135	240	250	245	40	200	151	105	9	11*18	160	190	220	125	20*3

The following table is spec. of THDi that Delta AC motor drives use with AC reactors.

Motor Drive Spec.	Wit	h Built in DC Reactor	
Reactor Spec.	Without Installation AC/DC Reactor	3% Input AC Reactor	5% Input AC Reactor
5 <sup>th</sup>	31.16%	27.01%	25.5%
7 <sup>th</sup>	23.18%	9.54%	8.75%
<b>11</b> <sup>th</sup>	8.6%	4.5%	4.2%
13 <sup>th</sup>	7.9%	0.22%	0.17%
THDi	42.28%	30.5%	28.4%

**NOTE:** THDi may have some difference due to different installation conditions and environment.

#### 7-4-2 AC Output Reactor

When using drives in long wiring output application, ground fault (GFF), over-current (oc) and motor over-voltage (ov) often occur. GFF and oc cause errors due to the drive's self-protective mechanism, over-voltage damages motor insulation.

The excessive length of the output wires makes the grounded stray capacitance too large, increase the three-phase output common mode current, and the reflected wave of the long wires makes the motor dv / dt and the motor terminal voltage too high. Thus, installing a reactor on the drive's output side can increase the high-frequency impedance to reduce the dv / dt and terminal voltage to protect the motor.

#### Installation

Install an AC output reactor in series between the three output phases U V W and the motor, as shown in the figure below:




Figure 7-28 Wiring an AC output reactor

Specifications of AC output reactors (standard item)

Following tables show the standard AC output reactors specification of Delta CFP2000:

#### 230V / 50-60 Hz, Light Duty

Model	kW	HP	Rated		3% Reactor		Built-in DC	Output AC Reactor Delta Part #	Weight (kg)	Dissipation
\/FD007FD0F4_44/_50			(Arms)	(Arms)	(mH)	(mH)	Reactor			(W)
VFD007FP2EA-41/-52 / VFD007FP2EA-52S	0.75	1	5	6	2.536	4.227	Yes	DR005L0254	1.5	15
VFD015FP2EA-41/-52 / VFD015FP2EA-52S	1.5	2	7.5	9	1.585	2.642	Yes	DR008L0159	2.5	30
VFD022FP2EA-41/-52 / VFD022FP2EA-52S	2.2	3	10	12	1.152	1.92	Yes	DR011L0115	3.0	33
VFD037FP2EA-41/-52 / VFD037FP2EA-52S	3.7	5	15	18	0.746	1.243	Yes	DR017LP746	3.6	34
VFD055FP2EA-41/-52 / VFD055FP2EA-52S	5.5	7.5	21	25.2	0.507	0.845	Yes	DR025LP507	5.5	50
VFD075FP2EA-41/-52 / VFD075FP2EA-52S	7.5	10	31	37.2	0.38	0.633	Yes	DR033LP320	6.5	50
VFD110FP2EA-41/-52 / VFD110FP2EA-52S	11	15	46	55.2	0.26	0.433	Yes	DR049LP215	8.6	62
VFD150FP2EA-41/-52 / VFD150FP2EA-52S	15	20	61	73.2	0.196	0.327	Yes	DR065LP162	12	70
VFD185FP2EA-41/-52 / VFD185FP2EA-52S	18.5	25	75	90	0.169	0.282	Yes	DR075LP170	14.5	80

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)		Built-in DC Reactor	Output AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD220FP2EA-41/-52 / VFD220FP2EA-52S	22	30	90	108	0.141	0.235	Yes	DR090LP141	15	80
VFD300FP2EA-41/-52 / VFD300FP2EA-52S	30	40	105	126	0.12	0.2	Yes	DR105LP106	19	95
VFD370FP2EA-41/-52 / VFD370FP2EA-52S	37	50	146	175.2	0.087	0.145	Yes	DR146LP087	22	110
VFD450FP2EA-41/-52 / VFD450FP2EA-52S	45	60	180	216	0.07	0.117	Yes	DR180LP070	26	125

Table 7-35

# $230 \text{V} \slash 50\text{--}60$ Hz, Normal Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)		Built-in DC Reactor	Output AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD007FP2EA-41/-52 / VFD007FP2EA-52S	0.75	1	4.6	7.36	2.536	4.227	Yes	DR005L0254	1.5	15
VFD015FP2EA-41/-52 / VFD015FP2EA-52S	1.5	2	5	8	2.536	4.227	Yes	DR005L0254	1.5	15
VFD022FP2EA-41/-52 / VFD022FP2EA-52S	2.2	3	8	12.8	1.585	2.642	Yes	DR008L0159	2.5	30
VFD037FP2EA-41/-52 / VFD037FP2EA-52S	3.7	5	11	17.6	1.152	1.92	Yes	DR011L0115	3.0	33
VFD055FP2EA-41/-52 / VFD055FP2EA-52S	5.5	7.5	17	27.2	0.746	1.243	Yes	DR017LP746	3.6	34
VFD075FP2EA-41/-52 VFD075FP2EA-52S	7.5	10	25	40	0.507	0.845	Yes	DR025LP507	5.5	50
VFD110FP2EA-41/-52 / VFD110FP2EA-52S	11	15	33	52.8	0.38	0.633	Yes	DR033LP320	6.5	50
VFD150FP2EA-41/-52 / VFD150FP2EA-52S	15	20	49	78.4	0.26	0.433	Yes	DR049LP215	8.6	62
VFD185FP2EA-41/-52 / VFD185FP2EA-52S	18.5	25	65	104	0.196	0.327	Yes	DR065LP162	12	70
VFD220FP2EA-41/-52 / VFD220FP2EA-52S	22	30	75	120	0.169	0.282	Yes	DR075LP170	14.5	80
VFD300FP2EA-41/-52 / VFD300FP2EA-52S	30	40	90	144	0.141	0.235	Yes	DR090LP141	15	80
VFD370FP2EA-41/-52 / VFD370FP2EA-52S	37	50	120	192	0.12	0.2	Yes	DR105LP106	19	95
VFD450FP2EA-41/-52 / VFD450FP2EA-52S	45	60	146	233.6	0.087	0.145	Yes	DR146LP087	22	110

Table 7-36

## 380V-460V / 50-60 Hz, Light Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)		5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD007FP4EA-41/-52 / VFD007FP4EA-52S	0.75	1	3	3.9	8.102	13.502	Yes	DR003L0810	1.5	13
VFD015FP4EA-41/-52 / VFD015FP4EA-52S	1.5	2	4.2	5.46	6.077	10.127	Yes	DR004L0607	2.5	18
VFD022FP4EA-41/-52 / VFD022FP4EA-52S	2.2	3	5.5	7.15	4.05	6.752	Yes	DR006L0405	3.0	22
VFD037FP4EA-41/-52 / VFD037FP4EA-52S	3.7	5	8.5	11.05	2.7	4.501	Yes	DR009L0270	3.6	35
VFD040FP4EA-41/-52 / VFD040FP4EA-52S	4	5	10.5	13.65	2.315	3.858	Yes	DR010L0231	5.5	40
VFD055FP4EA-41/-52 / VFD055FP4EA-52S	5.5	7.5	13	16.9	2.025	3.375	Yes	DR012L0202	6.0	45

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD075FP4EA-41/-52 / VFD075FP4EA-52S	7.5	10	18	23.4	1.174	1.957	Yes	DR018L0117	6.4	48
VFD110FP4EA-41/-52 / VFD110FP4EA-52S	11	15	24	31.2	0.881	1.468	Yes	DR024LP881	7.2	52
VFD150FP4EA-41/-52 / VFD150FP4EA-52S	15	20	32	41.6	0.66	1.101	Yes	DR032LP660	11	66
VFD185FP4EA-41/-52 / VFD185FP4EA-52S	18.5	25	38	49.4	0.639	1.066	Yes	DR038LP639	12	70
VFD220FP4EA-41/-52 / VFD220FP4EA-52S	22	30	45	58.5	0.541	0.9	Yes	DR045LP541	16	85
VFD300FP4EA-41/-52 / VFD300FP4EA-52S	30	40	60	78	0.405	0.675	Yes	DR060LP405	18	85
VFD370FP4EA-41/-52 / VFD370FP4EA-52S	37	50	73	94.9	0.334	0.555	Yes	DR073LP334	25	110
VFD450FP4EA-41/-52 / VFD450FP4EA-52S	45	60	91	118.3	0.267	0.445	Yes	DR091LP267	25	130
VFD550FP4EA-41/-52 / VFD550FP4EA-52S	55	75	110	143	0.221	0.368	Yes	DR110LP221	28	150
VFD750FP4EA-41/-52 / VFD750FP4EA-52S	75	100	150	195	0.162	0.27	Yes	DR150LP162	35	175
VFD900FP4EA-41/-52 / VFD900FP4EA-52S	90	125	180	234	0.135	0.225	Yes	DR180LP135	42	195

Table 7-37

#### 380V-460V / 50-60 Hz, Normal Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD007FP4EA-41/-52 / VFD007FP4EA-52S	0.75	1	2.8	2.72	13.344	22.241	Yes	DR003L0810*1	1.5	13
VFD015FP4EA-41/-52 / VFD015FP4EA-52S	1.5	2	3	4.8	8.102	13.502	Yes	DR003L0810	1.5	13
VFD022FP4EA-41/-52 / VFD022FP4EA-52S	2.2	3	4	6.4	6.077	10.127	Yes	DR004L0607	2.5	18
VFD037FP4EA-41/-52 / VFD037FP4EA-52S	3.7	5	6	9.6	4.05	6.752	Yes	DR006L0405	3.0	22
VFD040FP4EA-41/-52 / VFD040FP4EA-52S	4	5	9	14.4	2.7	4.501	Yes	DR009L0270	3.6	35
VFD055FP4EA-41/-52 / VFD055FP4EA-52S	5.5	7.5	10.5	16.8	2.315	3.858	Yes	DR010L0231	5.5	40
VFD075FP4EA-41/-52 / VFD075FP4EA-52S	7.5	10	12	19.2	2.025	3.375	Yes	DR012L0202	6.0	45
VFD110FP4EA-41/-52 / VFD110FP4EA-52S	11	15	18	28.8	1.174	1.957	Yes	DR018L0117	6.4	48
VFD150FP4EA-41/-52 / VFD150FP4EA-52S	15	20	24	38.4	0.881	1.468	Yes	DR024LP881	7.2	52
VFD185FP4EA-41/-52 / VFD185FP4EA-52S	18.5	25	32	51.2	0.66	1.101	Yes	DR032LP660	11	66
VFD220FP4EA-41/-52 / VFD220FP4EA-52S	22	30	38	60.8	0.639	1.066	Yes	DR038LP639	12	70
VFD300FP4EA-41/-52 / VFD300FP4EA-52S	30	40	45	72	0.541	0.9	Yes	DR045LP541	16	85
VFD370FP4EA-41/-52 / VFD370FP4EA-52S	37	50	60	96	0.405	0.675	Yes	DR060LP405	18	85
VFD450FP4EA-41/-52 / VFD450FP4EA-52S	45	60	73	116.8	0.334	0.555	Yes	DR073LP334	25	110
VFD550FP4EA-41/-52 / VFD550FP4EA-52S	55	75	91	145.6	0.267	0.445	Yes	DR091LP267	25	130

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)		5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Weight (kg)	Heat Dissipation (W)
VFD750FP4EA-41/-52 / VFD750FP4EA-52S	75	100	110	176	0.221	0.368	Yes	DR110LP221	28	150
VFD900FP4EA-41/-52 / VFD900FP4EA-52S	90	125	150	240	0.162	0.27	Yes	DR150LP162	35	175

NOTE: Table 7-38

- \*1: The inductance value for the above applications of Delta's reactors will be closer, but less than 3%.
- 2: The above heat dissipation is calculated based on AC reactor's rated current; the actual dissipation varies with the operation current.

#### 575V-600V / 50-60 Hz, Light Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Heat Dissipation (W)
VFD015FP5EA-41/-52 / VFD015FP5EA-52S	1.5	2	2.5	4	19.10	19.10	Yes	N/A	N/A
VFD022FP5EA-41/-52 / VFD022FP5EA-52S	2.2	3	3.6	6	13.26	13.26	Yes	N/A	N/A
VFD037FP5EA-41/-52 / VFD037FP5EA-52S	3.7	5	5.5	9	8.68	8.68	Yes	N/A	N/A
VFD055FP5EA-41/-52 / VFD055FP5EA-52S	5.5	5	8.2	13	5.82	5.82	Yes	N/A	N/A
VFD075FP5EA-41/-52 / VFD075FP5EA-52S	7.5	7.5	10	16	4.77	4.77	Yes	N/A	N/A
VFD110FP5EA-41/-52 / VFD110FP5EA-52S	11	10	15.5	25	3.08	3.08	Yes	N/A	N/A
VFD150FP5EA-41/-52 / VFD150FP5EA-52S	15	15	20	32	2.39	2.39	Yes	N/A	N/A
VFD185FP5EA-41/-52 / VFD185FP5EA-52S	18.5	25	30	38	1.99	1.99	Yes	N/A	N/A
VFD220FP5EA-41/-52 / VFD220FP5EA-52S	22	30	36	38	1.59	1.59	Yes	N/A	N/A
VFD300FP5EA-41/-52 / VFD300FP5EA-52S	30	40	45	48	1.33	1.33	Yes	N/A	N/A
VFD370FP5EA-41/-52 / VFD370FP5EA-52S	37	50	54	58	1.06	1.06	Yes	N/A	N/A
VFD450FP5EA-41/-52 / VFD450FP5EA-52S	45	60	67	72	0.88	0.88	Yes	N/A	N/A
VFD550FP5EA-41/-52 / VFD550FP5EA-52S	55	75	86	86	0.71	0.71	Yes	N/A	N/A
VFD750FP5EA-41/-52 / VFD750FP5EA-52S	75	100	104	107	0.56	0.56	Yes	N/A	N/A
VFD900FP5EA-41/-52 / VFD900FP5EA-52S	90	125	128	138	0.46	0.46	Yes	N/A	N/A

# 575V--600V / 50--60 Hz, Normal Duty

			D-4I	0-44:	20/	E0/	Duille in		114
Model	kW	HP	Rated Current	Saturation Current	3%	5% Reactor	Built-in DC	Output AC Reactor	Heat
Model	KVV	ПР		-	Reactor			Delta Part #	Dissipation
\/FD045FD5FA 44/ 50			(Arms)	(Arms)	(mH)	(mH)	Reactor		(W)
VFD015FP5EA-41/-52 / VFD015FP5EA-52S	1.5	2	3	4	15.92	26.53	Yes	N/A	N/A
VFD013FF3EA-323									
/ VFD022FP5EA-52S	2.2	3	4.3	5	11.10	18.51	Yes	N/A	N/A
VFD037FP5EA-41/-52		_				44.00			
/ VFD037FP5EA-52S	3.7	5	6.7	8	7.13	11.88	Yes	N/A	N/A
VFD055FP5EA-41/-52	5.5	5	9.9	12	4.82	8.04	Yes	N/A	N/A
/ VFD055FP5EA-52S	5.5	5	9.9	12	4.02	0.04	163	IN/A	IN/A
VFD075FP5EA-41/-52	7.5	7.5	12.1	15	3.95	6.58	Yes	N/A	N/A
/ VFD075FP5EA-52S	7.0	7.5	12.1	10	0.00	0.00	100	IN/A	IN//A
VFD110FP5EA-41/-52	11	10	18.7	22	2.55	4.26	Yes	N/A	N/A
/ VFD110FP5EA-52S			10.7		2.00	1.20		13/71	1 1// 1
VFD150FP5EA-41/-52	15	15	24.2	29	1.97	3.29	Yes	N/A	N/A
/ VFD150FP5EA-52S									
VFD185FP5EA-41/-52 / VFD185FP5EA-52S	18.5	25	24	36	1.59	2.65	Yes	N/A	N/A
VFD220FP5EA-41/-52									
/ VFD220FP5EA-52S	22	30	30	36	1.33	2.21	Yes	N/A	N/A
VFD300FP5EA-41/-52									
/ VFD300FP5EA-52S	30	40	36	43	1.06	1.77	Yes	N/A	N/A
VFD370FP5EA-41/-52	27	50	45	F.4	0.00	4 47	Yes	NI/A	NI/A
/ VFD370FP5EA-52S	37	50	45	54	0.88	1.47	162	N/A	N/A
VFD450FP5EA-41/-52	45	60	54	65	0.71	1.19	Yes	N/A	N/A
/ VFD450FP5EA-52S	40	00	J <del>-1</del>	00	0.7 1	1.13	100	IN/A	111/7
VFD550FP5EA-41/-52	55	75	67	80	0.56	0.93	Yes	N/A	N/A
/ VFD550FP5EA-52S					0.00	0.00		1 1/7 1	1 1// 1
VFD750FP5EA-41/-52	75	100	86	103	0.46	0.77	Yes	N/A	N/A
/ VFD750FP5EA-52S									
VFD900FP5EA-41/-52	90	125	104	125	0.37	0.62	Yes	N/A	N/A
/ VFD900FP5EA-52S									

0

0

## AC output reactor dimensions and specification:




Figure 7-29

Unit: mm

Output AC Reactor Delta Part #	А	В	С	D1*D2	Е	G1	G2	PE D
DR005L0254	96	110	70	6*9	42	60	40	M4
DR008L0159	120	135	96	6*12	60	80.5	60	M4
DR011L0115	120	135	96	6*12	60	80.5	60	M4
DR017LP746	120	135	105	6*12	65	80.5	60	M4
DR025LP507	150	160	120	6*12	88	107	75	M4
DR033LP320	150	160	120	6*12	88	107	75	M4

Table 7-41




Figure 7-30

Output AC Reactor Delta Part #	Α	В	С	D1*D2	Н	G	G1	Q	М	PE D
DR049LP215	180	205	175	6*12	115	85	122	16	1.2–1.4	M4
DR065LP162	180	215	185	6*12	115	85	122	35	2.5–3.0	M4

Table 7-42





Figure 7-31

Unit: mm

Output AC Reactor Delta Part #	Α	A1	В	B1	B2	С	C1	D1*D2	E	G1	Н	M*T
DR075LP170	240	228	215	44	170	151	100	7*13	152	176	85	20*3
DR090LP141	240	228	215	44	170	151	100	7*13	152	176	85	20*3
DR105LP106	240	228	215	44	170	165	110	7*13	152	176	97	20*3
DR146LP087	240	228	240	45	202	165	110	7*13	152	176	97	30*3
DR180LP070	250	240	250	46	205	175	110	11*18	160	190	124	30*5

Table 7-43



B max




Figure 7-32

Output AC Reactor Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR003L0810	96	115	65	6*9	42	60	40	M4
DR004L0607	120	135	95	6*12	60	80.5	60	M4
DR006L0405	120	135	95	6*12	60	80.5	60	M4
DR009L0270	150	160	100	6*12	74	107	75	M4
DR010L0231	150	160	115	6*12	88	107	75	M4
DR012L0202	150	160	115	6*12	88	107	75	M4
DR018L0117	150	160	115	6*12	88	107	75	M4
DR024LP881	150	160	115	6*12	88	107	75	M4
DR032LP660	180	190	145	6*12	114	122	85	M6

Table 7-44




Figure 7-33

Output AC Reactor Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR038LP639	180	205	170	6*12	115	85	122	M4
DR045LP541	235	245	155	7*13	85	/	176	M6

Table 7-45




Figure 7-34

Output AC Reactor Delta Part #	Α	A1	В	B1	B2	С	C1	D1*D2	E	G1	Н	M*T
DR060LP405	240	228	215	44	170	163	110	7*13	152	176	97	20*3
DR073LP334	250	235	235	44	186	174	115	11*18	160	190	124	20*3
DR091LP267	250	240	235	44	186	174	115	11*18	160	190	124	20*3
DR110LP221	270	260	245	50	192	175	115	10*18	176	200	106	20*3

Table 7-46




Figure 7-35

Output AC Reactor Delta Part #	А	A1	В	B1	B2	С	C1	D1*D2	Е	G1	G2	Н	M*T
DR150LP162	270	264	265	51	208	192	125	10*18	176	200	/	118	30*3
DR180LP135	300	295	310	55	246	195	125	11*22	200	230	190	142	30*3

Table 7-47

#### 7-4-3 Motor Cable Length

1. Consequence of leakage current on the motor

If the cable length is too long, the stray capacitance between cables increases and may cause leakage current. In this case, it activates the over-current protection, increases leakage current, or may affect the current display. The worst case is that it may damage the AC motor drive. If more than one motor is connected to one AC motor drive, the total wiring length should be the sum of the wiring length from AC motor drive to each motor.

For the 460V models AC motor drives, when you install an overload thermal relay between the drive and the motor to protect the motor from overheating, the connecting cable must be shorter than 50m; however, an overload thermal relay malfunction may still occur. To prevent the malfunction, install an output reactor (optional) to the drive or lower the carrier frequency setting (see Pr.00-17 Carrier Frequency).

2. Consequence of the surge voltage on the motor

When a motor is driven by a PWM-type AC motor drive, the motor terminals experience surge voltages (dv/dt) due to power transistor conversion of AC motor drive. When the motor cable is very long (especially for the 460V models), surge voltages (dv/dt) may damage the motor insulation and bearing. To prevent this, follow these rules:

- a. Use a motor with enhanced insulation.
- b. Reduce the cable length between the AC motor drive and motor to suggested values.
- c. Connect an output reactor (optional) to the output terminals of the AC motor drive.

Refer to the following tables for the suggested motor shielded cable length. For drive models < 490V, use a motor with a rated voltage  $\leq$  500 V<sub>AC</sub> and an insulation level  $\geq$  1.35 kV in accordance with IEC 60034-17.

	Rated Current (Arms)		Without AC C	output Reactor	3% With AC Output Reactor	
230V Models	Normal Duty	Light Duty	Shielded Cable (meter)	Non-shielded Cable (meter)	Shielded Cable (meter)	Non-shielded Cable (meter)
VFD007FP2EA-41/-52/ VFD007FP2EA-52S	4.6	5				
VFD015FP2EA-41/-52/ VFD015FP2EA-52S	5	7.5				
VFD022FP2EA-41/-52/ VFD022FP2EA-52S	8	10	50	75	75	115
VFD037FP2EA-41/-52/ VFD037FP2EA-52S	11	15				
VFD055FP2EA-41/-52/ VFD055FP2EA-52S	17	21				
VFD075FP2EA-41/-52/ VFD075FP2EA-52S	25	31				
VFD110FP2EA-41/-52/ VFD110FP2EA-52S	33	46				
VFD150FP2EA-41/-52/ VFD150FP2EA-52S	49	61	400	450	450	225
VFD185FP2EA-41/-52/ VFD185FP2EA-52S	65	75	100	150	150	225
VFD220FP2EA-41/-52/ VFD220FP2EA-52S	75	90				
VFD300FP2EA-41/-52/ VFD300FP2EA-52S	90	120				

	Rated Current (Arms)		Without AC C	utput Reactor	3% With AC Output Reactor	
230V Models	Normal Duty	Light Duty	Shielded Cable (meter)	Non-shielded Cable (meter)	Shielded Cable (meter)	Non-shielded Cable (meter)
VFD370FP2EA-41/-52/ VFD370FP2EA-52S	120	146	100	150	150	225
VFD450FP2EA-41/-52/ VFD450FP2EA-52S	146	180	150	225	225	325

Table 7-48

460V Models	kW HP		Rated Am Reactor		Without AC 0	Output Reactor	3% With AC Output Reactor	
400V Models	KVV	ПР	Normal Duty	Light Duty	Shielded Cable (meter)	Non-shielded Cable (meter)	Shielded Cable (meter)	Non-shielded Cable (meter)
VFD007FP4EA-41/-52/ VFD007FP4EA-52S	0.75	1	1.7	3				
VFD015FP4EA-41/-52/ VFD015FP4EA-52S	1.5	2	3	4.2				
VFD022FP4EA-41/-52/ VFD022FP4EA-52S	2.2	3	4	5.5	50	75	75	115
VFD037FP4EA-41/-52/ VFD037FP4EA-52S	3.7	5	6	8.5	50	75	75	115
VFD040FP4EA-41/-52/ VFD040FP4EA-52S	4	5	9	10.5				
VFD055FP4EA-41/-52/ VFD055FP4EA-52S	5.5	7.5	10.5	13				
VFD075FP4EA-41/-52/ VFD075FP4EA-52S	7.5	10	12	18				
VFD110FP4EA-41/-52/ VFD110FP4EA-52S	11	15	18	24				
VFD150FP4EA-41/-52/ VFD150FP4EA-52S	15	20	24	32				
VFD185FP4EA-41/-52/ VFD185FP4EA-52S	18.5	25	32	38	100	150	150	225
VFD220FP4EA-41/-52/ VFD220FP4EA-52S	22	30	38	45				
VFD300FP4EA-41/-52/ VFD300FP4EA-52S	30	40	45	60				
VFD370FP4EA-41/-52/ VFD370FP4EA-52S	37	50	60	73				
VFD450FP4EA-41/-52/ VFD450FP4EA-52S	45	60	73	91				
VFD550FP4EA-41/-52/ VFD550FP4EA-52S	55	75	91	110	150	225	225	325
VFD750FP4EA-41/-52/ VFD750FP4EA-52S	75	100	110	150	150	220	225	323
VFD900FP4EA-41/-52/ VFD900FP4EA-52S	90	125	150	180				


Table 7-49

575V	Rated Cur	rent (Arms)	Without AC Output Reactor		3% With AC Output Reactor		
Model	Normal	Light Duty	Shielded	Non-shielded	Shielded	Non-shielded	
	Duty		Cable (meter)	Cable (meter)	Cable (meter)	Cable (meter)	
VFD015FP5EA-41/-52/ VFD015FP5EA-52S	3	2.5					
VFD022FP5EA-41/-52/	4.3	3.6					
VFD022FP5EA-52S	4.3	3.0					
VFD037FP5EA-41/-52/	6.7	5.5					
VFD037FP5EA-52S	0.7	5.5	5.5	20	35	30	45
VFD055FP5EA-41/-52/	9.9	8.2	20	ან	30	45	
VFD055FP5EA-52S	9.9	0.2					
VFD075FP5EA-41/-52/	12.1	10					
VFD075FP5EA-52S	12.1	10					
VFD110FP5EA-41/-52/	18.7	15.5					
VFD110FP5EA-52S	10.7	10.0					

575V	Rated Current (Arms)		Without AC (	Output Reactor	3% With AC	Output Reactor
Model	Normal Duty	Light Duty	Shielded Cable (meter)	Non-shielded Cable (meter)	Shielded Cable (meter)	Non-shielded Cable (meter)
VFD150FP5EA-41/-52/ VFD150FP5EA-52S	24.2	20				
VFD185FP5EA-41/-52/ VFD185FP5EA-52S	30	24		0.5	30	45
VFD220FP5EA-41/-52/ VFD220FP5EA-52S	36	30		35		
VFD300FP5EA-41/-52/ VFD300FP5EA-52S	45	36			45	60
VFD370FP5EA-41/-52/ VFD370FP5EA-52S	54	45	20			
VFD450FP5EA-41/-52/ VFD450FP5EA-52S	67	54			00	75
VFD550FP5EA-41/-52/ VFD550FP5EA-52S	86	67		45	60	
VFD750FP5EA-41/-52/ VFD750FP5EA-52S	104	86				100
VFD900FP5EA-41/-52/ VFD900FP5EA-52S	128	104			75	

Table 7-50

## Requirements on insulation level of Curve B motor



#### Key

A Without filters for motors up to 500 V a.c.

B Without filters for motors up to 690 V a.c.

 $^{\star}$  Examples of measured results at 415 V supply, for different lengths of steel armoured cable

Figure 7-36

#### The t<sub>r</sub> is defined as:




Figure 7-37

#### 7-4-4 Sine-wave filter

When there is longer cable length connected between the motor drive and the motor, the damping leads to high frequency resonator, and makes impedance matching poor to enlarge the voltage reflection. This phenomenon generates twice-input voltage in the motor side, which easily makes motor voltage overshoot to damage insulation.

To prevent this, installing sine-wave filter can transform PWM output voltage to smooth and low-ripple sin wave, and motor cable length can be longer than 1000 meters.

#### Installation

Sine-wave filter is serially connected between motor drive UVW output side and motor, which is shown as below:




Figure 7-38 Wiring of non-shielded cable




Figure 7-39 Wiring of shielded cable

#### NOTE:

- 1. Sinusoidal filters must only be used in V/F operation mode (Pr.00-11 = 0). If the application requires FOC control, then Sinusoidal filters cannot be installed on the output.
- 2. Sinusoidal filters have strict limits on the output frequency (Pr.01-00), carrier frequency (Pr.00-17) and sometimes also on modulation type. Check the datasheet of the sine-wave filter and contact Delta for more information on how to set the drive to make sure that those limits never get exceeded.

# Following table shows the sine-wave filter specification of Delta CFP2000 230V–230V, 50–60 Hz

Mardal	1-10/	LID	Rated Curre	ent (Arms)	Suggested Sine-wave	Output Cable Length (m)
Model	kW	HP	Normal Duty	Light Duty	Filter Part #	(Shielded or Non-shielded)
VFD007FP2EA-41/-52/ VFD007FP2EA-52S	0.75	1	4.6	5	B84143V0006R227	1000
VFD015FP2EA-41/-52/ VFD015FP2EA-52S	1.5	2	5	7.5	B84143V0011R227	1000
VFD022FP2EA-41/-52/ VFD022FP2EA-52S	2.2	3	8	10	B84143V0011R227	1000
VFD037FP2EA-41/-52/ VFD037FP2EA-52S	3.7	5	11	15	B84143V0025R227	1000
VFD055FP2EA-41/-52/ VFD055FP2EA-52S	5.5	7.5	17	21	B84143V0025R227	1000
VFD075FP2EA-41/-52/ VFD075FP2EA-52S	7.5	10	25	31	B84143V0033R227	1000
VFD110FP2EA-41/-52/ VFD110FP2EA-52S	11	15	33	46	B84143V0050R227	1000
VFD150FP2EA-41/-52/ VFD150FP2EA-52S	15	20	49	61	B84143V0066R227	1000
VFD185FP2EA-41/-52/ VFD185FP2EA-52S	18.5	25	65	75	B84143V0075R227	1000
VFD220FP2EA-41/-52/ VFD220FP2EA-52S	22	30	75	90	B84143V0095R227	1000
VFD300FP2EA-41/-52/ VFD300FP2EA-52S	30	40	90	105	B84143V0132R227	1000
VFD370FP2EA-41/-52/ VFD370FP2EA-52S	37	50	120	146	B84143V0180R227	1000
VFD450FP2EA-41/-52/ VFD450FP2EA-52S	45	60	146	180	B84143V0180R227	1000
VFD007FP2EA-41/-52/ VFD007FP2EA-52S	55	75	180	215	B84143V0250R227	1000
VFD015FP2EA-41/-52/ VFD015FP2EA-52S	75	100	215	276	B84143V0320R227	1000
VFD022FP2EA-41/-52/ VFD022FP2EA-52S	90	125	255	322	Non-available	1000

#### Table 7-51

#### 380V-460V / 50-60 Hz

Model	kW	HP	Rated Current ND (Arms)	Sine Wave Filter Model Name For ND Current	Rated Current LD (Arms)	Sine Wave Filter Model Name For LD Current	Output Motor Cable Length (m) (Shielding or Non- shielding)
VFD007FP4EA-41/-52 / VFD007FP4EA-52S	0.75	1	2.8		3	D0 44 40 4000 4 D007	
VFD015FP4EA-41/-52 / VFD015FP4EA-52S	1.5	2	3	B84143V0004R227	4.2	B84143V0004R227	
VFD022FP4EA-41/-52 / VFD022FP4EA-52S	2.2	3	4		5.5	B84143V0006R227	1000
VFD037FP4EA-41/-52 / VFD037FP4EA-52S	3.7	5	6	B84143V0006R227	8.5	D04440\/0044D007	
VFD040FP4EA-41/-52 / VFD040FP4EA-52S	4	5	9	B84143V0011R227	10.5	B84143V0011R227	

Model	kW	HP	Rated Current ND (Arms)	Sine Wave Filter Model Name For ND Current	Rated Current LD (Arms)	Sine Wave Filter Model Name For LD Current	Output Motor Cable Length (m) (Shielding or Non- shielding)
VFD055FP4EA-41/-52 / VFD055FP4EA-52S	5.5	7.5	10.5	B84143V0011R227	13	B84143V0016R227	
VFD075FP4EA-41/-52 / VFD075FP4EA-52S	7.5	10	12	B84143V0016R227	18		
VFD110FP4EA-41/-52 / VFD110FP4EA-52S	11	15	18		24	B84143V0025R227	
VFD150FP4EA-41/-52 / VFD150FP4EA-52S	15	20	24	B84143V0025R227	32	B84143V0033R227	
VFD185FP4EA-41/-52 / VFD185FP4EA-52S	18.5	25	32	B84143V0033R227	38		
VFD220FP4EA-41/-52 / VFD220FP4EA-52S	22	30	38		45	B84143V0050R227	
VFD300FP4EA-41/-52 / VFD300FP4EA-52S	30	40	45	B84143V0050R227	60	B84143V0066R227	1000
VFD370FP4EA-41/-52 / VFD370FP4EA-52S	37	50	60	B84143V0066R227	73	B84143V0075R227	
VFD450FP4EA-41/-52 / VFD450FP4EA-52S	45	60	73	B84143V0075R227	91	B84143V0095R227	
VFD550FP4EA-41/-52 / VFD550FP4EA-52S	55	75	91	B84143V0095R227	110	B84143V0132R227	
VFD750FP4EA-41/-52 / VFD750FP4EA-52S	75	100	110	B84143V0132R227	144	D044404040400E00	
VFD900FP4EA-41/-52 / VFD900FP4EA-52S	90	125	150	B84143V0180R227	180	B84143V0180R227	

Table 7-52

Sine wave filter Model	Reference website: <a href="http://en.tdk.eu/inf/30/db/emc_2014/B84143V_R227.pdf">http://en.tdk.eu/inf/30/db/emc_2014/B84143V_R227.pdf</a>
B84143V0004R227	I <sub>R</sub> :4A, Sine-wave output filters for 3-phase systems
B84143V0006R227	I <sub>R</sub> :6A, Sine-wave output filters for 3-phase systems
B84143V0011R227	I <sub>R</sub> :11A, Sine-wave output filters for 3-phase systems
B84143V0016R227	I <sub>R</sub> :16A, Sine-wave output filters for 3-phase systems
B84143V0025R227	I <sub>R</sub> :25A, Sine-wave output filters for 3-phase systems
B84143V0033R227	I <sub>R</sub> :33A, Sine-wave output filters for 3-phase systems
B84143V0050R227	I <sub>R</sub> :50A, Sine-wave output filters for 3-phase systems
B84143V0066R227	I <sub>R</sub> :66A, Sine-wave output filters for 3-phase systems
B84143V0075R227	I <sub>R</sub> :75A, Sine-wave output filters for 3-phase systems
B84143V0095R227	I <sub>R</sub> :95A, Sine-wave output filters for 3-phase systems
B84143V0132R227	I <sub>R</sub> :132A, Sine-wave output filters for 3-phase systems
B84143V0180R227	I <sub>R</sub> :180A, Sine-wave output filters for 3-phase systems

Table 7-53

#### 7-5 Zero Phase Reactors

You can also suppress interference by installing a zero phase reactor. When you encounter any interference after normal installation, buy and install a zero phase reactor. The following are information of zero phase reactors for signal cable.

#### **Zero Phase Reactors for Signal Cable**

To solve interference problems between signal cables and electric devices, install a zero phase reactor for the signal cable. This suppresses the noise for a better signal. The following table lists model names and dimensions.




Figure 7-40

Unit: mm

Model	A	В	С
RF026X00N	10.7	17.8	8.0
RF020X00N	17.5	27.3	12.3

Table 7-54

#### **Zero Phase Reactor for Motor Cable**

Unit: mm

Model	А	В	С
RF010FP00A	28.7	43.1	18.5
RF006FP00A	26.9	48.4	18.2
RF002FP001	59.3	83.5	27.8

## 7-6 EMC Filter

Following table is the built-in EMC filter of CFP2000 series. User can choose corresponding zero phase reactor and suitable shielded cable length in accord to required noise emission and electromagnetic interference level to achieve the best configuration to suppress the electromagnetic interference.

#### 230V Models

	CFP2000		CE Cable Length				Radiation Emission	
		Rated	Zero Phase Reactor*2	EN IEC 61800-3				
Frame	Model	Input Current (A)		Category C2	Carrier Frequency (Hz)	Category C1	Carrier Frequency (Hz)	C2
	VFD007FP2EA-41/-52/-52S	5						Pass
	VFD015FP2EA-41/-52/-52S	7.5				25 m ≤ 6		
Α	VFD022FP2EA-41/-52/-52S	10	RF010FP00A					
	VFD037FP2EA-41/-52/-52S	15					≤ 6 K	
	VFD055FP2EA-41/-52/-52S	21						
	VFD075FP2EA-41/-52/-52S	31						
В	VFD110FP2EA-41/-52/-52S	46	RF006FP00A	75 m	≤ 6 K			
	VFD150FP2EA-41/-52/-52S	61	DECOCEDOOA					
С	VFD185FP2EA-41/-52/-52S	75	RF002FP00A					
	VFD220FP2EA-41/-52/-52S	90	-					
D0	VFD300FP2EA-41/-52/-52S	105						
	VFD370FP2EA-41/-52/-52S	146	-					
D	VFD450FP2EA-41/-52/-52S	180	-					

Table 7-56

### 460V Models

	050000			0F 0 - b l - 1 b				Radiation
CFP2000			CE Cable Length				Emission	
	Model	Rated	Zero Phase Reactor*2		E	N IEC 618	00-3	
Frame		Input Current (A)		Category C2	Carrier frequency (Hz)	Category C1	Carrier frequency (Hz)	C2
	VFD007FP4EA-41/-52/-52S	3.0					≤ 4 K*1	
	VFD015FP4EA-41/-52/-52S 4.:	4.2						
	VFD022FP4EA-41/-52/-52S	5.5	RF010FP00A					
Α	VFD037FP4EA-41/-52/-52S	8.5						
	VFD040FP4EA-41/-52/-52S	10.5						Pass
	VFD055FP4EA-41/-52/-52S	13		75 m	≤ 8 K	25 m		
	VFD075FP4EA-41/-52/-52S	18						
	VFD110FP4EA-41/-52/-52S	24						
	VFD150FP4EA-41/-52/-52S	32	DE000ED00A					
В	VFD185FP4EA-41/-52/-52S	38	RF006FP00A					
	VFD220FP4EA-41/-52/-52S	45						

	CFP2000		CE Cable Length				Radiation Emission	
	Rated		Zero Phase Reactor*2	EN IEC 61800-3				
Frame	Model	Input Current (A)		Category C2	Carrier frequency (Hz)	Category C1	Carrier frequency (Hz)	C2
	VFD300FP4EA-41/-52/-52S	60	RF002FP00A		≤ 8 K		≤ 4 K*1	
С	VFD370FP4EA-41/-52/-52S	73	RF002FF00A	20K		2 4 K		
<b>D</b> 0	VFD450FP4EA-41/-52/-52S	91	-	75 m ≤ 10 K	- 10 K	10 K 25 m		Dana
D0	VFD550FP4EA-41/-52/-52S	110	-		≥ 10 K		- 416	Pass
	VFD750FP4EA-41/-52/-52S	150	-		< 0 K		≤ 4 K	
D	VFD900FP4EA-41/-52/-52S	180			≤ 9 K			

NOTE: Table 7-57

- \*1: For Frame A–C to comply with EN IEC 61800-3 C1 regulations (when the length of the cable is less than 25 m, it complies with the C1 regulations), install a zero phase reactor on the output side. Pass the three UVW cables through the zero phase reactor. Do not pass the grounding cable and the pigtail of the insulation through the zero phase reactor.
- \*2: When the length of the cable is longer than 25 m, do not install the zero phase reactors listed in the table above.

#### 575V Models

	CFP2000			CE Cable Length				Radiation Emission
		Rated	Zero Phase Reactor*2	EN IEC 61800-3			0-3	
Frame	Model	Input Current (A)		Category C3	Carrier Frequency (Hz)	Category C2	Carrier Frequency (Hz)	C2
	VFD015FP5EA-41/-52/-52S	3						
	VFD022FP5EA-41/-52/-52S	4.3						
Α	VFD037FP5EA-41/-52/-52S	6.7	RF010FP00A					
	VFD055FP5EA-41/-52/-52S	9.9						
	VFD075FP5EA-41/-52/-52S	12.1				20m	≤ 6K* <sup>1</sup>	
	VFD110FP5EA-41/-52/-52S	18.7	RF006FP00A					
В	VFD150FP5EA-41/-52/-52S	24.2						
	VFD185FP5EA-41/-52/-52S	30		50m	≤ 6K			Pass
	VFD220FP5EA-41/-52/-52S	36						
С	VFD300FP5EA-41/-52/-52S	45	RF002FP00A					
	VFD370FP5EA-41/-52/-52S	54						
Do	VFD450FP5EA-41/-52/-52S	67	-					
D0	VFD550FP5EA-41/-52/-52S	86	-				≤ 6K	
	VFD750FP5EA-41/-52/-52S	104	-				> 0K	
D	VFD900FP5EA-41/-52/-52S	125	-					

NOTE: Table 7-58

- \*1: For Frame A–C to comply with EN IEC 61800-3 C2 regulations (when the length of the cable is less than 20 m, it complies with the C2 regulations), install a zero phase reactor on the output side. Pass the three UVW cables through the zero phase reactor. Do not pass the grounding cable and the pigtail of the insulation through the zero phase reactor.
- \*2: When the length of the cable is longer than 20 m, do not install the zero phase reactors listed in the table above, or the zero phase reactor may be overheated.

#### **EMC Filter Installation**

All electrical equipment (including AC motor drives) generate high or low frequency noise that interferes with peripheral equipment by radiation or conduction during operation. Correctly install an EMC filter can eliminate much interference. It is recommended to use DELTA EMC filter to have the best interference elimination performance.

We assure that it can comply with the following rules when the AC motor drive and EMC filter are both installed and wired according to user manual:

- 1. EN61000-6-4
- 2. EN IEC 61800-3
- 3. EN55011 Class A Group 1

#### **General precaution**

To ensure the EMC filter maximizes the effect of suppressing the interference of AC motor drive, the installation and wiring of AC motor drive should follow the user manual. In addition, be sure to observe the following precautions:

- ☑ All the cables should be divided into several classifications, and kept away from each other. The metal layer inside the control cabinet can separate the cables as well. For susceptible cables (Class 1), there should always be an uninterrupted partition between the two terminals. Use the following classifications (Class 1–4):
  - Class 1: Cables susceptible to interference (e.g. low-voltage / high-speed signal cable, control
    cable, data cable...)
  - Class 2: Cables susceptible to interference (e.g. low-speed communication cable, low-voltage (24 V) power cable...)
  - Class 3: Disturbance cable (e.g. R.S.T. power input cable)
  - Class 4: Strong disturbance cable. (e.g. U.V.W. motor output cable)
  - The following figure shows the recommended cables and their installation clearance:




Figure 7-41

- ☑ If the installation distance does not meet the above separation requirement, connect a zero-phase reactor to the Class 4 cable in series, and use shielded cable or connect core in series to the Class 1 cable.
- When the installation distances of different cables do not meet the separation requirement, place the cables at right angles. For example, the filtered cable should be separated from the non-filtered cable; signal cable, data cable and filtered cable can only be placed at right angles with the non-filtered cable.

- ☑ All cables should be as short as possible.
- ☑ For extra cables, remove them or ground them on each end to avoid floating connection.
- ☑ Separate the motor cable from the data cables that connect to the motor (for example, encoder line or motor temperature sensors).
- ☑ Place the cable on the metal plate, do not hang it in the air.
- ☑ Use an independent isolated transformer to segregate susceptible equipment from equipment with stronger interference.
- ☐ The RC filter is required for the magnetic contactor coil, relay and solenoid valve to eliminate high-frequency radiation interference (for example, RC elements or varistors with AC coils and free-wheeling diodes or varistors for DC coils) that comes from turning the unit ON and OFF. All these protection circuit should be close to the coil.
- Make sure the cover, equipment and accessories installed inside the control cabinet (for example, motor drive or filter) are installed with good-conductivity mounting plate, and are connected to the cabinet frame with good connection and large contact areas. Most of all, the wiring should be connected to the PE and EMC isolation bar.
- ☑ To build up the grounding system, remove the cover with a protective layer or anodic treatment on its connection, or connect it to the non-conductive layer with a special metal sheet before connecting to the AC drive.
- Keep wires as short as possible and ground metal plates. The cover of the AC motor drive or grounding should be fixed to the metal plate and the contact area should be as large as possible.

#### Choose suitable motor cable and precautions

Isolate the motor wires, signal wires and data wires.

The recommended shielded wire can be selected from the three types of shielding wire in Figure 1. The figure on the left is a symmetric three-phase power cord with symmetric PE wires. The middle figure is a three-phase power cord with a separated PE wire. The figure on the right is the asymmetric three-phase power cord with a PE wire.)

The size of the power cord should be based on the rated current. Using high density braided shielding avoids electromagnetic noise that results from high frequency signals, as well as prevents external sources from interfering with signal transmissions. We recommend two types of shielded cables:

- Braided copper shielding of 85% density or more (as shown in figure 2a).
- 100% aluminum foil / copper foil wrapping inside, and in braided shielding of 80% or more outside (as shown in figure 2b).




Figure 1 Types shielded cables recommended




Figure 2a Figure 2b

#### Precautions for motor cable installation

Improper installation and choice of motor cable affects the performance of EMC filter. Be sure to observe the following precautions when selecting motor cable. The shielded layers of motor cable must be grounded by using omega clips or pigtail. If using omega clips, the shielded layers must have a 360-degree contact with the motor and the PE on motor drive (as shown in Figure 3).

If using a pigtail for grounding, the length of the pigtail cannot be more than five times of the wire size (WVW wire sizing)



Figure 3

#### **Zero Phase Reactors at Output Side**

- For Frame A–C (230V / 460V models): to comply with EN IEC 61800-3 C1 regulations (when the length of shielded cable is 25 m), install a zero phase reactor on the output side. Pass the three UVW cables through the zero phase reactor. Do not pass the grounding cable and the pigtail of the insulation through the zero phase reactor. When the length of the cable is longer than 25 m, do not install the zero phase reactors.
- For Frame A–C (575V models): to comply with EN IEC 61800-3 C2 regulations (when the length of the cable is 20 m), install a zero phase reactor on the output side. Pass the three UVW cables through the zero phase reactor. Do not pass the grounding cable and the pigtail of the insulation through the zero phase reactor. When the length of the cable is longer than 20 m, do not install the zero phase reactors.





Figure 7-44

## 7-7 Panel Mounting (MKC-KPPK)

For MKC-KPPK model, you can choose wall mounting or embedded mounting, the protection level is IP66.

Applicable to the digital keypad (KPC-CC01).







Figure 7-47

22.0 [0.87]



Normal cutout dimension Panel 1.6 mm 2.0 mm

Thickness	1.2 111111	1.0 111111	2.0 111111			
^	66.4					
A	(2.614)					
Б	110.2	111.3	112.5			
В	(4.339)	(4.429)				
*D : "	Table 7-50					


\*Deviation: ±0.15 mm /±0.0059 inch

ı	Cutout	dimension	(Water	proof	level:	IP66
1	Calcat	annonoion	(vvatoi	piooi	IOVOI.	

Panel Thickness	1.2 mm	1.6 mm	2.0 mm	
Α	66.4 (2.614)			
В	110.8 (4.362)			

<sup>\*</sup>Deviation: ±0.15 mm /±0.0059 inch

Table 7-60



#### 7-8 Fan Kit

## 7-8-1 Appearance of the Fan Kit


Frames of heatsink fans:

# NOTE: The fan does not support hot swap function. Turn the power off before replacing the fan. Frame A Heat sink Fan Model MKFP-AFKM Applicable Model VFD022FP2EA-41/-52/-52S, VFD022FP4EA-41/-52/-52S, VFD022FP5EA-41/-52/-52S, VFD037FP2EA-41/-52/-52S, VFD037FP4EA-41/-52/-52S, VFD037FP5EA-41/-52/-52S, VFD040FP4EA-41/-52/-52S, VFD055FP2EA-41/-52/-52S, VFD055FP4EA-41/-52/-52S, VFD055FP5EA-41/-52/-52S, VFD075FP4EA-41/-52/-52S, VFD075FP5EA-41/-52/-52S Figure 7-51 Frame B Heat sink Fan Model 『MKFP-BFKM』 Applicable Model VFD075FP2EA-41/-52/-52S, VFD110FP2EA-41/-52/-52S, VFD110FP4EA-41/-52/-52S, VFD110FP5EA-41/-52/-52S, VFD150FP4EA-41/-52/-52S, VFD150FP5EA-41/-52/-52S, VFD185FP4EA-41/-52/-52S, VFD185FP5EA-41/-52/-52S, VFD220FP4EA-41/-52/-52S Figure 7-52 Frame C Heat sink Fan Model 『MKFP-CFKM』 Applicable Model VFD150FP2EA-41/-52/-52S, VFD185FP2EA-41/-52/-52S, VFD220FP5EA-41/-52/-52S, VFD300FP4EA-41/-52/-52S, VFD300FP5EA-41/-52/-52S, VFD370FP4EA-41/-52/-52S, VFD370FP5EA-41/-52/-52S Figure 7-53 Frame D0 Heat sink Fan Model 『MKFP-D0FKM』 Applicable Model VFD220FP2EA-41/-52/-52S, VFD300FP2EA-41/-52/-52S, VFD450FP4EA-41/-52/-52S, VFD450FP5EA-41/-52/-52S, VFD550FP4EA-41/-52/-52S, VFD550FP5EA-41/-52/-52S

Figure 7-54

## Applicable Model

VFD370FP2EA-41/-52/-52S, VFD450FP2EA-41/-52/-52S, VFD750FP4EA-41/-52/-52S, VFD750FP5EA-41/-52/-52S, VFD900FP4EA-41/-52/-52S, VFD900FP5EA-41/-52/-52S



#### • Frames of capacitor fans:

NOTE: The fan does not support hot swap function. Turn the power off before replacing the fan.

#### Frame A

#### Applicable Model

VFD007FP2EA-41/-52/-52S, VFD007FP4EA-41/-52/-52S,

VFD015FP2EA-41/-52/-52S, VFD015FP4EA-41/-52/-52S,

VFD015FP5EA-41/-52/-52S, VFD022FP2EA-41/-52/-52S,

VFD022FP4EA-41/-52/-52S, VFD022FP5EA-41/-52/-52S,

VFD037FP2EA-41/-52/-52S, VFD037FP4EA-41/-52/-52S,

VFD037FP5EA-41/-52/-52S, VFD040FP4EA-41/-52/-52S,

VFD055FP2EA-41/-52/-52S, VFD055FP4EA-41/-52/-52S,

VFD055FP5EA-41/-52/-52S, VFD075FP4EA-41/-52/-52S,

VFD075FP5EA-41/-52/-52S

#### Capacitor Fan Model 『MKFP-AFKB』




Figure 7-56

#### Frame B

#### Applicable Model

VFD075FP2EA-41/-52/-52S, VFD110FP2EA-41/-52/-52S,

VFD110FP4EA-41/-52/-52S, VFD110FP5EA-41/-52/-52S,

VFD150FP4EA-41/-52/-52S, VFD150FP5EA-41/-52/-52S,

VFD185FP4EA-41/-52/-52S, VFD185FP5EA-41/-52/-52S,

VFD220FP4EA-41/-52/-52S

#### Capacitor Fan Model 『MKFP-BFKB』




Figure 7-57

#### Frame C

#### Applicable Model

VFD150FP2EA-41/-52/-52S, VFD185FP2EA-41/-52/-52S,

VFD220FP5EA-41/-52/-52S, VFD300FP4EA-41/-52/-52S,

VFD300FP5EA-41/-52/-52S, VFD370FP4EA-41/-52/-52S,

VFD370FP5EA-41/-52/-52S

#### Frame D0

#### Applicable Model

VFD220FP2EA-41/-52/-52S, VFD300FP2EA/41/-52/-52S,

VFD450FP4EA-41/-52/-52S, VFD450FP5EA-41/-52/-52S,

VFD550FP4EA-41/-52/-52S, VFD550FP5EA-41/-52/-52S

## Frame D

#### Applicable Model

VFD370FP2EA-41/-52/-52S, VFD450FP2EA-41/-52/-52S,

VFD750FP4EA-41/-52/-52S, VFD750FP5EA-41/-52/-52S,

VFD900FP4EA-41/-52/-52S, VFD900FP5EA-41/-52/-52S

#### Capacitor Fan Model MKFP-CFKB




Figure 7-58

## 7-8-2 Fan Removal


#### Frame A

Model『MKFP-AFKM』: Heat Sink Fan

#### Applicable model

VFD022FP2EA-41/-52/-52S, VFD022FP4EA-41/-52/-52S, VFD022FP5EA-41/-52/-52S, VFD037FP2EA-41/-52/-52S, VFD037FP4EA-41/-52/-52S, VFD037FP5EA-41/-52/-52S, VFD040FP4EA-41/-52/-52S, VFD055FP2EA-41/-52/-52S, VFD055FP5EA-41/-52/-52S, VFD075FP4EA-41/-52/-52S, VFD075FP5EA-41/-52/-52S

- 1. Refer to the figure below, loosen the 4 screws then remove the fan kit.
- 2. Screw torque: 10–12 kg-cm / (8.7–10.4 lb-in.) / (1.0–1.2 Nm)



#### Frame A

## Model 『MKFP-AFKB』: Capacitor Fan

#### Applicable model

VFD007FP2EA-41/-52/-52S, VFD007FP4EA-41/-52/-52S, VFD015FP2EA-41/-52/-52S,

VFD015FP4EA-41/-52/-52S, VFD015FP5EA-41/-52/-52S, VFD022FP2EA-41/-52/-52S,


VFD022FP4EA-41/-52/-52S, VFD022FP5EA-41/-52/-52S, VFD037FP2EA-41/-52/-52S,

VFD037FP4EA-41/-52/-52S, VFD037FP5EA-41/-52/-52S, VFD040FP4EA-41/-52/-52S,

VFD055FP2EA-41/-52/-52S, VFD055FP4EA-41/-52/-52S, VFD055FP5EA-41/-52/-52S,

VFD075FP4EA-41/-52/-52S, VFD075FP5EA-41/-52/-52S

- 1. Press the hook in the top of digital keypad, and then rotate to remove the digital keypad. (Refer to Figure 7-60)
- 2. Screw 1–4 torque: 14–16 kg-cm / (12.2–13.9 lb-in.) / (1.4–1.6 Nm)
- 3. Loosen the screws 7–13 then remove the fan kit. (Refer to Figure 7-61)
- Screw 7–12 torque: 6–8 kg-cm / (5.2–6.9 lb-in.) / (0.6–0.8 Nm);
   Screw 13 torque: 12–14 kg-cm / (10.4–12.2 lb-in.) / (1.2–1.4 Nm)



#### Frame B


## Model『MKFP-BFKM』: Heat Sink Fan

## Applicable model

VFD075FP2EA-41/-52/-52S, VFD110FP2EA-41/-52/-52S, VFD110FP4EA-41/-52/-52S, VFD150FP4EA-41/-52/-52S, VFD150FP5EA-41/-52/-52S, VFD185FP4EA-41/-52/-52S,

VFD185FP5EA-41/-52/-52S, VFD220FP4EA-41/-52/-52S

- 1. Refer to the figure below, loosen the 4 screws then remove the fan kit.
- 2. Screw torque: 10–12 kg-cm / (8.7–10.4 lb-in.) / (1.0–1.2 Nm)



#### Frame B

## Model 『MKFP-BFKB』: Capacitor Fan

#### Applicable model


VFD075FP2EA-41/-52/-52S, VFD110FP2EA-41/-52/-52S, VFD110FP4EA-41/-52/-52S,

VFD110FP5EA-41/-52/-52S, VFD150FP4EA-41/-52/-52S, VFD150FP5EA-41/-52/-52S,

VFD185FP4EA-41/-52/-52S, VFD185FP5EA-41/-52/-52S, VFD220FP4EA-41/-52/-52S

- 1. Press the hook in the top of digital keypad, and then rotate to remove the digital keypad. (Refer to Figure 7-63)
- 2. Screw 1–6 torque: 14–16 kg-cm / (12.2–13.9 lb-in.) / (1.4–1.6 Nm)
- 3. Loosen the screws 7–13 then remove the fan kit. (Refer to Figure 7-64)
- 4. Screw 7–12 torque: 6–8 kg-cm / (5.2–6.9 lb-in.) / (0.6–0.8 Nm);

Screw 13 torque: 10–12 kg-cm / (8.7–10.4 lb-in.) / (1.0–1.2 Nm)




## Frame C

## Model『MKFP-CFKM』: Heat Sink Fan

## Applicable model

VFD150FP2EA-41/-52/-52S, VFD185FP2EA-41/-52/-52S, VFD220FP5EA-41/-52/-52S, VFD300FP4EA-41/-52/-52S, VFD370FP4EA-41/-52/-52S, VFD370FP5EA-41/-52/-52S

- 1. Refer to the figure below, loosen the 4 screws then remove the fan kit.
- 2. Screw torque: 24–26 kg-cm / (20.8–22.6 lb-in.) / (2.4–2.6 Nm)



#### Frame C

## Model 『MKFP-CFKB』: Capacitor Fan


#### Applicable model

VFD150FP2EA-41/-52/-52S, VFD185FP2EA-41/-52/-52S, VFD220FP5EA-41/-52/-52S,

VFD300FP4EA-41/-52/-52S, VFD300FP5EA-41/-52/-52S, VFD370FP4EA-41/-52/-52S,

VFD370FP5EA-41/-52/-52S

- 1. Press the hook in the top of digital keypad, and then rotate to remove the digital keypad. (Refer to Figure 7-66)
- 2. Screw 1–6 torque: 14–16 kg-cm / (12.2–13.9 lb-in.) / (1.4–1.6 Nm)
- 3. Loosen the screw 7 then remove the fan kit. (Refer to Figure 7-67)
- 4. Screw 7 torque: 14–16 kg-cm / (12.2–13.9 lb-in.) / (1.4–1.6 Nm)




Model 『MKFP-D0FKM』: Heat Sink Fan

## Applicable model

VFD220FP2EA-41/-52/-52S, VFD300FP2EA-41/-52/-52S, VFD450FP4EA-41/-52/-52S,

VFD450FP5EA-41/-52/-52S, VFD550FP4EA-41/-52/-52S, VFD550FP5EA-41/-52/-52S

- 1. Loosen the screw and remove the fan kit. Screw torque: 24–26 kg-cm / (20.8–22.6 lb-in) / (2.4–2.6 Nm)
- 2. Before pulling out the fan, make sure the fan power is disconnected. (Refer to Figure 7-68)




Model 『MKFP-CFKB』: Capacitor Fan

#### Applicable model

VFD220FP2EA-41/-52/-52S, VFD300FP2EA-41/-52/-52S, VFD450FP4EA-41/-52/-52S,

VFD450FP5EA-41/-52/-52S, VFD550FP4EA-41/-52/-52S, VFD550FP5EA-41/-52/-52S

- 1. Press the hook in the top of digital keypad, and then rotate to remove the digital keypad. (Refer to Figure 7-69)
- 2. Screw 1–6 torque: 14–16 kg-cm / (12.2–13.9 lb-in.) / (1.4–1.6 Nm)
- 3. Loosen the screw 7 then remove the fan kit. (Refer to Figure 7-70)
- 4. Screw 7 torque: 12–15 kg-cm / (10.4–13 lb-in.) / (1.2–1.5 Nm)




## Model『MKFP-DFKM』: Heat Sink Fan

## Applicable model

VFD370FP2EA-41/-52/-52S, VFD450FP2EA-41/-52/-52S, VFD750FP4EA-41/-52/-52S,

VFD750FP5EA-41/-52/-52S, VFD900FP4EA-41/-52/-52S, VFD900FP5EA-41/-52/-52S

- 1. Loosen the screw and remove the fan kit. Screw torque: 14–16 kg-cm / (12.2–13.9 lb-in.) / (1.4–1.6 Nm)
- 2. Before pulling out the fan, make sure the fan power is disconnected. (Refer to the figure below)




Model 『MKFP-CFKB』: Capacitor Fan

#### Applicable model

VFD370FP2EA-41/-52/-52S, VFD450FP2EA-41/-52/-52S, VFD750FP4EA-41/-52/-52S,

VFD750FP5EA-41/-52/-52S, VFD900FP4EA-41/-52/-52S, VFD900FP5EA-41/-52/-52S

- 1. Press the hook in the top of digital keypad, and then rotate to remove the digital keypad. (Refer to Figure 7-72)
- 2. Screw 1–8 torque: 14–16 kg-cm / (12.2–13.9 lb-in.) / (1.4–1.6 Nm)
- 3. Loosen the screw 9 then remove the fan kit. (Refer to Figure 7-73)
- 4. Screw 9 torque: 12–15 kg-cm / (10.4–13 lb-in.) / (1.2–1.5 Nm)



## 7-9 USB/RS-485 Communication Interface IFD6530

# Warning

- ✓ Thoroughly read this instruction sheet before installation and putting it into use.
- ✓ The content of this instruction sheet and the driver file may be revised without prior notice. Consult our distributors or <u>download</u> the most updated instruction/driver version.

#### Introduction

IFD6530 is a convenient RS-485-to-USB converter, which does not require external power-supply and complex setting process. It supports baud rate from 75 to 115.2 Kbps and auto switching direction of data transmission. In addition, it adopts RJ45 in RS-485 connector for users to wire conveniently. Moreover, its tiny dimension, handy use of plug-and-play and hot-swap provide more conveniences for connecting all DELTA IABG products to your PC.

Applicable Models: All DELTA IABG products.

## Application & Dimension




Figure 7-74 Figure 7-75

#### Specifications

Specifications				
Power supply	No external power is needed			
Power consumption	1.5 W			
Isolated voltage	2,500 V <sub>DC</sub>			
Baud rate	75 Kbps, 150 Kbps, 300 Kbps, 600 Kbps, 1,200 Kbps, 2,400 Kbps, 4,800 Kbps, 9,600 Kbps, 19,200 Kbps, 38,400 Kbps, 57,600 Kbps, 115,200 Kbps			
RS-485 connector	RJ45			
USB connector	A type (plug)			
Compatibility	Full compliance with USB V2.0 specification			
Max. cable length RS-485 Communication Port: 100 m				
Support RS-485 half-duplex transmission				

Table 7-61

#### **RJ45**



PIN	Description
1	Reserved
2	Reserved
3	GND
4	SG-

Description
SG+
GND
Reserved
+9V


### Preparations before Driver Installation

Extract the driver file (IFD6530\_Drivers.exe) by following steps. Download the driver file (IFD-


6530 Drivers.exe) at www.deltaww.com/iadownload acmotordrive/IFD6530 Drivers.

**NOTE:** DO NOT connect IFD6530 to PC before extracting the driver file.


#### STEP 1



#### STEP 2



#### STEP 3



STEP 4



#### STEP 5


You should have a folder marked SiLabs under drive C. c:\ SiLabs

#### **Driver Installation**


After connecting IFD6530 to PC, please install driver by following steps.

#### STEP 1





#### Chapter 7 Optional Accessories | CFP2000



Repeat Step 1 to Step 4 to complete COM PORT setting.

## LED Display

- 1. Steady Green LED ON: power is ON.
- 2. Blinking orange LED: data is transmitting.

# **Chapter 8 Option Cards**

- 8-1 Option Card Installation
- 8-2 EMC-D42A -- Extension card for 4-point digital input / 2-point digital input
- 8-3 EMC-D611A -- Extension card for 6-point digital input (110 VAC input voltage)
- 8-4 EMC-R6AA -- Relay output extension card (6-point N.O. output contact)
- 8-5 EMC-BPS01 -- +24V power card
- 8-6 EMC-A22A Extension card for 2-point analog input / 2-point analog output
- 8-7 CMC-PD01 Communication card, PROFIBUS DP
- 8-8 CMC-DN01 Communication card, DeviceNet
- 8-9 CMC-EIP01 / CMC-EIP02 Communication card, EtherNet/IP
- 8-10 CMC-PN01 Communication card, PROFINET
- 8-11 eZVFD Communication card, BACnet Ethernet/BACnet IP
- 8-12 EMC-COP01 Communication card, CANopen
- 8-13 Delta Standard Fieldbus Cables

- Select applicable option cards for your drive or contact your local distributor for suggestion.
- To prevent damage to the drive during installation, remove the digital keypad and the cover before wiring. Refer to the following instruction.
- The option card does not support hot swap function. Power off the motor drive before you install or remove the option cards.


## **8-1 Option Card Installation**

## 8-1-1 Remove the Top Cover

## Frame A & B

Screw Torque: 14-16 kg-cm / (12.2-13.9 lb-in.) / (1.4-1.6 Nm)


- 1. Remove the keypad (as shown in below figure 2).
- 2. Loosen the screws, then remove the top cover (as shown in below figure 3).



Frame C

Screw Torque: 14-16 kg-cm / (12.2-13.9 lb-in.) / (1.4-1.6 Nm)


- Remove the keypad (as shown in below figure 2).
- 2. Loosen the screws, then remove the top cover (as shown in below figure 3).




#### Frame D0-D

Screw Torque: 14-16 kg-cm / (12.1-13.9 lb-in.) / (1.4-1.6 Nm)

- 1. Remove the keypad (as shown in below figure 2).
- 2. Loosen the screws, then remove the top cover (as shown in below figure 3).









Figure 2 Figure 3

#### 8-1-2 Location to Install Extension Card



- RJ45 (Socket) for digital keypad KPC-CC01
   Refer to Chapter 10 for more details on digital keypad.
   Refer to Chapter 10 for more details on optional accessory RJ45 extension cable.
- 2 Communication extension card (Slot 1)
  CMC-PD01; CMC-DN01; CMC-EIP01; CMC-EIP02;
  EMC-COP01; CMC-PN01
- 3 I/O & Relay extension card (Slot 3)
  EMC-D42A; EMC-D611A; EMC-A22A; EMC-R6AA;
  EMC-BPS01
- 4 PG Card (Slot 2)

  \*\*CFP2000 does not support PG card.


Figure 8-1 Table 8-1

#### Screws Specification for option card terminals:


EMC-D42A; EMC-D611A; EMC-BPS01	Wire gauge	0.2-0.5 mm² (26-20 AWG )
EINC-D42A, EINC-D011A, EINC-BF301	Torque	5 kg-cm / (4.4 lb-in.) / (0.5 Nm)
EMC-R6AA	Wire gauge	0.2-0.5 mm <sup>2</sup> (26-20 AWG )
	Torque	8 kg-cm / (7 lb-in.) / (0.8 Nm)
EMC A22A	Wire gauge	0.2–4 mm² (24–12 AWG)
EMC-A22A	Torque	5 kg-cm / (4.4 lb-in) / (0.5 Nm)

Table 8-2

## Communication extension card (Slot 1)




## I/O / Relay extension card & 24V Power extension card (Slot 3)



#### 8-1-3 Install and Uninstall of Extension Cards

#### 8-1-3-1 Installation

Communication card: EMC-COP01, CMC-EIP01, CMC-EIP02, CMC-DN01, CMC-PD01, CMC-PN01



As shown in the figure on the left.
Put the isolation sheet into the positioning pin.
Aim the two holes at the positioning pin.
Press the pin to clip the holes with the PCB.

Figure 8-13





Figure 8-14



installation is completed.

As shown in the figure on the left,

Figure 8-15

# I/O & Relay Card: EMC-D42A, EMC-D611A, EMC-R6AA, EMC-BPS01, EMC-A22A




Figure 8-16





Figure 8-17



As shown in the figure on the left, installation is completed.

Figure 8-18

## 8-1-3-2 Disconnect the extension card

Communication Card: EMC-COP01, CMC-EIP01, CMC-EIP02, CMC-DN01, CMC-PD01, CMC-PN01






Figure 8-19



As shown in the figure on the left. Twist to open the clip. Insert a slot type screwdriver into the hollow to prize the PCB off the clip.


Figure 8-20



Twist to open the other clip to remove the PCB.


Figure 8-21

## I/O & Relay Card: EMC-D42A, EMC-D611A, EMC-R6AA, EMC-BPS01, EMC-A22A



Remove the two screws as shown in the figure on the left.

Figure 8-22



As shown in the figure on the left.
Twist to open the clip.
Insert a slot type screwdriver into the hollow to prize the PCB off the clip.

Figure 8-23




Figure 8-24

# **8-2 EMC-D42A** -- Extension card for 4-point digital input / 2-point digital input

	Terminals	Descriptions		
		Common for Multi-function input terminals		
	СОМ	Select SINK (NPN) / SOURCE (PNP) in J1 jumper / external		
		power supply		
		Refer to Pr.02-26–Pr.02-29 to program the multi-function inputs		
		MI10-MI13.		
		Internal power is applied from terminal E24: +24 $V_{DC}\pm$ 5% 200 mA,		
	MI10-MI13	5 W		
		External power +24 $V_{DC}$ : max. voltage 30 $V_{DC}$ , min. voltage 19 $V_{DC}$		
		ON: the activation current is 6.0 mA		
I/O Extension		OFF: leakage current tolerance is 10 μA		
Card	MO10-MO11	Multi-function output terminals (photocoupler)		
		The AC motor drive releases various monitor signals, such as		
		drive in operation, frequency attained and overload indication, via		
		transistor (open collector).		
		MO10		
		MO11		
		MXM Figure 8-25		
		Common for multi-function output terminals MO10, MO11 (photo		
	MXM	coupler)		
		Max 48 V <sub>DC</sub> 50 mA		

Table 8-3

# 8-3 EMC-D611A -- Extension card for 6-point digital input (110 V<sub>AC</sub> input voltage)

I/O Extension Card	Terminals	Descriptions
	AC	AC power Common for multi-function input terminal (Neutral)
	MI10–MI15	Refer to Pr.02-26–Pr.02-31 for multi-function input selection
		Input voltage: 100–130 V <sub>AC</sub>
		Input frequency: 47–63 Hz
		Input impedance: 27 kΩ
		Terminal response time:
		ON: 10 ms
		OFF: 20 ms

Table 8-4

# **8-4 EMC-R6AA** -- Relay output extension card (6-point N.O. output contact)

Relay Extension Card	Terminals	Descriptions
	RA10-RA15 RC10-RC15	Refer to Pr.02-36–Pr.02-41 for multi-function relay selection
		Resistive load:
		3 A (N.O.) / 250 V <sub>AC</sub>
		5 A (N.O.) / 30 V <sub>DC</sub>
		Inductive load (COS 0.4)
		1.2 A (N.O.) / 250 V <sub>AC</sub>
		2.0 A (N.O.) / 30 V <sub>DC</sub>
		It is used to output each monitor signal, such as drive is in
		operation, frequency attained or overload indication.

Table 8-5


## **8-5 EMC-BPS01** -- +24V power card

	Terminals	Descriptions
External Power Supply	24V GND	Input power: 24V ± 5%
		Maximum input current: 0.5 A
		Note:
		Do not connect drive control terminal GND directly to the EMC-BPS01
		input terminal GND.
		Function: When the drive is only powered by EMC-BPS01, the
		communications can be assured and support all communication cards
		and following functions:
		Parameters read and write.
		2. Keypad can be displayed.
		3. Keypad button can be operated (except RUN).
		4. Analog input is effective.
		5. Multi-function (FWD, REV, MI1–MI8) needs external power supply
		to operate.
		The following functions are NOT supported.
		Relay out (including extension card), PG card and PLC function.

Table 8-6

## **8-6 EMC-A22A** – Extension card for 2-point analog input / 2-point analog output

## 8-6-1 Product File



- 1. Screw fixing hole
- 2. Positioning hole
- 3. POWER indicator
- 4. Switch
- 5. Fool-proof groove
- 6. Terminal block
- 7. AC motor drive connection port

8-6-2 Terminal Specification

	Terminals		Descriptions
Analog I/O Extension Card	Al10, Al11	Pr.14-19 for mode selection	ort, SSW3 (AI10) and SSW4 (AI11), which can Current mode. V mA / 4–20 mA
		Analog current frequency command  ACI ACI circuit  ACM Internal circuit  Figure 8-28	Impedance: 250 Ω Range: 0–20 mA / 4–20 mA = 0–Max. Output Frequency (Pr.01-00) Switch: AI10 / AI11 Switch, default 0–10 V

AO10, AO11	Pr.14-37 for mode select	o port, SSW1 (AO10) and SSW2 (AO11), which ge or Current mode10 V
	ACM AO11  Figure 8-29	Resolution: 0–10 V corresponds to Max. operation frequency Switch: AO10 / AO11 Switch, default 0–10 V ACO: 0–20 mA Max. Load 500 Ω Output current: 20 mA max Resolution: 0–20 mA / 4–20 mA corresponds to Max. operation frequency Switch: AO10 / AO11 Switch, default 0–10 V
ACM	Analog Signal Common	Common for analog terminals


Table 8-8

## 8-7 CMC-PD01 – Communication card, PROFIBUS DP

#### 8-7-1 Features

- 1. Supports PZD control data exchange.
- 2. Supports PKW polling AC motor drive parameters.
- 3. Supports user diagnosis function.
- 4. Auto-detects baud rates; supports Max. 12 Mbps.

## 8-7-2 Product Profile



- 1. NET indicator
- 2. POWER indicator
- 3. Positioning hole
- 4. AC motor drive connection port
- 5. PROFIBUS DP connection port
- 6. Screw fixing hole
- 7. Fool-proof groove

Table 8-9

## 8-7-3 Specifications

#### PROFIBUS DP Connector

Interface	DB9 connector
Transmission	High-speed RS-485
Transmission Cable	Shielded twisted pair cable
Electrical Isolation	500 V <sub>DC</sub>

Table 8-10

#### Communication

Message Type	Cyclic data exchange
Module Name	CMC-PD01
GSD Document	DELA08DB.GSD
Company ID	08DB (HEX)
Serial Transmission Speed Supported (Auto-Detection)	9.6 Kbps, 19.2 Kbps, 93.75 Kbps, 187.5 Kbps, 500 Kbps, 1.5 Mbps, 3 Mbps, 6 Mbps, 12 Mbps (bit per second)

Table 8-11

## **Electrical Specification**

Power Supply	5 V <sub>DC</sub> (supplied by AC motor drive)
Insulation Voltage	500 V <sub>DC</sub>
Power	1 W
Weight	28 g

Table 8-12

#### Environment

Noise Immunity	ESD (EN 61800-5-1, IEC 61000-4-2) EFT (EN 61800-5-1, IEC 61000-4-4) Surge Teat (EN 61800-5-1, IEC 61000-4-5) Conducted Susceptibility Test (EN 61800-5-1, IEC 61000-4-6)
Operation / Storage	Operation: -10°C–50°C (temperature), 90% (humidity) Storage: -25°C–70°C (temperature), 95% (humidity)
Shock / Vibration Resistance	International standards: IEC 61131-2, IEC 60068-2-6 (TEST Fc) / IEC 61131-2 & IEC 60068-2-27 (TEST Ea)

Table 8-13

## 8-7-4 Installation

## PROFIBUS DP Connector

PIN	PIN Name	Definition
1	-	Not defined
2	-	Not defined
3	Rxd/Txd-P	Sending/receiving data P(B)
4	-	Not defined
5	DGND	Data reference ground
6	VP	Power voltage – positive
7	-	Not defined
8	Rxd/Txd-N	Sending/receiving data N(A)
9	-	Not defined




Figure 8-31

Table 8-14

## 8-7-5 LED Indicator & Troubleshooting

There are 2 LED indicators on CMC-PD01: POWER LED and NET LED. POWER LED displays the status of the working power. NET LED displays the connection status of the communication.

#### **POWER LED**

LED Status	Indication	Corrective Action
Green light ON	Power supply in normal status.	
OFF	No power	Check if the connection between CMC-PD01 and AC motor drive is normal.

Table 8-15

## **NET LED**

LED Status	Indication	Corrective Action
Green light ON	Normal status	
Red light ON	CMC-PD01 is not connected to PROFIBUS DP bus.	Connect CMC-PD01 to PROFIBUS DP bus.
IRed light flashes	Invalid PROFIBUS communication address	Set the PROFIBUS address of CMC-PD01 between 1– 125 (decimal)
Orange light flashes	ICMC-PD01 tails to communicate with	Switch off the power and check whether CMC-PD01 is correctly and normally connected to AC motor drive.


Table 8-16

## 8-8 CMC-DN01 - Communication card, DeviceNet

## 8-8-1 Functions

- 1. Based on the high-speed communication interface of Delta HSSP protocol, able to conduct immediate control to AC motor drive.
- 2. Supports Group 2 only connection and polling I/O data exchange.
- 3. For I/O mapping, supports Max. 32 words of input and 32 words of output.
- 4. Supports EDS file configuration in DeviceNet configuration software.
- 5. Supports all baud rates on DeviceNet bus: 125 Kbps, 250 Kbps, 500 Kbps and extendable serial transmission speed mode.
- 6. Node address and serial transmission speed can be set up on AC motor drive.
- 7. Power supplied from AC motor drive.

## 8-8-2 Product Profile



1. NS indicator	
2 MS indicator	•

- 3. POWER indicator
- 4. Positioning hole
- 5. DeviceNet connection port
- 6. Screw fixing hole
- 7. Fool-proof groove
- 8. AC motor drive connection port

Table 8-17

## 8-8-3 Specifications

#### **DeviceNet Connector**

Interface	5-PIN open removable connector of 5.08 mm PIN interval
Transmission	CAN
Transmission Cable	Shielded twisted pair cable (with 2 power cables)
Transmission Speed	125 Kbps, 250 Kbps, 500 Kbps and extendable serial transmission speed
Network Protocol	DeviceNet protocol

Table 8-18

#### AC Motor Drive Connection Port

Interface	50 PIN communication terminal
Transmission	SPI communication
Terminal Function	Communicating with AC motor drive     Transmitting power supply from AC motor drive
Communication	Delta HSSP protocol

## **Electrical Specification**

Power Supply	5 V <sub>DC</sub> (supplied by AC motor drive)	
Insulation Voltage	500 V <sub>DC</sub>	
Communication Wire Power Consumption	0.85 W	
Power Consumption	1 W	
Weight	23 g	

**Table 8-20** 

#### **Environment**

Noise Immunity	ESD (EN 61800-5-1, IEC 61000-4-2)  EFT (EN 61800-5-1, IEC 61000-4-4)  Surge Teat (EN 61800-5-1, IEC 61000-4-5)  Conducted Susceptibility Test (EN 61800-5-1, IEC 61000-4-6)
Operation / Storage	Operation: -10°C–50°C (temperature), 90% (humidity) Storage: -25°C–70°C (temperature), 95% (humidity)
Shock / Vibration Resistance	International standards: EN 61800-5-1, IEC 60068-2-6 / EN 61800-5-1 & IEC 60068-2-27

**Table 8-21** 

#### 8-8-4 Installation

## **DeviceNet Connector**

PIN	Signal	Color	Definition
1	V+	Red	DC24V
2	Н	White	Signal+
3	S	-	Earth
4	L	Blue	Signal-
5	V-	Black	0V




Table 8-22

Figure 8-33

## 8-8-5 LED Indicator & Troubleshooting

There are 3 LED indicators on CMC-DN01: POWER LED, MS LED and NS LED. POWER LED displays the status of power supply. MS LED and NS LED are dual-color LED, displaying the connection status of the communication and error messages.

## **POWER LED**

LED status	Indication	Corrective Action
OFF	Power supply in abnormal status.	Check the power supply of CMC-DN01.
Green light ON	Power supply in normal status	

**Table 8-23** 

## NS LED

LED Status	Indication	Corrective Action	
OFF	No power supply or CMC-DN01 has not completed MAC ID test yet.	<ol> <li>Check the power of CMC-DN01 and see if the connection is normal.</li> <li>Make sure at least one or more nodes are on the bus.</li> <li>Check if the serial transmission speed of CMC-DN01 is the same as that of other nodes.</li> </ol>	
Green light flashes	CMC-DN01 is on-line but has not established connection to the master.	<ol> <li>Configure CMC-DN01 to the scan list of the master.</li> <li>Re-download the configured data to the master.</li> </ol>	
Green light ON	CMC-DN01 is on-line and is normally connected to the master		
Red light flashes	CMC-DN01 is on-line, but I/O connection is timed-out.	<ol> <li>Check if the network connection is normal.</li> <li>Check if the master operates normally.</li> </ol>	
Red light ON	<ol> <li>The communication is down.</li> <li>MAC ID test failure.</li> <li>No network power supply.</li> <li>CMC-DN01 is off-line.</li> </ol>	<ol> <li>Make sure all the MAC IDs on the network are not repeated.</li> <li>Check if the network installation is normal.</li> <li>Check if the baud rate of CMC-DN01 is consistent with that of other nodes.</li> <li>Check if the node address of CMC-DN01 is illegal.</li> <li>Check if the network power supply is normal.</li> </ol>	

Table 8-24

## MS LED


LED Status	Indication	Corrective Action
OFF	No power supply or being off-line	Check the power supply of CMC-DN01 and see if the connection is normal.
Green light flashes	Waiting for I/O data	Switch the master PLC to RUN status
Green light ON	I/O data are normal	
Red light flashes	Mapping error	Reconfigure CMC-DN01     Re-power AC motor drive
Red light ON	Hardware error	<ol> <li>See the error code displayed on AC motor drive.</li> <li>Send back to the factory for repair if necessary.</li> </ol>
Orange light flashes	CMC-DN01 is establishing connection with AC motor drive.	If the flashing lasts for a long time, turn off the power and check if CMC-DN01 and AC motor drive are correctly installed and normally connected to each other.

## 8-9 CMC-EIP01 / CMC-EIP02 - Communication card, EtherNet/IP

#### 8-9-1 Features

- 1. Supports Ethernet/IP and Modbus TCP protocol
- 2. User-defined corresponding parameters (EIP V1.06 and above)
- 3. Simple firewall function for IP Filter
- 4. MDI/MDI-X auto-detect
- 5. Baud rate: 10/100 Mbps auto-detect mail alarm

## 8-9-2 Product Profile



## (Figure1)

- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. LINK indicator
- 5. RJ45 connection port
- 6. POWER indicator
- 7. Fool-proof groove

**Table 8-26** 

#### CMC-EIP02




Figure 8-35

- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. MS indicator
- 5. NS indicator
- 6. LINK indicator
- 7. POWER indicator
- 8. Ethernet connection port (RJ45)
- 7. Fool-proof groove

## 8-9-3 Specifications

## Network Interface

Interface	RJ45 with Auto MDI/MDIX	
Number of Ports	CMC-EIP01: 1 Port	
Number of Forts	CMC-EIP02: 2 Ports (switch)	
Transmission		
Method IEEE 802.3, IEEE 802.3u		
Transmission Cable	Category 5e shielding 100M	
Transmission Speed 10/100 Mbps Auto-Detect		
Network Protocol ICMP, IP, TCP, UDP, DHCP, BOOTP, SMTP, EtherNet/IP, Modbus T		

Table 8-28

## **Electrical Specification**

Weight	25 g (CMC-EIP01) / 30 g (CMC-EIP02)	
Insulation Voltage	500 V <sub>DC</sub>	
Power Consumption	0.8 W (CMC-EIP01) / 1.4 W (CMC-EIP02)	
Power Supply	5 V <sub>DC</sub>	

Table 8-29

#### Environment

Noise Immunity	ESD (EN 61800-5-1, IEC 61000-4-2) EFT (EN 61800-5-1, IEC 61000-4-4)
	Surge Test (EN 61800-5-1, IEC 61000-4-5)
	Conducted Susceptibility Test (EN 61800-5-1, IEC 61000-4-6)
Operation/Storage	Operation: -10°C–50°C (temperature), 90% (humidity)
	Storage: -25°C–70°C (temperature), 95% (humidity)
Vibration/Shock Immunity	International standard: EN 61800-5-1, IEC 60068-2-6 / EN 61800-5-1, IEC 60068-2-27

Table 8-30

## 8-9-4 Installation

Connecting CMC-EIP01 to Network

- 1. Turn off the power of AC motor drive.
- 2. Open the cover of AC motor drive.
- 3. Connect CAT-5e network cable to RJ45 port on CMC-EIP01 (See Figure 8-36).




Figure 8-36

#### **RJ45 PIN Definition**

PIN	Signal	Definition
1	Tx+	Positive pole for data transmission
2	Tx-	Negative pole for data transmission
3	Rx+	Positive pole for data receiving
4		N/C

PIN	Signal	Definition
5		N/C
6	Rx-	Negative pole for data receiving
7		N/C
8		N/C



Figure 8-37

Table 8-31 Table 8-32

## 8-9-5 Communication Parameters for CFP2000 Connected to Ethernet

When the CFP2000 is connected to an Ethernet network, set up the communication parameters for it according to the table below. The Ethernet master is only able to read/write the frequency word and control word of CFP2000 after the communication parameters are set.

Parameter	Function	Set Value (Dec)	Explanation
Pr.00-20	Source of frequency	8	The frequency command is controlled by
F1.00-20	command setting	0	communication card.
Pr.00-21	Source of operation	5	The operation command is controlled by
F1.00-21	command setting	3	communication card.
Pr.09-30	Decoding method for	0	The decoding method for Delta AC motor
P1.09-30	communication	U	drive
Pr.09-75	IP setting	0	Static IP(0) / Dynamic distribution IP(1)
Pr.09-76	IP address -1	192	IP address 192.168.1.5
Pr.09-77	IP address -2	168	IP address 192.168.1.5
Pr.09-78	IP address -3	1	IP address 192.168.1.5
Pr.09-79	IP address -4	5	IP address 192.168.1.5
Pr.09-80	Netmask -1	255	Netmask 255.255.255.0
Pr.09-81	Netmask -2	255	Netmask 255.255.255.0
Pr.09-82	Netmask -3	255	Netmask 255.255.255.0
Pr.09-83	Netmask -4	0	Netmask 255.255.255.0
Pr.09-84	Default gateway -1	192	Default gateway 192.168.1.1
Pr.09-85	Default gateway -2	168	Default gateway 192.168.1.1
Pr.09-86	Default gateway -3	1	Default gateway 192.168.1.1
Pr.09-87	Default gateway -4	1	Default gateway 192.168.1.1

**Table 8-33** 

## 8-9-6 LED Indicator & Troubleshooting

There are 2 LED indicators on CMC-EIP01: POWER LED and LINK LED. The POWER LED displays the status of power supply, and the LINK LED displays the connection status of the communication.

#### **LED Indicators**

LED	Status		Indication	Corrective Action
POWER	ON ON		Power supply in normal status	
FOWER	POWER Green OFF	OFF	No power supply	Check the power supply.
LINK Green	ON	Network connection in normal status		
	Flashes	Network in operation		
		OFF	Network not connected	Check if the network cable is connected.

Table 8-34

## Troubleshooting

Abnormality	Cause	Corrective Action
POWER LED OFF	AC motor drive not powered	Check if AC motor drive is powered, and if the power supply is normal.
POWER LED OFF	CMC-EIP01 not connected to AC motor drive	Make sure CMC-EIP01 is connected to AC motor drive.
	CMC-EIP01 not connected to network	Make sure the network cable is correctly connected to network.
LINK LED OFF	Poor contact to RJ45 connector	Make sure RJ45 connector is connected to Ethernet port.
	CMC-EIP01 not connected to network	Make sure CMC-EIP01 is connected to network.
No communication card found	PC and CMC-EIP01 in different networks and blocked by network firewall.	Search by IP or set up relevant settings by AC motor drive keypad.
	CMC-EIP01 not connected to network	Make sure CMC-EIP01 is connected to the network.
Fail to open CMC-	Incorrect communication setting in DCISoft	Make sure the communication setting in DCISoft is set to Ethernet.
EIP01 setup page	PC and CMC-EIP01 in different networks and blocked by network firewall.	Conduct the setup by AC motor drive keypad.
Able to open CMC- EIP01 setup page but fail to utilize webpage monitoring	Incorrect network setting in CMC-EIP01	Check if the network setting for CMC-EIP01 is correct. For the Intranet setting in your company, please consult your IT staff. For the Internet setting in your home, please refer to the network setting instruction provided by your ISP.
Fail to send e-mail	Incorrect network setting in CMC-EIP01	Check if the network setting for CMC-EIP01 is correct.
	Incorrect mail server setting	Confirm the IP address for SMTP-Server.

## 8-10 CMC-PN01 - Communication card, PROFINET


#### 8-10-1 Features

CMC-PN01 connects CFP2000 to PROFINET, so the drive is able to exchange data with the upper unit. It is a simple NET solution, which can reduce the cost and time of connection/ installing factory automation, also provide compatibility of similar components from multiple suppliers.


Connect CMC-PN01 to CFP2000 via PROFINET device:

- Control the AC motor drive via PROFINET
- 2. Change the drive parameters via PROFINET
- 3. Monitor the drive status via PROFINET

#### 8-10-2 Product Profile







- 1. Screw fixing hole
- 2. Positioning hole
- 3. Ready out indicator
- 4. MT out indicator
- 5. SD indicator
- 6. BF out indicator
- 7. ACT PHY2 indicator
- 8. Link PHY2 indicator
- 9. ACT PHY1 indicator
- 10. Link PHY1 indicator
- 11. Switch
- 12. Fool-proof groove
- 13. RJ45 connection port (Port 2)
- 14. RJ45 connection port (Port 1)
- 15. Connection port of control board

Table 8-36

#### MAC Address label definition




Figure 8-39

Def.	Explanation		
MAC1	Port 1 MAC Address		
MAC2	Port 2 MAC Address		
MAC3	Interface MAC Address		

**Table 8-37** 

## 8-10-3 Specifications

## Network Interface

Interface	RJ45
Number of Ports	2 ports
Transmission Method	IEEE 802.3
Transmission Cable	Category 5e shielding 100 M
Transmission Speed	10/100 Mbps auto-negotiate
Network Protocol	PROFINET

Table 8-38

## **Electrical Specification**

Power Supply Voltage	5 V <sub>DC</sub>
Power Consumption	0.8 W
Insulation Voltage	500 V <sub>DC</sub>
Weight (g)	27

Table 8-39

## Environment

	ESD (EN 61800-5-1, IEC 61000-4-2)
Noise Immunity	EFT (EN 61800-5-1, IEC 61000-4-4)
Noise Immunity	Surge Test (EN 61800-5-1, IEC 61000-4-5)
	Conducted Susceptibility Test (EN 61800-5-1, IEC 61000-4-6)
Operation	-10–50°C (temperature), 90% (humidity)
Storage	-25–70°C (temperature), 95% (humidity)
Vibration / Shock Immunity	International standard: EN 61800-5-1, IEC 60068-2-6 / EN 61800-5-1,
	IEC 60068-2-27

Table 8-40

## 8-10-4 RJ45 PIN Definition

RJ45	PIN No.	Signal	Definition
	1	Tx+	Positive pole for data transmission
12345678	2	Tx-	Negative pole for data transmission
	3	Rx+	Positive pole for data receiving
	4		N/C
	5	-	N/C
Figure 8-40	6	Rx-	Negative pole for data receiving
rigule 0-40	7		N/C
	8		N/C

# 8-10-5 Communication Parameters for CFP2000 Conneted to PROFINET When operating CFP2000 via CMC-PN01, please set the control and operation command as controlled by communication card. When CFP2000 is connected to PROFINET network, please set up the communication parameters according to the table below.

Parameter	Set Value (Dec)	Explanation
Pr.00-20	8	The frequency command is controlled by communication card.
Pr.00-21	5	The operation command is controlled by communication card.
Pr.09-30	1	Set Pr.09-30 to 60xx or 20xx as the decoding method.
Pr.09-60	12	Identification: when CMC-PN01 is connected, Pr.09-60 will show value 12.

Table 8-42

## 8-10-6 LED Indicator

LED	Status		Indication	
Doody out	Yellow	ON	PN Stack operates in normal status	
		Flashes	PN Stack operates in normal status, and	
Ready out			waiting to sync with MCU	
		OFF	PN Stack operates with error	
MT out	Green	-	-	
SD	Red	-	-	
		ON	Connection with PROFINET Controller breaks off	
BF out	Red	Flashes	Connection is normal, but an error occurs to the	
Br out			communication with PROFINET Controller	
		OFF	Connection with PROFINET Controller is normal	
	Orange	ON	Online, exchanging data with the master	
ACT PHY1		Flashes	Off line, but handshaking data with the master	
		OFF	Initial status	
LINK PHY1	Green	ON	Network connection is normal	
LINK PHY I		OFF	Network is not connected	
	Orange		ON	On line, exchanging data with the master
ACT PHY2		Flashes	Off line, but handshaking data with the master	
		OFF	Initial status	
LINK PHY2	Green	ON	Network connection is normal	
LINK PRIZ		OFF	Network is not connected	

Table 8-43

## 8-10-7 Network Connection

Wiring of CMC-PN01 is as following:



Figure 8-41

When the hardware is installed and power on, the current set value of Pr.09-60 will be 12, and shows "PROFINET" on the display. If the above information does not show on the display, check the version of CFP2000 and the connection of the card.



Figure 8-42


#### **8-11 eZVFD** – Communication card, BACnet Ethernet/BACnet IP

#### 8-11-1 Features

The eZVFD Integration Module provides BACnet/IP and BACnet over Ethernet communication to BACnet compliant devices. When used with a Delta Controls system, you can use the module's GCL+ programs and Delta Controls internal control loops to directly control pumps and fan motors. Quickly configure and save drive parameters in enteliWEB and load the saved configuration onto other CFP2000 AC motor drives over the BACnet network. Features include:

- Native BACnet firmware
- BACnet/IP, BACnet over Ethernet communication protocols
- Fully programmable in GCL+ (Delta Controls General Control Language)
- Dual port ethernet to support daisy-chaining multiple CFP2000 devices
- Monitor and utilize CFP2000 AC motor drive I/O terminals as BACnet I/O
- Set up and configure using enteliWEB. Use enteliWEB to read, write, save and load CFP2000 AC motor drive parameters.

#### 8-11-2 Product Profile



- 1. Screw fixing hole 1
- 2. Screw fixing hole 2
- 3. Positioning hole
- 4. Status and Power LED
- 5. Fool-proof groove
- 6. RJ45 Ethernet Port 1
- 7. RJ45 Ethernet Port 2
- 8. AC motor drive connection port

Table 8-44

Figure 8-43

NOTE: MAC address is displayed in the IPS object in entelliWEB.

## 8-11-3 Specifications

## **Network Interface**

Interface	RJ45
Number of Ports	2 ports
Daisy Chaining	Up to 30 devices (daisy chain is discontinued if drive is not powered)
Transmission Method	IEEE 802.3
Transmission Cable	10/100 BaseT CAT5E/CAT6
Maximum Length	100m (port-to-port)
Transmission Speed	10/100 Mbps auto-negotiate
Network Protocol	BACnet/IP or BACnet/Ethernet

Table 8-45

## **Electrical Specification**

Power Supply Voltage	5 V <sub>DC</sub> (supplied by AC Motor Drive)
Power Consumption	< 2 W
Insulation Voltage	500 V <sub>DC</sub>
Weight (g)	2.6g
Tachnalasy	32-bit CPU, field upgradeable firmware, real-time clock with
Technology	supercapacitor backup

Table 8-46

## Environment

Compliance	EN IEC 61800-3, EMC Standard for Variable Speed Drives
	LVD EN 61800-5-1 Safety Requirements for Electrical Power Drive Systems
Operation	0–55°C (temperature), 10–95% RH (non-condensing)
Storage	-25–70°C (temperature), 95% RH

Table 8-47

## 8-11-4 RJ45 PIN Definition

RJ45	PIN No.	Signal	Definition	
	1	Tx+	Positive pole for data transmission	
12345678	2	Tx-	Negative pole for data transmission	
	3 Rx+ P		Positive pole for data receiving	
	4		N/C	
	5		N/C	
Figure 8-44	6	Rx-	Negative pole for data receiving	
Figure 6-44	7		N/C	
	8		N/C	

8-11-5 Communication Parameters for CFP2000 Connected to eZVFD BACnet Controller When operating the CFP2000 using the eZVFD card you must set the parameters according to the table below:

Parameter	Function	Set Value (Dec)	Explanation		
Pr.00-20	Source of frequency	8	The frequency command is controlled by		
P1.00-20	command setting	0	communication card.		
Pr.00-21	Source of operation	5	The operation command is controlled by		
P1.00-21	command setting	5	communication card.		
Dr 00 20	Decoding method for	4	Decoding method 2		
Pr.09-30	communication	l	The frequency command is controlled by communication card.  The operation command is controlled by communication card.		
Dr.00.60	Identification for	Dood only	When eZVFD is connected, Pr.09-60 will show		
Pr.09-60	Communication Card	Read-only	value 8 (BACnet IP)		

Table 8-49

The following parameters should be set according to your desired network configuration. The table below shows default values:

Parameter	Function	Default Value (Dec)	Explanation		
Pr.04-50	UDP port number	47808	UDP/IP communication port		
Pr.04-51	BACnet network	BACnet/Ethernet: 19999	Demands on setting of Dr 00 04		
P1.04-51	number	BACnet/IP: 49999	Depends on setting of Pr.09-91		
Pr.09-52	BACnet device address, low word (range 0-65535)	4100000 + (last 4 hex in MAC address in decimal)	This value is added to the value of Pr.09-53 × 65536		
Pr.09-53	BACnet device address, high word (range 0-63)	-	This value is multiplied by 65536 and added to the value of Pr.09-52		
Pr.09-75	IP setting	0	0: Static IP 1: Dynamic Distribution IP (DHCP)		
Pr.09-91	BACnet IP or Ethernet	1	0: BACnet/ Ethernet 1: BACnet/IP		

Table 8-50

If static IP is chosen (Pr.09-75 = 0), then the following parameters must be set according to your local network configuration:

Parameter	Function	Set value (Dec)	Explanation
Pr.09-76	IP address -1	192	IP address 192.168.1.5
Pr.09-77	IP address -2	168	IP address 192.168.1.5
Pr.09-78	IP address -3	1	IP address 192.168.1.5
Pr.09-79	IP address -4	5	IP address 192.168.1.5
Pr.09-80	Netmask -1	255	Netmask 255.255.255.0
Pr.09-81	Netmask -2	255	Netmask 255.255.255.0
Pr.09-82	Netmask -3	255	Netmask 255.255.255.0
Pr.09-83	Netmask -4	0	Netmask 255.255.255.0

## Chapter 8 Option Cards | CFP2000

Parameter	Function	Set value (Dec)	Explanation
Pr.09-84	Default gateway -1	192	Default gateway 192.168.1.1
Pr.09-85	Default gateway -2	168	Default gateway 192.168.1.1
Pr.09-86	Default gateway -3	1	Default gateway 192.168.1.1
Pr.09-87	Default gateway -4	1	Default gateway 192.168.1.1

Table 8-51


## 8-11-6 LED Indicator


Color	LED Pattern	Indication
Red	ON	Hardware startup before system is running
Red	Blinks in a regular repeating pattern 1 second on, 1 second off.	Hardware failure
Green	Blinks in a regular repeating pattern 1 second on, 1 second off.	ок
Amber	Blinks at approx. 100 Hz	Flash loading Main from Boot
Amber	ON	Database saving or restoring from Flash

Table 8-52

## 8-12 EMC-COP01 – Communication card, CANopen

## 8-12-1 Product Profile






- 1. Screw fixing hole
- 2. Communication card fixing hole
- 3. POWER indicator
- 4. POWER indicator
- 5. Fool-proof groove
- 6. RJ45 port
- 7. RJ45 port
- 8. Control board connection port

Table 8-53

Figure 8-45 8-12-2 Terminal Resistor Position






Figure 8-46

8-12-3 RJ45 Pin definition



RS-485 socket

Figure 8-47

Pin	Pin name	Definition
1	CAN_H	CAN_H bus line (dominant high)
2	CAN_L	CAN_L bus line (dominant low)
3	CAN_GND	Ground/0V/V-
7	CAN_GND	Ground/0V/V-

## 8-12-4 Specifications

## Network Interface

Interface	RJ45
Number of Ports	2 Ports
Transmission Method	CAN
Transmission Cable	CAN standard cable
Transmission Speed	1 Mbps, 500 Kbps, 250 Kbps, 125 Kbps, 100 Kbps, 50 Kbps
Communication Protocol	CANopen

Table 8-55

## **Electrical Specification**

Weight	27g
Insulation Voltage	500 V <sub>DC</sub>
Power Consumption	0.8 W
Power Supply Voltage	5 V <sub>DC</sub>

Table 8-56

## **Environmental Conditions**

	ESD (EN 61800-5-1, IEC 61000-4-2)			
Naiss Inspectific	EFT (EN 61800-5-1, IEC 61000-4-4)			
Noise Immunity	Surge Test (EN 61800-5-1, IEC 61000-4-5)			
	Conducted Susceptibility Test (EN 61800-5-1, IEC 61000-4-6)			
Operation	-10–50°C (temperature), 90% (humidity)			
Storage	-25–70°C (temperature), 95% (humidity)			
Vibration & Shock	International Standard:			
Resistance	EN 61800-5-1, IEC 60068-2-6 / EN 61800-5-1, IEC 60068-2-27			

## 8-13 Delta Standard Fieldbus Cables

Delta Cables	Part Number	Description	Length
	UC-CMC003-01A	CANopen Cable, RJ45 Connector	0.3 m
	UC-CMC005-01A	CANopen Cable, RJ45 Connector	0.5 m
	UC-CMC010-01A	CANopen Cable, RJ45 Connector	1 m
	UC-CMC015-01A	CANopen Cable, RJ45 Connector	1.5 m
CANopen Cable	UC-CMC020-01A	CANopen Cable, RJ45 Connector	2 m
	UC-CMC030-01A	CANopen Cable, RJ45 Connector	3 m
	UC-CMC050-01A	CANopen Cable, RJ45 Connector	5 m
	UC-CMC100-01A	CANopen Cable, RJ45 Connector	10 m
	UC-CMC200-01A	CANopen Cable, RJ45 Connector	20 m
DeviceNet Cable	UC-DN01Z-01A	DeviceNet Cable	305 m
Devicenet Cable	UC-DN01Z-02A	DeviceNet Cable	305 m
	UC-EMC003-02A	Ethernet/EtherCAT cable, Shielding	0.3 m
	UC-EMC005-02A	Ethernet/EtherCAT cable, Shielding	0.5 m
	UC-EMC010-02A	Ethernet/EtherCAT cable, Shielding	1 m
Ethernet / EtherCAT Cable	UC-EMC020-02A	Ethernet/EtherCAT cable, Shielding	2 m
	UC-EMC050-02A	Ethernet/EtherCAT cable, Shielding	5 m
	UC-EMC100-02A	Ethernet/EtherCAT cable, Shielding	10 m
	UC-EMC200-02A	Ethernet/EtherCAT cable, Shielding	20 m
	TAP-CN01	1 in 2 out, built-in 121Ω terminal resistor	1 in 2 out
CANopen / DeviceNet TAP	TAP-CN02	1 in 4 out, built-in 121Ω terminal resistor	1 in 4 out
	TAP-CN03	1 in 4 out, RJ45 connector, built-in 121Ω terminal resistor	1 in 4 out
PROFIBUS Cable	UC-PF01Z-01A	PROFIBUS DP Cable	305 m

[This page is intentionally left blank]

# **Chapter 9 Specification**

- 9-1 230V Models
- 9-2 460V Models
- 9-3 575V Models
- 9-4 General Specifications
- 9-5 Environment for Operation, Storage and Transportation
- 9-6 Operation Noise Level
- 9-7 Specifications for Operation Temperature and Protection Level
- 9-7 Derating Curve for Ambient Temperature, Altitude and Carrier Frequency
- 9-8 Efficiency Curve

## 9-1 230V Models

Frame Size				Α			E	3		
	Model VFDFP2EA			007	015	022	037	055	075	110
	Rated Output Capacity (kVA)			2	3	4	6	8.4	12	18
	nty	Rated Output Current (A)		5	7.5	10	15	21	31	46
	Light Duty	Applicable Motor Output (kW)		0.75	1.5	2.2	3.7	5.5	7.5	11
	Lig	Applicable N	Notor Output (HP)	1	2	3	5	7.5	10	15
рu		Overloa	ad Tolerance	120%	of rated cur	rent can en	dure for 1 n	ninute durin	g every 5 m	inutes
Output Rating		Rated Outpo	ut Capacity (kVA)	1.2	2	3.2	4.4	6.8	10	13
utput	<u>-</u>	Rated Out	put Current (A)	3	5	8	11	17	25	33
ō	al Duty	Applicable N	lotor Output (kW)	0.4	0.75	1.5	2.2	3.7	5.5	7.5
	Normal I	Applicable N	Notor Output (HP)	0.5	1	2	3	5	7.5	10
	Z	Overlos	Overload Tolerance		of rated cur	rent can en	dure for 1 n	ninute durin	g every 5 m	inutes
		Overload Tolerance		150% of	rated curre	nt can endı	ure for 3 sec	conds during	g every 25 s	seconds
	Max. Output Frequency (Hz)		599.00							
	Carrier Frequency (kHz)		2–15 (Default: 6)							
	Inn	Input Current (A)		5	7.5	10	15	21	31	46
g	ШР	at Garrent (71)	Normal Duty	3	5	8	11	17	25	33
Input Rating		Rated Voltage / Frequency		Three-phase, 200–240 V <sub>AC</sub> (-15–10%), 50 / 60 Hz						
nput		Operating Volta	ge Range (V <sub>AC</sub> )	170–265						
=		Frequency To	olerance (Hz)				47–63			
	Р	ower Supply	Light Duty	2.7	4.0	6.2	9.1	10.4	14.5	20.8
	Ca	apacity (kVA)	Normal Duty	1.6	2.7	5.0	6.7	8.3	11.6	15.0
		Efficiency	(%)	97 97						
		Power Fa	ctor	> 0.98						
		Weight (	kg)			6.8			14	.5
		Cooling Me	ethod	Convectiv	e cooling			Fan cooling		
		Braking Ch	opper	Optional						
		DC Cho	ke	Built-in DC choke meets EN 61000-3-12						
		EMC Fil	ter		Built-in E	MC filter me	eets EN IEC	C 61800-3 C	1*1 & C2	

Table 9-1

- 1. \*To comply with the C1 specifications, install a zero phase reactor. Refer to Section 7-6 EMC Filter for more information.
- 2. The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Section 9-7 Derating Curve of Ambient Temperature.
- 3. Select the AC motor drive with capacity one grade larger for the impact load application.

## 230V Models

		Frame S	ize	(	<b>C</b>	D	0	D			
	M	odel VFDF	P2EA	150	185	220	300	370	450		
		Rated Output Capacity (kVA)		24	30	36	42	58	72		
	uty	Rated Ou	tput Current (A)	61	75	90	105	146	180		
	Light Duty	Applicable N	Notor Output (kW)	15	18.5	22	30	37	45		
	Lig	Applicable N	Motor Output (HP)	20	25	30	40	50	60		
ng		Overloa	ad Tolerance	120% of rated current can endure for 1 min. during every 5 min.							
Output Rating		Rated Outp	ut Capacity (kVA)	20	26	30	36	48	58		
rtbut	ty	Rated Ou	tput Current (A)	49	65	75	90	120	146		
ő	al Duty	Applicable N	Motor Output (kW)	11	15	18.5	22	30	37		
	Normal I	Applicable Motor Output (HP)		15	20	25	30	40	50		
	Z	Overload Tolerance						uring every 5 uring every 25	180 45 60 y 5 min. 58 146 37 50 y 5 minutes y 25 seconds (Default: 6) 180 146		
	Max. Output Frequency (Hz)					599	.00				
		Carrier Freq		2–10 (De	efault: 6)		2–9 (De	fault: 6)			
	Input Current (A)		Light Duty	61	75	90	105	146	180		
g	ШР	ut Guirent (A)	Normal Duty	49	65	75	90	120	146		
Ratir		Rated Voltage	Three-phase, 200–240 V <sub>AC</sub> (-15–10%), 50 / 60 Hz								
Input Rating		Operating Volta	ge Range (V <sub>AC</sub> )	170–265							
_		Frequency To	olerance (Hz)	47–63							
	Po	ower Supply	Light Duty	27	34.5	41.6	48.2	60.7	74.8		
	Ca	pacity (kVA)	Normal Duty	21.6	29.9	34.5	41.2	51.5	59.4		
		Efficiency	(%)	9	7	9	7	9	7		
		Power Fa	ctor			>0	.98				
	Weight (kg)			26	3.5	4	2	59	.5		
	Cooling Method				Fan Cooling						
	Braking Chopper			Optional							
	DC Choke			Built-in DC choke meets EN 61000-3-12							
		EMC Fil	ter		Built-in EMC	filter meets E	EN IEC 61800	-3 C1*1 & C2			

Table 9-2

- 1. \*To comply with the C1 specifications, install a zero phase reactor. Refer to Section 7-6 EMC Filter for more information.
- 2. The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Section 9-7 Derating Curve of Ambient Temperature.
- 3. Select the AC motor drive with capacity one grade larger for the impact load application.

## 9-2 460V Models

		Frame S	Bize				Α						В				
	Model VFDFP4EA			007	015	022	037	040	055	075	110	150	185	220			
		Rated Output Capacity (kVA)		2.4	3.3	4.4	6.8	8.4	10.4	14.3	19	25	30	36			
		Rated Output Current (A)		3.0	4.2	5.5	8.5	10.5	13	18	24	32	38	45			
		Applicable M	Applicable Motor Output (kW)		1.5	2.2	3.7	4	5.5	7.5	11	15	18.5	22			
	Light duty	Applicable M	otor Output (HP)	1	2	3	5	5	7.5	10	15	20	25	30			
	Ligh	Overloa	d Tolerance			120% of	rated cu	rrent car	n endure	for 1 mir	n. during	every 5	min.				
		Max. Output	Frequency (Hz)						599.0	0							
Output Rating		Carrier Fre	equency (kHz)					2–15 (D	efualt: 6)					2–10 (Default: 6)			
put R		Rated Outpu	it Capacity (kVA)	1.4	2.4	3.2	4.8	7.2	8.4	9.6	14.3	19	25	30			
Out		Rated Out	put Current (A)	1.7	3.0	4.0	6.0	9.0	10.5	12	18	24	32	38			
		Applicable Motor Output (kW)		0.4	0.75	1.5	2.2	3.7	4	5.5	7.5	11	15	18.5			
	l dut	Applicable Motor Output (HP)		0.5	1	2	3	5	5	7.5	10	15	20	25			
	Normal duty	Overload Tolerance				0% of rat					•	•		5			
	_	Max Output	Frequency (Hz)		160%	6 of rated	d current	can end	ure for 3 599.0		s during	every 30	second	S			
		Max. Output	Trequency (TIZ)											2–10			
		Carrier Frequency (kHz)						2–15 (D	efault: 6)					(Default: 6)			
	Input Current (A)			3.0	4.2	5.5	8.5	10.5	13	18	24	32	38	45			
	Normal duty		1.7	3	4	6	9.0	10.5	12	18	24	32	38				
ating		Rated Voltage	e / Frequency	Three-phase 380–480 V <sub>AC</sub> ( -15%– +10%), 50/60 Hz													
Input Rating	O	perating Volta	ge Range (V <sub>AC</sub> )						323–5	28							
lnp		Frequency To	olerance (Hz)		ı	1	ı	ı	47–6	3		ı					
	Po	ower Supply	Light duty	3.6	5.0	6.7	10.3	13.3	16.6	18.3	21.6	29.1	34.9	41.6			
	Ca	pacity (kVA)	Normal duty	2.9	3.6	4.9	7.2	11.6	12.9	14.1	16.6	21.6	29.1	33.3			
		Efficiency	′ (%)						97								
		Power Fa	actor						>0.98	3							
	Weight (kg)						6.8						14.5				
	Cooling Method			Convective Fan cooling cooling													
	Braking Chopper			Frame A to C: built-in													
	DC Choke			Built-in DC reactor meets EN 61000-3-12													
		Emc Fil	ter			Bui	ilt-in EM	C meets	Filter EN	IEC 618	300-3 C1	*1 & C2					
														able 9-3			

Table 9-3

- 1. \*To comply with the C1 specifications, install a zero phase reactor. Refer to Section 7-6 EMC Filter for more information.
- 2. The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Section 9-7 Derating Curve of Ambient Temperature.
- 3. Select the AC motor drive with capacity one grade larger for the impact load application.

#### **460V Models**

		Frame S	Size		C	D	0	]	)				
	Mod	lel VFDF	FP4EA	300	370	450	550	750	900				
		Rated Output Capacity (kVA)		48	58	73	88	120	143				
		Rated Output Current (A)		60	73	91	110	150	180				
		Applicable M	otor Output (kW)	30	37	45	55	75	90				
	duty	Applicable M	otor Output (HP)	40	50	60	75	100	125				
	Light duty	Overload Tol	erance		120% of rated	current can endu	re for 1 min. duri	ng every 5 min,					
		Max. Output	Frequency (Hz)			599	0.00						
		Carrier Frequ	Joney (kHz)			2 10 (Default: 6)			2–9				
ating		Carrier Frequ	dericy (kmz)			2–10 (Default: 6)			(Default: 4)				
Output Rating		Rated Outpu	t Capacity (kVA)	36	48	58	73	88	120				
Outp		Rated Outpu	t Current (A)	45	60	73	91	110	150				
		Applicable Motor Output (kW)		22	30	37	45	55	75				
	duty	Applicable Motor Output (HP)		30	40	50	60	75	100				
	Normal duty	Overload Tolerance			120% of rated	current can endu	re for 1 min. duri	ng every 5 min.	ery 5 min.				
	Nor	Overload for	erance		160% of rated	current can endur	e for 3 sec. durir	ng every 30 sec.					
		Max. Output	Frequency (Hz)			599	0.00						
		Carrier Frequency (kHz)			2–10 (Default: 6)								
		Camor Frequ	aonoy (Kriz)			Z 10 (Boldani. 0)			(Default: 4)				
	Inni	nput Current (A)		60	73	91	110	150	180				
	mpe	out Current (A)	Normal Duty	45	60	73	91	110	150				
ating	ı	Rated Voltage	e / Frequency	3-phase 380–480 V <sub>AC</sub> (-15%– +10%), 50/60 Hz									
Input Rating	Op	perating Volta	ge Range (V <sub>AC</sub> )			323-	-528						
lnp		Frequency To	olerance (Hz)		1	47-	-63		T				
	Ро	wer Supply	Light Duty	54.9	66.5	75.7	91.4	124.7	149.6				
	Ca	pacity (kVA)	Normal Duty	39.1	52.4	61.5	84.0	94.8	130.5				
		Efficiency	<i>(</i> %)			9	7						
	Power Factor					>0	.98						
	Weight (kg)			26	5.5	42	2	59	).5				
	Cooling Method			Fan cooling									
	Braking Chopper			Frame A to C (built-in)									
	DC Choke			Built-in DC reactor mets EN 61000-3-12									
		Emc Fil	ter		Built-in E	MC Filter meets E	EN IEC 61800-3	C1*1 & C2					

Table 9-4

- 1. \*To comply with the C1 specifications, install a zero phase reactor. Refer to Section 7-6 EMC Filter for more information.
- 2. The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Section 9-7 Derating Curve of Ambient Temperature.
- 3. Select the AC motor drive with capacity one grade larger for the impact load application.

## 9-3 575V Models

		Frame S	ize			Α			В		
	Mode	VFDF	P5EA	15	22	37	55	75	110	150	185
	ıty	Rated Output Capacity (kVA)		3	4.3	6.7	9.9	12.1	18.6	24.1	30
		Rated Out	tput Current (A)	3	4.3	6.7	9.9	12.1	18.7	24.2	30
	Light Duty	Applicable N	Notor Output (kW)	1.5	2.2	3.7	5.5	7.5	11	15	18.5
	Lig	Applicable N	Notor Output (HP)	2	3	5	7.5	10	15	20	25
ng		Overloa	ad Tolerance	120%	% of rated	current car	n endure fo	r 1 minute	during eve	ry 5 minute	es
Output Rating		Rated Outp	ut Capacity (kVA)	2.5	3.6	5.5	8.2	10	15.4	19.9	24
ntbut	<b>≱</b>	Rated Out	tput Current (A)	2.5	3.6	5.5	8.2	10	15.5	20	24
Ō	al Duty	Applicable Motor Output (kW)		0.75	1.5	2.2	3.7	5.5	7.5	11	15
	Normal	Applicable N	Notor Output (HP)	1	2	3	5	7.5	10	15	20
	Z	Overload Tolerance							-	ery 5 minute ery 25 seco	
	Max. Output Frequency (Hz)						599.	00			
	Carrier Frequency (kHz)						2–15 (Def	fault: 6)			
	Input Current (A)		Light Duty	3	4.3	6.7	9.9	12.1	18.7	24.2	30
g			Normal Duty	2.5	3.6	5.5	8.2	10	15.5	20	24
Ratin	F	Rated Voltage / Frequency		Three-phase, 525–600 V <sub>AC</sub> (-15–10%), 50 / 60 Hz							
Input Rating	Ор	erating Volta	ge Range (V <sub>AC</sub> )	446–660							
_ =	F	requency To	olerance (Hz)				47–6	33			
	Pov	ver Supply	Light Duty	3.9	5.6	10.8	15.5	17.6	22.1	27.3	43.0
	Сар	acity (kVA)	Normal Duty	3.2	4.7	7.5	12.8	15.6	18.7	23.7	34.7
		Efficiency	(%)				97				
		Power Fa	ctor				> 0.9	98			
	Weight (kg)					6.8				14.5	
	Cooling Method			Convective cooling Fan Cooling							
	Braking Chopper			Built-in in frame A, B, C							
	DC Choke			Built-in DC choke meets EN 61000-3-12							
		EMC Fil	ter		Build-i	n EMC filte	r meets EN	N IEC 6180	0-3 C2*1 8	k C3	

Table 9-5

- 1. \*To comply with the C2 specifications, install a zero phase reactor. Refer to Section 7-6 EMC Filter for more information.
- 2. The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Section 9-7 Derating Curve of Ambient Temperature.
- 3. Select the AC motor drive with capacity one grade larger for the impact load application.

## **575V Models**

		Frame S	ize		С		С	D0 D				
	М	odel VFDF	P5EA	220	300	370	450	550	750	900		
		Rated Output Capacity (kVA)		36	45	54	67	86	104	125		
	nty	Rated Ou	Rated Output Current (A)		45	54	67	86	104	125		
	Light Duty	Applicable N	Notor Output (kW)	22	30	37	45	55	75	90		
	Lig	Applicable N	Notor Output (HP)	30	40	50	60	75	100	125		
ing		Overloa	ad Tolerance	120%	of rated cur	rent can en	dure for 1 n	ninute durin	g every 5 m	inutes		
Output Rating		Rated Outp	ut Capacity (kVA)	30	36	45	54	67	86	104		
ntbn	ıty	Rated Ou	tput Current (A)	30	36	45	54	67	86	104		
0	Normal Duty	Applicable Motor Output (kW)		18.5	22	30	37	45	55	75		
	lorm	Applicable Motor Output (HP)		25	30	40	50	60	75	100		
	_	Overload Tolerance							g every 5 m g every 25 s	125 minutes 104 104 75 100 minutes		
	Max. Output Frequency (Hz)						599.00					
		Carrier Freq	uency (kHz)		2–	10 (Default:	6)		2–9 (De	fault: 6)		
	Input Current (A)  Light Duty  Normal Duty		36	45	54	67	86	104	125			
g			Normal Duty	30	36	45	54	67	86	104		
Input Rating	Rated Voltage / Frequency			Three-phase, 525–600 V <sub>AC</sub> ( -15–10%), 50 / 60 Hz								
put		Operating Volta	ge Range (V <sub>AC</sub> )	446–660								
=		Frequency To	olerance (Hz)	47–63								
	Po	ower Supply	Light Duty	51.4	64.5	77.7	96.8	100.4	121.9	145.8		
	Ca	pacity (kVA)	Normal Duty	43.0	51.4	64.5	77.7	78.9	100.4	121.9		
		Efficiency	(%)				97					
	Power Factor						> 0.98					
	Weight (kg)			26.5 42 59.5						.5		
Cooling Method				Fan Cooling								
	Braking Chopper			Built-in in frame A, B, C								
	DC Choke			Built-in DC choke meets EN 61000-3-12								
		EMC Fil	ter		Build-in E	EMC filter m	eets EN IE	C 61800-3 (	C2*1 &C3			

Table 9-6

- 1. \*To comply with the C2 specifications, install a zero phase reactor. Refer to Section 7-6 EMC Filter for more information.
- 2. The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Section 9-7 Derating Curve of Ambient Temperature.
- 3. Select the AC motor drive with capacity one grade larger for the impact load application.

# 9-4 General Specifications

	Control Method	Pulse-Width Modulation (PWM)
	Control Mode	1: V/F, 2: SVC, 3: PM Sensorless, 4: SynRM Sensorless (applied to 230V / 460V
	Control Mode	models)
	Starting Torque	Reach up to 150% above at 0.5 Hz.
	V/F Curve	4 point adjustable V/F curve and square curve
	Speed Response Ability	5 Hz (vector control can reach up to 40 Hz)
	Torque Limit	Light duty: max. 130% torque current  Normal duty: max. 175% torque current
	Torque Accuracy	$\pm  5\%$
ics	Max. Output Frequency (Hz)	599.00 Hz
cterist	Frequency Output Accuracy	Digital command: ±0.01% (-10 – +40°C) of max. output frequency (Pr.01-00) Analog command: ±0.1% (25±10°C) of max. output frequency (Pr.01-00)
ara	Output Frequency	Digital command: 0.01 Hz
Ch	Resolution	Analog command: 0.05% × max. output frequency (Pr.01-00) (± 11 bit)
Control Characteristics	Overload Tolerance	Light duty: 120% of rated current can endure for 1 minute  Normal duty: 120% of rated current can endure for1 minute; 150% of rated current can endure for 3 seconds
	Frequency Setting Signal	0–10 V, 4–20 mA, 0–20 mA, PU
	Accel./Decel. Time	0.00-600.00 / 0.0-6000.0 seconds
	Main Control function	Momentary power loss ride thru, Speed search, Over-torque detection, Torque limit, 16-step speed (max), Accel/Decel time switch, S-curve accel./decel., Three-wire sequence, Auto-tuning, Dwell, Slip compensation, Torque compensation, JOG frequency, Frequency upper / lower limit settings, DC injection braking at start / stop, High slip braking, Energy saving control, Modbus communication (RS-485
	Fan Control	RJ45, max. 5.2 Kbps) Frame A–B are ON / OFF switch control.
		Frame C–D are PWM control
	Motor Protection	Electronic thermal relay protection
	Over-current Protection	Light Duty: Over-current protection for 200% rated current Normal Duty: Over-current protection for 240% rated current Current clamp: "Light duty: 130–135%"; "Normal duty: 170–175%"
eristics	Over-voltage Protection	230V models: Drive stops when DC bus voltage exceeds 410 V. 460V models: Drive stops when DC bus voltage exceeds 820 V. 575V models: Drive stops when DC bus voltage exceeds 1016 V.
aracte	Over-temperature Protection	Built-in temperature sensor
2	Stall Prevention	Stall prevention during acceleration, deceleration and running independently
Protection Characteristics	Restart after Instantaneous Power Failure	Parameter setting up to 20 seconds
Ш	Grounding Leakage Current Protection	Leakage current is higher than 50% of rated current of the AC motor drive
	Short-circuit Current Rating (SCCR)	Per UL508C, the drive is suitable for use on a circuit capable of delivering not more than 100 kA symmetrical amperes (rms) when protected by fuses given in the fuse table.
	Certifications	CE EFIL & SEMIF47

Table 9-7

NOTE: For information of Certifications and Declaration of Conformity (DoC), visit <a href="Double-D

## 9-5 Environment for Operation, Storage and Transportation

Do NOT expose the AC motor drive in the bad environment, such as dust, direct sunlight, corrosive/inflammable gasses, humidity, liquid and vibration environment. The salt in the air must be less than 0.01 mg/cm² every year. Installation IEC60364-1/IEC60664-1 Pollution degree 2, Indoor use only Location -25- +70 Storage Surrounding Transportation |-25- +70 Temperature (°C) Non-condensation, non-frozen Operation Max. 95% Storage/ Rated Max. 95% Humidity Transportation No condense water Operation/ 86-106 Air Pressure Storage (kPa) Transportation 70–106 IEC 60721-3-3 Operation Class 3C3, Class 3S2 Pollution Environment Level Class 1C2, Class 1S2 Storage Transportation Class 2C2, Class 2S2 If the AC motor drive is installed at altitude 0-1000 m, follow normal operation restriction. If it is install at altitude 1000-2000 m, decrease 1% of rated current or lower 0.5°C of temperature for every 100 m Operation Altitude increase in altitude. Maximum altitude for Corner Grounded is 2000 m. Contact Delta for more information, if you need to use this motor drive at an altitude of 2000 m or higher. IEC 60068-2-6 Frame A:  $2 \text{ Hz} \le f \le 13.2 \text{ Hz}$  / Amplitude 1 mm;  $13.2 \text{ Hz} < f \le 55 \text{ Hz}$  / Gravity 0.7 G to 2.0 G; 55 Hz < f ≤ 512 Hz / Gravity 2.0 G Vibration Frame B:  $2 \text{ Hz} \le f \le 13.2 \text{ Hz}$  / Amplitude 1 mm;  $13.2 \text{ Hz} < f \le 55 \text{ Hz}$  / Gravity 0.7 G to Operating 1.5 G; 55 Hz < f ≤ 512 Hz / Gravity 1.5 G Frame C / D0 / D: 2 Hz  $\leq$  f  $\leq$  13.2 Hz / Amplitude 1 mm; 13.2 Hz < f  $\leq$  55 Hz / Gravity 0.7 G to 1.0 G; 55 Hz <  $f \le 512$  Hz / Gravity 1.0 G IEC 60068-2-27 Shock Frame A; B; C; D0: Max 30 G; 11 ms Operating Frame D: Max 15 G; 11 ms IEC 60068-2-64  $10Hz \le f \le 100Hz / ASD: 1.0m2/s3$ Vibration  $100Hz \le f \le 200Hz / Slope: -3dB/octave$ Package Cardboard box type: Free fall drop in accordance with ISTA 1A Drop

Table 9-8

Shock

installation position)

Operation

Position

side drop)

Max. allowed offset angle ±10° (under normal

Wooden box type: In accordance with ISTA 1E (4 side incline) and ISTA 2B (Bottom

# 9-6 Operation Noise Level

According to EN 61800-5-1, operators working in an environment above 70dB must take appropriate hearing protection.

Frame	Model	Noise Le	evel (dB)	
Frame	Wodei	50% Output Load	100% Output Load	
	VFD007FP4EA-52			
	VFD015FP4EA-52			
	VFD022FP4EA-52	E7 0	<b>57.0</b>	
Α	VFD037FP4EA-52	57.8	57.9	
	VFD040FP4EA-52	(No speed control on fan)	(No speed control on fan)	
	VFD055FP4EA-52			
	VFD075FP4EA-52			
	VFD110FP4EA-52			
В	VFD150FP4EA-52	63.1	63.2	
В	VFD185FP4EA-52	(No speed control on fan)	(No speed control on fan)	
	VFD220FP4EA-52			
С	VFD300FP4EA-52	61	64.0	
	VFD370FP4EA-52	- 61	61.8	
D0	VFD450FP4EA-52	50.4	GE G	
	VFD550FP4EA-52	59.4	65.6	
D	VFD750FP4EA-52	64.0	76.6	
	VFD900FP4EA-52	64.9		

Table 9-9

# 9-7 Specifications for Operation Temperature and Protection Level

Model	Frame A-D	Protection Level	Operation Temperature
VFDxxxFP2EA-52x VFDxxxFP4EA-52x VFDxxxFP5EA-52x	230V: 0.75-45 kW 460V: 0.75-90 kW	IP55 / NEMA12	-10–50°C
VFDxxxFP2EA-41 VFDxxxFP4EA-41 VFDxxxFP5EA-41	575V: 1.5–90 kW	IP41 / NEMA1	-10-50 C

Table 9-10

## 9-7 Derating Curve for Ambient Temperature, Altitude and Carrier Frequency

- ☑ For more information on calculation for derating curve, see Pr.06-55.
- ☑ When choosing the correct model, consider factors such as ambient temperature, altitude, carrier frequency, control mode, and so on. That is,
- Actual rated current for application (A) = Rated output current (A) × Ambient temp. rated derating (%) × Altitude rated derating (%) × [Normal / Advanced control] carrier frequency rated derating (%)

Protection Level Operating Environment				
	If the AC motor drive operates at the rated current, the ambient temperature needs			
NEMA1	to be between -10–50°C. If the temperature is above 50°C, decrease 2% of the			
NEMA12	rated current for every 1°C increase in temperature. The maximum allowable			
	temperature is 60°C.			

Table 9-11

#### Ambient Temperature Derating Curve

#### 230-575V




Figure 9-1

#### NEMA12:

The rated output current derating (%) in normal duty / light duty when carrier frequency is the default value:

Ambient Temp. / 100% Load Fc (kHz)	30°C	50°C	60°C
Default Value	100	100	80

Table 9-12

## Altitude Derating Curve

Condition	Operating Environment
	If the AC motor drive is installed at an altitude of 0–1000 m, follow normal operation
	restrictions. For altitudes of 1000–2000 m, decrease the drive's rated current by 1% or
High Altitude	lower the temperature by 0.5°C for every 100 m increase in altitude. The maximum
	altitude for corner grounding is 2000 m. If installing at an altitude higher than 2000 m is
	required, contact Delta for more information.

Table 9-13




Figure 9-2

The rated output current derating (%) for different altitudes above sea level:

Altitude above Sea Level (Meter)	0	1000	1500	2000
Output Current /	100	100	95	90
Rated Current (%)	100	100	95	90

Table 9-14

## Carrier Frequency Derating Curve

230V Normal Control (VF / SVC)




Figure 9-3

The rated output current derating (%) of 230V models in normal control mode for different carrier frequencies:

Fc (kHz) Model No.	4	5	6	7	8	9	10	11	12	13	14	15
VFD007-110FP2EA	100	100	100	95	91	88	85	82	79	76	73	71
VFD150-300FP2EA	100	100	100	93	87	72	76	-	-	-	-	-
VFD370-450FP2EA	100	100	100	94	89	84	-	-	-	-	-	-

Table 9-15

230V Advanced Control (FOB / SynRM)

$$Pr.00-11 = 6 (FOB)$$
  
= 8 (SynRM)




Figure 9-4

The rated output current derating (%) of 230V models in advanced control mode for different carrier frequencies:

Fc (kHz) Model No.	4	5	6	7	8	9	10
VFD007-110FP2EA	100	93	88	83	79	75	71
VFD150-300FP2EA	100	90	82	74	66	58	50
VFD370-450FP2EA	100	91	84	78	73	68	-

Table 9-16

460V Normal Control (VF / SVC)

$$Pr.00-11 = 0 (IMVF)$$

$$= 2 (IM SVC, Pr.05-33 = 0)$$




Figure 9-5

The rated output current derating (%) of 460V models in normal control mode for different carrier frequencies:

Fc (kHz) Model No.	4	5	6	7	8	9	10	11	12	13	14	15
VFD007-185FP4EA	100	100	100	94	88	83	79	74	71	67	63	61
VFD220-750FP4EA	100	100	100	92	85	80	74	-	-	-	-	-
VFD900FP4EA	100	100	100	92	85	80	-	-	-	-	-	-

Table 9-17

460V Advanced Control (FOB / SynRM)




Figure 9-6

The rated output current derating (%) of 460V models in advanced control mode for different carrier frequencies:

Fc (kHz) Model No.	2.67	3.33	4	4.67	5.33	6	6.67	7.33	8	8.67	9.33	10
VFD007-1185FP4EA	100	100	100	94	88	83	79	74	71	67	63	61
VFD220-1750FP4EA	100	100	100	92	85	80	74	-	-	-	-	-
VFD900FP4EA	100	100	100	92	85	80	-	-	-	-	-	-

Table 9-18

575V Normal Control (VF / SVC)

$$Pr.00-11 = 0 (IMVF)$$

$$= 2 (IM SVC, Pr.05-33 = 0)$$




Figure 9-7

The rated output current derating (%) of 575V models in normal control mode for different carrier frequencies:

Fc (kHz) Model No.	4	5	6	7	8	9	10	11	12	13	14	15
VFD015-185FP5EA	100	100	100	91	84	78	72	67	63	59	55	52
VFD220-550FP5EA	100	100	100	90	81	73	65	-	-	-	-	-
VFD750-900FP5EA	100	100	100	91	84	77	-	-	-	-	-	-

**Table 9-19** 

# 9-8 Efficiency Curve

# • 230V Models: VFD007-450FP2EA




Figure 9-8

# Efficiency (%) under different loads:

Speed (%) Load (%)	16.7	50	66.7	100
100% Load	83.9	91.8	93.1	95.1
75% Load	82.1	87.6	89.8	92.5
50% Load	81.0	85.0	88.0	92.0
25% Load	80.0	83.0	86.4	91.5

Table 9-20

# 460V Models: VFD007–900FP4EA




Figure 9-9

# Efficiency (%) under different loads:

Speed (%) Load (%)	16.7	50	66.7	100
100% Load	91.9	95.8	96.4	97.0
75% Load	91.4	95.6	96.3	97.0
50% Load	89.6	95.0	95.8	96.6
25% Load	83.1	91.1	92.4	94.0

**Table 9-21** 

# • 575V Models: VFD015-900FP5EA




Figure 9-10

# Efficiency (%) under different loads:

Speed (%) Load (%)	16.7	50	66.7	100
100% Load	90.6	95.6	96.3	97.7
75% Load	90.1	95.1	96.1	97.8
50% Load	87.4	93.0	93.9	97.0
25% Load	63.0	75.0	84.6	95.5

Table 9-22

[This page is intentionally left blank]

# Chapter 10 Digital Keypad

- 10-1 Descriptions of Digital Keypad
- 10-2 Function of Digital Keypad KPC-CC01
- 10-3 TPEditor Installation Instruction
- 10-4 Fault Code Description of Digital Keypad KPC-CC01
- 10-5 Unsupported Functions when using TPEditor with the KPC-CC01

# 10-1 Descriptions of Digital Keypad

KPC-CC01



Communication Interface RJ45 (socket), RS-485 interface

Communication protocol: RTU19200, 8, N, 2

#### Installation Method

- 1. Embedded type and can be put flat on the surface of the control box. The front cover is water proof.
- 2. Buy a MKC-KPPK model to do wall mounting or embedded mounting. Its protection level is IP66.
- 3. The maximum RJ45 extension lead is 5 m (16ft)
- 4. This keypad can only be used on Delta's motor drive C2000 series, CH2000, CP2000 and CFP2000.

# **Descriptions of Keypad Functions**

Key	Descriptions
	Start Operation Key
RUN	Only valid when the source of operation command is the keypad.
KON	2. Operates the AC motor drive by the function setting. The RUN LED will be ON.
	Can be pressed repeatedly at the stop process.
	Stop Command Key.
	This key has the highest priority when the command is from the keypad.
	2. When it receives the STOP command, regardless of whether the AC motor drive is in
	operation or stop status, the AC motor drive needs to execute the "STOP" command.
STOP	3. Use the RESET key to reset the drive after a fault occurs.
RESET	4. If you cannot reset after the error:
	a. The condition which triggers the fault is not cleared. After you clear the condition, you
	can then reset the fault.
	b. The drive is in the fault status when powered on. After you clear the condition, restart
	and then you can reset the fault.
	Operation Direction Key
FWD	1. Only controls the operation direction, NOT the drive activation. FWD: forward, REV:
REV	reverse.
	2. Refer to the LED descriptions for more details.
ENTER	ENTER Key
ENTER	Goes to the next menu level. If at the last level, press ENTER to execute the command.
	ESC Key
ESC	Leaves the current menu and returns to the previous menu; also functions as a return key or
	cancel key in a sub-menu.


Key		Descriptions						
	Returns to the main menu.	·						
	Menu commands:							
	Parameter Setup	7. Language Setup	13. Startup Menu					
NACNIL	2. Quick Start	Quick Start 8. Time Setup 14. Main Page						
MENU	3. Application Selection List	Application Selection List 9. Keypad Locked 15. PC Link						
	4. Changed List	10. PLC Function	16. Start Wizard					
	5. Copy Parameter	11. Copy PLC						
	6. Fault Record	12. Display Setup						
<b>( )</b>	Direction: Left / Right / Up / D	own						
	1. In the numeric value setti	ng mode, moves the cursor	and changes the numeric value.					
	2. In the menu / text selection	on mode, selects an item.						
	Function Key							
	1. The functions keys have	defaults and can also be us	e-defined. The defaults for F1 and F4					
F1 F2	work with the function list	below. For example, F1 is	the JOG function, and F4 is a speed					
	setting key for adding / de	setting key for adding / deleting user-defined parameters.						
F3 F4	2. Other functions must be o	Other functions must be defined using TPEditor.						
	( <u>Download</u> TPEditor softv	( <u>Download</u> TPEditor software at Delta website, select TPEditor version 1.60 or above.						
	Refer to the installation in	struction for TPEditor in Se	ction 10-3.)					
	HAND Key							
	1. Use this key to select HA	ND mode. In this mode, the	e drive's parameter settings for					
	frequency command sour	rce is Pr.00-30, and that for	operation command source is Pr.00-					
	31.							
HAND	2. Press HAND key at STOR	P, then the setting switches	to HAND frequency source and HAND					
	operation source.							
	3. Press HAND key at RUN	, and it stops the AC motor	drive first (displays AHSP warning),					
	and switches to HAND fre	equency source and HAND	operation source.					
	4. Successful mode switching	ng for the KPC-CC01 displa	ys HAND mode on the screen.					
	AUTO Key							
	The default for the drive is	s AUTO mode.						
	2. Use this key to select AU	Use this key to select AUTO mode. In this mode, the drive's parameter settings for						
	frequency command sour	frequency command source is Pr.00-20, and that for operation command is Pr.00-21.						
AUTO	3. Press AUTO key at STOF	Press AUTO key at STOP, then the setting switches to AUTO frequency source and AUTO						
	operation source.							
	•	·	drive first (displays AHSP warning), and					
	switches to AUTO frequen	ncy source and AUTO oper	ation source.					
	5. Successful mode switching	Successful mode switching for the KPC-CC01 displays AUTO on the screen.						

**NOTE:** The defaults for the frequency command and operation command source of HAND / AUTO mode are both from the keypad.

# **Descriptions of LED Functions**

LED	ED Functi	Descriptions
STOP	Blinking: the	STOP indicator for the AC motor drive. e drive is in standby. f: the drive does not execute the "STOP" command.
FWD REV	<ol> <li>Green</li> <li>Red lig</li> <li>Flashin</li> <li>Operation D</li> <li>Green</li> <li>Red lig</li> </ol>	light: the drive is running forward.  ht: the drive is running backward.  g light: the drive is changing direction.  birection LED under Torque Mode  light: when the torque command ≥ 0, and the motor is running forward.  ht: when the torque command < 0, and the motor is running backward.  g light: when the torque command < 0, and the motor is running forward.
	RUN LED: LED status OFF	Condition / State CANopen at initial No LED
CANopen– "RUN"	Blinking	CANopen at pre-operation  ON   200 ms ms ms   CANopen at stop
	Single flash	ON 200 1000 ms ms ms
	ON	CANopen at operation status  ERR ——————————————————————————————————
	ERR LED:	
	LED status	Condition / State
	OFF	No Error
	Single flash	One message fail  ON 1000  OFF ms ms
CANopen- "ERR"	Double flash	Node guarding failure or heartbeat message failure  ON 200 200 1000  OFF ms ms ms
	Triple flash	Synchronization failure  ON 200 200 200 1000 ms ms ms ms ms
	ON	Bus off  ERR —— CAN —— RUN


# 10-2 Function of Digital Keypad KPC-CC01




#### NOTE:

- 1. Start-up screen can only display pictures, not animation.
- When powered ON, it displays the start-up screen then the main screen. The main screen displays Delta's default setting F/H/A/U. You can set the display order with Pr.00-03 (Start-up display). When you selected the U screen, use the left / right keys to switch between the items, and set the display order for the U screen with Pr.00-04 (User display).

# **Display Icon**





- : present setting
- ▼ : Scroll down the page for more options

for more options

▶ : show complete sentence Press (< ) > ) for complete information


#### Display item



# **MENU**

- 1: Parameter Setup 2: Quick Start
- 3: Application Selection List
- 5: Copy Parameter
- 4: Changed List
- 6: Fault Record
- 7: Language Setup 8: Time Setup
- 9: Keypad Locked
- 10: PLC Function
- 11: Copy PLC
- 12: Display Setup
- 13: Start-up Menu
- 14: Main Page
- 15: PC Link
- 16: Start Wizard


#### 1. Parameter Setup




Press ENTER to select.

Press Up / Down keys to select the parameter group.

Once you select a parameter group, press ENTER to go into that group.



#### 2. Quick Start




Press ENTER to select.

Quick Start:


- 1. V/F Mode
- 2. SVC Mode
- 3. My Mode

#### Description:

VF Mode



01:Password Decoder



Items

circumstances.

- Parameter protection password input (Pr.00-07)
- Parameter protection password setting (Pr.00-08)
- 3. Speed control mode (Pr.00-11)
- Load selection (Pr.00-16)

written or is protected by the password under this

- 5. Carrier frequency (Pr.00-17)
- Master frequency command (AUTO) source / Source selection of the PID target (Pr.00-20)
- Operation command (AUTO) source (Pr.00-21)
- 8. Stop method (Pr.00-22)
- Digital keypad STOP function (Pr.00-32)
- 10. Max. operation frequency (Pr.01-00)
- 11. Output frequency of motor 1 (Pr.01-01)
- 12. Output voltage of motor 1 (Pr.01-02)

- 13. Mid-point frequency 1 of motor 1 (Pr.01-03)
- 14. Mid-point voltage 1 of motor 1 (Pr.01-04)
- 15. Mid-point frequency 2 of motor 1 (Pr.01-05)
- 16. Mid-point voltage 2 of motor 1 (Pr.01-06)
- 17. Min. output frequency of motor 1 (Pr.01-07)
- 18. Min. output voltage of motor 1 (Pr.01-08)
- Output frequency upper limit (Pr.01-10)
- Output frequency lower limit (Pr.01-11)
- 21. Acceleration time 1 (Pr.01-12)
- 22. Deceleration time 1 (Pr.01-13)
- 23. Over-voltage stall prevention (Pr.06-01)
- 24. Derating protection (Pr.06-55)
- 25. Software brake chopper action level (Pr.07-00)
- 26. Speed tracking during start-up
- 27. (Pr.07-12)
- 28. Emergency stop (EF) & force to stop selection (Pr.07-20)
- Torque command filter time
   (Pr.07-24)
- 30. Slip compensation filter time (Pr.07-25)
- 31. Torque compensation gain (Pr.07-26)
- 32. Slip Compensation Gain (Pr.07-27)
- 2. SVC Mode

\$VC Mode :P00-07 \$01:Password Inp 02:Password Inp 03:Control Meth

01: Password Decoder


#### Items

- Parameter protection password input (Pr.00-07)
- Parameter protection password setting (Pr.00-08)
- 3. Speed control mode (Pr.00-11)
- 4. Load selection (Pr.00-16)
- 5. Carrier frequency (Pr.00-17)



- Master frequency command (AUTO) source / Source selection of the PID target (Pr.00-20)
- 7. Operation command (AUTO) source (Pr.00-21)
- 8. Stop method (Pr.00-22)
- Digital keypad STOP function (Pr.00-32)
- 10. Max. operation frequency (Pr.01-00)
- 11. Output frequency of motor 1 (Pr.01-01)
- 12. Output voltage of motor 1 (Pr.01-02)
- 13. Min. output frequency of motor 1 (Pr.01-07)
- Min. output voltage of motor 1 (Pr.01-08)
- Output frequency upper limit (Pr.01-10)
- Output frequency lower limit (Pr.01-11)
- 17. Acceleration time 1 (Pr.01-12)
- 18. Deceleration time 1 (Pr.01-13)
- Full-load current for induction motor 1 (Pr.05-01)
- 20. Rated power for induction motor 1 (Pr.05-02)
- 21. Rated speed for induction motor 1 (Pr.05-03)
- 22. Number of poles for induction motor 1 (Pr.05-04)
- 23. No-load current for induction motor 1 (Pr.05-05)
- 24. Over-voltage stall prevention (Pr.06-01)
- 25. Over-current stall prevention during acceleration (Pr.06-03)
- 26. Derating protection (Pr.06-55)
- 27. Software brake chopper action level (Pr.07-00)

- 28. Emergency stop (EF) & Force to stop selection (Pr.07-20)
- 29. Torque command filter time (Pr.07-24)
- Slip compensation filter time (Pr.07-25)
- 31. Slip compensation gain (Pr.07-27)
- 3. My Mode



Press F4 in parameter setting screen to save the parameter to My Mode. To delete or correct the parameter, select this parameter and press F4 for DEL in the bottom right corner.


**Items** 

It can save 1–32 sets of parameters (Pr). Setup process


Go to Parameter Setup function.
 Press ENTER to select the parameter to use. There is an ADD on the bottom right corner of the screen. Press F4 to add this parameter to My Mode.




 The parameter (Pr) displays in My mode if it is properly saved.
 To correct or to delete this parameter, press F4 for DEL.




 To delete a parameter, go to My Mode and select the parameter to delete.
 Press ENTER to enter the parameter setting screen. DEL appears in the bottom left corner of the screen. Press F4 to delete this parameter from My Mode.




# 3. Application Selection List






#### 4.




#### 5. Copy Parameter



Press ENTER to go to 001– 004: content storage Four groups of parameters are available to copy.

The steps are shown in the example below.

Example: parameter saved in the motor drive.



- 1. Go to "Copy Parameter"
- Select the parameter group to copy and press ENTER key.




- 1. Select 1: keypad → VFD
- 2. Press ENTER key to go to "keypad → VFD" screen.




Begin copying parameters until it is done.

After copying parameters is done, the keypad automatically returns to this screen.

Example: parameter saved in the keypad.



- 1. Go to Copy parameter
- 2. Select the parameter group to copy and press ENTER.



Press ENTER to go to "VFD → keypad" screen.




Press Up / Down keys to select a symbol.


Press Left / Right keys to move the cursor to select a file name.

# String & Symbol Table:


! " # \$ % & ' ( ) \* + · - · / 0 1 2 3 4 5 6 7 8 9 : ; < = > ? @ A B C D E F G
H I J K L M N O P Q R S T U V W X Y Z [ \ ] ^ \_ ' a b c d f g h i j k l m n
o p q r s t u v w x y z { | } ~



After you confirm the file name, press ENTER key.




To begin copying parameters until it is done.




After copying parameters is done, the keypad automatically returns to this screen.

Press Right key to see the date of the parameters copied.



Press Right key to see the time of the parameters copied.

#### 6. Fault Record




Press ENTER to see an error record's details.

Able to store 6 error codes (Keypad V1.02 and previous versions)

Able to store 30 error codes (Keypad V1.20 and later version)

The most recent error record shows as the first record. Choose an error record to see its details such as date, time, frequency, current, voltage, and DC bus voltage)



Press Up / Down keys to select an error record.


After selecting an error code, press ENTER to see that error record's details.



Press Up / Down keys to scroll through an error record's details such as date, time, frequency, current, voltage, and DC bus voltage.

Press Up / Down keys to select the next error code.

After selecting an error code, press ENTER to see that error record's details.



Press Up / Down keys to see an error record's detail such as date, time, frequency, current, voltage, and DC bus voltage.

#### NOTE:

The AC motor drive actions are recorded and saved to the KPC-CC01. When you remove the KPC-CC01 and connect it to another AC motor drive, the previous fault records are not deleted. The new fault records of the new AC motor drive continue to be added to the KPC-CC01.

# 7. Language Setup



Use Up / Down keys to select the language, and then press ENTER. The language setting option is displayed in the language of your choice. Language setting options:


- 1. English
- 5. Русский
- 9. Polski

- 2. 繁體中文
- 6. Español
- 10. Deutsch


- 3. 简体中文
- 7. Português
- 11. Italiano

- 4. Türkçe
- 8. Français
- 12. Svenska

#### 8. Time Setup



Use Left / Right keys to select Year, Month, Day, Hour, Minute or Second to change.



Press Up / Down keys to set the Year

Press Up / Down keys to set the Month

Press Up / Down keys to set the Day

Press Up / Down keys to set the Hour

Press Up / Down keys to set the Minute


Press Up / Down keys to set the Second

Press ENTER to confirm the Time Setup.

#### NOTE:

Limitation: The charging process for the keypad super capacitor finishes in about 6 minutes. When the digital keypad is removed, the time setting is saved for 7 days. After 7 days, you must reset the time.

#### 9. Keypad Locked



Press ENTER to lock

Lock the keypad

Use this function to lock the keypad. The main screen does not display "keypad locked" when the keypad is locked; however, it displays the message "Press ESC 3 sec to UnLock Key" when you press any key.

to UnLock Key

When the keypad is locked, the main screen does not indicate the lock status.

Press any key on the keypad; a message displays as shown on the left.



If you do not press ESC, the keypad automatically returns to this screen.

Press any key on the keypad, a message displays as shown on the left.


Press ESC for 3 seconds to unlock the keypad; the keypad returns to this screen. All keys on the keypad is functional.

All keys on the keypad is functional. Turning the power off and on does not lock the keypad.

#### 10. PLC Function



Press Up/Down keys to select a PLC's function, and then press ENTER. When activating and stopping the PLC function (choosing 2: PLC Run or 3: PLC Stop), the PLC status displays on main screen (Delta default setting).



Choose option 2: PLC Run to enable the PLC function

The default on the main screen displays the PLC / RUN status message.


Choose option 3: PLC Stop to disable the PLC function.

The default on the main screen displays the PLC / STOP status message.

If the PLC program is not available in the control board, the PLFF warning displays when you choose option 2 or 3.

In this case, choose option 1: Disable to clear PLFF warning.

## 11. Copy PLC



Four groups of parameters are available to copy.


The steps are shown in the example below.

Example: Saved in the motor drive.



2: VFD->Keypad

- Go to Copy PLC
- Select the PLC program to copy and press ENTER.
- 1. Select 1: Keypad→VFD
- Press ENTER to go to the "Keypad→VFD" screen.



Begin copying the PLC program until it is done.


After copying is done, the keypad automatically returns to this screen.



Warning

If you select "Option 1: Keypad→VFD", check if the PLC program is built-in to the KPC-CC01 keypad. If the PLC program is not available in the keypad when you select "Option 1: Keypad→VFD", an "ERR8 Warning: Type Mismatch" displays on the screen. If you unplug the keypad and plug it back while copying the PLC program, the screen displays a CPLt warning.

Example: PLC program saved in the keypad.




**CPLt** 

Copy PLC Timeout

- 1. Go to Copy PLC.
- 2. Select the PLC program to copy and press ENTER.



Press ENTER to go to the "VFD→Keypad" screen.




If the WPLSoft editor is installed uses password, enter the password to save the file to the keypad.




Press the Up / Down keys to select a symbol. Press the Left / Right keys to move the cursor to select a file name.

#### String & Symbol Table:

 $!" # $\%&' () *+ \cdot - \cdot / 0123456789 : ; <=>?@$ ABCDEFGHIJKLMNOPQRSTUVWXYZ (\) \ abcdfghijklmnopqrstuvwxyz{|}~




After you confirm the file name, press ENTER.




Begin copying the PLC program until it is done.


Copy PLC ♦ 001:Manual\_001▶ 002: 003:

After copying is done, the keypad automatically returns to this screen.




# 12. Display setup






## 13. Start-up



## 14. Main page



Default screen and editable screen are available upon selection.

Press ENTER to select.

1. Default page




F 60.00Hz >>> H >>> U (options rotate)

User Define: an optional accessory is required (TPEditor & USB / RS-485
Communication Interface-IFD6530) to design your own main screen.
 If the editor accessory is not installed, the User Define option displays a



blank screen.




USB/RS-485 Communication Interface-IFD6530

Refer to Chapter 07 Optional Accessories for more detail.


**TPEditor** 

<u>Download</u> TPEditor software at Delta website, select TPEditor version 1.60 or above. Refer to the installation instruction for TPEditor in Section 10-3.

#### 15. PC Link




 TPEditor: This function enables you to connect the keypad to a computer then to download and edit user-defined screens.




Click ENTER to go to <Waiting to connect to PC>


In TPEditor, from the Communication menu, then choose "Write to HMI"





Cancel





Start to upload parameters to VFDSoft

Uploading parameter is completed

Before using the user-defined start-up screen and user-defined main screen, you must preset the start-up screen and the main screen as user- defined. If you do not download the user-defined screen to the KPC-CC01, the start-up screen and the main screen are blank.

# 16. Start Wizard (applicable for CFP2000 firmware V1.06 and above)

# 16.1 New drive start-up setting process

When a new drive is powered on, it directly enters the Start Wizard. There are three modes in the startup setting process: Start Wizard, Exit Wizard and Test Mode.

#### (1) Start Wizard:

- In Start Wizard, you can set drive's parameters such as Calendar, Maximum operation frequency and Maximum voltage...; refer to Table 1 for setting items and orders.
- The drive exits Start Wizard when you finish the complete setting process, and will not enter this process when rebooting the power.

# (2) Exit Wizard:

• Exit the Start Wizard mode. The drive does not go to Start Wizard when rebooting the power.


# (3) Test Mode:

- This function is hidden to avoid misuse. Refer to the following flow chart to enter Test Mode.
- When the drive is in Test mode, it temporarily disables the Start Wizard and Exit Wizard mode.
- The Test Mode is designed for distributors / suppliers / clients to manage and operate the drive before shipping it out.
- If you enter Test Mode without exiting the Start Wizard process, the drive will begin with the new drive start-up process upon next power on.


Setting Order	Description	Parameter
1	Calendar	N/A
2	Output frequency of motor 1	01-01
3	Output voltage of motor 1	01-02
4	Full-load current for induction motor 1 (A)	05-01
5	Number of poles for induction motor 1	05-04
6	Rated speed for induction motor 1 (rpm)	05-03
7	Minimum output frequency of motor 1	01-07
8	Maximum operation frequency	01-00
9	Master frequency command source (AUTO) / Source selection of the PID target	00-20
10	Operation command source (AUTO)	00-21
11	V/F curve selection	01-43
12	Acceleration time 1	01-12
13	Deceleration time 1	01-13

Table 1: Start Wizard setting items

Flow chart for the above setting process:




# 16.2 Re-start Start Wizard




**NOTE:** The "16: Start Wizard" on the menu is to set whether the screen shows start wizard when powering on the drive.

## Other displays

When a fault occurs, the screen displays shows the fault or warning:





- 1. Press STOP / RESET key to reset the fault code. If there is no response, contact your local distributor or return to the unit to the factory. To view the fault DC bus voltage, output current and output voltage, press MENU and then choose 6: Fault Record.
- 2. After resetting, if the screen returns to the main screen and shows no fault after you press ESC, the fault is cleared.
- 3. When the fault or warning message appears, the LED backlight blinks until you clear the fault or the warning.

Optional accessory: RJ45 Extension Lead for Digital Keypad

Part No.	Description
CBC-K3FT	RJ45 extension lead, 3 feet (approximately 0.9 m)
CBC-K5FT	RJ45 extension lead, 5 feet (approximately 1.5 m)
CBC-K7FT	RJ45 extension lead, 7 feet (approximately 2.1 m)
CBC-K10FT	RJ45 extension lead, 10 feet (approximately 3 m)
CBC-K16FT	RJ45 extension lead, 16 feet (approximately 4.9 m)

**NOTE:** When you need to buy communication cables, buy non-shielded, 24 AWG, four-wire twisted pair, 100 ohms communication cables.


# 10-3 TPEditor Installation Instruction

TPEditor can edit up to 256 HMI (Human-Machine Interface) pages with a total storage capacity of 256 KB. Each page can include 50 normal objects and 10 communication objects.


- 1. TPEditor: Setup & Basic Functions
  - (1) Run TPEditor version 1.60 or above by double-clicking the program icon.



(2) On the **File** menu, click **New**. In the New project dialog box, for **Set Device Type**, select **DELTA VFD-C Inverter**. For **TP Type**, select **VFD-C KeyPad**. For **File Name**, enter TPE0 and then click **OK**.




(3) The editor displays the Design window. On the **Edit** menu, click **Add a New Page**. You can also right-click on the TP page in the upper right corner of the Design window and click **Add** to add one more page(s) to edit.




(4) Edit the start-up screen

(5) Add static text. Open a blank page (step 3), then on the toolbar click . Double-click the blank page to display the **Static Text Setting** dialog box, and then enter the static text.




(6) Add a static bitmap. Open a blank page (step 3), then on the toolbar, click . Double-click the blank page to display the **Static Bitmap Setting** dialog box where you can choose the bitmap.



You can only use images in the BMP format. Click the image and then click Open to show the image in the page.


- (7) Add a geometric bitmap. There are 11 kinds of geometric bitmaps to choose. Open a new blank page (step 3), then on the toolbar click the geometric bitmap icon that you need
  - In the page, drag the geometric bitmap and enlarge it to the size that you need.
- (8) When you finish editing the start-up screen, on the **Communication** menu, click **Input User Defined Keypad Starting Screen.**




- (9) Download the new setting: On the **Tool** menu, click **Communication**. Set up the communication port and speed for the IFD6530. There are three speeds available: 9600 bps, 19200 bps, and 38400 bps.
- (10) On the Communication menu, click Input User Defined Keypad Starting Screen.




(11) The Editor displays a message asking you to confirm the new setting. Before you click **OK**, on the keypad, go to MENU, select PC LINK, press ENTER and then wait for few seconds. Then click **YES** in the confirmation dialog box to start downloading.



- 2. Edit the Main Page and Download to the Keypad
  - (1) In the Editor, add a page to edit. On the Edit menu, click Add a New Page. You can also right-click on the TP page in the upper right corner of the Design window and click Add to add one more pages to edit. This keypad currently supports up to 256 pages.



(2) In the bottom right-hand corner of the Editor, click the page number to edit, or on the **View** menu, click **HMI Page** to start editing the main page. As shown in the picture above, the following objects are available. From left to right they are: Static Text, ASCII Display, Static Bitmap, Scale, Bar Graph, Button, Clock Display, Multi-state bit map, Units, Numeric Input, the 11 geometric bitmaps, and lines of different widths. Use the same steps to add Static Text, Static Bitmap, and geometric bitmaps as for the start-up page.




(3) Add a numeric/ASCII display. On the toolbar, click the **Numeric/ASCII** button. In the page, double-click the object to specify the **Refer Device**, **Frame Setting**, **Font Setting** and **Alignment**.



Click [...]. In the **Refer Device** dialog box, choose the VFD communication port that you need. If you want to read the output frequency (H), set the **Absolute Addr.** to 2202. For other values, refer to the ACMD Modbus Comm Address List (see Pr.09-04 in Chapter 12 Group 09 Communication Parameters).




(4) Scale Setting. On the toolbar, click to add a scale. You can also edit the Scale Setting in the Property Window on the right-hand side of your computer screen.



- A. **Scale Position**: specifies where to place the scale.
- B. **Scale Side**: specifies whether the scale is numbered from smaller numbers to larger numbers or from larger to smaller.
- C. Font Setting: specifies the font.
- D. Value Length: specifies 16 bits or 32 bits.
- E. **Main Scale & Sub-Scale**: divides the whole scale into equal parts; enter the numbers for the main scale and sub-scale.
- F. Max Value & Min Value: specifies the numbers on the two ends of the scale. They can be negative numbers, but the maximum and minimum values are limited by the Value Length setting. For example, when Value Length is hexadecimal (16 bits), the maximum and the minimum value cannot be entered as -40000.


Clicking **OK** creates a scale as in the picture below.



(5) Bar Graph setting. On the toolbar, click ito add a bar graph.



- A. **Refer Device**: specifies the VFD communication port.
- B. Direction Setting: specifies the direction: From Bottom to Top, From Top to Bottom, From Left to Right or From Right to Left.
- C. **Max Value** and **Min Value**: specifies the maximum value and minimum value. A value smaller than or equal to the minimum value causes the bar graph to be blank (0). A value is bigger or equal to the maximum value causes the bar graph is full (100%). A value between the minimum and maximum values causes the bar graph to be filled proportionally.
- (6) Button \$\mathbb{S}\$: on the toolbar, click \$\mathbb{S}\$. Currently this function only allows the keypad to switch pages; other functions are not yet available (including text input and insert image). In the blank page, double-click \$\mathbb{S}\$ to open the Button Setting dialog box.



**Button Type**: specifies the button's functions.

Page Jump and Constant Setting are the only functions currently supported.

#### A. Page Jump Setting


- Page Jump Setting: in the Button Type list, choose Page Jump to show the Page Jump Setting.
- b. Function Key: specifies the functions for the following keys on the KPC-CC01 keypad: F1, F2, F3, F4, Up, Down, Left and Right. Note that the Up and Down keys are locked by TPEditor. You cannot program these two keys. If you want to program Up and Down keys, on the Tool menu, click Function Key Setting, and then click Re-Define Up/Down Key.



**c. Button Text**: specifies the text that appears on a button. For example, when you enter Next Page for the button text, that text appears on the button.

#### **B.** Constant setting

This function specifies the memory address' values for the VFD or PLC. When you press the **Function Key**, it writes a value to the memory address specified by the value for **Constant Setting**. You can use this function to initialize a variable.




Open a new page and click once in that window to add a clock display.

Choose to display **Time**, **Day**, or **Date** on the keypad. To adjust time, go to #8 on the keypad's menu. You can also specify the **Frame Setting**, **Font Setting**, and **Alignment**.



(8) Multi-state bitmap: on the toolbar, click . Open a new page and click once in that window to add a Multi-state bitmap. This object reads a bit's property value from the PLC. It defines the image or text that appears when this bit is 0 or 1. Set the initial status (**Current State**) to be 0 or 1 to define the displayed image or text.




(9) Unit Measurement: on the toolbar, click




Open a new blank page, and double-click on that window to display the **Units Setting** dialog box. Choose the Metrology Type and the Unit Name. For Metrology, the choices are Length, Square Measure, Volume/Solid Measure, Weight, Speed, Time, and Temperature. The unit name changes automatically when you change metrology type.



(10) Numeric Input Setting: on the toolbar, click



Open a new file and double click on that window to display the **Numeric Input Setting** dialog box.




- A. **Refer Device**: specifies the **Write** and the **Read** values. Enter the numbers to display and the corresponding parameter and communication port numbers. For example, enter 012C to Read and Write Parameter Pr.01-44.
- B. OutLine Setting: specifies the Frame Setting, Font Setting, Hori. Alignment, and Vert. Alignment for the outline.
- C. **Function Key**: specifies the function key to program on the keypad in the **Function Key** box. The corresponding key on the keypad starts to blink. Press ENTER to confirm the setting.
- D. Value Type and Value Length: specify the range of the Min Value and Max Value for the Limit Setting. Note that the corresponding supporting values for MS300 must be 16 bits. 32-bit values are not supported.
- E. **Value Setting**: automatically set by the keypad itself.
- F. **Limit Setting**: specifies the range for the numeric input here.


For example, if you set **Function Key** to **F1**, **Min Value** to 0 and **Max Value** to 4, when you press F1 on the keypad, then you can press Up/Down on the keypad to increase or decrease the value. Press ENTER on the keypad to confirm your setting. You can also view the parameter table 01-44 to verify if you correctly entered the value.


(11) Download TP Page: Press Up / Down on the keypad to select #13 PC Link.


Then press ENTER on the keypad. The screen displays "Waiting". In TPEditor, choose a page that you have created, and then on the **Communication** menu click **Write to TP** to start downloading the page to the keypad.

When you see "Completed" on the keypad screen, the download is finished. You can then press ESC on the keypad to go back to the menu screen.










## 10-4 Fault Code Description of Digital Keypad KPC-CC01



#### **Fault Codes**

LCD Display	Fault Name	Description	Corrective Actions
Fault FrEr kpd Flash Read Er	Flash memory read error (FrEr)	Keypad flash memory read error	Error in the keypad's flash memory.  1. Press RESET to clear the errors.  2. Check for any problem on Flash IC.  3. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your authorized local dealer for assistance.
Fault FsEr kpd Flash Save Er	Flash memory save error (FsEr)	Keypad flash memory save error	Error in the keypad's flash memory.  1. Press RESET to clear the errors.  2. Check for any problem on Flash IC.  3. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your authorized local dealer for assistance.
Fault FPEr kpd Flash Pr Er	Flash memory parameter error (FPEr)	Keypad flash memory parameter error	Error in the default parameters. It might be caused by a firmware update.  1. Press RESET to clear the errors.  2. Check for any problem on Flash IC.  3. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your authorized local dealer for assistance.
Fault VFDr Read VFD Info Er	Reading AC motor drive data error (VFDr)	Keypad error when reading AC motor drive data	<ul> <li>Keypad cannot read any data sent from the VFD.</li> <li>1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.</li> <li>2. Press RESET to clear the errors.</li> <li>3. Shut down the system, wait for ten minutes, and then restart the system.</li> <li>If none of the above solutions works, contact your authorized local dealer for assistance.</li> </ul>
Fault  CPUEr  CPU Error	CPU error (CPUEr)	Keypad CPU error	A serious error in the keypad's CPU.  1. Check for any problem on CPU clock.  2. Check for any problem on Flash IC.  3. Check for any problem on RTC IC.  4. Verify that the communication quality of the RS-485 cable is good.  5. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your authorized local dealer for assistance.

### Warning Codes

LCD Display	Warning Name	Description	Corrective Actions
Warning CE1 Comm. Error 1	Communication error 1 (CE1)	RS-485 Modbus illegal function code	Motor drive does not accept the communication command sent from the keypad.  1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.  2. Press RESET on the keypad to clear errors.  If none of the above solutions works, contact your local authorized dealer for assistance.
АИТО Warning CK1 Comm Command Er	Communication command error 1 (CK1)	Keypad communication data, illegal function code (Keypad auto- detect this error and display it)	Keypad does not accept the motor drive's communication command.  1. Remove the keypad and reconnect it.  2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2  3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solution works, contact your local authorized dealer.
Warning CE2 Comm. Error 2	Communication error 2 (CE2)	RS-485 Modbus illegal data address	Motor drive does not accept the keypad's communication address.  1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.  2. Press RESET to clear the errors. If none of the above solutions works, contact your local authorized dealer for assistance.
Аито Warning CK2 Comm Address Er	Communication address error (CK2)	Keypad communication data, illegal data address (Keypad auto- detect this error and display it)	Keypad does not accept the motor drive's communication command.  1. Remove the keypad and reconnect it.  2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2  3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solution works, contact your local authorized dealer.

Chapter 10 Digital Keypad | CFP2000

LCD Display	Warning Name	Description	Corrective Actions
Warning CE3 Comm. Error 3	Communication error 3 (CE3)	RS-485 Modbus illegal data value	Motor drive does not accept the communication data sent from the keypad.  1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.  2. Press RESET to clear the errors. If none of the above solutions works, contact your local authorized dealer for assistance.
АИТО Warning CK3 Comm Data Error	Communication data error (CK3)	Keypad communication data, illegal data value (Keypad auto-detect this error and display it)	Keypad does not accept the motor drive's communication command.  1. Remove the keypad and reconnect it.  2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2  3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solution works, contact your local authorized dealer.
Warning CE4 Comm. Error 4	Communication error 4 (CE4)	RS-485 Modbus data is written to read-only address	Motor drive cannot process the communication command sent from the keypad.  1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.  2. Press RESET to clear the errors.  3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
Аито Warning CK4 Comm Slave Error	Communication slave error (CK4)	Keypad communication data is written to read- only address (Keypad auto-detect this error and display it)	Keypad does not accept the motor drive's communication command.  1. Remove the keypad and reconnect it.  2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2  3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solution works, contact your local authorized dealer.


LCD Display	Warning Name	Description	Corrective Actions
Warning CE10 Comm. Error 10	Communication error 10 (CE10)	Modbus transmission time-Out	Motor drive does not respond to the communication command sent from the keypad.  1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.  2. Press RESET to clear the errors.  3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
Аито Warning CK10 KpdComm Time Out	Keypad communication time out (CK10)	Digital keypad transmission time-out (The keypad automatically detects and shown this warning)	Keypad does not accept the motor drive's communication command.  1. Remove the keypad and reconnect it.  2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2  3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45. If none of the above solution works, contact your local authorized dealer.
Warning TPNO TP No Object	TP object not defined (TPNO)	Object not supported by TP Editor	<ul> <li>Keypad's TPEditor uses an unsupported object.</li> <li>1. Verify that the TPEditor is not using an unsupported object or setting. Delete unsupported objects and unsupported settings.</li> <li>2. Re-edit the object in the TPEditor, and then download it to the keypad.</li> <li>3. Verify that the motor drive supports the TP functions. If the drive does not support TP function, the main page displays Default.</li> <li>If none of the above solutions works, contact your local authorized dealer for assistance.</li> </ul>

**NOTE:** The warning code CExx only occurs when the communication problem is between the drive and the keypad. It has nothing to do with the drive and other devices. Note the warning code description to find the cause of the error if CExx appears.

#### Chapter 10 Digital Keypad | CFP2000

File Copy Setting Fault Description:

These faults occur when KPC-CC01 cannot perform the command after clicking the ENTER key in the copy function.



LCD Display	Fault Name	Description	Corrective Actions
001> P00-00 ERR1 Read Only	Read only (ERR1)	Parameter and file are read-only	The parameter / file is read-only and cannot be written to.  1. Verify the specification in the user manual.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00  ERR2  Write Fail	Write in error (ERR2)	Fail to write parameter and file	An error occurred while writing to a parameter / file.  1. Check for any problem on the Flash IC.  2. Shut down the system, wait for ten minutes, and then restart the system.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00 ERR3 VFD Running	Drive operating (ERR3)	AC motor drive is in operating status	A setting cannot be changed while the motor drive is in operation.  1. Verify that the drive is not in operation.  If this solution does not work, contact your local authorized dealer for assistance.
001> P00-00 ERR4 Pr Lock	Parameter locked (ERR4)	AC motor drive parameter is locked	A setting cannot be changed because a parameter is locked.  1. Check if the parameter is locked. If it is locked, unlock it and try to set the parameter again.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00  ERR5  Pr Changing	Parameter changing (ERR5)	AC motor drive parameter is changing	A setting cannot be changed because a parameter is being modified.  1. Check if the parameter is being modified. If it is not being modified, try to change that parameter again.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00  ERR6  Fault Code	Fault code (ERR6)	Fault code is not cleared	A setting cannot be changed because an error has occurred in the motor drive.  1. Check if any error occurred in the motor drive. If there is no error, try to change the setting again.  If this solution does not work, contact your local authorized dealer for assistance.

LCD Display	Fault Name	Description	Corrective Actions
. ,		·	A setting cannot be changed because of a
ERR7 Warning Code	Warning code (ERR7)	Warning code is not cleared	warning message given to the motor drive.  1. Check if there is a warning message given to the motor drive.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00  ERR8  Type Mismatch	File type mismatch (ERR8)	File type mismatch	Data to be copied are not the correct type, so the setting cannot be changed.  1. Check if the products' serial numbers to be copied are in the same category. If they are in the same category, try to copy the setting again.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00  ERR9  Password Lock	Password locked (ERR9)	File is locked with password	A setting cannot be changed because some data are locked.  1. Check if the data are unlocked or able to be unlocked. If the data are unlocked, try to change the setting again.  2. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
P00-00  ERR10  Password Fail	Password fail (ERR10)	File password mismatch	A setting cannot be changed because the password is incorrect.  1. Check if the password is correct. If the password is correct, try to change the setting again.  2. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.
P00-00  ERR11  Version Fail	Version fail (ERR11)	File version mismatch	A setting cannot be changed because the version of the data is incorrect.  1. Check if the version of the data matches the motor drive. If it matches, try to change the setting again.  If none of the above solutions works, contact your local authorized dealer for assistance.

Chapter 10 Digital Keypad | CFP2000

LCD Display	Fault Name	Description	Corrective Actions
001> P00-00 ERR12 VFD Time Out	VFD Time out (ERR12)	AC motor drive copy function time-out	A setting cannot be changed because the data copying time-out expired.  1. Try copying the data again.  2. Check if copying data is authorized. If it is authorized, try to copy the data again.  3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your local authorized dealer for assistance.


NOTE: The content in this chapter only applies on V1.01 and above of KPC-CC01 keypad.

### 10-5 Unsupported Functions when using TPEditor with the KPC-CC01


1. Local Page Setting and Global Setting functions are not supported.



2. In the **Communication** menu, **Read from TP** function is not supported.



3. In the RTC Display Setting, you cannot change the Refer Device.



[This page is intentionally left blank]

- 00 Drive Parameters
- 01 Basic Parameters
- 02 Digital Input / Output Parameters
- 03 Analog Input / Output Parameters
- 04 Multi-step Speed Parameters
- 05 Motor Parameters
- 06 Protection Parameters
- 07 Special Parameters
- 08 High-function PID Parameters
- 09 Communication Parameters
- 10 Sensorless Motor Control Parameters
- 11 Advanced Parameters (Applied to 230V / 460V models)
- 12 PUMP Parameters
- 13 Application Parameters by Industry
- 14 Extension Card Parameters

This chapter provides a summary of parameter (Pr.) setting ranges and defaults. You can set, changed and reset parameters through the digital keypad.

#### NOTE:

- 1. **\( \nabla \)**: You can set this parameter during operation
- 2. For more details on parameters, refer to Chapter 12 Description of Parameter Settings.
- 3. The following are abbreviations for different types of motors:
  - IM: Induction motor
  - PM: Permanent magnet synchronous AC motor
  - IPM: Interior permanent magnet synchronous AC motor
  - SPM: Surface permanent magnet synchronous AC motor
  - SynRM: Synchronous reluctance motor

#### **00 Drive Parameters**

Pr.	Parameter Name	Settings Range	Default
		4: 230V, 0.75 kW	
		5: 460V, 0.75 kW	
		6: 230V, 1.50 kW	
	4: 230V, 0.75 kW 5: 460V, 0.75 kW 6: 230V, 1.50 kW 7: 460V, 1.50 kW 8: 230V, 2.20 kW 9: 460V, 2.20 kW 10: 230V, 3.70 kW 11: 460V, 3.70 kW 12: 230V, 5.50 kW 13: 460V, 5.50 kW 14: 230V, 7.50 kW 15: 460V, 7.50 kW 16: 230V, 11.0 kW		
		8: 230V, 2.20 kW	
		9: 460V, 2.20 kW	
		10: 230V, 3.70 kW	
		11: 460V, 3.70 kW	
		12: 230V, 5.50 kW	
		13: 460V, 5.50 kW	
		14: 230V, 7.50 kW	
	15: 460V, 7: 16: 230V, 1	15: 460V, 7.50 kW	
		16: 230V, 11.0 kW	
00-00	AC Motor Drive Identity Code	17: 460V, 11.0 kW	Read
00-00	AC Motor Drive Identity Code	18: 230V, 15.0 kW	only
		19: 460V, 15.0 kW	
		20: 230V, 18.5 kW	
		21: 460V, 18.5 kW	
		22: 230V, 22.0 kW	
		23: 460V, 22.0 kW	
		24: 230V, 30.0 kW	
		25: 460V, 30.0 kW	
		26: 230V, 37.0 kW	
		27: 460V, 37.0 kW	
		28: 230V, 45.0 kW	
		29: 460V, 45.0 kW	
		31: 460V, 55.0 kW	
		33: 460V, 75.0 kW	

Pr.	Parameter Name	Settings Range	Default
		35: 460V, 90.0 kW	
		93: 460V, 4.00 kW	
		505: 575V, 1.5 kW	
		506: 575V, 2.2 kW	
		507: 575V, 3.7 kW	
		508: 575V, 5.5 kW	
		509: 575V, 7.5 kW	
		510: 575V, 11 kW	
		511: 575V, 15 kW	
		512: 575V, 18.5 kW	
		513: 575V, 22 kW	
		514: 575V, 30 kW	
		515: 575V, 37 kW	
		516: 575V, 45 kW	
		517: 575V, 55 kW	
		518: 575V, 75 kW	
		519: 575V, 90 kW	
00-01	AC Motor Drive Rated Current	Dienley by medele	Read
00-01	Display	Display by models	only
		0: No function	
		1: Write protection for parameters	
		5: Reset kWh display to 0	
		6: Reset PLC (including CANopen Master Index)	
00-02	Parameter Reset	7: Reset CANopen Slave Index	0
		9: Reset all parameters to defaults	
		(base frequency is 50 Hz)	
		10: Reset all parameters to defaults	
		(base frequency is 60 Hz)	
		0: F (frequency command)	
00-03	Start-Up Display	1: H (output frequency)	0
00-03	Start-Op Display	2: U (user-defined, see Pr.00-04)	
		3: A (output current)	
		0: Display output current (A) (Unit: Amp)	
		1: Display counter value (c) (Unit: CNT)	
		2: Display the motor's actual output frequency (H.)	
00-04	Content of Multi-Function	(Unit: Hz)	3
00-04	Display (User-Defined)	3: Display the drive's DC bus voltage (v) (Unit: V <sub>DC</sub> )	3
		4: Display the drive's output voltage (E) (Unit: V <sub>AC</sub> )	
		5: Display the drive's output power angle (n)	
		(Unit: deg)	

Pr.	Parameter Name	Settings Range	Default
		6: Display the drive's output power (P) (Unit: kW)	
		7: Display the motor speed rpm (r) (Unit: rpm)	
		10: Display PID feedback (b) (Unit: %)	
		11: Display AVI1 analog input terminal signal (1.)	
		(Unit: %)	
		12: Display ACI analog input terminal signal (2.)	
		(Unit: %)	
		13: Display AVI2 analog input terminal signal (3.)	
		(Unit: %)	
		14: Display the drive's IGBT temperature (i.)	
		(Unit: °C)	
		15: Display the drive's capacitance temperature (c.)	
		(Unit: °C)	
		16: The digital input status (ON / OFF) (i)	
		17: The digital output status (ON / OFF) (o)	
		18: Display multi-step speed (S)	
		19: The corresponding CPU digital input pin status (d)	
		20: The corresponding CPU digital output pin status	
		(0.)	
		26: Ground fault GFF (G.) (Unit: %)	
		27: DC bus voltage ripple (r.) (Unit: V <sub>DC</sub> )	
		28: Display PLC register D1043 data (C)	
		30: Display the output of user-defined (U)	
		31: Display Pr.00-05 user gain (K)	
		34: Operation speed of fan (F.) (Unit: %)	
		36: Present operating carrier frequency of the drive	
		(J.) (Unit: Hz)	
		38: Display the drive status (6.)	
		41: kWh display (J) (Unit: kWh)	
		42: PID target value (h.) (Unit: %)	
		43: PID compensation (o.) (Unit: %)	
		44: PID output frequency (b.) (Unit: Hz)	
		45: Hardware ID	
		51: PMSVC torque offset	
		52: AI10%	
		53: AI11%	
		54: PMFOC Ke estimation value	
		68: STO version	
		69: STO checksum-high word (d)	
		70: STO checksum-low word (d)	

	Pr.	Parameter Name	Se	ettings Rar	ige		Default
*	00-05	Coefficient Gain in Actual Output Frequency	0.00–160.00				1.00
	00-06	Firmware Version	Read only				Read only
	00-07	Parameter Protection Password	0–65535				0
_	00-07	Input	0-4: the number of pa	assword at	tempts all	owed	U
			0–65535				
~	00-08	Parameter Protection Password	0: No password prote	ction or pa	ssword er	ntered	0
	00-00	Setting	correctly (Pr.00-07)	)			o o
			1: Parameter has bee	en set			
			0: IMVF (IM V/F contr	ol)			
			2: IM / PM SVC (IM /	PM Space	vector co	ntrol)	
	00-11	Speed Control Mode	6: PM Sensorless (PM		nted sense	orless	0
	00-11	opeed Control Mode	vector control) (app	olied to 230	OV / 460V	models)	O
			8: SynRM Sensorless	control (a	pplied to 2	230V / 460V	
			models)				
			bit0: Enable or disable	е			
	00-15	Start Wizard	0: Disable				1
			1: Enable				
	00-16	Load Selection	0: Light duty				0
			1: Normal duty				
			230V / 460V models				
			Control mode Model	VF, SVC	PMFOC	SRMFOC*	
			VFD007–110FP2EA VFD007–185FP4EA	2–15	4–10	4–8	
			VFD150-300FP2EA VFD220-750FP4EA	2–10	4–10	4–8	6
	00-17	Carrier Frequency (kHz)	VFD370-450FP2EA VFD900FP4EA	2–9	4–9	4–8	
			*The default is 4 kHz	in SRMFO	C mode.	<u>,                                      </u>	
			575V models				
			Control mode  Model		VF, SVC		
			VFD015–185FP5EA		2–15		6
			VFD220-550FP5EA		2–10		
			VFD750–900FP5EA		2-10		
			VI 2700 00011 0LA				
	00-19	PLC Command Mask	bit0: Control comman		•		Read
			bit1: Frequency comm	nand is for	ced by PL	C control	only

	Pr.	Parameter Name	Settings Range	Default
			0: Digital keypad	
		Master Frequency Command Source (AUTO) / Source	1: RS-485 communication input	
	00-20		2: External analog input (Refer to Pr.03-00–Pr.03-02)	
			3: External UP / DOWN terminal (multi-function input	0
	00-20	,	terminals)	0
		Selection of the PID Target	6: CANopen communication card	
			8: Communication card (does not include CANopen	
			card)	
			0: Digital keypad	
			1: External terminals	
	00.04	Operation Command Source	2: RS-485 communication input	
	00-21	(AUTO)	3: CANopen communication card	0
			5: Communication card (does not include CANopen	
			card)	
			0: Ramp to stop	
×	00-22	Stop Method	1: Coast to stop	0
			0: Enable forward / reverse	
×	00-23	Motor Direction Control	1: Disable reverse	0
			2: Disable forward	
	00.04	Digital Operator (Keypad)		Read
	00-24	Frequency Command Memory	Read only	only
			bit0–3: user-defined decimal place	
			0000b: no decimal place	
			0001b: one decimal place	
			0010b: two decimal places	
			0011b: three decimal places	
			bit4–15: user-defined unit	
			000xh: Hz	
			001xh: rpm	
			002xh: %	
×	00-25	User-Defined Characteristics	003xh: kg	0
			004xh: m/s	
			005xh: kW	
			006xh: HP	
			007xh: ppm	
			008xh: 1/m	
			009xh: kg/s	
			00Axh: kg/m	
			00Bxh: kg/h	
				1

Pr.	Parameter Name	Settings Range	Default
		00Dxh: lb/m	
		00Exh: lb/h	
		00Fxh: ft/s	
		010xh: ft/m	
		011xh: m	
		012xh: ft	
		013xh: degC	
		014xh: degF	
		015xh: mbar	
		016xh: bar	
		017xh: Pa	
		018xh: kPa	
		019xh: mWG	
		01Axh: inWG	
		01Bxh: ftWG	
		01Cxh: psi	
		01Dxh: atm	
		01Exh: L/s	
		01Fxh: L/m	
		020xh: L/h	
		021xh: m3/s	
		022xh: m3/h	
		023xh: GPM	
		024xh: CFM	
		xxxxh: Hz	
		0: No function	
		0–65535 (when Pr.00-25 set to no decimal place)	
00-26	Maximum User-Defined Value	0.0–6553.5 (when Pr.00-25 set to 1 decimal place)	0
		0.00–655.35 (when Pr.00-25 set to 2 decimal places)	
		0.000–65.535 (when Pr.00-25 set to 3 decimal places)	
00-27	User-Defined Value	Read only	Read
			only
		bit0: Sleep function control bit	
		0: Cancel sleep function	
		1: Sleep function and AUTO mode are the same	
00-28	Switching from AUTO Mode to	bit1: Control bit unit	
	HAND Mode	0: Displaying unit in Hz	
		1: Same unit as the AUTO mode	
		bit2: PID control bit	
		0: Cancel PID control	

Pr.	Parameter Name	Settings Range	Default
		1: PID control and AUTO mode are the same	
		bit3: Frequency source control bit	
		0: Frequency source set up by parameter, if the	
		multi-step speed is activated, then multi-step	
		speed has the priority.	
		1: Frequency command set up by Pr.00-30,	
		regardless of whether the multi-step speed is	
		activated.	
		0: Standard HOA function	
		1: When switching between local and remote, the	
		drive stops	
		2: When switching between local and remote, the	
		drive runs with REMOTE settings for frequency and	
		operation status	
		3: When switching between local and remote, the	
00-29	LOCAL / REMOTE Selection	drive runs with LOCAL setting for frequency and	0
		operation status	
		4: When switching between local and remote, the	
		drive runs with LOCAL settings when switched to	
		Local and runs with REMOTE settings when	
		switched to Remote for frequency and operation	
		status.	
		0: Digital keypad	
		1: RS-485 communication input	
		2: External analog input (Pr.03-00–Pr.03-02)	
00-30	Master Frequency Command	3: External UP / DOWN terminal	0
	Source (HAND)	6: CANopen communication card	
		8: Communication card (does not include CANopen	
		card)	
		0: Digital keypad	
		1: External terminals	
	Operation Command Source	2: RS-485 communication input	
00-31	(HAND)	3: CANopen communication card	0
		5: Communication card (does not include CANopen	
		card)	
00.55	D. 11.11.	0: STOP key disabled	_
00-32	Digital Keypad STOP Function	1: STOP key enabled	0
		0: Disable	
00-33	RPWM Mode Selection	1: RPWM mode 1	0
		2: RPWM mode 2	

264

	Pr.	Parameter Name	Settings Range	Default
			3: RPWM mode 3	
×	00-34	RPWM Range	0.0–4.0 kHz	0.0
×	00-37	Over-Modulation Gain	80–120	100
×	00-48	Display Filter Time (Current)	0.001–65.535 sec.	0.100
×	00-49	Display Filter Time (Keypad)	0.001–65.535 sec.	0.100
	00-50	Software Version (Date)	Read only	Read
	00-30	Software version (Date)	rtead only	only

### **01 Basic Parameters**

	Pr.	Parameter Name	Settings Range	Default
*	01-00	Maximum Operation Frequency of Motor 1	0.00–599.00 Hz	60.00 / 50.00
	01-01	Rated / Base Frequency of Motor	0.00-599.00 Hz	60.00 / 50.00
			230V models: 0.0–255.0 V	200.0
	01-02	Rated / Base Voltage of Motor 1	460V models: 0.0–510.0 V	400.0
		_	575V models: 0.0–637.0 V	575.0
	01-03	Mid-Point Frequency 1 of Motor 1	0.00–599.00 Hz	3.00 /
			230V models: 0.0–240.0 V	11.0
N	01-04	Mid-Point Voltage 1 of Motor 1	460V models: 0.0–480.0 V	22.0
		Ü	575V models: 0.0–637.0 V	0.0
	01-05	Mid-Point Frequency 2 of Motor 1	0.00–599.00 Hz	1.50
		<u> </u>	230V models: 0.0–240.0 V	5.0
×	01-06	Mid-Point Voltage 2 of Motor 1	460V models: 0.0–480.0 V	10.0
			575V models: 0.0–637.0 V	0.0
	01-07	Minimum Output Frequency of Motor 1	0.00–599.00 Hz	0.50
		Minimum Outrot Valtage of Mater	230V models: 0.0–240.0 V	1.0
×	01-08	Minimum Output Voltage of Motor  1	460V models: 0.0–480.0 V	2.0
		1	575V models: 0.0–637.0 V	0.0
	01-09	Start-Up Frequency	0.00–599.00 Hz	0.50
×	01-10	Output Frequency Upper Limit	0.00–599.00 Hz	599.00
×	01-11	Output Frequency Lower Limit	0.00–599.00 Hz	0.00
			Pr.01-45 = 0: 0.00–600.00 sec.	
×	01-12	Acceleration Time 1	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
			Pr.01-45 = 0: 0.00–600.00 sec.	
×	01-13	Deceleration Time 1	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
			Pr.01-45 = 0: 0.00–600.00 sec.	
×	01-14	Acceleration Time 2	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
.,	04.45	Deceleration Toy 0	Pr.01-45 = 0: 0.00–600.00 sec.	40.00
*	01-15	Deceleration Time 2	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
	01.16	Appolaration Time 2	Pr.01-45 = 0: 0.00-600.00 sec.	10.00
7	01-16	Acceleration Time 3	Pr.01-45 = 1: 0.0–6000.0 sec.  Motor drive with 22 kW and above: 60.00 / 60.0	10.00
			iviolor drive with 22 kvv and above: 60.00 / 60.0	

	Pr.	Parameter Name	Settings Range	Default
			Pr.01-45 = 0: 0.00–600.00 sec.	
×	01-17	Deceleration Time 3	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
			Pr.01-45 = 0: 0.00–600.00 sec.	
×	01-18	Acceleration Time 4	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
			Pr.01-45 = 0: 0.00-600.00 sec.	
×	01-19	Deceleration Time 4	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
			Pr.01-45 = 0: 0.00-600.00 sec.	
×	01-20	JOG Acceleration Time	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
			Pr.01-45 = 0: 0.00-600.00 sec.	
×	01-21	JOG Deceleration Time	Pr.01-45 = 1: 0.0–6000.0 sec.	10.00
			Motor drive with 22 kW and above: 60.00 / 60.0	
×	01-22	JOG Frequency	0.00–599.00 Hz	6.00
	01-23	Switch Frequency between First	0.00–599.00 Hz	0.00
~	01-23	and Fourth Accel. / Decel.	0.00-599.00 HZ	0.00
	01-24	S-Curve for Acceleration Begin	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
~	01-24	Time 1	Pr.01-45 = 1: 0.0–250.0 sec.	0.20
	01-25	S-Curve for Acceleration Arrival	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
~	01-25	Time 2	Pr.01-45 = 1: 0.0–250.0 sec.	0.20
	04.00	S-Curve for Deceleration Begin	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
×	01-26	Time 1	Pr.01-45 = 1: 0.0–250.0 sec.	0.20
	01-27	S-Curve for Deceleration Arrival	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
~	01-27	Time 2	Pr.01-45 = 1: 0.0–250.0 sec.	0.20
	01-28	Skip Frequency 1 (Upper Limit)	0.00–599.00 Hz	0.00
	01-29	Skip Frequency 1 (Lower Limit)	0.00–599.00 Hz	0.00
	01-30	Skip Frequency 2 (Upper Limit)	0.00–599.00 Hz	0.00
	01-31	Skip Frequency 2 (Lower Limit)	0.00–599.00 Hz	0.00
	01-32	Skip Frequency 3 (Upper Limit)	0.00–599.00 Hz	0.00
	01-33	Skip Frequency 3 (Lower Limit)	0.00–599.00 Hz	0.00
			0: Output waiting	
	01-34	Zero-Speed Mode	1: Zero-speed operation	0
	01-34	Zero-opeeu Mode	2: Minimum frequency (Refer to Pr.01-07 and	0
			Pr.01-41)	
	01-35	Rated / Base Frequency of Motor	0.00 500 00 Hz	60.00 /
	01-35	2	0.00–599.00 Hz	50.00
	01-36	Pated / Rase Voltage of Mater 2	230V models: 0.0–255.0 V	200.0
	01-30	Rated / Base Voltage of Motor 2	460V models: 0.0–510.0 V	400.0

	Pr.	Parameter Name	Settings Range	Default
			575V models: 0.0–637.0 V	575.0
	01-37	Mid-Point Frequency 1 of Motor 2	0.00–599.00 Hz	3.00
			230V models: 0.0–240.0 V	11.0
×	01-38	Mid-Point Voltage 1 of Motor 2	460V models: 0.0–480.0 V	22.0
			575V models: 0.0–637.0 V	0.0
	01-39	Mid-Point Frequency 2 of Motor 2	0.00–599.00 Hz	1.50
			230V models: 0.0–240.0 V	5.0
×	01-40	Mid-Point Voltage 2 of Motor 2	460V models: 0.0–480.0 V	10.0
			575V models: 0.0–637.0 V	0.0
	01-41	Minimum Output Frequency of Motor 2	0.00–599.00 Hz	0.50
		M: : 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	230V models: 0.0–240.0 V	1.0
×	01-42	Minimum Output Voltage of Motor	460V models: 0.0–480.0 V	2.0
		2	575V models: 0.0–637.0 V	0.0
			0: V/F curve determined by Pr.01-00-01-08	
			1: V/F curve to the power of 1.5	
		01-43 V/F Curve Selection	2: V/F curve to the power of 2	
			3: 60 Hz, voltage saturation in 50 Hz	
			4: 72 Hz, voltage saturation in 60 Hz	
			5: 50 Hz, decrease gradually with cube	
			6: 50 Hz, decrease gradually with square	
	01-43		7: 60 Hz, decrease gradually with cube	0
	01-40		8: 60 Hz, decrease gradually with square	
			9: 50 Hz, medium starting torque	
			10: 50 Hz, high starting torque	
			11: 60 Hz, medium starting torque	
			12: 60 Hz, high starting torque	
			13: 90 Hz, voltage saturation in 60 Hz	
			14: 120 Hz, voltage saturation in 60 Hz	
			15: 180 Hz, voltage saturation in 60 Hz	
			0: Linear acceleration and deceleration	
			1: Auto-acceleration and linear deceleration	
×	01-44	Auto-Acceleration and Auto-	2: Linear acceleration and auto-deceleration	0
		Deceleration Setting	3: Auto-acceleration and auto-deceleration	
			4: Stall prevention by auto-acceleration and auto-	
		The state of the American	deceleration (limited by Pr.01-12–01-21)	
	01-45	Time Unit for Acceleration /	0: Unit: 0.01 sec.	0
		Deceleration and S-Curve	1: Unit: 0.1 sec.	4.00
×	01-46	CANopen Quick Stop Time	Pr.01-45 = 0: 0.00–600.00 sec.	1.00
			Pr.01-45 = 1: 0.0–6000.0 sec.	1.0

	Pr.	Parameter Name	Settings Range	Default
	01-49	TEC Function Selection	0: Disable	0
	01-43	TEC Function Selection	1: Enable	
	01-50	Electromagnetic Traction Energy	0.00–5.00 Hz	0.50
~	01-30	Consumption Coefficient	0.00-5.00 HZ	0.50
		Flux-Weakening Overload Stall		
×	01-51	Prevention Time	0.00-600.00 sec.	1.00
		(Applied to 230V / 460V Models)		

# **02 Digital Input / Output Parameters**

Pr.	Parameter Name	Setting Range	Default
02-00	Two-Wire / Three-Wire Operation Control	0: Two-wire mode 1, power on for operation control  1: Two-wire mode 2, power on for operation control  2: Three-wire, power on for operation control	0
02-01	Multi-Function Input Command 1 (MI1)	No function     Nulti-step speed command 1	1
02-02	Multi-Function Input Command 2 (MI2)	2: Multi-step speed command 2 3: Multi-step speed command 3	2
02-03	Multi-Function Input Command 3 (MI3)	4: Multi-step speed command 4 5: Reset	3
02-04	Multi-Function Input Command 4 (MI4)	6: JOG command (By external control or KPC-CC01)	4
02-05	Multi-Function Input Command 5 (MI5)	7: Acceleration / deceleration speed inhibit 8: 1st and 2nd acceleration / deceleration time	0
02-06	Multi-Function Input Command 6 (MI6)	selection 9: 3 <sup>rd</sup> and 4 <sup>th</sup> acceleration / deceleration time	0
02-07	Multi-Function Input Command 7 (MI7)	selection 10: External Fault (EF) input (Pr.07-20)	0
02-08	Multi-Function Input Command 8 (MI8)	11: Base Block (B.B) input from external 12: Output voltage stops	0
02-26	Input Terminal of I/O Extension Card (MI10)	13: Cancel the setting of auto-acceleration / auto-deceleration time	0
02-27	Input Terminal of I/O Extension Card (MI11)	14: Switch between motor 1 and motor 2 15: Rotating speed command from AVI1	0
02-28	Input Terminal of I/O Extension Card (MI12)	16: Rotating speed command from ACI 17: Rotating speed command from AVI2	0
02-29	Input Terminal of I/O Extension Card (MI13)	18: Forced to stop (Pr.07-20) 19: Frequency up command	0
02-30	Input Terminal of I/O Extension Card (MI14)	20: Frequency down command 21: PID function disabled	0
02-31	Input Terminal of I/O Extension Card (MI15)	22: Clear the counter 23: Input the counter value (MI6)	0
		24: FWD JOG command 25: REV JOG command 28: Emergency stop (EF1) 29: Signal confirmation for Y-connection 30: Signal confirmation for △-connection 38: Disable write EEPROM function	

	Pr.	Parameter Name	Setting Range	Default
			40: Force coasting to stop	
			41: HAND switch	
			42: AUTO switch	
			49: Enable drive	
			50: Slave dEb action to execute	
			51: Selection for PLC mode bit0	
			52: Selection for PLC mode bit1	
			53: Trigger CANopen quick stop	
			54: UVW output electromagnetic valve switch	
			55: Brake release	
			56: Local / Remote selection	
			58: Enable fire mode (with RUN command)	
			59: Enable fire mode (without RUN command)	
			60: Disable all the motors	
			61: Disable Motor 1	
			62: Disable Motor 2	
			63: Disable Motor 3	
			64: Disable Motor 4	
			65: Disable Motor 5	
			66: Disable Motor 6	
			67: Disable Motor 7	
			68: Disable Motor 8	
			69: Enable preheating function	
~	02-09	External Terminal UP / DOWN Key	0: By the acceleration / deceleration time	0
~	02-09	Mode	1: Constant speed (Pr.02-10)	U
~	02-10	External Terminal Speed of the UP /	0.001–1.000 Hz / ms	0.001
~	02-10	DOWN Key	0.001-1.000112711IS	0.001
N	02-11	Multi-Function Input Response Time	0.000-30.000 sec.	0.005
N	02-12	Multi-Function Input Mode Selection	0000h-FFFFh (0: N.O.; 1: N.C.)	0000h
N	02-13	Multi-Function Output 1 RLY1	0: No function	11
N	02-14	Multi-Function Output 2 RLY2	1: Indication during RUN	1
N	02-15	Multi-Function Output 3 RLY3	2: Operation speed reached	66
	02.26	Output Terminal of I/O Extension	3: Desired frequency reached 1 (Pr.02-22)	0
<b>*</b>	02-36	Card (MO10) or (RA10)	4: Desired frequency reached 2 (Pr.02-24)	0
.,	02-37	Output Terminal of I/O Extension	5: Zero speed (Frequency command)	0
*	02-37	Card (MO11) or (RA11)	6: Zero speed including STOP (Frequency	0
,	00.00	Output Terminal of I/O Extension	command)	0
~	02-38	Card-(RA12)	7: Over-torque 1 (Pr.06-06-08)	0
,	00.00	Output Terminal of I/O Extension	8: Over-torque 2 (Pr.06-09–06-11)	
<b>*</b>	02-39	Card (RA13)	9: Drive is ready	0
				t

	Pr.	Parameter Name	Setting Range	Default
	02.40	Output Terminal of I/O Extension	10: Low voltage warning (Lv) (Pr.06-00)	0
*	02-40	Card (RA14)	11: Malfunction indication	0
	02-41	Output Terminal of I/O Extension	12: Mechanical brake release (Pr.02-32)	0
~		Card (RA15)	13: Overheat warning (Pr.06-15)	U
	02-42	Output Terminal of I/O Extension	14: Software brake signal indication (Pr.07-00)	0
^	02-42	Card (MO16 Virtual Terminal)	15: PID feedback error (Pr.08-13, Pr.08-14)	U
<b>.</b>	02-43	Output Terminal of I/O Extension	16: Slip error (oSL)	0
^	02-43	Card (MO17 Virtual Terminal)	17: Count value reached, does not return to 0	U
	02-44	Output Terminal of I/O Extension	(Pr.02-20)	0
^	02-44	Card (MO18 Virtual Terminal)	18: Count value reached, returns to 0	U
	02-45	Output Terminal of I/O Extension	(Pr.02-19)	0
^	02-43	Card (MO19 Virtual Terminal)	19: External interrupt B.B. input (Base Block)	U
	02-46	Output Terminal of I/O Extension	20: Warning output	0
_	02-40	Card (MO20 Virtual Terminal)	21: Over-voltage	U
			22: Over-current stall prevention	
			23: Over-voltage stall prevention	
			24: Operation mode	
			25: Forward command	
			26: Reverse command	
			27: Output when current ≥ Pr.02-33	
			28: Output when current < Pr.02-33	
			29: Output when frequency ≥ Pr.02-34	
			30: Output when frequency < Pr.02-34	
			31: Y-connection for the motor coil	
			32: △-connection for the motor coil	
			33: Zero speed (actual output frequency)	
			34: Zero speed including stop (actual output	
			frequency)	
			35: Error output selection 1 (Pr.06-23)	
			36: Error output selection 2 (Pr.06-24)	
			37: Error output selection 3 (Pr.06-25)	
			38: Error output selection 4 (Pr.06-26)	
			40: Speed reached (including stop)	
			44: Low current output (use with Pr.06-71–06-73)	
			45: UVW output electromagnetic valve switch	
			46: Master dEb output	
			50: Output control for CANopen	
			51: Analog output control for RS-485 interface	
			(InnerCOM / Modbus)	
			52: Output control for communication cards	

	Pr.	Parameter Name	Setting Range	Default
			53: Fire mode indication	
			54: Bypass fire mode indication	
			55: Motor 1 output	
			56: Motor 2 output	
			57: Motor 3 output	
			58: Motor 4 output	
			59: Motor 5 output	
			60: Motor 6 output	
			61: Motor 7 output	
			62: Motor 8 output	
			66: SO output logic A	
			67: Analog input level reached	
			68: SO output logic B	
			69: Preheating output indication	
×	02-18	Multi-Function Output Direction	0000h-FFFFh (0: N.O.; 1: N.C.)	0000h
	02-19	Terminal Counting Value Reached	0–65500	0
^	02-19	(Returns to 0)	0-65500	0
	02-20	Preliminary Counting Value Reached	0–65500	0
^	02-20	(Does not Return to 0)		U
<b>₩</b>	02-22	Desired Frequency Reached 1	0.00–599.00 Hz	60.00 /
^	02-22	Desired Frequency Reached 1	0.00-399.00 112	50.00
	02-23	The Width of the Desired Frequency	0.00–599.00 Hz	2.00
<i>/</i> ·	02-20	Reached 1	0.00 000.00 112	2.00
~	02-24	Desired Frequency Reached 2	0.00–599.00 Hz	60.00 /
<i>/</i>	02-24	Desired Frequency Reached 2	0.00-399.00 112	50.00
N	02-25	The Width of the Desired Frequency	0.00–599.00 Hz	2.00
,	02 20	Reached 2	0.00 000.00 112	2.00
	02-32	Brake Delay Time	0.000–65.000 sec.	0.000
×	02-33	Output Current Level Setting for	0–150%	0
,		Multi-Function Output Terminals	- 1007	
N	02-34	Output Frequency Setting for Multi-	0.00–599.00 Hz	3.00
,		Function Output Terminals		0.00
	02-35	External Operation Control Selection	0: Disable	
×		35 after Reset and Reboot	1: Drive runs if the RUN command remains after	0
			reset or reboot	
	02-50	Display The Status of Multi-Function	Monitor the status of multi-function input	Read
		Input Terminal	terminals	only
	02-51	Display The Status of Multi-Function	Monitor the status of multi-function output	Read
	5 <u>-</u> 51	Output Terminal	terminals	only

Pr.	Parameter Name	Setting Range	Default
02-52	Display the External Multi-Function	Monitor the status of PLC input terminals	Read
02-32	Input Terminals Used by PLC	ivionitor the status of PLC input terminals	only
02-53	Display the External Multi-Function	Monitor the status of PLC output terminals	Read
02-33	Output Terminals Used by PLC	information the status of PLC output terminals	only
02-54	Display the Frequency Command	0.00, 500,00 Hz (Road only)	Read
02-34	Executed by External Terminal	0.00–599.00 Hz (Read only)	only
		1: EMC-BPS01	
	IO Card Types	4: EMC-D611A	Read
02-70		5: EMC-D42A	
		6: EMC-R6AA	only
		11: EMC-A22A	
02-72	Preheating Output Current Level	0–100%	0
02-73	Preheating Output Cycle	0–100%	0

274

# 03 Analog Input / Output Parameters

	Pr.	Parameter Name	Setting Range	Default
×	03-00	AVI1 Analog Input Selection	0: No function	1
×	03-01	ACI Analog Input Selection	1: Frequency command (speed limit under torque	0
×	03-02	AVI2 Analog Input Selection	control mode)	0
ŀ			4: PID target value	
			5: PID feedback signal	
			6: Thermistor (PTC) input value	
			11: PT100 thermistor input value	
			13: PID compensation value	
×	03-03	AVI1 Analog Input Bias		
×	03-04	ACI Analog Input Bias	400.0.400.0%	0.0
	00.05	AVI2 Analog Positive Voltage	-100.0–100.0%	0.0
*	03-05	Input Bias		
	02.07	AVI1 Positive / Negative Bias	0: No bias	
~	03-07	Mode	1: Lower than or equal to bias	
	03-08	ACI Positive / Negative Bias	2: Greater than or equal to bias	0
~	03-06	Mode	3: The absolute value of the bias voltage while	0
	00.00	AVI2 Positive / Negative Bias	serving as the center	
~	03-09	Mode	4: Bias serves as the center	
*	03-10	Reverse Setting when Analog Signal Input is Negative Frequency	<ul> <li>0: Negative frequency is not allowed.</li> <li>The digital keypad or external terminal controls the forward and reverse direction.</li> <li>1: Negative frequency is allowed.</li> <li>Positive frequency = run in a forward direction; negative frequency = run in a reverse direction.</li> <li>The digital keypad or external terminal control cannot change the running direction.</li> </ul>	0
×	03-11	AVI1 Analog Input Gain		
×	03-12	ACI Analog Input Gain		
×	03-13	AVI2 Analog Positive Input Gain	-500.0–500.0%	100.0
×	03-14	AVI2 Analog Negative Input Gain		
×	03-15	AVI1 Analog Input Filter Time		
×	03-16	ACI Analog Input Filter Time	0.00–20.00 sec.	0.01
×	03-17	AVI2 Analog Input Filter Time		
*	03-18	Analog Input Addition Function	0: Disable (AVI1, ACI, AVI2) 1: Enable	0
	03-19	Signal Loss Selection for The Analog Input 4–20 mA	O: Disable     1: Continue operation at the last frequency     2: Decelerate to 0 Hz	0
			1	

	Pr.	Parameter Name	Setting Range	Default
			3: Stop immediately and display ACE	
			4: Operate with output frequency lower limit	
×	03-20	AFM1 Analog Output Selection	0: Output frequency (Hz)	0
×	03-23	AFM2 Analog Output Selection	1: Frequency command (Hz)	0
			2: Motor speed (Hz)	
			3: Output current (rms)	
			4: Output voltage	
			5: DC bus voltage	
			6: Power factor	
			7: Power	
			9: AVI1%	
			10: ACI%	
			11: AVI2%	
			20: CANopen analog output	
			21: RS-485 analog output	
			22: Communication card analog output	
			23: Constant voltage output	
×	03-21	AFM1 Analog Output Gain	0.0–500.0%	100.0
		AFM1 Analog Output REV Direction	0: Absolute Value In Output Voltage	
×	03-22		1: Reverse Output 0 V; Forward Output 0–10 V	0
			2: Reverse Output 5–0 V; Forward Output 5–10 V	
×	03-24	AFM2 Analog Output Gain	0.0–500.0%	100.0
	03-25	AFM2 Analog Output REV Direction	0: Absolute Value In Output Voltage	
×			1: Reverse Output 0 V; Forward Output 0–10 V	0
			2: Reverse Output 5–0 V; Forward Output 5–10 V	
×	03-27	AFM2 Output Bias	-100.00–100.00%	0.00
			0: 0–10 V	
×	03-28	AVI1 Terminal Input Selection	1: 0–20 mA	0
			2: 4–20 mA	
		ACI Terminal Input Selection	0: 4–20 mA	
×	03-29		1: 0–10 V	0
			2: 0–20 mA	
	03-30	PLC Analog Output Terminal Status	Monitor the status of PLC analog output terminals	Read
			mental and states of 1 20 analog output terminals	only
N	03-31	AFM2 Output Selection	0: 0–20 mA output	0
, .	00 01	7.1 M2 Galpat Goldonon	1: 4–20 mA output	
×	03-32	AFM1 DC Output Setting Level	0.00–100.00%	0.00
×	03-33	AFM2 DC Output Setting Level	0.00 100.0070	3.00
	03-34 AFM1 Output Selection	0: 0–20 mA output	0	
	00-04	74 WT Output Ociociion	1: 4–20 mA output	U

	Pr.	Parameter Name	Setting Range	Default
~	03-35	AFM1 Filter Output Time	0.00.00	0.04
×	03-36	AFM2 Filter Output Time	0.00–20.00 sec.	0.01
*	03-44		0: AVI1	
		Multi-Function Output (MO) by	1: ACI	0
		Al Level Source	2: AVI2	
~	03-45	Al Upper Level	-100.00-100.00%	50.00
*	03-46	Al Lower Level	-100.00–100.00%	10.00
			0: Normal curve	
			1: Three-point curve of AVI1	
			2: Three-point curve of ACI	
	03-50	Analog Input Curvo Soloation	3: Three-point curve of AVI1 & ACI	7
	03-30	Analog Input Curve Selection	4: Three-point curve of AVI2	,
			5: Three-point curve of AVI1 & AVI2	
			6: Three-point curve of ACI & AVI2	
			7: Three-point curve of AVI1 & ACI & AVI2	
			Pr.03-28 = 0, 0.00–10.00 V	0.00
×	03-51	AVI1 Lowest Point	Pr.03-28 = 1, 0.00–20.00 mA	0.00
			Pr.03-28 = 2, 4.00–20.00 mA	4.00
*	03-52	AVI1 Proportional Lowest Point	-100.00–100.00%	0.00
			Pr.03-28 = 0, 0.00–10.00 V	5.00
×	03-53	AVI1 Mid-Point	Pr.03-28 = 1, 0.00–20.00 mA	10.00
			Pr.03-28 = 2, 0.00–20.00 mA	12.00
*	03-54	AVI1 Proportional Mid-Point	-100.00–100.00%	50.00
			Pr.03-28 = 0, 0.00–10.00 V	10.00
×	03-55	AVI1 Highest Point	Pr.03-28 = 1, 0.00–20.00 mA	20.00
			Pr.03-28 = 2, 0.00–20.00 mA	20.00
×	03-56	AVI1 Proportional Highest Point	-100.00–100.00%	100.00
×			Pr.03-29 = 0, 4.00–20.00 mA	4.00
	03-57	ACI Lowest Point	Pr.03-29 = 1, 0.00–10.00 V	0.00
			Pr.03-29 = 2, 0.00–20.00 mA	0.00
*	03-58	ACI Proportional Lowest Point	-100.00–100.00%	0.00
			Pr.03-29 = 0, 0.00–20.00 mA	12.00
×	03-59	ACI Mid-Point	Pr.03-29 = 1, 0.00–10.00 V	5.00
			Pr.03-29 = 2, 0.00–20.00 mA	10.00
×	03-60	ACI Proportional Mid-Point	-100.00–100.00%	50.00
			Pr.03-29 = 0, 0.00–20.00 mA	20.00
×	03-61	ACI Highest Point	Pr.03-29 = 1, 0.00–10.00 V	10.00
			Pr.03-29 = 2, 0.00–20.00 mA	20.00
*	03-62	ACI Proportional Highest Point	-100.00–100.00%	100.00

	Pr.	Parameter Name	Setting Range	Default
*	03-63	Positive AVI2 Voltage Lowest Point	0.00–10.00 V	0.00
*	03-64	Positive AVI2 Proportional Lowest Point	-100.00–100.00%	0.00
×	03-65	Positive AVI2 Voltage Mid-Point	0.00-10.00 V	5.00
*	03-66	Positive AVI2 Proportional Mid- Point	-100.00–100.00%	50.00
*	03-67	Positive AVI2 Voltage Highest Point	0.00-10.00 V	10.00
*	03-68	Positive AVI2 Proportional Highest Point	-100.00–100.00%	100.00

# 04 Multi-step Speed Parameters

	Pr.	Parameter Name	Setting Range	Default
×	04-00	1st Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-01	2 <sup>nd</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-02	3 <sup>rd</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-03	4 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-04	5 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-05	6 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-06	7 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-07	8 <sup>th</sup> Step Speed Frequency	0.00-599.00 Hz	0.00
×	04-08	9 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-09	10 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-10	11 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-11	12 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-12	13 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-13	14 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-14	15 <sup>th</sup> Step Speed Frequency	0.00–599.00 Hz	0.00
×	04-50	PLC Buffer 0	0–65535	0
×	04-51	PLC Buffer 1	0–65535	0
×	04-52	PLC Buffer 2	0–65535	0
×	04-53	PLC Buffer 3	0–65535	0
×	04-54	PLC Buffer 4	0–65535	0
×	04-55	PLC Buffer 5	0–65535	0
×	04-56	PLC Buffer 6	0–65535	0
×	04-57	PLC Buffer 7	0–65535	0
×	04-58	PLC Buffer 8	0–65535	0
×	04-59	PLC Buffer 9	0–65535	0
×	04-60	PLC Buffer 10	0–65535	0
×	04-61	PLC Buffer 11	0–65535	0
×	04-62	PLC Buffer 12	0–65535	0
×	04-63	PLC Buffer 13	0–65535	0
×	04-64	PLC Buffer 14	0–65535	0
×	04-65	PLC Buffer 15	0–65535	0
×	04-66	PLC Buffer 16	0–65535	0
×	04-67	PLC Buffer 17	0–65535	0
×	04-68	PLC Buffer 18	0–65535	0
×	04-69	PLC Buffer 19	0–65535	0
×	04-70	PLC Application Parameter 0	0–65535	0
×	04-71	PLC Application Parameter 1	0–65535	0
×	04-72	PLC Application Parameter 2	0–65535	0

Chapter 11 Summary of Parameter Settings | CFP2000

	Pr.	Parameter Name	Setting Range	Default
*	04-73	PLC Application Parameter 3	0–65535	0
*	04-74	PLC Application Parameter 4	0–65535	0
×	04-75	PLC Application Parameter 5	0–65535	0
*	04-76	PLC Application Parameter 6	0–65535	0
*	04-77	PLC Application Parameter 7	0–65535	0
×	04-78	PLC Application Parameter 8	0–65535	0
*	04-79	PLC Application Parameter 9	0–65535	0
×	04-80	PLC Application Parameter 10	0–65535	0
×	04-81	PLC Application Parameter 11	0–65535	0
×	04-82	PLC Application Parameter 12	0–65535	0
×	04-83	PLC Application Parameter 13	0–65535	0
×	04-84	PLC Application Parameter 14	0–65535	0
×	04-85	PLC Application Parameter 15	0–65535	0
×	04-86	PLC Application Parameter 16	0–65535	0
×	04-87	PLC Application Parameter 17	0–65535	0
×	04-88	PLC Application Parameter 18	0–65535	0
×	04-89	PLC Application Parameter 19	0–65535	0
×	04-90	PLC Application Parameter 20	0–65535	0
×	04-91	PLC Application Parameter 21	0–65535	0
×	04-92	PLC Application Parameter 22	0–65535	0
×	04-93	PLC Application Parameter 23	0–65535	0
×	04-94	PLC Application Parameter 24	0–65535	0
×	04-95	PLC Application Parameter 25	0–65535	0
×	04-96	PLC Application Parameter 26	0–65535	0
×	04-97	PLC Application Parameter 27	0–65535	0
*	04-98	PLC Application Parameter 28	0–65535	0
*	04-99	PLC Application Parameter 29	0–65535	0

# **05 Motor Parameters**

	Pr.	Parameter Name	Setting Range	Default
			0: No function	
			1: Simple rolling auto-tuning for induction motor (IM)	
			2: Static auto-tuning for induction motor (IM)	
	05-00	Motor Parameter Auto-Tuning	5: Rolling auto-tuning for PM (IPM / SPM)	0
			11: SynRM parameter auto-tuning	
			(applied to 230V / 460V models)	
			13: Static auto-tuning for PM (IPM / SPM)	
	05-01	Full-Load Current for Induction Motor 1 (A)	Depending on the model power	Depending on the model power
*	05-02	Rated Power for Induction Motor 1 (kW)	0.00-655.35 kW	Depending on the model power
		Rated Speed for Induction	0-xxxx rpm (Depending on the number of motor poles)	Depending on the
×	05-03	Motor 1 (rpm)	1710 (60 Hz 4 poles): 1410 (50 Hz 4 poles)	number of
		Number of Poles for Induction		motor poles
	05-04	Motor 1	2–64	4
	05-05	No-Load Current for Induction	0.00–Pr.05-01 default	Depending on the
	00 00	Motor 1 (A)	olog i nos er deladi.	model power
		Stator Resistance (Rs) for		Depending on the
	05-06	Induction Motor 1	$0.000-65.535 \Omega$	model power
	05-07	Rotor Resistance (Rr) for	0.000–65.535 Ω	0.000
	00-01	Induction Motor 1	0.000 00.000 12	0.000
	05-08	Magnetizing Inductance (Lm) for Induction Motor 1	0.0–6553.5 mH	0.0
	05-09	Stator Inductance (Lx) for Induction Motor 1	0.0–6553.5 mH	0.0
	05-13	Full-Load Current for Induction  Motor 2 (A)	Depending on the model power	Depending on the model
				power Depending
×	05-14	Rated Power for Induction  Motor 2 (kW)	0.00–655.35 kW	on the model
		Dated Chard for Indention	O years rom (Dononding on the much or function at 1)	power Depending
×	05-15	Rated Speed for Induction	0-xxxx rpm (Depending on the number of motor poles)	on the number of
		Motor 2 (rpm)	1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)	motor poles
	05-16	Number of Poles for Induction  Motor 2	2–64	4
	05.43	No-Load Current for Induction	0.00 Dr.05 42 defects	Depending on the
	05-17	Motor 2 (A)	0.00-Pr.05-13 default	model power
			ı	F 351

	Pr.	Parameter Name	Setting Range	Default
	05-18	Stator Resistance (Rs) for Induction Motor 2	0.000–65.535 Ω	Depending on the model power
	05-19	Rotor Resistance (Rr) for Induction Motor 2	0.000–65.535 Ω	0.000
	05-20	Magnetizing Inductance (Lm) for Induction Motor 2	0.0–6553.5 mH	0.0
	05-21	Stator Inductance (Lx) for Induction Motor 2	0.0–6553.5 mH	0.0
	05-22	Induction Motor 1 / 2 Selection	1: Motor 1 2: Motor 2	1
*	05-23	Frequency for Y-Connection /  △-Connection Switch for an Induction Motor	0.00–599.00 Hz	60.00
	05-24	Y-Connection / △-Connection Switch for Induction Motor	0: Disable 1: Enable	0
*	05-25	Delay Time For Y-Connection /  △-Connection Switch for an Induction Motor	0.000-60.000 sec.	0.200
	05-28	Accumulated Watt-Hour for a Running Motor (W-Hour)	0.0–999.9	Read only
	05-29	Accumulated Kilowatt-Hour for a Running Motor (kW-Hour)	0.0–999.9	Read only
	05-30	Accumulated Megawatt-Hour for a Running Motor (MW-Hour)	0–65535	Read only
	05-31	Accumulated Motor Operation Time (Minutes)	0–1439	0
	05-32	Accumulated Motor Operation Time (Days)	0–65535	0
	05-33	Induction Motor (IM) or Permanent Magnet Synchronous AC Motor (PM) Selection	0: IM 1: SPM 2: IPM 3: SynRM (applied to 230V / 460V models)	0
	05-34	Full-Load Current for a Permanent Magnet Synchronous AC Motor / Reluctance Motor	Depending on the model power	Depending on the model power
*	05-35	Rated Power for a Permanent Magnet Synchronous AC Motor / Reluctance Motor	0.00–655.35 kW	Depending on the motor power

	Pr.	Parameter Name	Setting Range	Default
		Rated Speed for a Permanent		
~	05-36	Magnet Synchronous AC Motor	0–65535 rpm	2000
		/ Reluctance Motor		
		Pole Number for a Permanent		
	05-37	Magnet Synchronous AC Motor	nt tor 0–65535 rpm  nt tor 0–65535  ent tor 0.0–6553.5 kg-cm²  0.000–655.35 mH  0.00–655.35 mH  0-65535 (Unit: V / krpm)	10
		/ Reluctance Motor		
		System Inertia for a Permanent		Depending
		Magnet Synchronous AC Motor	0.0–6553.5 kg-cm <sup>2</sup>	on the motor
		/ Reluctance Motor		power
05-39		Stator Resistance for a		
	05.20	Permanent Magnet	$0.000$ – $65.535\Omega$	0.000
	05-39	Synchronous AC Motor /		0.000
		Reluctance Motor		
		Permanent Magnet		
	05-40	Synchronous AC Motor /	0.00–655.35 mH	0.00
		Reluctance Motor Ld		
		Permanent Magnet		
	05-41	Synchronous AC Motor /	0.00–655.35 mH	0.00
		Reluctance Motor Lq		
.,	05.40	Ke Parameter for a Permanent	0.05505 (Unit )/ / / / / / / /	_
~	05-43	Magnet Synchronous AC Motor	U–osss (Unit: v / krpm)	0

# **06 Protection Parameters**

	Pr.	Parameter Name	Setting Range	Default
			230V models: 150.0–220.0 V <sub>DC</sub>	180.0
×	06-00	Low Voltage Level	460V models: 300.0–440.0 V <sub>DC</sub>	360.0
			575V models: 420.0–520.0 V <sub>DC</sub>	470.0
			0: Disable	
./	06.04	Over Veltage Stell Prevention	230V models: 0.0–450.0 V <sub>DC</sub>	380.0
~	06-01	Over-Voltage Stall Prevention	460V models: 0.0–900.0 V <sub>DC</sub>	760.0
			575V models: 0.0–1116.0 V <sub>DC</sub>	920.0
			0: Traditional over-voltage and traditional over-	
			current stall prevention	
			1: Smart over-voltage and traditional over-current	
	00.00	Calastian for Chall Dusconting	0: Traditional over-voltage and traditional over- current stall prevention 1: Smart over-voltage and traditional over-current stall prevention 2: Traditional over-voltage and smart over-current stall prevention 3: Smart over-voltage and smart over-current stall prevention  230V / 460V models: Light duty: 0–130% (100% corresponds to the rated current of the drive) Normal duty: 0–160% (100% corresponds to the rated current of the drive)  575V models: Light duty: 0–125% (100% corresponds to the rated current of the drive) Normal duty: 0–150% (100% corresponds to the rated current of the drive)  230V / 460V models:	0
~	06-02	Selection for Stall Prevention		U
			stall prevention	
			3: Smart over-voltage and smart over-current stall	120 d 120
			prevention	
			230V / 460V models:	
	current of the drive)  Normal duty: 0–160% (100% corresponds to the		Light duty: 0–130% (100% corresponds to the rated	120
<i>*</i>				
		120		
		Over-Current Stall Prevention	rated current of the drive)	
~	06-03	during Acceleration	575V models:	
			Light duty: 0–125% (100% corresponds to the rated	120
			current of the drive)	
			Normal duty: 0–150% (100% corresponds to the	120
			rated current of the drive)	
			230V / 460V models:	
			Light duty: 0–130% (100% corresponds to the rated	120
			current of the drive)	
			Normal duty: 0–160% (100% corresponds to the	120
	06-04	Over-Current Stall Prevention	rated current of the drive)	
~	06-04	during Operation	575V models:	
			Light duty: 0–125% (100% corresponds to the rated	120
			current of the drive)	
			Normal duty: 0–150% (100% corresponds to the	120
			rated current of the drive)	
		Appeloration / Decalar-time Time	0: By current acceleration / deceleration time	
,,	06.05	Acceleration / Deceleration Time	1: By the first acceleration / deceleration time	0
*	06-05	Selection for Stall Prevention at	2: By the second acceleration / deceleration time	0
		Constant Speed	3: By the third acceleration / deceleration time	

	Pr.	Parameter Name	Setting Range	Default
			4: By the fourth acceleration / deceleration time	
			5: By auto-acceleration / auto-deceleration	
			0: No function	
			1: Continue operation after over-torque detection	
			during constant speed operation	
<b>⊿</b>	06-06	Over-Torque Detection Selection	2: Stop after over-torque detection during constant	0
~	00-00	(OT1)	speed operation	0
			3: Continue operation after over-torque detection	
			during RUN	
			4: Stop after over-torque detection during RUN	
<b>√</b>	06-07	Over-Torque Detection Level	10-200% (100% corresponds to the drive's light-	120
_	06-07	(OT1)	duty rated current)	120
	06-08	Over-Torque Detection Time	0.0-60.0 sec.	0.1
_	00-06	(OT1)	0.0–60.0 sec.	0.1
			0: No function	
			1: Continue operation after over-torque detection	
			during constant speed operation	
	06.00	Over-Torque Detection Selection	2: Stop after over-torque detection during constant	0
_	06-09	(OT2)	speed operation	0
			3: Continue operation after over-torque detection	
			during RUN	
			4: Stop after over-torque detection during RUN	
<b>✓</b>	06-10	Over-Torque Detection Level	10–200% (100% corresponds to the drive's light-	120
,	00-10	(OT2)	duty rated current)	120
<b>√</b>	06-11	Over-Torque Detection Time	0.0-60.0 sec.	0.1
^	00-11	(OT2)	0.0-00.0 sec.	0.1
×	06-12	Current Limit	0–200%	150
		Electronic Thermal Relay	0: Inverter motor (with external forced cooling)	
×	06-13	•	1: Standard motor (motor with fan on the shaft)	2
		Selection 1 (Motor 1)	2: Disable	
	06.44	Electronic Thermal Relay Action	20.0.000.0	60.0
_	06-14	Time 1 (Motor 1)	30.0–600.0 sec.	60.0
	06.45	Temperature Level Overheat (OH)	0.0.440.0°C	105.0
~	06-15	Warning	0.0-110.0°C	105.0
		Stall Prevention Limit Level		
×	06-16	(Weak Magnetic Area Current	0–100% (Pr.06-03)	50
		Stall Prevention Level)		
	06-17	Fault Record 1	0: No fault record	0
	06-18	Fault Record 2	1: Over-current during acceleration (ocA)	0
	06-19	Fault Record 3	2: Over-current during deceleration (ocd)	0

Pr.	Parameter Name	Setting Range	Default
06-20	Fault Record 4	3: Over-current during steady speed (ocn)	0
06-21	Fault Record 5	4: Ground fault (GFF)	0
06-22	Fault Record 6	5: IGBT short-circuit between upper bridge and lower	0
		bridge (occ)	
		6: Over-current at stop (ocS)	
		7: Over-voltage during acceleration (ovA)	
		8: Over-voltage during deceleration (ovd)	
		9: Over-voltage at constant speed (ovn)	
		10: Over-voltage at stop (ovS)	
		11: Low-voltage during acceleration (LvA)	
		12: Low-voltage during deceleration (Lvd)	
		13: Low-voltage at constant speed (Lvn)	
		14: Low-voltage at stop (LvS)	
		15: Phase loss protection (OrP)	
		16: IGBT overheating (oH1)	
		17: Heatsink overheating (oH2)	
		18: IGBT temperature detection failure (tH1o)	
		19: Capacitor hardware error (tH2o)	
		21: Over load (oL)	
		22: Electronic thermal relay 1 protection (EoL1)	
		23: Electronic thermal relay 2 protection (EoL2)	
		24: Motor overheating (oH3) (PTC / PT100)	
		26: Over torque 1 (ot1)	
		27: Over torque 2 (ot2)	
		28: Under current (uC)	
		30: EEPROM write error (cF1)	
		31: EEPROM read error (cF2)	
		33: U-phase error (cd1)	
		34: V-phase error (cd2)	
		35: W-phase error (cd3)	
		36: cc (current clamp) hardware error (Hd0)	
		37: oc (over-current) hardware error (Hd1)	
		38: ov (over-voltage) hardware error (Hd2)	
		39: occ hardware error (Hd3)	
		40: Auto-tuning error (AUE)	
		41: PID loss ACI (AFE)	
		48: ACI loss (ACE)	
		49: External fault (EF)	
		50: Emergency stop (EF1)	
		51: External base block (bb)	

Pr.	Parameter Name	Setting Range	Default
		52: Enter wrong password three times and locked	
		(Pcod)	
		53: Firmware version error (ccod)	
		54: Illegal command (CE1)	
		55: Illegal data address (CE2)	
		56: Illegal data value (CE3)	
		57: Data is written to read-only address (CE4)	
		58: Modbus transmission time-out (CE10)	
		60: Brake transistor error (bF)	
		61: Y-connection / △-connection switch error (ydc)	
		63: Over slip error (oSL)	
		64: Electric valve switch error (ryF)	
		68: Reverse direction of the speed feedback (SdRv)	
		69: Over speed rotation feedback (SdOr)	
		70: Large deviation of speed feedback (SdDe)	
		71: Watchdog (WDTT)	
		72: STO loss 1 (STL1)	
		73: Emergency stop for external safety (S1)	
		74: FIRE mode output (Fire)	
		76: Safe torque off (STO)	
		77: STO loss 2 (STL2)	
		78: STO loss 3 (STL3)	
		82: Output phase loss U phase (OPHL)	
		83: Output phase loss V phase (OPHL)	
		84: Output phase loss W phase (OPHL)	
		87: Overload protection at low frequency (oL3)	
		89: Rotor position detection error (RoPd)	
		90: Forced to stop (FStp)	
		93: CPU error 0 (TRAP)	
		101: CANopen guarding error (CGdE)	
		102: CANopen heartbeat error (CHbE)	
		104: CANopen bus off error (CbFE)	
		105: CANopen index error (CidE)	
		106: CANopen station address error (CAdE)	
		107: CANopen memory error (CFrE)	
		111: InerCOM time-out error (ictE)	
		112: PM sensorless shaft lock error (SfLK)	
		113: Software over-current (SWOC)	
		142: Auto-tuning error 1 (no feedback current error)	
		(AUE1)	

	Pr.	Parameter Name	Setting Range	Default
			143: Auto-tuning error 2 (motor phase loss error)	
			(AUE2)	
			144: Auto-tuning error 3 (no-load current I <sub>0</sub>	
			measuring error) (AUE3)	
			148: Auto-tuning error 4 (leakage inductance Lsigma	
			measuring error) (AUE4)	
*	06-23	Fault Output Option 1		
*	06-24	Fault Output Option 2		
~	06-25	Fault Output Option 3	0–65535 (refer to bit table for fault code)	0
~	06-26	Fault Output Option 4		
			0: Inverter motor (with external forced cooling)	
×	06-27	Electronic Thermal Relay	1: Standard motor (motor with fan on the shaft)	2
		Selection 2 (Motor 2)	2: Disable	
-		Electronic Thermal Relay Action		_
*	06-28	Time 2 (Motor 2)	30.0–600.0 sec.	60.0
_		, ,	0: Warn and continue operation	
	06-29	6-29 PTC Detection Selection / PT100 Motion	1: Fault and ramp to stop	
*			2: Fault and coast to stop	0
			3: No warning	
~	06-30	PTC Level	0.0–100.0%	50.0
-		Frequency Command at		Read
	06-31	Malfunction	0.00–599.00 Hz	only
-				Read
	06-32	Output Frequency at Malfunction	0.00–599.00 Hz	only
-				Read
	06-33	Output Voltage at Malfunction	0.0–6553.5 V	only
-				Read
	06-34	DC Bus Voltage at Malfunction	0.0–6553.5 V	only
}				Read
	06-35	Output Current at Malfunction	0.0–6553.5 Amp	only
ŀ				Read
	06-36	IGBT Temperature at Malfunction	-3276.7–3276.7°C	only
-		Capacitance Temperature at		Read
	06-37	Malfunction	-3276.7–3276.7°C	only
}				Read
	06-38	Motor Speed at Malfunction	-32767–32767 rpm	only
-		Status of the Multi-Function Input		Read
	06-40	Terminal at Malfunction	0000h-FFFFh	only
-		Status of the Multi-Function		Read
	06-41	Output Terminal at Malfunction	0000h-FFFFh	only

	Pr.	Parameter Name	Setting Range	Default
	06-42	Drive Status at Malfunction	0000h-FFFFh	Read only
*	06-44	STO Latch Selection	0: STO latch 1: STO no latch	0
*	06-45	Output Phase Loss Detection Action (OPHL)	O: Warn and continue operation  1: Fault and ramp to stop  2: Fault and coast to stop  3: No warning	3
*	06-46	Detection Time for Output Phase Loss	0.000–65.535 sec.	0.500
*	06-47	Current Detection Level for Output Phase Loss	0.00-100.00%	1.00
*	06-48	DC Brake Time for Output Phase Loss	0.000-65.535 sec.	0.000
*	06-49	Lvx Auto-Reset	0: Disable 1: Enable	0
*	06-50	Time for Input Phase Loss Detection	0.00-600.00 sec.	0.20
*	06-52	Ripple of Input Phase Loss	230V models: 0.0–160.0 V <sub>DC</sub> 460V models: 0.0–320.0 V <sub>DC</sub> 575V models: 0.0–400.0 V <sub>DC</sub>	30.0 60.0 75.0
*	06-53	Input Phase Loss Detection Action (Orp)	Fault and ramp to stop     Fault and coast to stop	0
*	06-55	Derating Protection	O: Auto-decrease carrier frequency and limit output current     1: Constant carrier frequency and limit output current     2: Auto-decrease carrier frequency	0
×	06-56	PT100 Voltage Level 1	0.000–10.000 V	5.000
×	06-57	PT100 Voltage Level 2	0.000–10.000 V	7.000
×	06-58	PT100 Level 1 Frequency Protection	0.00–599.00 Hz	0.00
*	06-59	PT100 Activation Level 1 Protection Frequency Delay Time	0–6000 sec.	60
*	06-60	Software Detection GFF Current Level	0.0–6553.5% (100% corresponds to the drive's light- duty rated current)	60.0
*	06-61	Software Detection GFF Filter Time	0.00-655.35 sec.	0.10
	06-63	Operation Time of Fault Record 1 (Day)	0–65535 days	Read only

Chapter 11 Summary of Parameter Settings | CFP2000

06-64   Operation Time of Fault Record 1 (Minutes)		Pr.	Parameter Name	Setting Range	Default
(Minutes)		06.64	Operation Time of Fault Record 1	0.4420 min	Read
06-65 (Day)		00-04	(Minutes)	0-1439 Min.	only
(Day)		06.65	Operation Time of Fault Record 2	0. SEE25 days	Read
06-66   Minutes		00-05	(Day)	0-0000 days	only
Minutes    Operation Time of Fault Record 3 (Day)   Operation Time of Fault Record 3 (Day)   Operation Time of Fault Record 3 (Minutes)   Operation Time of Fault Record 4 (Day)   Operation Time of Fault Record 4 (Day)   Operation Time of Fault Record 4 (Minutes)   Operation Time of Read only rated current)   Operation Time of Read only rated current)   Operation Operation on time of Record Read only rated current on the drive's light duty rated current on time on time on time on time on time on time on the drive's light duty rated current on time on time on the drive's light duty rated current on time on the drive's light duty rated current on time on time on time on the drive's light duty rated current on time on the drive's light duty rated current on		06-66	Operation Time of Fault Record 2	0_1/30 min	Read
06-67		00-00	(Minutes)	0-1409 111111.	only
(Day)		06-67	Operation Time of Fault Record 3	0_65535 days	Read
06-68		00-07	(Day)	0 00000 days	only
Minutes   Only   Operation Time of Fault Record 4 (Day)		06-68	Operation Time of Fault Record 3	0–1439 min	Read
06-69			(Minutes)	0 1100 Hills.	only
Day   Only   Operation Time of Fault Record 4   O-1439 min.		06-69	Operation Time of Fault Record 4	0–65535 days	Read
06-70 (Minutes) 0-1439 min. only  06-71 Low Current Setting Level 0.0−100.0% (100% corresponds to the drive's light-duty rated current) 0.0  06-72 Low Current Detection Time 0.00−360.00 sec. 0.00  1: Fault and coast to stop 2: Fault and ramp to stop by the second deceleration time 3: Warn and continue operation  230V models: 0.0−200.0 Vpc 40.0 575V models: 0.0−200.0 Vpc 50.0  0: Disable 1: Forward (counterclockwise) operation 0  2: Reverse (clockwise) operation 0  3: Reverse (clockwise) operation 0  3: Reverse (clockwise) operation 0  3: Reverse (clockwise) operation 0  4: Enable Bypass in Fire Mode 0: Disable bypass 0  60-83 Bypass Delay Time in Fire Mode 0.0−6550.0 sec. 0.0  Number of Times of Reset in Fire Mode 0.0−6550.0 sec. 0.0  Number of Times of Reset in Fire Mode 0.0−6000.0 sec. 60.0			(Day)	0 00000 44,0	only
(Minutes)         0.0–100.0% (100% corresponds to the drive's light-duty rated current)         0.0           06-71         Low Current Setting Level         0.0–100.0% (100% corresponds to the drive's light-duty rated current)         0.0           06-72         Low Current Detection Time         0.00–360.00 sec.         0.00           06-73         Low Current Action         1: Fault and coast to stop         2: Fault and ramp to stop by the second deceleration time         0           3: Warn and continue operation         230V models: 0.0–200.0 Vpc         20.0           460V models: 0.0–200.0 Vpc         40.0         575V models: 0.0–200.0 Vpc         50.0           06-80         Fire Mode         1: Forward (counterclockwise) operation         0         0         2: Reverse (clockwise) operation         0         0         2: Reverse (clockwise) operation         0		06-70	Operation Time of Fault Record 4	0–1439 min.	Read
06-71   Low Current Setting Level   duty rated current)   0.0			(Minutes)		only
M         06-72         Low Current Detection Time         0.00–360.00 sec.         0.00           0: No function         1: Fault and coast to stop         0.00–360.00 sec.         0.00           0: No function         1: Fault and coast to stop         0.00–360.00 sec.         0.00–360.00 sec.           0: No function         0: Fault and ramp to stop by the second deceleration time         0.00–360.00 sec.         0.00–200.0 Vpc         20.0           0: Fault and coast to stop         2: Fault and ramp to stop by the second deceleration         0.00–200.0 Vpc         20.0         20.0           0: Disable         230V models: 0.0–200.0 Vpc         40.0         40.0         575V models: 0.0–200.0 Vpc         50.0           0: Disable         0: Disable         1: Forward (counterclockwise) operation         0         0           0: Reverse (clockwise) operation         0         2: Reverse (clockwise) operation         0         60.00           0: Disable bypass         0         0: Disable bypass         0         0         0           0: Disable bypass         0: Disable bypass         0         0         0         0           0: Disable bypass         0: Disable bypass         0         0         0         0           0: Disable bypass         0: Disable bypass         0	~	06-71	Low Current Setting Level	, , , , , , , , , , , , , , , , , , ,	0.0
0: No function 1: Fault and coast to stop 2: Fault and ramp to stop by the second deceleration time 3: Warn and continue operation  230V models: 0.0−200.0 Vpc 20.0  460V models: 0.0−200.0 Vpc 40.0 575V models: 0.0−200.0 Vpc 575V models: 0.0−200.0 Vpc 50.0  0: Disable 1: Forward (counterclockwise) operation  0: Reverse (clockwise) operation  0: Reverse (clockwise) operation  0: Disable bypass in Fire Mode  0: Disable bypass 1: Enable bypass 1: Enable bypass 0: Disable bypass 1: Enable bypas				,	
1: Fault and coast to stop       2: Fault and coast to stop by the second deceleration time       0         2: Fault and ramp to stop by the second deceleration time       2: Fault and ramp to stop by the second deceleration       0         3: Warn and continue operation       20.0       46.0         460V models: 0.0–200.0 Vpc       40.0         575V models: 0.0–200.0 Vpc       50.0         0: Disable       0: Disable         1: Forward (counterclockwise) operation       0         2: Reverse (clockwise) operation       0         2: Reverse (clockwise) operation       0         06-81 Running Fire Mode       0: Disable bypass         06-82 Enable Bypass in Fire Mode       0: Disable bypass         06-83 Bypass Delay Time in Fire Mode       0: O-6550.0 sec.         06-84 Mode       0         06-85 Length of Time of Reset in Fire       0         06-85 Length of Time of Reset in Fire       0.0-6000.0 sec.	×	06-72	Low Current Detection Time		0.00
M         06-73         Low Current Action         2: Fault and ramp to stop by the second deceleration time         0           3: Warn and continue operation         230V models: 0.0–200.0 Vpc         20.0           460V models: 0.0–200.0 Vpc         40.0           575V models: 0.0–200.0 Vpc         50.0           0: Disable         1: Forward (counterclockwise) operation           0: Disable         1: Forward (counterclockwise) operation           0: Disable Bypass in Fire Mode         0: Disable bypass           0: Disable bypass         0					
time 3: Warn and continue operation  230V models: 0.0–200.0 Vpc 20.0  460V models: 0.0–200.0 Vpc 40.0  575V models: 0.0–200.0 Vpc 50.0  0: Disable 1: Forward (counterclockwise) operation 2: Reverse (clockwise) operation 0: Running Frequency when Running Fire Mode 0: Disable bypass 1: Enable bypass 1: Enable bypass 0 06-82 Enable Bypass in Fire Mode 0: Disable bypass 1: Enable bypass 0 06-83 Bypass Delay Time in Fire Mode 0-10 0 0 0-6000.0 sec. 60.0		00.70		·	
3: Warn and continue operation  230V models: 0.0–200.0 V <sub>DC</sub> 20.0  460V models: 0.0–200.0 V <sub>DC</sub> 40.0  575V models: 0.0–200.0 V <sub>DC</sub> 50.0  0: Disable  06-80 Fire Mode 1: Forward (counterclockwise) operation 0  2: Reverse (clockwise) operation  0-2: Reverse (clockwise) operation  0-2: Reverse (clockwise) operation  0-2: Reverse (clockwise) operation  0-2: Reverse (clockwise) operation  0-3: Reverse (clockwise) operation  0-4: Reverse (clockwise) operation  0-599.00 Hz  0-6-81	×	06-73	Low Current Action		0
230V models: 0.0–200.0 Vpc   20.0					
M         06-76         dEb Motion Offset         460V models: 0.0–200.0 V <sub>DC</sub> 40.0           575V models: 0.0–200.0 V <sub>DC</sub> 50.0           06-80         Fire Mode         1: Forward (counterclockwise) operation         0           2: Reverse (clockwise) operation         0         2: Reverse (clockwise) operation         60.00           M         06-81         Operating Frequency when Running Fire Mode         0: Disable bypass         0           M         06-82         Enable Bypass in Fire Mode         0: Disable bypass         0           M         06-83         Bypass Delay Time in Fire Mode         0.0–6550.0 sec.         0.0           M         06-84         Number of Times of Reset in Fire Mode         0–10         0           M         06-85         Length of Time of Reset in Fire         0.0–6000.0 sec.         60.0				·	20.0
575V models: 0.0–200.0 V <sub>DC</sub> 50.0           06-80         Fire Mode         1: Forward (counterclockwise) operation         0           2: Reverse (clockwise) operation         0         0           N         06-81         Operating Frequency when Running Fire Mode         0.00–599.00 Hz         60.00           N         06-82         Enable Bypass in Fire Mode         0: Disable bypass 1: Enable bypass 1: Enable bypass 1: Enable bypass 2: Enable bypass 2: Enable bypass 3: Enable	<b>.</b>	06.76	dEh Motion Offsot		
06-80 Fire Mode 1: Forward (counterclockwise) operation 0 2: Reverse (clockwise) operation 0 2: Reverse (clockwise) operation 0 06-81 Operating Frequency when Running Fire Mode 0.00–599.00 Hz 60.00  06-82 Enable Bypass in Fire Mode 0: Disable bypass 1: Enable bypass 1: Enable bypass 1: Enable bypass 0.00  06-83 Bypass Delay Time in Fire Mode 0.0–6550.0 sec. 0.0  06-84 Number of Times of Reset in Fire Mode 0-10 0  06-85 Length of Time of Reset in Fire 0.0–6000.0 sec. 60.0	_	00-70	deb Motion Onset		
06-80Fire Mode1: Forward (counterclockwise) operation02: Reverse (clockwise) operation2: Reverse (clockwise) operationN06-81Operating Frequency when Running Fire Mode0.00–599.00 Hz60.00N06-82Enable Bypass in Fire Mode0: Disable bypass 1: Enable bypass0N06-83Bypass Delay Time in Fire Mode0.0–6550.0 sec.0.0N06-84Number of Times of Reset in Fire Mode0–100N06-85Length of Time of Reset in Fire Mode0.0–6000.0 sec.60.0					30.0
2: Reverse (clockwise) operation  06-81 Operating Frequency when Running Fire Mode  0: Disable bypass  0: Disable bypass  1: Enable bypass  0: Disable bypass  0: Dis		06-80	Fire Mode		0
NO6-81Operating Frequency when Running Fire Mode0.00–599.00 Hz60.00NO6-82Enable Bypass in Fire Mode0: Disable bypass0NO6-83Bypass Delay Time in Fire Mode0.0–6550.0 sec.0.0NO6-84Number of Times of Reset in Fire Mode0–100NO6-85Length of Time of Reset in Fire Mode0.0–6000.0 sec.60.0				, , ,	
N       06-81       Running Fire Mode       0.00-599.00 Hz       60.00         N       06-82       Enable Bypass in Fire Mode       0: Disable bypass       0         N       06-83       Bypass Delay Time in Fire Mode       0.0-6550.0 sec.       0.0         N       06-84       Number of Times of Reset in Fire Mode       0-10       0         N       06-85       Length of Time of Reset in Fire Mode       0.0-6000.0 sec.       60.0			Operating Frequency when	, ,	
N         06-82         Enable Bypass in Fire Mode         0: Disable bypass         0           N         06-83         Bypass Delay Time in Fire Mode         0.0–6550.0 sec.         0.0           N         06-84         Number of Times of Reset in Fire Mode         0–10         0           N         06-85         Length of Time of Reset in Fire Mode         0.0–6000.0 sec.         60.0	×	06-81	, , , , ,	0.00–599.00 Hz	60.00
N         06-82         Enable Bypass in Fire Mode         1: Enable bypass         0           N         06-83         Bypass Delay Time in Fire Mode         0.0-6550.0 sec.         0.0           N         06-84         Number of Times of Reset in Fire Mode         0-10         0           N         06-85         Length of Time of Reset in Fire         0.0-6000.0 sec.         60.0				0: Disable bypass	
N         06-84         Number of Times of Reset in Fire Mode         0-10         0           N         06-85         Length of Time of Reset in Fire         0.0-6000.0 sec.         60.0	×	06-82	Enable Bypass in Fire Mode		0
N       06-84       Mode       0-10       0         N       06-85       Length of Time of Reset in Fire       0.0-6000.0 sec.       60.0	×	06-83	Bypass Delay Time in Fire Mode	0.0-6550.0 sec.	0.0
Mode  Length of Time of Reset in Fire  0.0–6000.0 sec.  60.0		00.04	Number of Times of Reset in Fire	0.40	_
M   06-85     0.0-6000.0 sec.   60.0	×	06-84	Mode	U=1U 	U
Mode   0.0-6000.0 sec.   60.0		06.05	Length of Time of Reset in Fire	0.0, 6000, 0.000	60.0
	×	06-85	Mode	U.U-6UUU.U sec.	60.0

	Pr.	Parameter Name	Setting Range	Default
			bit0: 0 = Open Loop; 1 = Close Loop (PID control)	
			bit1: 0 = Manual reset fire mode; 1 = Auto reset fire	
			mode	
	06-86	Fire Mode Motion	0: Open loop control and manual reset fire mode	0
			1: Close loop control and manual reset fire mode	
			2: Open loop control and auto reset fire mode	
			3: Close loop control and auto reset fire mode	
~	06-87	Fire Mode PID Set Point	0.00-100.00%	0.00
	06-88	Software Overcurrent Level	Depending on the models	0.00
			0: LvS always detects	
	06-89	LvS Low Voltage Error Enable	1: LvS always not detect	0
			2: LvS not detect only for the first power on	

# **07 Special Parameters**

	Pr.	Parameter Name	Setting Range	Default
		Cofficer Ducks Observed Astion	230V models: 350.0–450.0 V <sub>DC</sub>	370.0
×	07-00	Software Brake Chopper Action	460V models: 700.0–900.0 V <sub>DC</sub>	740.0
		Level	575V models: 850.0–1116.0 V <sub>DC</sub>	895.0
×	07-01	DC Brake Current Level	0–100%	0
×	07-02	DC Brake Time at Start-Up	0.0-60.0 sec.	0.0
×	07-03	DC Brake Time at STOP	0.0-60.0 sec.	0.0
×	07-04	DC Brake Frequency at STOP	0.00-599.00 Hz	0.00
×	07-05	Voltage Increasing Gain	1–200%	100
			0: Stop operation	
*	07-06	Restart after Momentary Power Loss	Speed tracking by the speed before the power loss	0
			2: Speed tracking by the minimum output frequency	
×	07-07	Allowed Power Loss Duration	0.0–20.0 sec.	2.0
*	07-08	Base Block Time	0.0–5.0 sec. (Depending on the model power)	Depending on the model power
*	07-09	Current Limit of Speed Tracking	20–200% (100% corresponds to the drive's light-load rated current)	100
*	07-10	Restart after Fault Action	<ul><li>0: Stop operation</li><li>1: Speed tracking by current speed</li><li>2: Speed tracking by the minimum output frequency</li></ul>	0
*	07-11	Number of Times of Restart after Fault	0–10	0
*	07-12	Speed Tracking During Start-Up	O: Disable  1: Speed tracking by the maximum output frequency  2: Speed tracking by the motor frequency at start-up  3: Speed tracking by the minimum output frequency	0
*	07-13	Deb Function Selection	<ol> <li>Disable</li> <li>dEb with auto-acceleration / auto-deceleration, the drive does not output the frequency after the power is restored.</li> <li>dEb with auto-acceleration / auto-deceleration, the drive outputs the frequency after the power is restored.</li> <li>dEb low-voltage control, then the drive's voltage increases to 350 V<sub>DC</sub> / 700 V<sub>DC</sub> and ramps to stop after low frequency</li> <li>dEb high-voltage control of 350 V<sub>DC</sub> / 700 V<sub>DC</sub>, and the drive ramps to stop</li> </ol>	0

	Pr.	Parameter Name	Setting Range	Default
×	07-15	Dwell Time at Acceleration	0.00-600.00 sec.	0.00
×	07-16	Dwell Frequency at Acceleration	0.00-599.00 Hz	0.00
×	07-17	Dwell Time at Deceleration	0.00-600.00 sec.	0.00
×	07-18	Dwell Frequency at  Deceleration	0.00-599.00 Hz	0.00
*	07-19	Fan Cooling Control	<ul> <li>0: Fan is always ON</li> <li>1: Fan is OFF after the AC motor drive stops for one minute</li> <li>2: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops</li> <li>3: Fan turns ON when temperature (IGBT) reaches around 60°C.</li> </ul>	0
*	07-20	Emergency Stop (EF) & Force to Stop Selection	4: Fan always OFF  0: Coast to stop  1: Stop by the first deceleration time  2: Stop by the second deceleration time  3: Stop by the third deceleration time  4: Stop by the fourth deceleration time  5: System deceleration  6: Automatic deceleration	0
*	07-21	Automatic Energy-Saving Selection	Disable     Power factor energy-saving improvement     Automatic energy-saving optimization	0
N	07-22	Energy-Saving Gain	10–1000%	100
*	07-23	Automatic Voltage Regulation (AVR) Function	0: Enable AVR 1: Disable AVR 2: Disable AVR during deceleration	0
×	07-24	Torque Command Filter Time (V/F And SVC Control Mode)	0.001-10.000 sec.	0.500
*	07-25	Slip Compensation Filter Time (V/F And SVC Control Mode)	0.001-10.000 sec.	0.100
×	07-26	Torque Compensation Gain	IM: 0–10 (when Pr.05-33 = 0) PM: 0–5000 (when Pr.05-33 = 1 or 2)	0
~	07-27	Slip Compensation Gain	0.00-10.00	0.00 (Default value is 1.00 in SVC mode)
×	07-29	Slip Deviation Level	0.0–100.0% 0 : No detection	0.0

	Pr.	Parameter Name	Setting Range	Default
*	07-30	Over-Slip Deviation Detection Time	0.0–10.0 sec.	1.0
*	07-31	Over-Slip Deviation Treatment	<ul><li>0: Warn and continue operation</li><li>1: Fault and ramp to stop</li><li>2: Fault and coast to stop</li><li>3: No warning</li></ul>	0
*	07-32	Motor Oscillation Compensation Factor	0-10000 0: Disable	1000
×	07-33	Auto-Restart Interval of Fault	0.0-6000.0 sec.	60.0
*	07-38	PMSVC Voltage Feed Forward Gain	0.00-2.00	1.00
×	07-41	Minimum Frequency for AES	0.00–40.00 Hz	10.00
×	07-42	Delay Time for AES	0–600 sec.	5
*	07-43	Targeted Power Factor Angle for AES	0.00–65.00°	40.00
×	07-44	Maximum Voltage Drop for AES	0.00-70.00%	60.00
×	07-45	AES Coefficient	0–10000%	100
×	07-50	PWM Fan Speed	60–100%	60
×	07-62	dEb Gain (Kd)	0–65535	3000
×	07-63	dEb Gain (Kp)	0–65535	30

# **08 High-function PID Parameters**

	Pr.	Parameter Name	Setting Range	Default
			0: No function	
		Tamain al Calactico et DID	1: Negative PID feedback: by analog input	
×	<b>№</b> 08-00		(Pr.03-00-03-02)	0
		Feedback	4: Positive PID feedback: by analog input	
			(Pr.03-00-03-02)	
~	08-01	Proportional Gain (P)	0.0–100.0	1.0
	00.00	Luta and Time (I)	0.00-100.00 sec.	4.00
~	08-02	Integral Time (I)	0.00: No integral	1.00
~	08-03	Differential Time (D)	0.00-1.00 sec.	0.00
×	08-04	Upper Limit of Integral Control	0.0–100.0%	100.0
×	08-05	PID Output Command Limit	0.0–110.0%	100.0
	00.00	DID Foodbook Value Dienley	200 00 200 000/	Read
~	08-06	PID Feedback Value Display	-200.00–200.00%	only
×	08-07	Delay Time	0.0–35.0 sec.	0.0
	08-08	Feedback Signal Detection	0.0-3600.0 sec.	0.0
~	00-00	Time	0.0–3000.0 sec.	0.0
			0: Warn and continue operation	
	08-09	Feedback Signal Fault	1: Fault and ramp to stop	
×	00-09	Treatment	2: Fault and coast to stop	0
			3: Warn and operate at last frequency	
×	08-10	Sleep Level	0.00–599.00 Hz or 0–200.00%	0.00
×	08-11	Wake-Up Level	0.00–599.00 Hz or 0–200.00%	0.00
×	08-12	Sleep Delay Time	0.0-6000.0 sec.	0.0
*	08-13	PID Feedback Signal Error Deviation Level	1.0-50.0%	10.0
	08-14	PID Feedback Signal Error	0.1–300.0 sec.	5.0
~	00-14	Deviation Detection Time	0.1–300.0 Sec.	5.0
<u>,                                    </u>	08-16	PID Compensation Selection	0: Parameter setting (Pr.08-17)	0
~	00-10	PID Compensation Selection	1: Analog input	
×	08-17	PID Compensation	-100.0–100.0%	0.0
	08-18	Sleep Mode Function Setting	0: Refer to PID output command	0
	00-10	Sleep Wode Fullchort Setting	1: Refer to PID feedback signal	U
×	08-19	Wake-Up Integral Limit	0.0–200.0%	50.0
	08-20	PID Mode Selection	0: Serial connection	0
	00-20	I INIONE SEIECTION	1: Parallel connection	U
	08-21	Enable PID To Change The	0: Operation direction cannot be changed	0
	00 <b>-</b> 21	Operation Direction	1: Operation direction can be changed	U
×	08-22	Wake-Up Delay Time	0.00-600.00 sec.	0.00

# **09 Communication Parameters**

	Pr.	Parameter Name	Setting Range	Default
N	09-00	Modbus Communication Address	1–254	1
×	09-01	COM1 Modbus Transmission Speed	4.8–115.2 Kbps	9.6
*	09-02	COM1 Modbus Transmission Fault Treatment	Warn and continue operation     Fault and ramp to stop     Fault and coast to stop     No warning, no fault and continue operation	3
N	09-03	COM1 Modbus Time-Out Detection	0.0–100.0 sec.	0.0
*	09-04	COM1 Modbus Communication Protocol	1: 7, N, 2 (ASCII) 2: 7, E, 1 (ASCII) 3: 7, O, 1 (ASCII) 4: 7, E, 2 (ASCII) 5: 7, O, 2 (ASCII) 6: 8, N, 1 (ASCII) 7: 8, N, 2 (ASCII) 8: 8, E, 1 (ASCII) 9: 8, O, 1 (ASCII) 10: 8, E, 2 (ASCII) 11: 8, O, 2 (ASCII) 12: 8, N, 1 (RTU) 13: 8, N, 2 (RTU) 14: 8, E, 1 (RTU) 15: 8, O, 1 (RTU) 16: 8, E, 2 (RTU) 17: 8, O, 2 (RTU)	1
	09-06	Modbus Control bit	bit0: 0x2104 Decimal digits of output current bit0 = 0: The number of decimal places depends on the size of the value bit0 = 1: Fixed 1 decimal place	0
×	09-09	Communication Response Delay Time	0.0–200.0 ms	2.0
	09-10	Communication Main Frequency	0.00–599.00 Hz	60.00
×	09-11	Block Transfer 1	0000-FFFFh	0000h
×	09-12	Block Transfer 2	0000-FFFFh	0000h
×	09-13	Block Transfer 3	0000-FFFFh	0000h
×	09-14	Block Transfer 4	0000-FFFFh	0000h
×	09-15	Block Transfer 5	0000-FFFFh	0000h
×	09-16	Block Transfer 6	0000-FFFFh	0000h
×	09-17	Block Transfer 7	0000-FFFFh	0000h
×	09-18	Block Transfer 8	0000-FFFFh	0000h

	Pr.	Parameter Name	Setting Range	Default
×	09-19	Block Transfer 9	0000-FFFFh	0000h
×	09-20	Block Transfer 10	0000-FFFFh	0000h
×	09-21	Block Transfer 11	0000-FFFFh	0000h
×	09-22	Block Transfer 12	0000-FFFFh	0000h
×	09-23	Block Transfer 13	0000-FFFFh	0000h
×	09-24	Block Transfer 14	0000-FFFFh	0000h
×	09-25	Block Transfer 15	0000-FFFFh	0000h
×	09-26	Block Transfer 16	0000-FFFFh	0000h
	00.30	Communication Deceding Method	0: Decoding method 1 (20xx)	1
	09-30	Communication Decoding Method	1: Decoding method 2 (60xx)	1
			1: BACnet	
			0: Modbus 485	
			-1: Internal communication Slave 1	
			-2: Internal communication Slave 2	
			-3: Internal communication Slave 3	
	00.21	09-31 Internal Communication Protocol -5: Internal commun -6: Internal commun	-4: Internal communication Slave 4	0
	09-31		-5: Internal communication Slave 5	0
			-6: Internal communication Slave 6	
			-7: Internal communication Slave 7	
			-8: Internal communication Slave 8	
			-10: Internal communication Master	
			-12: Internal PLC control	
<b>~</b>	09-33	PLC Command Force to 0	bit0: Before PLC scans, set up PLC target	0000h
^	09-33	r LC Command r orce to 0	frequency = 0	000011
	09-35	PLC Address	1–254	2
	09-36	CANopen Slave Address	0: Disable	0
	03-00	OANOpen Glave Address	1–127	Ü
			0: 1 Mbps	
			1: 500 Kbps	
	09-37	CANopen Speed	2: 250 Kbps	0
	00 01	o, ii toponi opoda	3: 125 Kbps	
			4: 100 Kbps (Delta only)	
			5: 50 Kbps	
			bit0: CANopen Guarding Time out	
			bit1: CANopen heartbeat Time out	
			bit2: CANopen SYNC Time out	Read
	09-39	CANopen Warning Record	bit3: CANopen SDO Time out	
			bit4: CANopen SDO buffer overflow	
			bit5: Can Bus off	Read only
			bit6: Error protocol of CANopen	

bit8: The setting values of CANopen indexes are fail     bit9: The setting value of CANopen address is fail     bit10: The checksum value of CANopen address is fail     bit10: The checksum value of CANopen indexes is fail     bit10: The checksum value of CANopen indexes is fail     can be considered decoding method     1: Enable (CANopen D8402 standard protocol)	Pr.	Parameter Name	Setting Range	Default
bit9: The setting value of CANopen address is fail			bit8: The setting values of CANopen indexes	
is fail			are fail	
bit10: The checksum value of CANopen			bit9: The setting value of CANopen address	
1			is fail	
Os-40   CANopen Decoding Method   1: Enable (CANopen DS402 standard protocol)   1: Enable (CANopen Control Status   1: Com reset state   1: Com reset s			bit10: The checksum value of CANopen	
09-40         CANopen Decoding Method         1: Enable (CANopen DS402 standard protocol)         1           09-41         CANopen Communication Status         0: Node reset state 1: Com reset state 2: Boot up state 3: Pre-operation state 4: Operation state 4: Operation state 4: Operation state 5: Stop state 5: Stop state 7: Inhibit start state 2: Ready for use state 1: Inhibit start state 2: Ready to switch on state 3: Switched on state 4: Enable operation state 7: Quick stop active state 13: Error reaction activation state 14: Error state 7: Quick stop active state 13: Error reaction activation state 14: Error state 7: Error reaction activation state 14: Error state 7: Error state 7: Error reaction Deceleration State 7: Enable 8: Enable 9: Enable 8: Enable 9:			indexes is fail	
December 2009-41   CANopen Communication Status   1: Com reset state   1: Com reset state   1: Com reset state   2: Boot up state   3: Pre-operation state   4: Operation state   5: Stop state   0: Not ready for use state   1: Inhibit start state   2: Ready to switch on state   3: Switched on state   4: Enable operation state   7: Quick stop active state   1: Inhibit start state   2: Ready to switch on state   3: Switched on state   4: Enable operation state   7: Quick stop active state   13: Error reaction activation state   14: Error state   14: Error state   15: Enable   0: Disable   0: Disable   0: Update Index 604F and 6050 to Acceleration / Deceleration time 1   bit0 = 0: Enabled (default)   bit0 = 1: Disabled   1: Distinguish the CANopen identity code by models   bit1 = 0: Distinguish the CANopen identity code by models   bit1 = 1: Distinguish the CANopen identity code by models   bit1 = 1: Distinguish the CANopen identity code by series   09-50   BACnet MS / TP Node Address   0-127   10   09-51   BACnet Baud Rate   9:6-76.8 Kbps   38.4   09-52   BACnet Device Index L   0-65535   10			0: Disable (Delta-defined decoding method)	
O: Node reset state   1: Com reset state   1: Com reset state   2: Boot up state   3: Pre-operation state   4: Operation state   4: Operation state   5: Stop state   7: Inhibit start state   7: Quick stop active stat	09-40	CANopen Decoding Method	1: Enable (CANopen DS402 standard	1
1: Com reset state   2: Boot up state   3: Pre-operation state   4: Operation state   4: Operation state   5: Stop state   0: Not ready for use state   1: Inhibit start state   2: Ready to switch on state   3: Switched on state   4: Enable operation state   7: Quick stop active state   13: Error reaction activation state   14: Error state   15: Enable   16: Enable			protocol)	
09-41         CANopen Communication Status         2: Boot up state 3: Pre-operation state 4: Operation state 5: Stop state         Read only           09-42         CANopen Control Status         0: Not ready for use state 1: Inhibit start state 2: Ready to switch on state 4: Enable operation state 7: Quick stop active state 13: Error reaction activation state 14: Error state         Read only           09-45         CANopen Master Function         0: Disable 1: Enable         0           09-46         CANopen Master Address         0-127         100           09-49         CANopen Extension Setting         0: Update Index 604F and 6050 to Acceleration / Deceleration time 1 bit0 = 0: Enabled (default) bit0 = 1: Disabled 1: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series         0002h           09-50         BACnet MS / TP Node Address         0-127         10           09-51         BACnet Baud Rate         9.6-76.8 Kbps         38.4           09-52         BACnet Device Index L         0-65535         10			0: Node reset state	
09-41         CANopen Communication Status         3: Pre-operation state         only           4: Operation state         5: Stop state         only           09-42         CANopen Control Status         0: Not ready for use state         ready for use state           1: Inhibit start state         2: Ready to switch on state         Read only           3: Switched on state         4: Enable operation state         only           4: Enable operation state         only           13: Error reaction activation state         14: Error state           09-45         CANopen Master Function         0: Disable           1: Enable         0           09-46         CANopen Master Address         0-127           0: Update Index 604F and 6050 to Acceleration / Deceleration time 1 bit0 = 0: Enabled (default) bit0 = 1: Disabled         0           09-49         CANopen Extension Setting         1: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series         0           09-50         BACnet MS / TP Node Address         0-127         10           09-51         BACnet Baud Rate         9.6-76.8 Kbps         38.4           09-52         BACnet Device Index L         0-65535         10			1: Com reset state	
1.   1.   1.   1.   1.   1.   1.   1.	00.44	CANICA COMPANIA STATES	2: Boot up state	Read
5: Stop state	09-41	CANopen Communication Status	3: Pre-operation state	only
O9-42   CANopen Control Status   CANopen Con			4: Operation state	
1: Inhibit start state			5: Stop state	
09-42       CANopen Control Status       2: Ready to switch on state			0: Not ready for use state	
O9-42 CANopen Control Status  3: Switched on state 4: Enable operation state 7: Quick stop active state 13: Error reaction activation state 14: Error state  0: Disable 1: Enable  0: Disable 1: Enable  0: Update Index 604F and 6050 to Acceleration / Deceleration time 1 bit0 = 0: Enabled (default) bit0 = 1: Disabled 1: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series  09-50 BACnet MS / TP Node Address  0-127  10  09-51 BACnet Baud Rate  9:6-76.8 Kbps  38.4  10  10  10  10  10  10  10  10  10  1	09-42		1: Inhibit start state	
09-42         CANopen Control Status         4: Enable operation state         only           7: Quick stop active state         13: Error reaction activation state         14: Error state           09-45         CANopen Master Function         0: Disable 1: Enable         0           09-46         CANopen Master Address         0-127         100           09-47         CANopen Master Address         0: Update Index 604F and 6050 to Acceleration / Deceleration time 1 bit0 = 0: Enabled (default) bit0 = 1: Disabled         0: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series         00-127         10           09-50         BACnet MS / TP Node Address         0-127         10           09-51         BACnet Baud Rate         9.6-76.8 Kbps         38.4           09-52         BACnet Device Index L         0-65535         10			2: Ready to switch on state	
4: Enable operation state   7: Quick stop active state   13: Error reaction activation state   14: Error state		CANlonen Control Status	3: Switched on state	Read
13: Error reaction activation state   14: Error state		CANOPER CORROL Status	4: Enable operation state	only
09-45       CANopen Master Function       0: Disable 1: Enable       0         09-46       CANopen Master Address       0-127       100         09-49       0: Update Index 604F and 6050 to Acceleration / Deceleration time 1 bit0 = 0: Enabled (default) bit0 = 1: Disabled       1: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series       0002h         09-50       BACnet MS / TP Node Address       0-127       10         09-51       BACnet Baud Rate       9.6-76.8 Kbps       38.4         09-52       BACnet Device Index L       0-65535       10			7: Quick stop active state	
09-45         CANopen Master Function         0: Disable 1: Enable         0           09-46         CANopen Master Address         0-127         100           0: Update Index 604F and 6050 to			13: Error reaction activation state	
09-45         CANopen Master Function         1: Enable         0           09-46         CANopen Master Address         0-127         100           0: Update Index 604F and 6050 to			14: Error state	
09-46         CANopen Master Address         0-127         100           09-46         CANopen Master Address         0: Update Index 604F and 6050 to	00.45	CANonen Master Function	0: Disable	
0: Update Index 604F and 6050 to	09-43	CANopen Master Function	1: Enable	U
Acceleration / Deceleration time 1 bit0 = 0: Enabled (default) bit0 = 1: Disabled  1: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series  09-50 BACnet MS / TP Node Address  0-127  10  09-51 BACnet Baud Rate  9.6-76.8 Kbps  38.4  09-52 BACnet Device Index L  Acceleration / Deceleration time 1 bit0 = 0: Enabled (default) bit0 = 1: Disabled  1: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series  0-127  10	09-46	CANopen Master Address	0–127	100
bit0 = 0: Enabled (default) bit0 = 1: Disabled 1: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series  09-50 BACnet MS / TP Node Address 0-127 10 09-51 BACnet Baud Rate 9.6-76.8 Kbps 38.4 09-52 BACnet Device Index L 0-65535			0: Update Index 604F and 6050 to	
bit0 = 1: Disabled 1: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series  09-50 BACnet MS / TP Node Address 0-127 10 09-51 BACnet Baud Rate 9.6-76.8 Kbps 38.4 09-52 BACnet Device Index L 0-65535			Acceleration / Deceleration time 1	
1: Distinguish the CANopen identity code by models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series  09-50 BACnet MS / TP Node Address  09-51 BACnet Baud Rate  09-52 BACnet Device Index L  1: Distinguish the CANopen identity code by series  00-127  10  9-65535  10			bit0 = 0: Enabled (default)	
09-49 CANopen Extension Setting models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series  09-50 BACnet MS / TP Node Address 0-127 10 09-51 BACnet Baud Rate 9.6-76.8 Kbps 38.4 09-52 BACnet Device Index L 0-65535 10			bit0 = 1: Disabled	
models or by series bit1 = 0: Distinguish the CANopen identity code by models bit1 = 1: Distinguish the CANopen identity code by series  09-50 BACnet MS / TP Node Address 0-127 10 09-51 BACnet Baud Rate 9.6-76.8 Kbps 38.4 09-52 BACnet Device Index L 0-65535 10	00.40	CANonen Extension Setting	1: Distinguish the CANopen identity code by	00026
code by models         bit1 = 1: Distinguish the CANopen identity         code by series         09-50 BACnet MS / TP Node Address       0-127       10         09-51 BACnet Baud Rate       9.6-76.8 Kbps       38.4         09-52 BACnet Device Index L       0-65535       10	09-49	CANOPER Extension Setting	models or by series	000211
bit1 = 1: Distinguish the CANopen identity code by series  09-50 BACnet MS / TP Node Address  0-127  10  09-51 BACnet Baud Rate  9.6-76.8 Kbps  38.4  09-52 BACnet Device Index L  0-65535  10			bit1 = 0: Distinguish the CANopen identity	
code by series           09-50 BACnet MS / TP Node Address         0-127         10           09-51 BACnet Baud Rate         9.6-76.8 Kbps         38.4           09-52 BACnet Device Index L         0-65535         10			code by models	
09-50         BACnet MS / TP Node Address         0-127         10           09-51         BACnet Baud Rate         9.6-76.8 Kbps         38.4           09-52         BACnet Device Index L         0-65535         10			bit1 = 1: Distinguish the CANopen identity	
09-51       BACnet Baud Rate       9.6–76.8 Kbps       38.4         09-52       BACnet Device Index L       0–65535       10			code by series	
09-52 BACnet Device Index L 0–65535 10	09-50	BACnet MS / TP Node Address	0–127	10
	09-51	BACnet Baud Rate	9.6–76.8 Kbps	38.4
09-53 BACnet Device Index H 0–63 0	09-52	BACnet Device Index L	0–65535	10
	09-53	BACnet Device Index H	0–63	0

	Pr.	Parameter Name	Setting Range	Default
	09-55	BACnet Max Address	0–127	127
	09-56	BACnet Password	0–65535	0
			0: No communication card	
			1: DeviceNet slave	
			2: Profibus-DP slave	Pood
	09-60	Communication Card Identifications	3: CANopen slave / master	
			5: EtherNet/IP Slave	Offig
			8: BACnet IP	
			12: PROFINET	
	09-61	Firmware Version of Communication	Read only	Read
	09-01	Card	rteau only	only
	09-62	Product Code	Read only	Read
	09-02	Floudel Code	Read Offiy	only
	09-63	Error Code	Read only	Read
	09-03	Elloi Code	Read Offiy	only
,	09-70	Communication Card Address	DeviceNet: 0–63	1
^	09-70	(for DeviceNet or PROFIBUS)	Profibus-DP: 1–125	1
			Standard DeviceNet:	
			0: 125 Kbps	
			1: 250 Kbps	
			2: 500 Kbps	Read only Read only Read only Read
			3: 1 Mbps (Delta only)	
			Non-standard DeviceNet: (Delta only)	
		Communication Card Speed Setting	0: 10 Kbps	
×	09-71	(for DeviceNet)	1: 20 Kbps	Read only Read only Read only 2
		(ioi Device Not)	2: 50 Kbps	
			3: 100 Kbps	
			4: 125 Kbps	
			5: 250 Kbps	Read only Read only Read only 2
			6: 500 Kbps	
			7: 800 Kbps	
			8: 1 Mbps	
			0: Standard DeviceNet	
			In this mode, baud rate can only be 125	
		Additional Settings for Communication	Kbps, 250 Kbps, 500 Kbps in standard	
×	09-72	Card Speed (for DeviceNet)	DeviceNet speed	0
			1: Non-standard DeviceNet	
			In this mode, DeviceNet baud rate can be	
			the same as that for CANopen (0–8).	

	Pr.	Parameter Name	Setting Range	Default
	09-74	Communication Card Control Flag	bit0: set the EDS identity definition of EIP card bit0 = 0: identify EIP card by the drive's family (EDS, old) bit0 = 1: identify EIP card by the drive's series (EDS, new)	0
*	09-75	Communication Card IP Configuration (for Modbus TCP)	0: Static IP 1: Dynamic IP (DHCP)	0
*	09-76	Communication Card IP Address 1 (for Modbus TCP)	0–65535	0
*	09-77	Communication Card IP Address 2 (for Modbus TCP)	0–65535	0
*	09-78	Communication Card IP Address 3 (for Modbus TCP)	0–65535	0
*	09-79	Communication Card IP Address 4 (for Modbus TCP)	0–65535	0
*	09-80	Communication Card Address Mask 1 (for Modbus TCP)	0–65535	0
*	09-81	Communication Card Address Mask 2 (for Modbus TCP)	0–65535	0
*	09-82	Communication Card Address Mask 3 (for Modbus TCP)	0–65535	0
*	09-83	Communication Card Address Mask 4 (for Modbus TCP)	0–65535	0
*	09-84	Communication Card Gateway Address 1 (for Modbus TCP)	0–65535	0
*	09-85	Communication Card Gateway Address 2 (for Modbus TCP)	0–65535	0
*	09-86	Communication Card Gateway Address 3 (for Modbus TCP)	0–65535	0
*	09-87	Communication Card Gateway Address 4 (for Modbus TCP)	0–65535	0
*	09-88	Communication Card Password (Low Word) (for Modbus TCP)	0–99	0
*	09-89	Communication Card Password (High Word) (for Modbus TCP)	0–99	0
×	09-90	Reset Communication Card (for Modbus TCP)	0: Disable 1: Reset, return to default	0

	Pr.	Parameter Name	Setting Range	Default
M	09-91	Additional Settings for the Communication Card (for Modbus TCP)	bit0: Enable IP filter bit1: Enable internet parameters (1 bit). When IP address is set, this bit is enabled. After updating the communication card parameters, this bit changes to disabled. bit2: Enable login password (1 bit). When you enter the login password, this bit is enabled. After updating the communication card parameters, this bit changes to disabled.	0
	09-92	Communication Card Status (for Modbus TCP)	bit0: Enable password  When the communication card is set with password; this bit is enabled.  When the password is cleared; this bit is disabled.	0

# **10 Sensorless Motor Control Parameters**

	Pr.	Parameter Name	Setting Range	Default
		Treatment for Speed Observer	0: Warn and continue operation	
×	10-08	Feedback Fault	1: Fault and ramp to stop	2
		(applied to 230V / 460V Models)	2: Fault and coast to stop	
		Detection Time of Speed	0.0–10.0 sec.	
×	10-09	Observer Feedback Fault	0: Disable	1.0
		(applied to 230V / 460V Models)	U. Disable	
~	10-10	Speed Observer Stall Level	0–120%	115
	10-10	(applied to 230V / 460V Models)	0: No function	115
		Detection Time of Speed		
×	10-11	Observer Stall	0.0–2.0 sec.	0.1
		(applied to 230V / 460V Models)		
		Speed Observer Stall Action	0: Warn and continue operation	
×	10-12	Speed Observer Stall Action	1: Fault and ramp to stop	2
		(applied to 230V / 460V Models)	2: Fault and coast to stop	
[	10-13	Speed Observer Slip Range	0–50%	50
	10-13	(applied to 230V / 460V Models)	0: No function	50
		Detection Time of Speed		
×	10-14	Observer Slip	0.0–10.0 sec.	0.5
		(applied to 230V / 460V Models)		
		Speed Observer Stall And Slip	0: Warn and continue operation	
×	10-15	Error Action	1: Fault and ramp to stop	2
		(applied to 230V / 460V Models)	2: Fault and coast to stop	
×	10-31	I/F Mode, Current Command	0-150% of motor rated current	40
•		PM FOC Sensorless Speed		
×	10-32	Estimator Bandwidth (High	0.00–600.00 Hz	5.00
		Speed)		
•		PM FOC Sensorless Speed		
×	10-33	Estimator Bandwidth (Low Speed)	0.00–600.00 Hz	1.00
		(applied to 230V / 460V Models)		
	10.04	PM Sensorless Speed Estimator	0.00 655.25	1.00
~	10-34	Low-Pass Filter Gain	0.00–655.35	1.00
	10.05	AMR (Kp) Gain	0.00.2.00	4.00
~	10-35	(applied to 230V / 460V Models)	0.00–3.00	1.00
	10.00	AMR (Ki) Gain	0.00.3.00	4.00
*	10-36	(applied to 230V / 460V Models)	0.00–3.00	1.00
	10.00	Frequency to Switch from I/F	0.00 500 00 11-	20.00
*	10-39	Mode to PM Sensorless Mode	0.00–599.00 Hz	20.00
	10.40	Frequency to Switch from PM	0.00 500 00 H-	20.00
	10-40	Sensorless Mode to I/F Mode	0.00–599.00 Hz	20.00

	Pr.	Parameter Name	Setting Range	Default
*	10-41	I/F Mode, Id Current Low-Pass Filter Time	0.0-6.0 sec.	0.2
×	10-42	Initial Angle Detection Pulse Value	0.0–3.0 times of motor's rated current	1.0
*	10-49	Zero Voltage Time During Start- Up	0.000-60.000 sec.	0.000
×	10-51	Injection Frequency	0–1200 Hz	500
			0.0–200.0 V	
	10-52	Injection Magnitude	230V models: 0.0–100.0 V	0.2 1.0 0.000 500 15.0 30.0 30.0
~	10-32	Injection Magnitude	460V models: 0.0–200.0 V	
			575V models: 0.0–200.0 V	30.0
×	10-53	PM Initial Rotor Position  Detection Method	Disable     Using I/F current command to attract the rotor to zero degrees     High frequency injection     Pulse injection	0
*	10-54	Magnetic Flux Linkage Estimate Low-Speed Gain (applied to 230V / 460V Models)	10–1000%	100
*	10-55	Magnetic Flux Linkage Estimate High-Speed Gain (applied to 230V / 460V Models)	10–1000%	100
*	10-56	Kp of Phase-Locked Loop (applied to 230V / 460V Models)	10–1000%	100
*	10-57	Ki of Phase-Locked Loop (applied to 230V / 460V Models)	10–1000%	100
*	10-58	Mutual Inductance Gain Compensation (applied to 230V / 460V Models)	0.00-655.35	1.00

# 11 Advanced Parameters (Applied to 230V / 460V models)

	Pr.	Parameter Name	Setting Range	Default
			bit0: Auto-tuning for ASR and APR	
	11-00	System Control	bit6: 0 Hz linear-cross	0000h
			bit7: Saving or not saving the frequency	
•	11-01	Per-Unit of System Inertia	1–65535 (256 = 1PU)	256
×	11-02	ASR1 / ASR2 Switch Frequency	0.00–599.00 Hz	7.00
~	11-03	ASR1 Low-Speed Bandwidth	1-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
×	11-04	ASR2 High-Speed Bandwidth	1-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
×	11-05	Zero-Speed Bandwidth	1–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (SynRM)	10
*	11-06	ASR 1 Gain	0-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
×	11-07	ASR 1 Integral Time	0.000-10.000 sec.	0.100
×	11-08	ASR 2 Gain	0-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
~	11-09	ASR 2 Integral Time	0.000-10.000 sec.	0.100
~	11-10	ASR Gain of Zero Speed	0-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
*	11-11	ASR Integral Time of Zero Speed	0.000-10.000 sec.	0.100
*	11-12	Gain for ASR Speed Feed Forward	0–200%	0
×	11-13	PDFF Gain Value	0–200%	30
*	11-14	ASR Output Low Pass Filter Time	0.000-0.350 sec.	0.008
×	11-15	Notch Filter Depth	0–100 dB	0
*	11-16	Notch Filter Frequency	0.0–6000.0 Hz	0.0
*	11-17	Forward Motor Torque Limit Quadrant I	0–500%	500
*	11-18	Forward Regenerative Torque Limit Quadrant II	0–500%	500
*	11-19	Reverse Motor Torque Limit Quadrant III	0–500%	500
*	11-20	Reverse Regenerative Torque Limit Quadrant IV	0–500%	500
*	11-21	Flux Weakening Curve for Motor 1 Gain Value	0–200%	90
*	11-22	Flux Weakening Curve for Motor 2 Gain Value	0–200%	90
*	11-23	Flux Weakening Area Speed Response	0–150%	65
	11-24	Droop Rate Percentage	0.00-10.00%	0.00
	11-25	Droop Function Start Frequency	0.00–599.00 Hz	0.00

# **12 PUMP Parameters**

	Pr.	Parameter Name	Setting Range	Default	
			0: No operation		
			1: Fixed time circulation (by time)		
	40.00		2: Fixed quantity circulation	•	
	12-00	Circulation Control	3: Fixed quantity control	0	
12-01   Numerical Numerica			4: Fixed time circulation + fixed quantity circulation		
			5: Fixed time circulation + fixed quantity control		
•	10.01	Number of Motors to be		_	
	12-01	Connected	1–8	1	
•		Operating Time for Each Motor		_	
	12-02	(Minutes)	0–65500 min.	0	
•		Delay Time due to the			
	12-03	Acceleration (or the Increment )	0.0-3600.0 sec.	1.0	
		at Motor Switching (Seconds)			
		Delay Time due to the			
	12-04	Deceleration (or the Decrement)	0.0-3600.0 sec.	1.0	
		at Motor Switching (Seconds)			
•		Delay Time due to Fixed			
N	12-05	Quantity Circulation at Motor	0.0-3600.0 sec.	10.0	
	Sw Fre	Switching (Seconds)			
•		Frequency when Switching			
×	12-06	Motors at Fixed Quantity	0.00–599.00 Hz	60.0	
	12-06 Mo Cii	Circulation (Hz)			
•		A stier when Fired Overtite	0: Turn off all output		
	12-07	Action when Fixed Quantity	1: Motors powered by mains electricity continues to	0	
		Circulation Breaks Down	operate		
	12.00	Frequency for Stopping Auxiliary	0.00 500 00 Uz	0.00	
7	12-00	Motor (Hz)	0.00–599.00 Hz	0.00	
	10.00	Fixed Quantity Circulation	4.0. 2000 0	1.0	
<b>*</b>	12-09	Output Delay	1.0–3600.0 sec.	1.0	
	12-10	Motor 1 Operation Record	Dood only	Read	
	12-10	(Min./Sec.)	Read only	only	
	12-11	Motor 1 Operation Record	Dood only	Read	
	12-11	(Hour)	Read only	only	
	12-12	Motor 2 Operation Record	Dood only	Read	
	12-12	(Min./Sec.)	Read only	only	
	12-13	Motor 2 Operation Record	Pond only	Read	
	12-13	(Hour)	Read only	only	
	10 14	Motor 3 Operation Record	Pood only	Read	
	12-14	(Min./Sec.)	Read only	only	

Pr.	Parameter Name	Setting Range	Default	
12-15	Motor 3 Operation Record	Dood only	Read	
12-15	(Hour)	Read only	only	
12-16	Motor 4 Operation Record	Read only	Read	
12-10	(Min./Sec.)	Read only	only	
12-17	Motor 4 Operation Record	Read only	Read	
12-17	(Hour)	Read Only	only	
12-18	Motor 5 Operation Record	Read only	Read	
12-10	(Min./Sec.)	Read Only	only	
12-19	Motor 5 Operation Record	Read only	Read	
12-13	(Hour)	read only	only	
12-20	Motor 6 Operation Record	Read only	Read	
12-20	(Min./Sec.)	read only	only	
12-21	Motor 6 Operation Record	Read only	Read	
12 21	(Hour)	Troud Grilly	only	
12-22	Motor 7 Operation Record	Read only	Read	
12 22	(Min./Sec.)	Troud Grilly	only	
12-23	Motor 7 Operation Record	Read only	Read	
12 20	(Hour)	. toda cy	only	
12-24	(Hour)  Motor 8 Operation Record (Min./Sec.)	Read only	Read	
		. toda cy	only	
12-25	Motor 8 Operation Record	Read only	Read	
	(Hour)	,	only	
		0: No function		
		1: Clear operation time for motor 1		
		2: Clear operation time for motor 2		
		3: Clear operation time for motor 3		
12-26	Clear Motor's Operation Time	4: Clear operation time for motor 4	0	
12 20	Olean Motor o Operation Time	5: Clear operation time for motor 5	0	
		6: Clear operation time for motor 6		
		7: Clear operation time for motor 7		
		8: Clear operation time for motor 8		
		10: Clear operation time for all motors		
12-27	Priority for Circulated Operation	0: Terminal order	0	
12-21	Thomas of Chodiated Operation	1: Minimum operation time		

# 13 Application Parameters by Industry

Pr.	Parameter Name	Setting Range	Default
		0: Disable	
13-00		1: User-defined Parameter	
	Industry-Specific Parameters	2: Compressor (IM)	0
13-00	Application	3: Fan	0
		4: Pump	
		10: Air Handling Unit, AHU	
13-01			
- 1	Industry Parameters 1–99	0.00–655.35	0.00
13-99			

# **14 Extension Card Parameters**

	Pr.	Parameter Name	Setting Range	Default
~	14-00	Extension Card Input Terminal	0: Disable	0
<i>/</i> ·	14-00	Selection (Al10)	1: Frequency command	O
~	14-01	Extension Card Input Terminal	4: PID target value	0
<i>/</i> ·	14-01	Selection (AI11)	5: PID feedback signal	O
			6: Thermistor (PTC) input value	
			11: PT100 thermistor input value	
			13: PID compensation amount	
×	14-08	Analog Input Filter Time (Al10)	0.00–20.00 sec.	0.01
×	14-09	Analog Input Filter Time (AI11)	0.00–20.00 sec.	0.01
	14-10	Analog Input 4–20 mA Signal Loss	0: Disable	0
	14-10	Selection (Al10)	1: Continue operation at the last frequency	O
		Analog Input 4–20 mA Signal Loss	2: Decelerate to 0 Hz	
	14-11	Selection (Al11)	3: Stop immediately and display ACE	0
		00.0000(, 1111)	4: Operates with output frequency lower limit	
N	14-12	Extension Card Output Terminal	0: Output frequency (Hz)	0
		Selection (AO10)	1: Frequency command (Hz)	_
N	14-13	Extension Card Output Terminal	2: Motor speed (Hz)	0
ŕ		Selection (AO11)	3: Output current (rms)	-
			4: Output voltage	
			5: DC bus voltage	
			6: Power factor	
			7: Power	
			9: AVI1 proportional	
			10: ACI proportional	
			11: AVI2 proportional	
			20: CANopen analog output	
			21: RS-485 analog output	
			22: Communication card analog output	
			23: Constant voltage output	
×	14-14	Analog Output 1 Gain (AO10)	0.0–500.0%	100.0
×	14-15	Analog Output 1 Gain (AO11)	0.0–500.0%	100.0
	14-16	Analog Output 1 in REV Direction	O. Abachita value of autout valtage	0
~	14-10	(AO10)	0: Absolute value of output voltage	0
	44.47	Analog Output 1 in REV Direction	1: Reverse output 0 V; Forward output 0–10 V	
×	14-17	(AO11)	2: Reverse output 5–0 V; Forward output 5–10 V	0
			0: 0–10 V (AVI10)	
×	14-18	Extension Card Input Selection	1: 0–20 mA (ACI10)	0
		(Al10)	2: 4–20 mA (ACI10)	
	<u> </u>	I	<u>'</u>	

	Pr.	Parameter Name	Setting Range	Default	
		Extension Card Input Selection	0: 0–10 V (AVI11)		
<b>%</b> 14-19	14-19	Extension Card Input Selection	1: 0–20 mA (ACI11)	0	
	(Al11)	2: 4–20 mA (ACI11)			
	14-20	AO10 DC Output Setting Level	0.00-100.00%	0.00	
	14-21	AO11 DC Output Setting Level	0.00-100.00%	0.00	
×	14-22	AO10 Filter Output Time	0.00-20.00 sec.	0.01	
×	14-23	AO11 Filter Output Time	0.00-20.00 sec.	0.01	
*	14-36	AO10 Output Selection	0: 0–10 V	0	
			1: 0–20 mA		
×	14-37	AO11 Output Selection	2: 4–20 mA	0	

[This page is intentionally left blank]

# Chapter 12 Description of Parameter Settings

- 12-1 Description of Parameter Settings
- 12-2 Adjustment & Application

### 12-1 Description of Parameter Settings

### **00 Drive Parameters**

✓ You can set this parameter during operation.

**00-00** AC Motor Drive Identity Code

Default: Read only

Settings Read only

**00-01** AC Motor Drive Rated Current Display

Default: Read only

Settings Read only

- Pr.00-00 displays the AC motor drive identity code. Using the following specification table to check if Pr.00-01 setting is the rated current of the AC motor drive. Pr.00-01 corresponds to the identity code of the AC motor drive (Pr.00-00).
- The default is the rated current for light duty. Set Pr.00-16 to 1 to display the rated current for normal duty.

230V Models															
Frame					Α								В		
Power (kW)	0.75		1.5		2.2		3.	.7		5.5		7.5		11	
Power (HP)	1		2		3		5			7.5		10		15	
Identity Code	4		6		8		1	0		12		14		16	
Rated Current for	5		7.5		10		15			21		31		46	
Light Duty (A)	3		1.5		10		'			<u> </u>		J1		40	
Rated Current for	3	3 5			8		1	1		17		25		33	
Normal Duty (A)								<u>'</u>							
Frame	С						D	0					D		
Power (kW)	15		18.	.5		22			30		37	7		45	
Power (HP)	20		25	5		30			40		50	)		60	
Identity Code	18		20	)		22			24		26	3		28	
Rated Current for	61		75	5		90			105		1/	146		180	
Light Duty (A)	01		75			90			105		140			100	
Rated Current for	49		65		75			90		12	n		146		
Normal Duty (A)	73			,		7.5			30		12			140	
	460V Models														
Frame					Α	4								В	
Power (kW)	0.75	1.5	5	2.2	3.	.7	4.	.0	5.5	5.5 7		5 11		15	
Power (HP)	1	2		3	5	5		5	7.5		10	1	5	20	
Identity Code	5	7		9	1	1	9	3	13		15	1	7	19	
Rated Current for	3.0	4.2	,	5.5	8.	5	10.5		13		18		4	32	
Light Duty (A)	5.0	7.2	_	0.0	0.		10	,.0	10		10			52	
Rated Current for	1.7	3.0	n	4.0	6.	Λ	9.	0	10.5		12	1	8	24	
Normal Duty (A)	1.7			T.U	0.		3.	.0	10.0	<u> </u>	12	'			
Frame		В			С				D	0				)	
Power (kW)	18.5		22	30		3	7	4	5	55		75		90	
Power (HP)	25		30	40		5	0	60	0	75		100		125	
Identity Code	21		23	25		2	.7	29	9	31		33		35	
Rated Current for	38		45	60		7	3	0-	1	110	, ]	150		180	
Light Duty (A)	30		<del>4</del> 0	00			J	9	91		110			100	
Rated Current for	32		38	45		60		73		91		110		150	
Normal Duty (A)	02							13		91		110		100	

			575\	/ Mod	dels								
Frame			Α					В					
Power (kW)	1.5	2.2	3.7	3.7 5		5.5 7.5		11		15	18.5		
Power (HP)	2	3	5	-	7.5	10	)	15		20	25		
Identity Code	505	506	507	5	508	50	9	510		511	512		
Rated Current for Light Duty (A)	3	4.3	6.7	,	9.9	12.1		18.7		24.2	30		
Rated Current for Normal Duty (A)	2.5	3.6	5.5	8	3.2	10		15.5		20	24		
Frame		С		D0			0			D	١		
Power (kW)	22	30	37		4	45		55		75	90		
Power (HP)	30	40	50	l	6	0		75	•	100	125		
Identity Code	513	514	51	5	5′	16		517	1,	518	519		
Rated Current for Light Duty (A)	36	45	54		6	7		86	,	104	125		
Rated Current for Normal Duty (A)	30	36	45	i	54		67			86	104		

### 00-02 Parameter Reset

Default: 0

Settings 0: No Function

1: Write protection for parameters

5: Reset kWh display to 0

6: Reset PLC (including CANopen Master Index)

7: Reset CANopen Slave Index

9: Reset all parameters to defaults (base frequency is 50 Hz)

10: Reset all parameters to defaults (base frequency is 60 Hz)

- 1: All parameters are read only except Pr.00-02, Pr.00-07 and Pr.00-08. Set Pr.00-02 to 0 before changing other parameter settings.
- 5: You can return the kWh displayed value to 0 even during drive operation. For example, you can set Pr.05-26–Pr.05-30 to 0.
- 6: Clear the internal PLC program (includes the related settings of PLC internal CANopen master).
- 2 7: Reset the related settings of CANopen slave.
- 9 or 10: Reset all parameters to defaults. If you have set a password (Pr.00-08), unlock the password (Pr.00-07) to clear the password you have set before you reset all parameters.
- For settings of 6, 7, 9 and 10, you must reboot the motor drive after you finish the setting.

# Output Start-up Display

Default: 0

Settings 0: F (Frequency command)

1: H (Output frequency)

2: U (User defined, see Pr.00-04)

3: A (Output current)

Determines the start-up display page after power is applied to the drive. The user-defined contents display according to the Pr.00-04 setting.

### ✓ 00-04 Content of Multi-function Display (User-defined)

Default: 3

- Settings 0: Display output current (A) (Unit: Amp)
  - 1: Display counter value (c) (Unit: CNT)
  - 2: Display the motor's actual output frequency (H) (Unit: Hz)
  - 3: Display the drive's DC bus voltage (v) (Unit: V<sub>DC</sub>)
  - 4: Display the drive's output voltage (E) (Unit: V<sub>AC</sub>)
  - 5: Display the drive's output power angle (n) (Unit: deg)
  - 6: Display the drive's output power (P) (Unit: kW)
  - 7: Display the motor speed rpm (Unit: rpm)
  - 10: Display PID feedback (b) (Unit: %)
  - 11: Display AVI1 analog input terminal signal (1.) (Unit: %)
  - 12: Display ACI analog input terminal signal (2.) (Unit: %)
  - 13: Display AVI2 analog input terminal signal (3.) (Unit: %)
  - 14: Display the drive's IGBT temperature (i.) (Unit: °C)
  - 15: Display the drive's capacitance temperature (c.) (Unit: °C)
  - 16: The digital input status (ON/OFF) (i)
  - 17: The digital output status (ON/OFF) (o)
  - 18: Display multi-step speed (S)
  - 19: The corresponding CPU digital input pin status (d)
  - 20: The corresponding CPU digital output pin status (0.)
  - 26: Ground fault GFF (G.) (Unit: %)
  - 27: DC bus voltage ripple (r.) (Unit: V<sub>DC</sub>)
  - 28: Display PLC register D1043 data (C)
  - 30: Display the output of user-defined (U)
  - 31: Display Pr.00-05 user gain (K)
  - 34: Operation speed of fan (F.) (Unit: %)
  - 36: Present operating carrier frequency of the drive (Hz) (J.)
  - 38: Display the drive status (6.)
  - 41: kWh display (J) (Unit: kWh)
  - 42: PID target value (h) (Unit: %)
  - 43: PID compensation (o.) (Unit: %)
  - 44: PID output frequency (b.) (Unit: Hz)
  - 45: Hardware ID
  - 51: PMSVC torque offset
  - 52: AI10%
  - 53: AI11%
  - 54: PMFOC Ke estimation value
  - 68: STO version (d)
  - 69: STO checksum-high word (d)
  - 70: STO checksum-low word (d)

#### Explanation 1

It can display negative values when setting analog input bias (Pr.03-03-03-10).

Example: Assume that AVI1 input voltage is 0 V, Pr.03-03 is 10.0% and Pr.03-07 is 4 (Bias serves as the center).

#### **Explanation 2**

Example: If REV, MI1 and MI6 are ON, the following table shows the status of the terminals.

Normally opened contact (N.O.), 0: OFF, 1: ON

Terminal	MI15	MI14	MI13	MI12	MI11	MI10	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD
Status	0	0	0	0	0	0	0	0	1	0	0	0	0	1	1	0

**NOTE:** MI10–MI15 are terminals for extension cards (Pr.02-26–02-31).

- The value is 0000 0000 1000 0110 in binary and 0086h in HEX. When Pr.00-04 is set to 16 or 19, the u page on the keypad displays "0086h".
- The setting value 16 is ON / OFF status of digital input according to Pr.02-12 setting, and the setting value 19 is the corresponding CPU pin ON / OFF status of the digital input.
- You can set 16 to monitor the digital input ON / OFF status, and then set 19 to check if the circuit is normal.

### **Explanation 3**

Assume that RY1: Pr.02-13 is set to 9 (Drive ready). After the drive powered on, if there is no other abnormal status, the contact is ON. The display status is shown as below.

Normally opened contact (N.O.):

Termina	MO20	MO19	MO18	MO17	MO16	MO15	MO14	MO13	MO12	MO11	MO10	Reserved	Reserved	RY3	RY2	RY1
Status	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1

- If Pr.00-04 is set to 17 or 20, it displays the hexadecimal 0001h with LED u page is ON in the keypad.
- The setting value 17 is ON / OFF status of digital output according to Pr.02-18 setting, and the setting value 20 is the corresponding CPU pin ON / OFF status of the digital output.
- You can set 17 to monitor the digital output ON / OFF status, and then set 20 to check if the circuit is normal.

#### **Explanation 4**

Setting value 25: when displayed value reaches 100.00%, the drive shows oL as an overload warning.

#### Explanation 5

Setting value 38:


bit 0: The drive is running forward. bit 3: Errors occurred on the drive.

bit 1: The drive is running backward. bit 4: The drive is running.

bit 2: The drive is ready. bit 5: Warnings occurred on the drive.

N	00-05	Coeffici	ient Gain in Actual Output Frequency						
			Default: 1.00						
		Settings	0.00–160.00						
	Sets the	e user-defii	ined unit coefficient gain. Set Pr.00-04 = 31 to display the calculation res	sult on					
	the scre	een (calcula	lation = output frequency × Pr.00-05).						
	00-06	Firmwai	re Version						
			Default: Read only						
		Settings	Read only						
N	00-07	Parame	eter Protection Password Input						
			Default: 0						
		Settings							
		Display	0–4 (the number of password attempts allowed)						
	This pa	rameter all	lows you to enter your password (which is set in Pr.00-08) to unlock the						
	parame	ter protect	tion and to make changes to the parameter.						
	To avoid	d problems	s in the future, be sure to write down the password after you set this par	ameter.					
	Pr.00-07 and Pr.00-08 are used to prevent personnel from setting other parameters by accident.								
	If you fo	7 3 1 7 1 3 7 1 3 7 1							
	9999 aç	gain and pr	ress ENTER within 10 seconds. After decoding, all the settings return to	default.					
	When s	etting is ur	nder password protection, all the parameters read 0, except Pr.00-08.						
~	80-00	Parame	eter Protection Password Setting						
			Default: 0						
		Settings	0–65535						
			0: No password protection or password entered correctly (Pr.00-07)						
			1: Password has been set						
	This pa	rameter se	ets the password protection. Password can be set directly the first time.	After you					
	set the	password,	the value of Pr.00-08 is 1, which means password protection is activate	ed. At					
	this time	e, if you wa	ant to change any of the parameter settings, you must enter the correct						
	passwo	ord in Pr.00	0-07 to deactivate the password temporarily, and this would make Pr.00-	80					
	become	e 0. After yo	ou finish setting the parameters, reboot the motor drive and the passwo	rd is					
	activate	ed again.							
	Entering	g the corre	ect password in Pr.00-07 only temporarily deactivates the password. To						
	perman	ently deac	ctivate password protection, set Pr.00-08 to 0 manually. Otherwise, pass	word					
	protecti	on is alway	ys reactivated after you reboot the motor drive.						
	The key	ypad copy	function works only when the password protection is deactivated (temporary	orarily or					
	perman	ently), and	d the password set in Pr.00-08 cannot be copied to the keypad. So wher	า					
	copying	g paramete	ers from the keypad to the motor drive, set the password manually again	in the					
	motor d	Irive to acti	ivate password protection.						

#### Password Decode Flow Chart



### 00-11 Speed Control Mode


Default: 0

Settings 0: IMVF (IM V/F control)


2: IM / PM SVC (IM / PM space vector control)

6: PM Sensorless (PM field-oriented sensorless vector control) (applied to 230V / 460V models)


- 8: SynRM Sensorless Control (applied to 230V / 460V models)
- Determines the control method of the AC motor drive:
  - 0: IM V/F control: you can set the proportion of V/F as required and control multiple motors simultaneously.
  - 2: IM / PM space vector control: gets the optimal control by auto-tuning the motor parameters.
  - 6: PM sensorless: PM field-oriented sensorless vector control
  - 8: SynRM sensorless: SynRM field-oriented sensorless vector control
- When you set Pr.00-11 to 0, the V/F control diagram is as follows:




When you set Pr.00-11 to 2, the space vector control diagram is as follows. Induction Motor Space Vector Control (IMSVC)




Permanent Magnetic Motor Space Vector Control (PMSVC)



When you set Pr.00-11 to 6, PM FOC Sensorless control diagram is as follows:



When you set Pr.00-11 to 8, SynRM Sensorless control diagram is as follows:



### 00-15 Start Wizard

Default: 1

Settings bit0: Enable or disable

0: Disable1: Enable

- $\square$  bit0 = 0 disable the function; bit0 = 1 enable the function.
- The Start Wizard can also be disabled or enabled through keypad KPC-CC01, item 16 "Start Wizard" in the keypad menu.
- Start Wizard process is default ON for the first power on of new product. Refer to Section 10-2 for detailed information.

# 00-16 Load Selection

Default: 0

Settings 0: Light duty

1: Normal duty

- Light duty: over-load ability is 120% rated output current in 60 seconds. Refer to Pr.00-17 for the setting of carrier frequency. Refer to Chapter 9 Specifications or Pr.00-01 for the rated current.
- Normal duty: over-load ability is 120% rated output current in 60 seconds (160% rated output current in 3 seconds). Refer to Pr.00-17 for the setting of carrier frequency. Refer to Chapter 9 Specifications or Pr.00-01 for the rated current.
- Pr.00-01 varies with the setting value for Pr.00-16. The default value and maximum setting value for Pr.06-03 and Pr.06-04 also vary with the setting value for Pr.00-16.

# 00-17 Carrier Frequency

Default: Table below

Settings 2–15 kHz

- This parameter determines the PWM carrier frequency for the AC motor drive.
- When you set Pr.00-11 = 8 (SynRM Sensorless control), the maximum setting value of carrier frequency is 8 kHz.

#### 230V / 460V models:

Control Mode	VF,	SVC	PMF	-oc	SRM	FOC
Model	Settings	Default	Settings	Default	Settings	Default
VFD007-110FP2EA VFD007-185FP4EA	2–15 kHz	6 kHz	4–10 kHz	6 kHz	4–8 kHz	4 kHz
VFD150-300FP2EA VFD220-750FP4EA	2–10 kHz	6 kHz	4–10 kHz	6 kHz	4–8 kHz	4 kHz
VFD370–450FP2EA VFD900FP4EA	2–9 kHz	6 kHz	4–9 kHz	6 kHz	4–8 kHz	4 kHz

#### • 575V models:

Control Mode	VF,	SVC
Model	Settings	Default
VFD015-185FP5EA	2–15 kHz	6 kHz
VFD220-550FP5EA	2–10 kHz	6 kHz
VFD750-900FP5EA	2–9 kHz	6 kHz

	Carrier Frequency	Acoustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave
	2kHz	Significant	Minimal	Minimal	<del></del>
	8kHz	<b>1</b>	<b>1</b>	Ī	
Ī	15kHz			↓	-√√√√ ↓
		Minimal	Significant	Significant	

- From the table, you see that the PWM carrier frequency has significant influences on the electromagnetic noise, the AC motor drive heat dissipation, and the motor acoustic noise. Therefore, if the surrounding noise is greater than the motor noise, lower the carrier frequency to reduce the temperature rise. Although the motor has quiet operation in the higher carrier frequency, consider the entire wiring and interference.
- When the carrier frequency is higher than the default, decrease the carrier frequency to protect the drive. Refer to Pr.06-55 for the related setting and details.

# 00-19 PLC Command Mask

Default: Read only

Settings bit0: Control command is forced by PLC control

bit1: Frequency command is forced by PLC control

Determines if the frequency command or control command is locked by PLC.

Master Frequency Command (AUTO) Source / Source Selection of the PID Target

Default: 0

Settings

0: Digital keypad

1: RS-485 communication input

2: External analog input (Refer to Pr.03-00–Pr.03-02)

3: External UP / DOWN terminal (multi-function input terminals)

6: CANopen communication card

8: Communication card (does not include CANopen card)

- Determines the master frequency source in AUTO mode. The default is AUTO mode.
- Pr.00-20 and Pr.00-21 set the frequency source and operation source in AUTO mode. Pr.00-30 and Pr.00-31 set the frequency source and operation source in HAND mode. You can switch the AUTO / HAND mode with the keypad KPC-CC01 or the multi-function input terminal (MI) to set the master frequency source.
- ☐ It returns to AUTO mode whenever you cycle the power. If you use a multi-function input terminal to switch between AUTO (REMOTE) and HAND (LOCAL) mode, the highest priority is the multi-function input terminal. When the external terminal is OFF, the drive does not accept any operation signal and cannot execute JOG.

# **00-21** Operation Command Source (AUTO)

Default: 0

Settings 0: Digital keypad

1: External terminals

2: RS-485 communication input

3: CANopen communication card

5: Communication card (does not include CANopen card)

- Determines the operation frequency source in AUTO mode.
- When you control the operation command by the keypad KPC-CC01, keys RUN, STOP and JOG (F1) are valid.


### 00-22 Stop Method

Default: 0

Settings 0: Ramp to stop

1: Coast to stop

Determines how the motor is stopped when the drive receives the STOP command.



Ramp to Stop and Coast to Stop

- 1. **Ramp to stop:** the AC motor drive decelerates to 0 or the minimum output frequency (Pr.01-07) according to the set deceleration time, and then to stop.
- 2. **Coast to stop:** the AC motor drive stops output immediately, and the motor coasts to stop according to the load inertia.
  - ☑ Use "ramp to stop" for the safety of personnel, or to prevent material from being wasted in applications where the motor must stop immediately after the drive stops. You must set the deceleration time accordingly.

☑ If idling is allowed, or the load inertia is large, use "coast to stop". For example, blowers, punching machines and pumps.

### ✓ 00-23 Motor Direction Control

Default: 0

Settings 0: Enable forward / reverse

Disable reverse
 Disable forward

Enables the AC motor drives to run in the forward and reverse direction. You can use it to prevent a motor from running in a direction that would cause injure or damage to the equipment, especially when only on running direction is allowed from the motor load.

### **00-24** Digital Operator (Keypad) Frequency Command Memory

Default: Read only

Settings Read only

If the keypad is the frequency command source, when Lv or Fault occurs, this parameter stores the current frequency command.

### ✓ 00-25 User-Defined Characteristics

Default: 0

Settings bit0-3: user-defined decimal place

0000b: no decimal place 0001b: one decimal place 0010b: two decimal place 0011b: three decimal place

bit4-15: user-defined unit

000xh: Hz 001xh: rpm 002xh: % 003xh: kg

004xh: m/s

005xh: kW

006xh: HP

007xh: ppm 008xh: 1/m

000XII. 1/111

009xh: kg/s

00Axh: kg/m

00Bxh: kg/h

00Cxh: lb/s

00Dxh: lb/m


00Exh: lb/h

00Fxh: ft/s

010xh: ft/m

011xh: m 012xh: ft 013xh: degC 014xh: degF 015xh: mbar 016xh: bar 017xh: Pa 018xh: kPa 019xh: mWG 01Axh: inWG 01Bxh: ftWG 01Cxh: psi 01Dxh: atm 01Exh: L/s 01Fxh: L/m 020xh: L/h 021xh: m3/s 022xh: m3/h 023xh: GPM 024xh: CFM xxxxh: Hz

- bit0–3: the displayed units for the control frequency F page and user-defined (Pr.00-04 = d10, PID feedback) and the displayed number of decimal places for Pr.00-26 (supports up to three decimal places).
- bit4–15: the displayed units for the control frequency F page, user-defined (Pr.00-04 = d10, PID feedback) and Pr.00-26.



You must convert the setting value to decimal when using the keypad to set parameters. Example:

Assume that the user-defined unit is inWG and user-defined decimal place is the third decimal point. According to the information above, the corresponding unit to inWG is 01Axh (x is the set decimal point), and the corresponding unit to the third decimal place is 0003h, then inWG and the third decimal point displayed in hexadecimal is 01A3h, that is 419 in decimal value. Thus, set Pr.00-25 = 419 to complete the setting.

### 00-26 Maximum User-Defined Value

Default: 0

Settings 0: Disable

0-65535 (when Pr.00-25 is set to no decimal place)

0.0–6553.5 (when Pr.00-25 is set to one decimal place)

0.00–655.35 (when Pr.00-25 is set to two decimal places)

0.000-65.535 (when Pr.00-25 is set to three decimal places)

When Pr.00-26 is NOT set to 0, the user-defined value is enabled. After selecting the displayed unit and number of decimal places with Pr.00-25, the setting value of Pr.00-26 corresponds to Pr.01-00 (drive's maximum operating frequency).

Example: When the frequency set in Pr.01-00 = 60.00 Hz, the maximum user-defined value for Pr.00-26 is 100.0%. This also means that Pr.00-25 is set as 0021h.

**NOTE:** Set Pr.00-25 before using Pr.00-26. After you finish setting, when Pr.00-26 is not 0, the displayed unit on the keypad shows correctly according to Pr.00-25 settings.

### 00-27 User-Defined Value

Default: Read only

Settings Read only

- Pr.00-27 displays the user-defined value when Pr.00-26 is not set to 0.
- The user-defined value is valid only when Pr.00-20 (frequency source) is set to the digital keypad or to RS-485 communication.

# Switching from AUTO mode to HAND mode

Default: 0

Settings bit0: Slee

bit0: Sleep function control bit

0: Cancel sleep function

1: Sleep function and AUTO mode are the same

bit1: Control bit unit

- 0: Displaying unit in Hz
- 1: Same unit as the AUTO mode

bit2: PID control bit

- 0: Cancel PID control
- 1: PID control and AUTO mode are the same.

bit3: Frequency source control bit

- 0: Frequency source set up by parameter, if the multi-step speed is activated, then multi-step speed has the priority.
- 1: Frequency command set up by Pr.00-30, regardless of whether the multi-step speed is activated.

### 00-29 LOCAL / REMOTE Selection

Default: 0

### Settings

- 0: Standard HOA function
- 1: When switching between local and remote, the drive stops
- 2: When switching between local and remote, the drive runs with REMOTE settings for frequency and operation status
- 3: When switching between local and remote, the drive runs with LOCAL settings for frequency and operation status
- 4: When switching between local and remote, the drive runs with LOCAL settings when switched to Local and runs with REMOTE settings when switch to Remote for frequency and operation status.
- The default for Pr.00-29 is 0, that is, the standard HOA (Hand-Off-Auto) function. Set the AUTO and HAND frequency and operation source with Pr.00-20, Pr.00-21 and Pr.00-30, Pr.00-31. Use digital keypad (KPC-CC01) or multi-function input terminal to set MIx = 41 and 42 (AUTO / HAND mode).
- When you set the external terminal (MI) to 41 and 42 (AUTO / HAND mode), Pr.00-29 = 1, 2, 3, 4 are disabled. The external terminal has the highest command priority, and Pr.00-29 functions in standard HOA mode.
- If Pr.00-29 is not set to 0, the Local / Remote function is enabled, and the top right corner of digital keypad (firmware version 1.021 and above) displays LOC or REM. Set the REMOTE frequency and operation source with Pr.00-20 and Pr.00-21. Set the LOCAL frequency and operation source with Pr.00-30 and Pr.00-31. Select or switch Local / Remote mode with the digital keypad or set the multi-function input terminal MIx = 56. The AUTO key of the digital keypad is for the REMOTE function, and HAND key is for the LOCAL function.
- When you set the external terminal (MI) to 56 for LOC / REM mode selection, if you set Pr.00-29 to 0, then the external terminal function is disabled.
- When you set the external terminal (MI) to 56 for LOC / REM mode selection, if Pr.00-29 is not set to 0, then AUTO / HAND key is disabled, and the external terminal has the highest command priority.
- The comparison between the setting of each mode and the PLC address:

PLC Address /	HOA mode		LOC / RE	LOC / REM mode		
Mode	HAND-ON	AUTO-ON	LOC-ON	REM-ON	OFF	
M1090 =	0	0	0	0	1	
M1091 =	1	0	0	0	0	
M1092 =	0	1	0	0	0	
M1100 =	0	0	1	0	0	
M1101 =	0	0	0	1	0	

# Master Frequency Command Source (HAND) 00-30 Default: 0 Settings 0: Digital keypad 1: RS-485 communication input 2: External analog input (Refer to Pr.03-00–Pr.03-02) 3: External UP / DOWN terminal 6: CANopen communication card 8: Communication card (does not include CANopen card) Determines the master frequency source in HAND mode. 00-31 Operation Command Source (HAND) Default: 0 Settings 0: Digital keypad 1: External terminals 2: RS-485 communication input 3: CANopen communication card 5: Communication card (does not include CANopen card) Sets the operation frequency source in HAND mode. Use Pr.00-20 and Pr.00-21 to set the frequency source and the operation source in AUTO mode, and use Pr.00-30 and Pr.00-31 to set the frequency source and operation source in HAND mode. Select or switch AUTO / HAND mode by using the digital keypad KPC-CC01 or setting the multifunction input terminal (MI). $\square$ The default for the frequency source or operation source is AUTO mode. It returns to AUTO mode whenever you cycle the power. If you use a multi-function input terminal to switch AUTO / HAND mode, the multi-function input terminal has the highest priority. When the external terminal is OFF, the drive does not accept any operation signal and cannot execute JOG. 00-32 Digital Keypad STOP Function Default: 0 Settings 0: STOP key disabled 1: STOP key enabled $\square$ Valid when the operation command source is not the digital keypad (Pr.00-21 $\neq$ 0). When Pr.00-21 = 0, the STOP key on the digital keypad is not affected by this parameter. **RPWM Mode Selection** 00 - 33Default: 0 Settings 0: Disable 1: RPWM mode 1 2: RPWM mode 2 3: RPWM mode 3

Different control modes for Pr.00-33:

Motor	Induction	Motor (IM)	Permanen Synchronous	•	Synchronous Reluctance Motor (SynRM)
Control Mode	VF	SVC	PMSVC	PMFOC	SRMFOC
0: RPWM mode 1	✓	✓	✓	✓	
1: RPWM mode 2	✓	✓	✓	✓	
2: RPWM mode 3	✓	✓	✓	✓	

- When the RPWM function is enabled, the drive randomly distributes the carrier frequency based on actual Pr.00-17 carrier frequency settings.
- The RPWM function can be applied to all control modes.
- Once the RPWM function is enabled, particularly high frequency audio noise is reduced, and the audio frequency produced by the running motor also changes (usually from a higher to lower).
- Three RPWM modes are provided for different applications. Each mode corresponds to different frequency distribution, electromagnetic noise distribution, and audio frequency.

#### 00-34 RPWM Range


Default: 0.0

Settings 0.0–4.0 kHz


- When the RPWM function is enabled, the minimum carrier frequency setting for Pr.00-17 is 3 kHz, and the maximum is 7 kHz.
- $\square$  Pr.00-34 is valid only when the RPWM function is enabled (Pr.00-33  $\neq$  0).
- Example:

When Pr.00-17 = 4 kHz, Pr.00-33 is enabled (= 1, 2, or 3), Pr.00-34 = 2.0 kHz, then the carrier frequency outputs on the basis of 4 kHz, and the random frequency distribution tolerance is ±2 kHz, that is, the carrier frequency randomly fluctuates from 2 kHz to 6 kHz.

When Pr.00-17 = 3 or 7 kHz, the maximum setting for Pr.00-34 is 2.0 kHz (±1 kHz). The carrier frequency fluctuation range is according to the diagram below.




Min. carrier frequency setting




frequency setting

When Pr.00-17 = 4, 5, or 6 kHz, the maximum setting for Pr.00-34 is 4.0 kHz (±2 kHz). The carrier frequency fluctuation range is according to the diagram below.



Min. carrier frequency setting



8 kHz 6 kHz -2 kHz +2 kHz Max. carrier frequency setting

4 kHz

# 00-37 Over-modulation Gain Default: 100 Settings 80–120 When the motor operates in the flux-weakening region or voltage saturation region it can be that a higher voltage output is required. Increase Pr.00-37 to increase the output RMS voltage. Increasing the over-modulation gain reduces the output current and enhances the motor efficiency. However, note that low-frequency harmonics created by the six-step square-wave modulation may occur if the gain is too large. How to use Pr.00-37: Gradually increase Pr.00-37 setting value to check if the output current reduces and the operation performance improves for an optimal over-modulation gain value. 00-48 Display Filter Time (Current) Default: 0.100 Settings 0.001-65.535 sec. Minimizes the current fluctuation displayed by the digital keypad. 00-49 Display Filter Time (Keypad) Default: 0.100 Settings 0.001-65.535 sec. Minimizes the value fluctuation displayed by digital keypad. Software Version (Date) 00-50 Default: Read only Settings Read only Displays the current drive software version by date.

### 01 Basic Parameters

✓ You can set this parameter during operation.

### ✓ 01-00 Maximum Operation Frequency of Motor 1

Default: 60.00 / 50.00

Settings 0.00–599.00 Hz

Determines the AC motor drive's maximum operation frequency range. All the AC motor drive frequency command sources (0 – +10 V, 4–20 mA, 0–20 mA, ±10 V) are scaled to correspond to the output frequency range.

Minimum Carrier Wave Requirement	Maximum Operation Frequency (IM VF/ IM SVC)
2k	200 Hz
3k	300 Hz
4k	400 Hz
5k	500 Hz
6k	599 Hz

01-01	Rated / Base Frequency of Motor 1
01-35	Rated / Base Frequency of Motor 2

Default: 60.00 / 50.00

Settings 0.00-599.00 Hz

Set this parameter according to the motor's rated frequency on the motor's nameplate. If the motor's rated frequency is 60 Hz, set this parameter to 60. If the motor's rated frequency is 50 Hz, set this parameter to 50.

O1-36 Rated / Base Voltage of Motor 2  Default:	<b>01-02</b> Rated /	Base Voltage of Motor 1		
	<b>01-36</b> Rated /	Base Voltage of Motor 2		
0.44			Default:	
Settings 230V models: 0.0–255.0 V 200.0	Settings	230V models: 0.0–255.0 V	20	0.00
460V models: 0.0–510.0 V 400.0		460V models: 0.0–510.0 V	40	0.00
575V models: 0.0–637.0 V 575.0		575V models: 0.0–637.0 V	57	75.0

- Set this parameter according to the motor's rated voltage on the motor's nameplate. If the motor's rated voltage is 220 V, set this parameter to 220.0. If the motor's rated voltage is 200 V, set this parameter to 200.0.
- There are many motor types in the market and the power system for each country is also different. The economical and convenient solution is to install an AC motor drive. Then there is no problem using the motor with different voltage and frequency inputs, and the motor drive can improve the original motor characteristics and useful life.


01-03	Mid-poir	nt Frequency 1 of Motor 1	
			Default:
	Settings	230V models: 0.00-599.00 Hz	3.00
		460V models: 0.00-599.00 Hz	3.00
		575V models: 0.00-599.00 Hz	0.00

$\mathcal{M}$	01-04	Mid-poir	nt Voltage 1 of Motor 1		
				Default:	
		Settings	230V models: 0.0–240.0 V	11.0	
			460V models: 0.0–480.0 V	22.0	
			575V models: 0.0–637.0 V	0.0	
	01-37	Mid-poir	nt Frequency 1 of Motor 2		
				Default: 3.00	
		Settings	0.00–599.00 Hz		
*	01-38	Mid-poir	nt Voltage 1 of Motor 2		
				Default:	
		Settings	230V models: 0.0-240.0 V	11.0	
			460V models: 0.0–480.0 V	22.0	
			575V models: 0.0–637.0 V	0.0	
	01-05	Mid-poir	nt Frequency 2 of Motor 1		
				Default: 1.50	
		Settings	0.00–599.00 Hz		
$\sim$	01-06	Mid-poir	nt Voltage 2 of Motor 1		
				Default:	
		Settings	230V models: 0.0–240.0 V	5.0	
			460V models: 0.0–480.0 V	10.0	
			575V models: 0.0-637.0 V	0.0	
	01-39	Mid-poir	nt Frequency 2 of Motor 2		
				Default: 1.50	
		Settings	0.00–599.00 Hz		
$\sim$	01-40	Mid-poir	nt Voltage 2 of Motor 2		
				Default:	
		Settings	230V models: 0.0-240.0 V	5.0	
			460V models: 0.0–480.0 V	10.0	
			575V models: 0.0–637.0 V	0.0	
	01-07	Minimur	n Output Frequency of Motor 1		
				Default: 0.50	
		Settings	0.00–599.00 Hz		
×	01-08	Minimur	n Output Voltage of Motor 1		
				Default:	
		Settings	230V models: 0.0–240.0 V	1.0	
			460V models: 0.0–480.0 V	2.0	
			575V models: 0.0–637.0 V	0.0	
	01-41	Minimur	n Output Frequency of Motor 2		
				Default: 0.50	
		Settings	0.00–599.00 Hz		

### **01-42** Minimum Output Voltage of Motor 2

		Default:	
Settings	230V models: 0.0-240.0 V	1.0	
	460V models: 0.0-480.0 V	2.0	
	575V models: 0.0-637.0 V	0.0	


- You usually set the V/F curve according to the motor's allowable loading characteristics. Pay special attention to the motor's heat dissipation, dynamic balance, and bearing lubrication when the loading characteristics exceed the loading limit of the motor.
- There is no limit for the voltage setting, but a high voltage at a low frequency may cause motor damage, overheating, and trigger the stall prevention or the over-current protection; therefore, use low voltage at low frequency to prevent motor damage or drive error.
- Pr.01-35 to Pr.01-42 is the V/F curve for motor 2. When setting the multi-function input terminals [Pr.02-01–02-08 and Pr.02-26–Pr.02-31 (extension card)] to 14, the AC motor drive acts with the second V/F curve.
- The diagram below shows the V/F curve for motor 1. You can use the same V/F curve for motor 2.




V/F Curve and The Related Parameters

#### Common settings of the V/F curve:


#### (1) General purpose






Pr.	Setting
01-00	50.0
01-01	50.0
01-02	220.0
01-03 01-05	1.30
01-04 01-06	10.0
01-07	1.30
01-08	10.0

### (2) For fan and hydraulic machinery




Pr.	Setting
01-00	60.0
01-01	60.0
01-02	220.0
01-03 01-05	30.0
01-04 01-06	50.0
01-07	1.50
01-08	10.0




Pr.	Setting
01-00	50.0
01-01	50.0
01-02	220.0
01-03 01-05	25.0
01-04 01-06	50.0
01-07	1.30
01-08	10.0

(3) High starting torque



Pr.	Setting
01-00	60.0
01-01	60.0
01-02	220.0
01-03	3.00
01-05	3.00
01-04	00.0
01-06	23.0
01-07	1.50
01-08	18.0
01-00	10.0



Pr.	Setting
01-00	50.0
01-01	50.0
01-02	220.0
01-03	2.20
01-05	2.20
01-04	22.0
01-06	23.0
01-07	1.30
01-08	14.0

**01-09** Start-Up Frequency

Default: 0.50

Settings 0.00-599.00 Hz

When the starting frequency is larger than the Minimum Output Frequency, the drives' frequency output starts when the starting frequency reaches the F command. Refer to the following diagram for details.


Fcmd: frequency command

Fstart: start-up frequency (Pr.01-09)

fstart: actual start-up frequency of drive

Fmin: fourth output frequency setting (Pr.01-07 / Pr.01-41)

Flow: output frequency lower limit (Pr.01-11)



- - If Flow < Fcmd, drive runs directly by Fcmd.
  - If Flow ≥ Fcmd, drive runs by Fcmd, and then rises to Flow according to acceleration time.
- The output frequency goes directly to 0 when decelerating to Fmin.

# O1-10 Output Frequency Upper Limit

Default: 599.00


Settings 0.00-599.00 Hz

# Output Frequency Lower Limit

Default: 0.00

Settings 0.00-599.00 Hz

- If the output frequency setting is higher than the upper limit (Pr.01-10), the drive runs with the upper limit frequency. If the output frequency setting is lower than the lower limit (Pr.01-11) but higher than the minimum output frequency (Pr.01-07), the drive runs with the lower limit frequency. Set the upper limit frequency > the lower limit frequency (Pr.01-10 setting value must be > Pr.01-11 setting value).
- If the slip compensation function (Pr.07-27) is enabled for the drive, the drive's output frequency may exceed the Frequency command.



- When the drive starts, it operates according to the V/F curve and accelerates from the minimum output frequency (Pr.01-07). It is not limited by the lower output frequency settings.
- Use the frequency upper and lower limit settings to prevent operator misuse, overheating caused by the motor's operating at a too low frequency, or mechanical wear due to a too high operation frequency.
- If the frequency upper limit setting is 50 Hz and the frequency setting is 60 Hz, the maximum output frequency is 50 Hz.
- ☐ If the frequency lower limit setting is 10 Hz and the minimum operation frequency setting (Pr.01-07) is 1.5 Hz, then the drive operates at 10 Hz when the Frequency command is higher than Pr.01-07 and lower than 10 Hz. If the Frequency command is lower than Pr.01-07, the drive is in ready status with no output.

×	01-12	Acceleration Time 1
×	01-13	Deceleration Time 1
×	01-14	Acceleration Time 2
×	01-15	Deceleration Time 2
×	01-16	Acceleration Time 3
×	01-17	Deceleration Time 3
×	01-18	Acceleration Time 4
×	01-19	Deceleration Time 4
×	01-20	JOG Acceleration Time
×	01-21	JOG Deceleration Time

Default: 10.00


Default: 60.00 / 60.0 (22 kW

and above models)

Settings Pr.01-45 = 0: 0.00–600.00 seconds

Pr.01-45 = 1: 0.0-6000.0 seconds

- The acceleration time determines the time required for the AC motor drive to ramp from 0.00 Hz to the maximum operation frequency (Pr.01-00). The deceleration time determines the time required for the AC motor drive to decelerate from the maximum operation frequency (Pr.01-00) down to 0.00 Hz.
- The acceleration and deceleration time are invalid when using Pr.01-44 Auto-acceleration and Auto-deceleration Setting
- Select the Acceleration / Deceleration time 1, 2, 3, 4 with the multi-function input terminals settings. The defaults are Acceleration Time 1 and Deceleration Time 1.
- With the enabled torque limits and stall prevention functions, the actual acceleration and deceleration time are longer than the above action time.
- Note that setting the acceleration and deceleration time too short may trigger the drive's protection function (Pr.06-03 Over-current Stall Prevention during Acceleration or Pr.06-01 Over-voltage Stall Prevention), and the actual acceleration and deceleration time are longer than this setting.
- Note that setting the deceleration time too short may cause motor damage or trigger drive protection due to over-current during the drive's deceleration or over-voltage.
- Use suitable brake resistor (refer to Chapter 07 Optional Accessories) to decelerate in a short time and prevent over-voltage.
- When you enable Pr.01-24–Pr.01-27 (S-curve acceleration and deceleration begin and arrival time), the actual acceleration and deceleration time are longer than the setting.



#### Acceleration / Deceleration Time

# **01-22** JOG Frequency

Default: 6.00

Settings 0.00-599.00 Hz

- You can use both the external terminal JOG and F1 key on the optional keypad KPC-CC01 to set the JOG function. When the JOG command is ON, the AC motor drive accelerates from 0 Hz to the JOG frequency (Pr.01-22). When the JOG command is OFF, the AC motor drive decelerates from the JOG Frequency to stop. The JOG acceleration and deceleration time (Pr.01-20, Pr.01-21) are the time to accelerate from 0.0 Hz to JOG frequency (Pr.01-22).
- You cannot execute the JOG command when the AC motor drive is running. When the JOG command is executing, other operation commands are invalid.

### ✓ 01-23 Switch Frequency between First and Fourth Acceleration / Deceleration


Default: 0.00

Settings 0.00-599.00 Hz

- This function does not require the external terminal switching function; it switches the acceleration and deceleration time automatically according to the Pr.01-23 setting. If you set the external terminal, the external terminal has priority over Pr.01-23.
- Use this parameter to set the switch frequency between acceleration and deceleration slope. The First / Fourth Accel. / Decel. slope is calculated by the Max. Operation Frequency (Pr.01-00) / acceleration / deceleration time.

Example: when the Max. Operation Frequency (Pr.01-00) = 80 Hz, and Switch Frequency between First and Fourth Accel./ Decel. (Pr.01-23) = 40 Hz:

- a. If Acceleration Time 1 (Pr.01-02) = 10 sec., Acceleration Time 4 (Pr.01-18) = 6 sec., then the acceleration time is 3 sec. for 0–40 Hz and 5 sec. for 40–80 Hz.
- b. If Deceleration Time 1 (Pr.01-13) = 8 sec., Deceleration Time 4 (Pr.01-19) = 2 sec., then the deceleration time is 4 sec. for 80–40 Hz and 1 sec. for 40–0 Hz.




1st/4th Acceleration/Deceleration Frequency Switching

×	01-24	S-curve for Acceleration Begin Time 1
×	01-25	S-curve for Acceleration Arrival Time 2
×	01-26	S-curve for Deceleration Begin Time 1
×	01-27	S-curve for Deceleration Arrival Time 2

Default: 0.20

Settings Pr.01-45 = 0: 0.00–25.00 seconds Pr.01-45 = 1: 0.0–250.0 seconds

- Using an S-curve gives the smoothest transition between speed changes. The acceleration and deceleration curve adjusts the acceleration and deceleration S-curve. When enabled, the drive produces a different acceleration and deceleration curve according to the acceleration and deceleration time.
- The S-curve function is invalid when you set the acceleration and deceleration time to 0.
- When Pr.01-12, Pr.01-14, Pr.01-16, Pr.01-18 ≥ Pr.01-24 and Pr.01-25, the actual acceleration time = Pr.01-12, Pr.01-14, Pr.01-16, Pr.01-18 + (Pr.01-24 + Pr.01-25) ÷ 2
- When Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 ≥ Pr.01-26 and Pr.01-27, the actual deceleration time = Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 + (Pr.01-26 + Pr.01-27) ÷ 2




01-28	Skip Frequency 1 (upper limit)
01-29	Skip Frequency 1 (lower limit)
01-30	Skip Frequency 2 (upper limit)
01-31	Skip Frequency 2 (lower limit)
01-32	Skip Frequency 3 (upper limit)
01-33	Skip Frequency 3 (lower limit)

Default: 0.00

Settings 0.00-599.00 Hz

- Sets the AC motor drive's skip frequency. The drive's frequency setting skips these frequency ranges. However, the frequency output is continuous. There are no limits for these six parameters and you can combine them. Pr.01-28 does not need to be greater than Pr.01-29; Pr.01-30 does not need to be greater than Pr.01-31; Pr.01-32 does not need to be greater than Pr.01-33. You can set Pr.01-28–01-33 as you required. There is no size distinction among these six parameters.
- These parameters set the skip frequency ranges for the AC motor drive. You can use this function to avoid frequencies that cause mechanical resonance. The skip frequencies are useful when a motor has resonance vibration at a specific frequency bandwidth. Skipping this frequency avoids the vibration. There are three frequency skip zones available.
- You can set the frequency command (F) within the range of skip frequencies. Then the output frequency (H) is limited to the lower limit of skip frequency ranges.
- During accelerating and decelerating, the output frequency still passes through the skip frequency ranges.



### **01-34** Zero-speed Mode

Default: 0


Settings 0: Output waiting

1: Zero-speed operation


2: Minimum frequency (Refer to Pr.01-07 and Pr.01-41)

- When the drive's Frequency command is lower than Fmin (Pr.01-07 or Pr.01-41), the drive operates according to this parameter.
- © 0: the AC motor drive is in waiting mode without voltage output from terminals U, V, W.
- 1: the drive executes the DC brake by Vmin (Pr.01-08 and Pr.01-42) in V/F and SVC modes.
- 2: the AC motor drive runs using Fmin (Pr.01-07, Pr.01-41) and Vmin (Pr.01-08, Pr.01-42) in V/F and SVC modes.
- When setting to 2 and the lower limit (Pr.01-11) is set larger than Fmin in V/F and SVC modes, the drive operates according to the lower limit set value.
  - In V/F and SVC modes

#### Pr.01-00 Lower limit > Pr.01-07 Fmin



#### Pr.01-11 Lower limit < Pr.01-07 Fmin



# 01-43 V/F Curve Selection

Default: 0

Settings 0: V/F curve determined by Pr.01-00–01-08

1: V/F curve to the power of 1.5

2: V/F curve to the power of 2

3: 60 Hz, voltage saturation in 50 Hz

4: 72 Hz, voltage saturation in 60 Hz

5: 50 Hz, decrease gradually with cube

6: 50 Hz, decrease gradually with square


7: 60 Hz, decrease gradually with cube

8: 60 Hz, decrease gradually with square

9: 60 Hz, medium starting torque

10: 60 Hz, high starting torque

- 11: 60 Hz, medium starting torque
- 12: 60 Hz, high starting torque
- 13: 90 Hz, voltage saturation in 60 Hz
- 14: 120 Hz, voltage saturation in 60 Hz
- 15: 180 Hz, voltage saturation in 60 Hz
- When setting to 0, refer to Pr.01-01-08 for the motor 1 V/F curve. For motor 2, refer to Pr.01-35-01-42.
- When setting to 1 or 2, the second and third voltage frequency setting are invalid.
- If the load on the motor is a variable torque load (torque is in direct proportion to rotating speed, such as the load of fan or pump), the load torque is low at low rotating speed. You can decrease the input voltage appropriately to make the magnetic field of the input current smaller and reduce flux loss and iron loss for the motor to increase efficiency.
- When you set the V/F curve to high power, it has lower torque at low frequency, and the drive is not suitable for rapid acceleration and deceleration. Do NOT use this parameter for rapid acceleration and deceleration.



# O1-44 Auto-acceleration and Auto-deceleration Setting

Default: 0


Settings 0: Linear acceleration and deceleration

1: Auto-acceleration and linear deceleration

- 2: Linear acceleration and auto-deceleration
- 3: Auto-acceleration and auto-deceleration
- 4: Linear, stall prevention by auto-acceleration and auto-deceleration (limited by Pr.01-12 to Pr.01-21)
- 0 (linear acceleration and linear deceleration): the drive accelerates and decelerates according to the setting for Pr.01-12–01-19.
- 1 or 2 (auto / linear acceleration and auto / linear deceleration): the drive auto-tunes the acceleration and deceleration to effectively reduce the mechanical vibration during the load start-up and stop and make the auto-tuning process more easily. It does not stall during acceleration and does no need a brake resistor during deceleration to stop. It can also improve operation efficiency and save energy.
- 3 (auto-acceleration and auto-deceleration-decelerate by the actual load): the drive auto-detects

the load torque and automatically accelerates from the fastest acceleration time and smoothest start-up current to the setting frequency. During deceleration, the drive automatically determines the loaded regenerative energy to steadily and smoothly stop the motor in the fastest deceleration time.

4 (stall prevention by auto-acceleration and deceleration—reference to the acceleration and deceleration time settings): if the acceleration and deceleration are within a reasonable range, the actual accelerates and decelerates time refer to Pr.01-12–01-19 settings. If the acceleration and deceleration time are too short, the actual acceleration and deceleration time are greater than the acceleration and deceleration time settings.



- Acceleration / Deceleration Time
- 1 Optimize the acceleration / deceleration time when Pr.01-44 is set to 0.
- 2 Optimize the acceleration / deceleration time which load needs actually when Pr.01-44 is set to 3.

### 01-45 Time Unit for Acceleration / Deceleration and S Curve

Default: 0

Settings 0: Unit 0.01 sec.

1: Unit 0.1 sec.

# 01-46 CANopen Quick Stop Time

Default: 1.00

Settings Pr.01-45 = 0: 0.00-600.00 sec.

Pr.01-45 = 1: 0.0-6000.0 sec.

Sets the time to decelerate from the maximum operation frequency (Pr.01-00) to 0.00 Hz through the CANopen control.

# 01-49 TEC Function Selection

Default: 0

Settings 0: Disable


1: Enable

Different control modes for Pr.01-49:

Motor	Induction Motor (IM)		Permanent Magnet Synchronous Motor (PM)			Synchronous Reluctance Motor (SynRM)
Control Mode	ol Mode VF SVC		PMSVC	PMFOC	HFI	FOC
TEC Function	✓					

- ① The drive decelerates or stops based on the original deceleration time settings. Use this setting when brake resistors are used.
- 1: During operation (acceleration / steady speed / deceleration), the drive adjusts the output voltage according to the amount of regenerative energy and consumes the regenerative energy timely to reduce the risk of over-voltage. Moreover, you can also use Pr.01-50 (Electromagnetic Traction Energy Consumption Coefficient) to adjust the drive's output voltage strength.
- ☐ If you use the electromagnetic energy traction control (Pr.01-49 = 1) during linear deceleration (no triggering of over-voltage stall prevention), you can enhance the output current by increasing the output voltage (V<sub>out</sub>) to further suppress the regenerative DC bus voltage that is prompt to rise.

  Using this function with Pr.06-02 = 1 or 3 (Smart Over-voltage Stall Prevention) can achieve a smoother and faster deceleration.



- TEC function activates in the following three conditions:
  - 1. Activates when DC bus is larger than the over-voltage stall prevention level (Pr.06-01) during acceleration and deactivates once Pr.06-01 is disabled.
  - 2. Activates when DC bus is larger than the over-voltage stall prevention level (Pr.06-01) during steady operation and deactivates once Pr.06-01 is disabled.
  - 3. Activates during deceleration (including stop) and deactivates once acceleration occurs or deceleration is stopped.
- When Pr.01-49 = 1, Pr.06-02 bit0-bit2 is automatically set to ON to increase the stability during deceleration.

# 01-50 Electromagnetic Traction Energy Consumption Coefficient Default: 0.50 Settings 0.00–5.00 Hz During acceleration / steady speed / deceleration, the drive will dynamically adjust the output voltage based on the DC bus voltage level in order to prevent the drive from tripping on overvoltage. The output voltage is adjusted based on this parameter setting. The drive's output current and the efficiency of regenerative energy consumption increase when Pr.01-50 is increased. When Pr.01-50 is decreased, also the drive's output current and the efficiency of regenerative energy consumption will decrease. When setting Pr.01-50, pay attention to the drive's output current. The drive's output current must be lower than 80% of the motor's rated current to prevent the motor from overheating. Flux-weakening Overload Stall Prevention Time 01-51 (applied to 230V / 460V models) Default: 1.00 Settings 0.00-600.00 sec. This parameter is only valid when Pr.00-11 = 8 (SynRM Sensorless Control Mode). When the drive operates in flux-weakening zone, and the motor decelerates due to its sudden loading increment, adjust the setting for this parameter.

# 02 Digital Input / Output Parameter

✓ You can set this parameter during operation.

### **02-00** Two-wire / Three-wire Operation Control

Default: 0

Settings 0: Two-wire mode 1, power on for operation control

1: Two-wire mode 2, power on for operation control

2: Three-wire, power on for operation control

This parameter sets the configuration of the terminals (Pr.00-21 = 1 or Pr.00-31 = 1) which control the operation. There are three different control modes listed in the following table.

Pr.02-00	Control Circuits of the External Terminal			
Settings: 0 Two-wire mode 1 FWD / STOP REV / STOP	FWD/STOP OO	FWD "OPEN": STOP  "CLOSE": FWD  REV "OPEN": STOP  "CLOSE": REV  DCM  CFP2000		
Settings: 1 Two-wire mode 2 RUN / STOP REV / FWD	RUN/STOP OO FWD/REV	FWD "OPEN": STOP  "CLOSE": RUN  REV "OPEN": FWD  "CLOSE": REV  DCM  CFP2000		
Settings: 2 Three-wire operation control	STOP RUN  REV/FWD	FWD "CLOSE": RUN  MI1 "OPEN": STOP  REV/FWD "OPEN": FWD  "CLOSE": REV  DCM  CFP2000		

<b>02-01</b> Multi-Function Input Command 1 (MI1)	
	Default: 1
<b>02-02</b> Multi-Function Input Command 2 (MI2)	
	Default: 2
<b>02-03</b> Multi-Function Input Command 3 (MI3)	
	Default: 3
02-04 Multi-Function Input Command 4 (MI4)	
	Default: 4
<b>02-05</b> Multi-Function Input Command 5 (MI5)	
<b>02-06</b> Multi-Function Input Command 6 (MI6)	
<b>02-07</b> Multi-Function Input Command 7 (MI7)	
<b>02-08</b> Multi-Function Input Command 8 (MI8)	

02-26	Input Terminal of I/O Extension Card (MI10)
02-27	Input Terminal of I/O Extension Card (MI11)
02-28	Input Terminal of I/O Extension Card (MI12)
02-29	Input Terminal of I/O Extension Card (MI13)
02-30	Input Terminal of I/O Extension Card (MI14)
02-31	Input Terminal of I/O Extension Card (MI15)

Default: 0

Settings Refer to the following summary of function settings

- This parameter selects the functions for each multi-function terminal.
- Pr.02-26–Pr.02-31 are entity input terminals only when the extension cards are installed, otherwise, these are virtual terminals. For example, when using the multi-function extension card EMC-D42A, Pr.02-26–Pr.02-29 are defined as the corresponded parameters for MI10–MI13. In this case, Pr.02-30–Pr.02-31 are virtual terminals.
- When Pr.02-12 is defined as virtual terminal, use digital keypad KPC-CC01 or communication method to change its status (0: ON; 1: OFF) of bit8–15.
- If Pr.02-00 is set to three-wire operation control, terminal MI1 is for the STOP contact. The function set previously for this terminal is automatically invalid.

Summary of function settings

Take the normally open contact (N.O.) for example, ON: contact is closed, OFF: contact is open

Settings	Functions	Descriptions
0	No Function	
1	Multi-step speed command 1	You can set 15 steps of speed or 15 positions with the digital
2	Multi-step speed command 2	status of these four terminals. You can use 16-steps of speed if
3	Multi-step speed command 3	you include the master speed when setting as 15 steps of speed
4	Multi-step speed command 4	(refer to Parameter Group 04 Multi-step Speed Parameters).
5	Reset	Use this terminal to reset the drive after clearing a drive fault.
6	JOG command	This function is valid when the source of the operation command is the external terminals.  The JOG operation executes when the drive stops completely.  While running, you can still change the operation direction, and the STOP key on the keypad* and the STOP command from communications are valid. Once the external terminal receives the OFF command, the motor stops in the JOG deceleration time. Refer to Pr.01-20–01-22 for details.  *: This function is valid when Pr.00-32 is set to 1.

Settings	Functions	Descriptions	
		Pr.01-22 JOG frequency  Pr.01-07  Min. output frequency of motor 1  Pr.01-20  JOG accel. time  MIx-GND  ON  OFF  MIx: External terminal	
7	Acceleration / deceleration speed inhibit	When you enable this function, the drive stops acceleration or deceleration immediately. After you disable this function, the AC motor drive starts to accelerate or decelerate from the inhibit point.  Frequency  Setting frequency  Accel. inhibit area  Actual operation frequency  Decel. inhibit area  ON  OPF	
8	1 <sup>st</sup> and 2 <sup>nd</sup> acceleration or deceleration time selection	You can select the acceleration and deceleration time of the drive with this function, or from the digital status of the terminals there are four acceleration and deceleration selection.	
9	3 <sup>rd</sup> and 4 <sup>th</sup> acceleration or deceleration time selection	MIx = 9         MIx = 8         Accel. / Decel.           OFF         OFF         1st Accel. / Decel.           OFF         ON         2nd Accel. / Decel.           ON         OFF         3rd Accel. / Decel.           ON         ON         4th Accel. / Decel.	
10	External fault (EF) input	For external fault input. The drive decelerates according to the Pr.07-20 setting, and the keypad shows EF. (It shows the fault record when an external fault occurs). The drive keeps running until the fault is cleared (terminal status restored) after RESET.	
11	B.B. input from external (B.B.: Base Block)	ON: the output of the drive stops immediately. The motor is in free run and the keypad displays the B.B. signal. Refer to Pr.07-08 for details.	

Settings	Functions	Descriptions			
		ON: the output of the drive stops immediately, and the motor is in			
		free run status. The drive is in output waiting status until the			
		switch is turned to OFF, and then the drive restarts and runs to			
		the current setting frequency.			
12	Output voltage stops	Voltage Frequency Setting frequency Time			
		MIx-GND ON OFF ON Operation ON			
	Cancel the setting for auto-	Set Pr.01-44 to one of the Pr.01-04 setting modes before using			
13	acceleration / auto-	this function. When this function is enabled, OFF is for auto			
	deceleration time	mode and ON is for linear acceleration / deceleration.			
	Switch between motor 1 and	ON: use parameters for motor 2.			
14	motor 2	OFF: use parameters for motor 1.			
	Rotating speed command from	ON: force the source of the frequency to be AVI1. (If the rotating			
15		speed commands are set to AVI1, ACI and AVI2 at the same			
	AVI1	time, the priority is AVI1 > ACI > AVI2)			
	Rotating speed command from ACI	ON: force the source of the frequency to be ACI. (If the rotating			
16		speed commands are set to AVI1, ACI and AVI2 at the same			
		time. The priority is AVI1 > ACI > AVI2)			
	Rotating speed command from AVI2	ON: force the source of the frequency to be AVI2. (If the rotating			
17		speed commands are set to AVI1, ACI and AVI2 at the same			
		time. The priority is AVI1 > ACI > AVI2)			
18	Forced to stop (Pr.07-20)	ON: the drive ramps to stop according to Pr.07-20 setting.			
	Frequency up command	ON: the frequency of the drive increases or decreases by one			
19		unit. If this function remains ON continuously, the frequency			
		increases or decreases according to Pr.02-09 / Pr.02-10.			
	Frequency down command	The Frequency command returns to zero when the drive stops,			
20		and the displayed frequency is 0.0 Hz. If the frequency			
20		command has to return to zero when the AC motor drive stops,			
		set Pr.11-00 bit7 = 1.			
21	PID function disabled	ON: the PID function is disabled.			
22	Clear the counter	ON: the current counter value is cleared and displays "0". The			
		drive counts up when this function is disabled.			
23	Input the counter value	ON: the counter value increases by 1. Use the function with			
		Pr.02-19.			
24	FWD JOG command	This function is valid when the source of the operation command			
∠-7		is external terminal. ON: the drive executes forward JOG.			

Settings	Functions	Descriptions		
25	REV JOG command	This function is valid when the source of the operation command		
		is external terminal. ON: the drive executes reverse JOG.		
		ON: the output of the drive stops immediately, displays EF1 on		
		the keypad, and the motor is in the free run status. The drive		
		keeps running until the fault is cleared after you press RESET on		
		the keypad (EF: External Fault).		
		Voltage Frequency		
28	Emorgoney stop (EE1)	Setting		
20	Emergency stop (EF1)	frequency		
		Time		
		MIX-GND ON OFF ON		
		Reset ON OFF		
		Operation ON		
29	Signal confirmation for Y-	When the control mode is V/F, ON: the drive operates by the first		
	connection	V/F.		
30	Signal confirmation for $\Delta$ -	When the control mode is V/F, ON: the drive operates by the		
	connection	second V/F.		
	Disable EEPROM write	ON: writing to EEPROM is disabled. Changed parameters are		
38	function (parameters memory	not saved after power off		
	disable)			
40	Force coasting to stop	ON: during operation, the drive free runs to stop.		
		When the MI terminal switches to OFF, it executes a STOP		
	HAND switch	command. Therefore, if the MI terminal switches to OFF		
		during operation, the drive stops.		
41		Use the keypad KPC-CC01 to switch between HAND and		
		AUTO. The drive stops first, and then switches to HAND or		
		AUTO status.		
	AUTO switch	3. The digital keypad KPC-CC01 displays the current status of		
		the drive (HAND / OFF / AUTO).		
42		bit1 bit0		
		OFF 0 0 AUTO 0 1		
		HAND 1 0		
		OFF 1 1		
49	Enable drive	When the drive is enabled, the RUN command is valid.		
		When the drive is disabled, the RUN command is invalid.		
		When drive is operating, the motor coasts to stop.		
		This function varies with MOx = 45.		

Settings	Functions	Descriptions			
		Enter the message setting in this param	neter when	the master	
50	Slave dEb action to execute	triggers dEb. This prevents over-low vo	Itage of the	slave DC	
		bus, causes the Lv error occurs and the	drive coas	ts to stop.	
51		PLC status	bit1	bit0	
	Selection for PLC mode bit0	Disable PLC function (PLC 0)	0	0	
		Trigger PLC to operation (PLC 1)	0	1	
52	Selection for PLC mode bit1	Trigger PLC to stop (PLC 2)	1	0	
32	Delection for 1 Lo mode bit 1	No function	1	1	
		When this function is enabled under CA	Nopen con	trol, it	
53	Trigger CANopen quick stop	changes to Quick Stop. Refer to Section	n 15 CANor	pen Overview	
		for more details.			
54	UVW output electromagnetic	Allows receiving confirmation signals while there is UVW			
	valve switch	magnetic contactor during output.			
		When Pr.02-56 ≠ 0, connect the brake r	elease sigr	nal to multi-	
55	Brake release	function input terminals. When the brake is opened, and the			
		drive does not receive its confirming sig	ınal, the Brk	c error occurs.	
		Use Pr.00-29 to select for LOCAL / REM		•	
		Pr.00-29). When Pr.00-29 is not set to 0, the digital keypad KPC-			
	LOCAL / REMOTE Selection	CC01 displays the LOC / REM status. (KPC-CC01 firmware			
56		version 1.021 and above).			
			it 0 0		
		LOC	1		
	Enable fire mode (with RUN			rive to run	
58	Command)	Enable this function under fire mode to force the drive to run (while there <b>is</b> RUN command).			
	Enable fire mode (without	Enable this function under fire mode to	force the dr	rive to run	
59	RUN Command)	(while there <b>is not</b> a RUN command).			
	Disable all the motors	ON: when the multi-motor circulative co	ntrol is ena	ble, all motors	
60		coast to stop.			
	Disable Motor 1–8	These functions work with multi-motor of	circulative c	ontrol, motor 1	
61–68		to 8 can be set to coast to stop. If any of Auxiliary Motor 1 to			
		Motor 8 is out of order or under maintenance, enable this			
		terminal to bypass that motor.			
69	Enable preheating function	ON: if the preheating function is open a	nd drive is i	in STOP	
		status, the preheating function is executed; until the contact			
		status changes to OFF, or the drive stat	tus turns to	RUN and	
		stops the preheating function. Refer to Pr.02-72–02-73 for detail.			

# 02-09 External Terminal UP / DOWN Key Mode

Default: 0

Settings 0: By the acceleration or deceleration time


1: Constant speed (Pr.02-10)

### **02-10** External Terminal Speed of the UP / DOWN Key


Default: 0.001

Settings 0.001-1.000 Hz/ms

- Use when the multi-function input terminals are set to 19, 20 (Frequency UP / DOWN command). The frequency increases or decreases according to Pr.02-09 and Pr.02-10.
- When Pr.02-09 is set to 0: the increasing or decreasing frequency command (F) operates according to the setting for acceleration or deceleration time (refer to Pr.01-12–Pr.01-19)



When Pr.02-09 is set to 1: the increasing / decreasing frequency command (F) operates according to the setting for Pr.02-10 (0.01–1.00 Hz/ms).



# Multi-Function Input Response Time

Default: 0.005

Settings 0.000-30.000 sec.

- Sets the response time of the digital input terminals FWD, REV and MI1–MI8.
- This function is to delay and confirm the digital input terminal signal. The time for delay is also the time for confirmation. The confirmation prevents interference that could cause error in the input to the digital terminals. In the meanwhile, it delays the response time, though confirmation improves accuracy.

<b>02-12</b> N	Multi-Function Input Mode Selection		
	Default: 0000h		
S	Settings 0000h–FFFFh (0: N.O.; 1: N.C.)		
The paran	neter setting is in hexadecimal.		
-	parameter sets the status of the multi-function input signal (0: normally open, 1: normally		
,	d it is not affected by the status of SINK / SOURCE.		
	correspond to MI1–MI15.		
	Ilt for bit0 is FWD terminal, and the default for bit1 is REV terminal. You cannot use this		
•	r to change the input mode. hange the terminal ON / OFF status through communications.		
	ole, MI1 is set to 1 (multi-step speed command 1), MI2 is set to 2 (multi-step speed		
•	2). Then the forward + $2^{nd}$ step speed command = $1001_2 = 9_{10}$ . As long as Pr.02-12 =		
9 is set thr	rough communications, there is no need to wire any multi-function terminal to run		
forward wi	ith the second step speed.		
bit15 bit1			
MI15 MI1	4   MI13   MI12   MI11   MI10   MI8   MI7   MI6   MI5   MI4   MI3   MI2   MI1   REV   FWD		
<b>02-13</b>	Multi-Function Output 1 (Relay1)		
	Default: 11		
<b>02-14</b>	Multi-Function Output 2 (Relay2)		
	Default: 1		
<b>02-15</b>	Multi-Function Output 3 (Relay3)		
	Default: 66		
02-36	Output Terminal of I/O Extension Card (MO10) or (RA10)		
	Output Terminal of I/O Extension Card (MO11) or (RA11)		
	·		
	Output Terminal of I/O Extension Card (RA12)		
	Output Terminal of I/O Extension Card (RA13)		
02-40	Output Terminal of I/O Extension Card (RA14)		
02-41	Output Terminal of I/O Extension Card (RA15)		
02-42	Output Terminal of I/O Extension Card (MO16 Virtual Terminal)		
02-43	Output Terminal of I/O Extension Card (MO17 Virtual Terminal)		
02-44	Output Terminal of I/O Extension Card (MO18 Virtual Terminal)		
02-45	Output Terminal of I/O Extension Card (MO19 Virtual Terminal)		
02-46	Output Terminal of I/O Extension Card (MO20 Virtual Terminal)		
	Default: 0		
<u> </u>	Settings Refer to the following summary of function settings		
Use this p	arameter to set the function of the multi-function terminals.		

Pr.02-36-Pr.02-41 requires additional extension cards to display the parameters; the choices of
optional cards are EMC-D42A and EMC-R6AA.
The optional card EMC-D42A provides two output terminals, use with Pr.02-36–02-37.

☐ The optional card EMC-R6AA provides six output terminals, use with Pr.02-36–02-41. ☐ MO16–MO20 are virtual terminals, set the status of bit11–15 of Pr.02-18 to control these virtual

terminals.

Summary of function settings

(Take the normally open contact (N.O.) for example, ON: contact is closed, OFF: contact is open)

Settings	Functions	Descriptions	
0	No function		
1	Operation indication	Activates when the drive is not in STOP.	
2	Operation speed	Activates when output frequency of the drive reaches the setting	
	reached	frequency.	
3	Desired frequency	Activates when the desired frequency (Pr.02-22) reached.	
3	reached 1 (Pr.02-22)	Activates when the desired frequency (F1.02-22) reached.	
4	Desired frequency	Activates when the desired frequency (Pr.02-24) reached.	
4	reached 2 (Pr.02-24)	Activates when the desired frequency (F1.02-24) reached.	
5	Zero Speed (frequency	Activates when frequency command = 0 (the drive must be in RUN	
	command)	status)	
	Zero Speed, includes		
6	Stop (frequency	Activates when frequency command = 0 or stopped.	
	command)		
	Over-torque 1	Activates when the drive detects over-torque. Pr.06-07 sets the over-	
7		torque detection level, Pr.06-08 sets the over-torque detection time.	
		Refer to Pr.06-06–Pr.06-08.	
		Activates when the drive detects over-torque. Pr.06-10 sets the over-	
8	Over-torque 2	torque detection level, and Pr.06-11 sets the over-torque detection	
		time. Refer to Pr.06-09-06-11.	
9	Drive is ready	Activates when the drive is ON with no error detected.	
10	Low voltage warning	Activates when the DC bus voltage is too low (refer to Pr.06-00 low	
	(Lv)	voltage level).	
11	Malfunction indication	Activates when fault occurs (except Lv stop).	
40	Mechanical Brake	Activates when the drive runs after the set delayed time for Pr.02-32.	
12	Release (Pr.02-32)	This function must use with DC brake function.	
	Over-heat warning	Activates when IGBT or heat sink overheats, to prevent the drive from	
13		shutting down due to over-heating (refer to Pr.06-15).	
14	Software brake signal	Activates when the soft brake function is ON (refer to Pr.07-00).	
	indication	notivates when the soft brake fullchorns ON (refer to F1.07-00).	
15	PID feedback error	Activates when the PID feedback signal error is detected.	
16	Slip Error (oSL)	Activates when the slip error is detected.	

Settings	Functions	Descriptions
	Count value reached,	Activates when the drive executes external counter, this contact is
17	does not return to 0	active if the count value is equal to the setting value for Pr.02-20. This
	(Pr.02-20)	contact is not active when the setting value for Pr.02-20 > Pr.02-19.
40	Counter value reached,	Activates when the drive executes the external counter, this contact is
18	returns to 0 (Pr.02-19)	active if the count value is equal to the setting value for Pr.02-19.
19	External interrupt B.B. input (Base Block)	Activates when external interrupt (B.B.) stop output occurs in the drive.
20	Warning Output	Activates when a warning is detected.
21	Over-voltage	Activates when the over-voltage is detected.
22	Over-current stall prevention	Activates when the over-current stall prevention is detected.
23	Over-voltage stall prevention	Activates when the over-voltage stall prevention is detected.
24	Operation mode indication	Activates when the operation command is not controlled by digital keypad. (Pr.00-21 ≠ 0)
25	Forward command	Activates when the operation direction is forward.
26	Reverse command	Activates when the operation direction is reverse.
	Output when Current ≥	A CONTROL OF STATION AND COURT TO TOVOICE.
27	Pr.02-33	Activates when the current is ≥ Pr.02-33.
28	Output when Current < Pr.02-33	Activates when the current is < Pr.02-33
29	Output when frequency ≥ Pr.02-34	Activates when the frequency is ≥ Pr.02-34.
30	Output when Frequency < Pr.02-34	Activates when the frequency is < Pr.02-34.
31	Y-connection for the	Activates when Pr.05-24 = 1, the frequency output is lower than Pr.05-
31	motor coil	23 minus 2 Hz, and the time is longer than Pr.05-25.
32	Δ-connection for the	Activates when Pr.05-24 = 1, the frequency output is higher than
32	motor coil	Pr.05-23 plus 2 Hz, and the time is longer than Pr.05-25.
33	Zero Speed (actual	Activates when the actual output frequency is 0. (the drive is in RUN
	output frequency)	mode)
	Zero Speed includes	
34	stop (actual output	Activates when the actual output frequency is 0 or Stopped.
	frequency)	
35	Error output selection 1 (Pr.06-23)	Activates when Pr.06-23 is ON.
36	Error output selection 2 (Pr.06-24)	Activates when Pr.06-24 is ON.
37	Error output selection 3 (Pr.06-25)	Activates when Pr.06-25 is ON.

Settings	Functions	Descriptions					
38	Error output selection 4 (Pr.06-26)	Activates when Pr.06-26 is ON.					
40	Speed reached (including STOP)	activates when the output frequency reaches the setting frequency or topped.					
44	Low current output	This function needs to be used with Pr.06-71–Pr.06-73					
45	UVW output electromagnetic valve switch	Use this function with external terminal input = 49 (drive enabled) and external terminal output = 45 (electromagnetic valve enabled), and then the electromagnetic valve is ON or OFF according to the status of the drive.  Enable Contactor ON MC Motor U/T1 Motor U/					
46	Master dEb output	When dEb rises at master, MO sends a dEb signal to the slave. Output the message when the master triggers dEb. This ensures that the slave also triggers dEb. Then slave follows the deceleration time of the master to stop simultaneously with the master.					
50	Output control for CANopen	1					

Settings	Functions	Descriptions						
		For RS-485 inter	face (InnerCOM / Mo	odbus) cor	mmunication control			
		output.						
		Physical	Setting of Related					
		Terminal	Parameters	Attribute	Corresponding Index			
		RY1	Pr.02-13 = 51	RW	The bit0 at 2640h			
	A	RY2	Pr.02-14 = 51	RW	The bit1 at 2640h			
51	Analog output control	RY3	Pr.02-15 = 51	RW	The bit2 at 2640h			
	for RS-485 interface	MO10 / RY10	Pr.02-36 = 51	RW	The bit5 at 2640h			
		MO11 / RY11	Pr.02-37 = 51	RW	The bit6 at 2640h			
		RY12	Pr.02-38 = 51	RW	The bit7 at 2640h			
		RY13	Pr.02-39 = 51	RW	The bit8 at 2640h			
		RY14	Pr.02-40 = 51	RW	The bit9 at 2640h			
		RY15	Pr.02-41 = 51	RW	The bit10 at 2640h			
		PN01 and CMC-l	DN01)	cation car	rds (CMC-EIP01, CMC-			
		Physical Terminal	Setting of Related Parameters	Attribute	Corresponding Index			
		RY1	Pr.02-13 = 52	RW	The bit0 at 2640h			
	Output control for	RY2	Pr.02-14 = 52	RW	The bit1 at 2640h			
52	communication cards	RY3	Pr.02-15 = 52	RW	The bit2 at 2640h			
		MO10 / RY10	Pr.02-36 = 52	RW	The bit5 at 2640h			
		MO11 / RY11	Pr.02-37 = 52	RW	The bit6 at 2640h			
		RY12 RY13	Pr.02-38 = 52 Pr.02-39 = 52	RW RW	The bit7 at 2640h The bit8 at 2640h			
		RY14	Pr.02-40 = 52	RW	The bit9 at 2640h			
		RY15	Pr.02-40 = 52	RW	The bit10 at 2640h			
53	Fire mode indication	This function is enabled when setting 58 or 59 is enabled.						
- 00		This fariotion is c	nabled when setting	00 01 00 1	o chabled.			
54	Bypass fire mode	The contact work	s when bypass funct	tion is ena	abled in the fire mode.			
	indication							
55	Motor 1 output	Mhon cotting mu	lti motor oiroulativa f	unation th	ne multi-function output			
56	Motor 2 output	1			15 and Pr.02-36– Pr.02-			
57	Motor 3 output		with the setting for F		10 and 1 1.02-30 1 1.02-			
58	Motor 4 output	40 III accordance	with the setting for t	1.12-01.				
59	Motor 5 output	Mhon ootting mu	lti matar airculativa f	unation th	no multi function cutout			
60	Motor 6 output				ne multi-function output			
61	Motor 7 output				15 and Pr.02-36– Pr.02-			
62	Motor 8 output	THO III ACCORDANCE	with the setting for F	-1.1∠ <b>-</b> U1.				
	SO output logic A		Stat	tus of safe	ety output			
66	(N.O.)	Status of driv	ve N.O. (MOx =		N.C. (MOx = 68)			
	(	Normal	Broken circuit (		Short circuit (Close)			
00	SO output logic B	STO	Short circuit (C	·	Broken circuit (Open)			
68	(N.C.)	STL1-STL3	Short circuit (C	Close) E	Broken circuit (Open)			
		I						

Settings	Functions	Descriptions
		The multi-function output terminals operate when the analog input
		level is between the high level and the low level.
		Pr.03-44: Select one of the analog signal channels (AVI1, ACI, and
	Analog input lovel	AVI2) to be compared.
67	Analog input level	Pr.03-45: The high level for the analog input, default is 50.00%
	reached	Pr.03-46: The low level for the analog input, default is 10.00%.
		If analog input > Pr.03-45, the multi-function output terminal operates.
		If analog input < Pr.03-46, the multi-function output terminal stops
		output.
	Preheating output	A 46: -4
69	indication	Activates when the preheating is detected.

Add Remote IO function to directly control the drive's AO / DO and read current AI / DI status through the standard Modbus. The corresponding index of 26xx is as following:

	bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
2600h	MI15	MI14	MI13	MI12	MI11	MI10	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD
2640h	-	ı	-	-	-	MO15	MO14	MO13	MO12	MO11	MO10	•	ı	RY3	RY2	RY1
2660h	A۱	/11	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2661h	Α	CI	-	-	-	-	-	-	-	-	-	•	1	-	-	-
2662h	A\	/12	-	-	-	-	-	-	-	-	-	ı	ı	-	-	-
266Ah	Al	10	-	-	-	-	-	-	-	-	-	-	-	-	-	-
266Bh	Al	11	-	-	-	-	-	-	-	-	-	-	-	-	-	-
26A0h		AFM1		-	-	-	-	-	-	-	-	-	•	-	-	-
26A1h		AFM2		-	-	-	-	-	-	-	-	-	-	-	-	-
26AAh AO10			-	-	-	-	-	-	-	-	-	-	-	-	-	
26ABh		AO11		-	-	-	-	-	-	-	-	ı	ı	-	-	-

In addition, the AI and DI values can be read directly, while DO and AO must be controlled by Modbus under corresponding parameter function. The related parameter definition is as following:

### DO

Terminal	Parameter Setting	Direct Control the Index Corresponded to Modbus
RY1	Pr.02-13 = 51	bit0 of 2640h
RY2	Pr.02-14 = 51	bit1 of 2640h
RY3	Pr.02-15 = 51	bit2 of 2640h
MO10 / RY10	Pr.02-36 = 51	bit5 of 2640h
MO11 / RY11	Pr.02-37 = 51	bit6 of 2640h
MO12	Pr.02-38 = 51	bit7 of 2640h
MO13	Pr.02-39 = 51	bit8 of 2640h
MO14	Pr.02-40 = 51	bit9 of 2640h
MO15	Pr.02-41 = 51	bit10 of 2640h

#### ΑO

Terminal Parameter Setting		Direct Control the Index Corresponded to Modbus		
AFM1	Pr.03-20 = 21	The value of 26A0h		
AFM2 Pr.03-23 = 21		The value of 26A1h		
AFM10	Pr.14-12 = 21	The value of 26AAh		
AFM11 Pr.14-13 = 21		The value of 26ABh		

# Multi-Function Output Direction

Default: 0000h

Settings 0000h-FFFFh (0: N.O.; 1: N.C.)

- This parameter is in hexadecimal.
- This parameter is set by a bit. If the bit is 1, the corresponding multi-function output acts in an opposite way.

#### Example:

Assume Pr.02-13 = 1 (indication when the drive is operating). If the output is positive, the bit is set to 0, and then Relay is ON when the drive runs and is OFF when the drive stops. On the contrary, if the output is negative, and the bit is set to 1, then the Relay is OFF when the drive runs and is ON when the drive stops.

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MO20	MO19	MO18	MO17	MO16	MO15	MO14	MO13	MO12	MO11	MO10	Rese	erved	RY3	RY2	RY1

# 7 Terminal Counting Value Reached (return to 0)

Default: 0

### Settings 0-65500

You can set the input point for the counter using the multi-function terminal MI6 as a trigger terminal (set Pr.02-06 to 23). When counting is completed, the specified multi-function output terminal is activated (Pr.02-13, Pr.02-14, Pr.02-36, Pr.02-37 are set to 18), and Pr.02-19 cannot be set to 0 at this time.

#### Example:


When the displayed value is c5555, the drive count is 5,555 times. If the displayed value is c5555•, the actual count value is 55,550–55,559.

# Preliminary Counting Value Reached (does not return to 0)

Default: 0

#### Settings 0-65500


When the count value counts from 1 to reach this value, the corresponding multi-function output terminal is activated (Pr.02-13, Pr.02-14, Pr.02-36, Pr.02-37 are set to 17). You can use this parameter as the end of counting to make the drive run from the low speed to stop.



×	02-22	Desired Frequency Reached 1	
×	02-24	Desired Frequency Reached 2	
			Default: 60.00 / 50.00
		Settings 0.00-599.00 Hz	
×	02-23	The Width of the Desired Frequency Reached	1
×	02-25	The Width of the Desired Frequency Reached	2
-			Default: 2.00

Settings 0.00-599.00 Hz

Once output speed (frequency) reaches the desired speed (frequency), if the corresponding multi-function output terminal is set to 3–4 (Pr.02-13, Pr.02-14, Pr.02-36, and Pr.02-37), this multi-function output terminal is "closed".




# **02-32** Brake Delay Time


Default: 0.000

#### Settings 0.000-65.000 sec.

When the AC motor drive runs after the setting delay time of Pr.02-32, the corresponding multifunction output terminal (12: mechanical brake release) is "closed". The function must be used with DC brake.



This parameter is invalid if it is used without DC brake. Refer to the following operation timing.



# ✓ 02-33 Output Current Level Setting for Multi-Function Output Terminals

Default: 0

Settings 0-150%

- When the drive outputs current higher than or equal to Pr.02-33 (≥ Pr.02-33), the multi-function output parameters active (Pr.02-13, Pr.02-14, and Pr.02-15 are set to 27).
- When the drive outputs current lower than Pr.02-33 (< Pr.02-33), the multi-function output parameters active (Pr.02-13, Pr.02-14, and Pr.02-15 are set to 28).

# Output Frequency Setting for Multi-Function Output Terminals

Default: 3.00

Settings 0.00-599.00 Hz

- When the drive outputs frequency higher than or equal to Pr.02-34 (actual output frequency H ≥ Pr.02-34), the multi-function terminal active (Pr.02-13, Pr.02-14 and Pr.02-15 are set to 29).
- When the drive outputs frequency lower than Pr.02-34 (actual output frequency H < Pr.02-34), the multi-function terminals active (Pr.02-13, Pr.02-14 and Pr.02-15 are set to 30).

# M 02-35 External Operation Control Selection after Reset and Reboot

Default: 0

Settings 0: Disable


1: Drive runs if the RUN command remains after reset or reboot

- Setting 1: the drive automatically executes the RUN command under the following circumstances, pay extra attention on this.
  - Status 1: After the drive is powered on and the external terminal for RUN stays ON, the drive runs.
  - Status 2: After clearing a fault once a fault is detected and the external terminal for RUN stays ON, you can run the drive by pressing RESET key.

## 02-50 Display the Status of Multi-function Input Terminal


Default: Read only

#### Settings Monitor the status of multi-function input terminals



### Example:


When Pr.02-50 displays 0034h (hex), (that is, the value is 110100 (binary), it means that MI1, MI3 and MI4 are ON.



## 02-51 Display the Status of Multi-function Output Terminal


Default: Read only

### Settings Monitor the status of multi-function output terminals



#### Example:

When Pr.02-51 displays 0023h (hex) (that is, the value is 100011 (binary)), it means that RY1, RY2 and MO10 are ON.




## 02-52 Display the External Multi-function Input Terminals Used by PLC

Default: Read only


Settings Monitor the status of PLC external output terminals

Pr.02-52 displays the external multi-function input terminals that used by PLC.



### Example:

When Pr.02-52 displays 0034h (hex) (that is, the value is 110100 (binary)), it means MI1, MI3 and MI4 are used by PLC.




## **02-53** Display the External Multi-function Output Terminal Used by PLC

Default: Read only


Settings Monitoring status of PLC external multi-function output terminal

Pr.02-53 displays the external multi-function output terminal that used by PLC.



#### Example:

When Pr.02-53 displays 0003h (hex) (that is, the value is 0011 (binary)), it means that RY1 and RY2 are used by PLC.



## **02-54** Display the Frequency Command Executed by External Terminal

Default: Read only

Settings 0.00-599.00 Hz

When you set the source of the frequency command as the external terminal, if Lv or Fault occurs, the external terminal frequency command is saved in this parameter.

## 02-70 IO Card Types

Default: Read only

Settings 1: EMC-BPS01

4: EMC-D611A 5: EMC-D42A 6: EMC-R6AA 11: EMC-A22A

# **02-72** Preheating Output Current Level

Default: 0

Settings 0–100%

When a motor drive is not in operation (STOP) and is placed in a cold and humid environment, enabling the preheating function to output DC current to heat up the motor drive can prevent the

invasion of humidity into the motor drive, which creates condensation affects the normal function of the motor drive.

Sets the output current level from the motor drive to the motor after enabling the preheating. The percentage of the preheating DC current is 100% of the rated current of the motor drive (Pr.05-01, Pr.05-13 and Pr.05-34). When setting this parameter, slowly increase the percentage to reach the sufficient preheating temperature.

## ✓ 02-73 Preheating Output Cycle


Default: 0

Settings 0–100%

Sets the output current cycle of preheating. 0–100% corresponds to 0–10 seconds. When set to 0%, there is no output current. When set to 100%, there is a continuous output. For example, when set to 50%, a cycle of preheating goes from OFF (5 seconds) to ON (5 seconds), and vice versa.

### Related Parameters of Preheating


Parameter	Description	Setting Range	Explanation	
02-72	Output current level of	0–100% (rated current of the motor)	Output current level of	
02-72	preheating	0% No output	preheating	
	Output avala of	0–100% (0–10 sec.)	Output cycle of	
02-73	2-73 Output cycle of	. I 0% No output		
	preheating	100% Continuous output	preheating	
02-01-08	Multi-input function	60 Drahaating command	Enable or disable the	
02-26-31	commands (MIx)	69 Preheating command	preheating	
02-13-15	Multi-output function	60 Output command of probacting	Indication of the	
02-36-46	commands (MOx)	69 Output command of preheating	preheating	



- Enable preheating: When Pr.02-72 and Pr.02-73 are NOT set to zero.
- Preheating function A: If Pr.07-72 and Pr.07-23 are set before the motor drive stops operation (STOP), preheating is enabled right after the motor drive stops. However, if Pr.07-72 and Pr.07-73 are set after the motor drives stops operation, preheating is not enabled. Preheating is enabled only when the motor drive stops again or restarts.
- Preheating function B: When the motor drive is in operation (RUN) or stops operating (STOP), set Pr.02-72 and Pr.02-73 between 1–100% and set MIx = 69 and MIx = ON. Preheating is enabled whenever the motor drive stops; no matter the motor drive is in operation (RUN) or stops operating (STOP).
- Preheating priority: if preheating function A and B are both enabled, function B takes priority.


## **Sequential Diagram of the Preheating Function:**

1. Setting parameters to enable preheating (Function A) Set Pr.02-72 and Pr.02-73 not equal to zero (50% in the diagram) and stop running the motor drive, then preheating is enabled to output DC current. At the same time, MOx (Output Command of Preheating) is ON (MOx = 69). Once the drive is rebooted, the preheating function is enabled right away. The sequence of preheating goes from OFF (5 seconds) to ON (5 seconds). When the motor is in operation (RUN), the preheating function is OFF even it is enabled. Meanwhile, MOx is OFF (MOx = 69) and the preheating is enabled when the motor drive stops.




2. Enable preheating via multi-input terminals (Function B)

Set Pr.02-72 and Pr.02-73 (50% in the diagram) not equal to zero and set MIx = 69, and MIx = ON, then Function B takes priority to enable / disable preheating on the motor drive. At the same time, enabling preheating by parameters is automatically invalid. If, at this moment, the motor drive is already STOP, the preheating function is enabled to output DC current and the MOx (Output Command of Preheating) is ON (MOx = 69). The sequence of preheating goes from OFF (5 seconds) to ON (5 seconds). When the motor is in operation (RUN), the preheating function is OFF even it is enabled. Meanwhile, MOx is OFF (MOx = 69) and the preheating is enabled when the motor drive stops.



#### 3. Enable DC brake function

DC brake and preheating are enabled at the same time. The motor drive operates with the same logic described above for preheating. The only difference is that no matter the motor drive is in operation (RUN) or stops operating (STOP), DC brake enables first. When the motor drive stops, preheating is activated.



[This page is intentionally left blank]

## 03 Analog Input / Output Parameter

✓ You can set this parameter during operation.

AVI1 Analog Input Selection
Default: 1
ACI Analog Input Selection (ACI)
Default: 0
AVI2 Analog Input Selection
Default: 0
Default: 0

Settings 0: No function

1: Frequency command (speed limit under torque control mode)

4: PID target value

5: PID feedback signal

6: Thermistor (PTC) input value

11: PT100 thermistor input value

13: PID compensation value


When you use analog input as the PID reference target input, you must set Pr.00-20 to 2 (external analog input).

Setting method 1: Pr.03-00–03-02 set 1 as Frequency command.


Setting method 4: Pr.03-00-03-02 set 4 as PID target value.

If the setting value 1 and setting value 4 exist at the same time, the AVI1 input has highest priority to become the PID reference target input value.

- When you use analog input as the PID compensation value, you must set Pr.08-16 to 1 (source of PID compensation value is analog input). You can see the compensation value with Pr.08-17.
- When using the Frequency command, the corresponding value for 0– ±10 V / 4–20 mA is 0– maximum output frequency (Pr.01-00).
- ☐ If the settings for Pr.03-00–Pr.03-02 are the same, the AVI1 input has highest priority.
- PT100 wiring method is as the following.



PTC wiring method is as the following.



## ✓ 03-03 AVI1 Analog Input Bias

Default: 0.0

Settings -100.0-100.0%

Sets the corresponding AVI1 voltage for the external analog input 0.

## ✓ 03-04 ACI Analog Input Bias

Default: 0.0

Settings -100.0-100.0%

Sets the corresponding ACI current for the external analog input 0.

## AVI2 Analog Voltage Input Bias

Default: 0.0

Settings -100.0–100.0%

- ☐ Sets the corresponding AVI2 voltage for the external analog input 0.
- The corresponding external input voltage / current signal and the set frequency is 0–10 V (4–20 mA) corresponds to 0–maximum frequency (Pr.01-00).
- ★ 03-07 AVI1 Positive / Negative Bias Mode
- O3-08 ACI Positive / Negative Bias Mode
- AVI2 Positive / Negative Bias Mode

Default: 0


Settings 0: No bias

- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Bias serves as the center

Using negative bias to set the frequency greatly reduces the noise interference. In a noisy environment, do NOT use signals less than 1 V to set the drive's operation frequency.

In the diagram below: Black line: Curve with no bias. Gray line: curve with bias

#### Diagram 1



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

#### Diagram 2



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

► V Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11Analog Input Gain (AVI1)=100%

## Diagram 3



Pr.03-03=10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

#### Diagram 5



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

### Diagram 6



Pr.03-03=10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11Analog Input Gain (AVI1)= 100%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.

  Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

### Diagram 8



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

#### Diagram 9



Pr.03-03=-10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

### Diagram 11



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

#### Diagram 12



Pr.03-03=-10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias


- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

## Diagram 14



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

#### Diagram 15



Pr.03-03=-10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

### Diagram 17



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

#### 1: Lower than or equal to bias

- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 111.1%

10/9=111.1%

## Diagram 18



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)=111.1%

10/9 =111.1%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1%

10/9 = 111.1%

### Diagram 20



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1%

10/9 = 111.1%

#### Diagram 21



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias


- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1%

10/9 = 111.1%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias

2: Greater than or equal to bias

- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1%

10/9 = 111.1%

#### Diagram 23



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias

- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1%

10/9 = 111.1%

#### Diagram 24



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1%

10/9 = 111.1%



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-xV)} \quad xV = \frac{10}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain:  $03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$ 

## Diagram 26



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{-60\text{-}6\text{Hz}}{10\text{V}} = \frac{6\text{-}0\text{Hz}}{(0\text{-}x\text{V})} \quad x\text{V} = \frac{10}{-9} = -1.11\text{V} \quad \therefore 03\text{-}03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain: 03-11=  $\frac{10V}{11.1}$ V×100%=90.0%

## Diagram 27



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6\text{Hz}}{10\text{V}} = \frac{6-0\text{Hz}}{(0-x\text{V})} \quad x\text{V} = \frac{10}{-9} = -1.11\text{V} \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

=-11.1%

Calculate the gain:  $03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$ 



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60\text{-}6\text{Hz}}{10\text{V}} = \frac{6\text{-}0\text{Hz}}{(0\text{-}x\text{V})} \quad x\text{V} = \frac{10}{-9} = -1.11\text{V} \quad \text{``03-03} = \frac{-1.11}{10} \times 100\%$$

Calculate the gain:  $03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$ 

## Diagram 29



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage
- while serving as the center 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid.
  Forward and reverse run is controlled
  by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-xV)} \quad xV = \frac{10}{-9} = 1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain: 03-11=  $\frac{10 \text{ V}}{11.1 \text{ V}} \times 100\% = 90.0\%$ 

#### Diagram 30



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
   Neagtive frequency is valid. Positive
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-xV)} \quad xV = \frac{10}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

=-11.19

Calculate the gain: 03-11=  $\frac{10V}{11.1V} \times 100\% = 90.0\%$ 



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0. No hias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.


Calculate the bias:

$$\frac{60-6\text{Hz}}{10\text{V}} = \frac{6-0\text{Hz}}{(0-x\text{V})} \quad x\text{V} = \frac{10}{-9} = 1.11\text{V} \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

$$= -1.11\%$$

Calculate the gain: 03-11= 
$$\frac{10 \text{ V}}{11.1 \text{ V}} \times 100\% = 90.0\%$$

Diagram 32



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6\text{Hz}}{10\text{V}} = \frac{6-0\text{Hz}}{(0-x\text{V})} \quad x\text{V} = \frac{10}{-9} = 1.11\text{V} \quad \text{``03-03} = \frac{-1.11}{10} \times 100\%$$

Calculate the gain: 
$$03-11 = \frac{10 \text{ V}}{11.1 \text{ V}} \times 100\% = 90.0\%$$


Diagram 33



Pr.00-21=0 (Digital keypad control and run in FWD direction)
Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%
Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 100%




Pr.00-21=0 (Digital keypad control and run in FWD direction) Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10% Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 100%

Diagram 35




Pr.00-21=0 (Digital keypad control and run in FWD direction) Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10% Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 100%


Diagram 36



Pr.00-21=0 (Digital keypad control and run in FWD direction) Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10% Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 100%



Pr.00-21=0 (Digital keypad control and run in FWD direction)
Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%
Pr.03-07-03-09 (Positive/Negative Bias Mode)


0: No bias

- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 111.1%  $(10/9) \times 100\% = 111.1\%$ 

Pr.03-14 Analog Positive Input Gain (AVI2) = 100%

### Diagram 38




Pr.00-21=0 (Digital keypad control and run in FWD direction)
Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%
Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 90.0% (10/11) × 100% = 90.9%

#### Diagram 39




Pr.00-21=0 (Digital keypad control and run in FWD direction)
Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%
Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 111.1%  $(10/9) \times 100\% = 111.1\%$  Pr.03-14 Analog Positive Input Gain (AVI2) = 90.9%  $(10/11) \times 100\% = 90.9\%$ 





## 

Default: 0

- Settings 0: Negative frequency is not allowed. The digital keypad or external terminal controls the forward and reverse direction.
  - 1: Negative frequency is allowed. Positive frequency = run in a forward direction; negative frequency = run in a reverse direction. The digital keypad or external terminal control cannot change the running direction.
- Use this parameter only for AVI1 or ACI analog input.
- Requirements for negative frequency (reverse running):
  - 1. Pr.03-10 = 1
  - 2. Bias mode = Bias as the center
  - 3. Corresponded analog input gain < 0 (negative); this makes the input frequency negative.
- In using the additional analog input function (Pr.03-18 = 1), when the analog signal is negative after the addition, you can set this parameter to allow or not allow the reverse running. The result after adding depends on the "Requirements for negative frequency (reverse running)".

×	03-11	AVI1 Analog Input Gain
×	03-12	ACI Analog Input Gain
×	03-13	AVI2 Analog Positive Input Gain
×	03-14	AVI2 Analog Negative Input Gain

Default: 100.0

Settings -500.0-500.0%

Use Pr.03-03–Pr.03-14 when the Frequency command source is the analog voltage or current signal.

AVI1 Analog Input Filter Time
 ACI Analog Input Filter Time
 AVI2 Analog Input Filter Time

Default: 0.01

Settings 0.00-20.00 sec.

- Analog signals, such as those entering AVI1, ACI and AVI2, are commonly affected by interference that affects the stability of the analog control. Use the Input Noise Filter to create a more stable system.
- When the time constant setting is too large, the control is stable, but the control response is slow. When the time constant setting is too small, the control response is be faster, but the control may be unstable. For optimal setting, adjust the setting based on the control stability or the control response.

## ✓ 03-18 Analog Input Addition Function

Default: 0

Settings 0: Disable (AVI1, ACI, AVI2)

1: Enable


Example 1: Pr.03-00 = Pr.03-01 = 1, Frequency command = AVI1 + ACI

Example 2: Pr.03-00 = Pr.03-01 = Pr.03-02 = 1, Frequency command = AVI1 + ACI + AVI2

Example 3: Pr.03-00 = Pr.03-02 = 1, Frequency command = AVI1 + AVI2

Example 4: Pr.03-01 = Pr.03-02 = 1, Frequency command = ACI + AVI2

When Pr.03-18 = 0 and the analog input selection settings (Pr.03-00, Pr.03-01 and Pr.03-02) are the same, AVI1 has priority over ACI and AVI2 (AVI1 > ACI > AVI2).



Fcmd: the corresponding frequency of 10V or 20mA

ay: 0~10V, 4~20mA, 0~20mA bias: Pr.03-03, Pr. 03-04, Pr.03-05

gain: Pr.03-11, Pr.03-12, Pr.03-13, Pr.03-14

# 03-19 Signal Loss Selection for the Analog Input 4–20 mA

Default: 0

Settings 0: Disable

1: Continue operation at the last frequency

2: Decelerate to 0 Hz

3: Stop immediately and display ACE

4: Operate with output frequency lower limit

- Determines the treatment when the 4–20 mA signal is lost [AVIc (Pr.03-28 = 2) or ACIc (Pr.03-29 = 0)].
- When Pr.03-28 ≠ 2, the voltage input to AVI1 terminal is 0–10 V or 0–20 mA, and the Pr.03-19 is invalid.

#### Chapter 12 Description of Parameter Settings | CFP2000

- When Pr.03-29 ≠ 0, the voltage input to ACI terminal is 0–10 V, and Pr.03-19 is invalid.
   When the setting is 1, 2 or 4, when ACI loss, the keypad displays the warning code "ANL". If this parameter is set to 4, the drive operates with output frequency lower limit (Pr.01-11). It keeps blinking until the ACI signal is recovered.
   When the setting is 3, and the ACI terminal is disconnected, the keypad displays "ACE" error. It keeps blinking until the connection is recovered and the error is reset.
   When the drive stops, the condition that causes the warning does not exist, so the warning automatically disappears.
   When the signal loss detection function is enabled and the analog input signal is lower than the loss level 3.6 mA, the drive executes a loss alarm until the analog input signal is larger than the 4.0 mA recovery level, and the drive stops the alarm. Refer to the diagram in Pr.03-68.
- AFM1 Analog Output Selection

  O3-23 AFM2 Analog Output Selection

Default: 0

Settings 0-23

#### **Function Chart**

Settings	Functions	Descriptions					
0	Output frequency (Hz)	Maximum frequency Pr.01-00 is processed as 100%					
1	Frequency command (Hz)	Maximum frequency Pr.01-00 is processed as 100%.					
2	Motor speed (Hz)	Maximum frequency P	r.01-00 is processed as 100%				
3	Output current (rms)	(2.5 × rated current) is	processed as 100%				
4	Output voltage	(2 × rated voltage) is p	rocessed as 100%				
5	DC bus voltage	450V (900V) = 100%					
6	Power factor	-1.000-1.000 = 100%					
7	Power	Drive rated power is p	rocessed as 100%				
9	AVI1 percentage	0–10 V / 0–20 mA / 4–	20 mA = 0–100%				
10	ACI percentage	4–20 mA / 0–10 V / 0–	20 mA = 0–100%				
11	AVI2 percentage	0-10 V = 0-100%					
		For CANopen communication analog output					
		Terminal	Corresponding Address				
00	OANI-n-n-an-al-n-a-stant	AFM1	2026-A1				
20	CANopen analog output	AFM2	2026-A2				
		AO10	2026-AB				
		AO11	2026-AC				
		For RS-485 (InnerCO	// Modbus) control analog output				
		Terminal	Corresponding Address				
0.4	DO 405	AFM1	26A0H				
21	RS-485 analog output	AFM2	26A1H				
		AO10	26AAH				
		AO11	26ABH				

Settings	Functions		Descriptions
22	Communication card analog output	For communication analog output (CMC-EIP01, CMC-PN01, CMC-DN01)	
		Terminal	Corresponding Address
		AFM1	26A0H
		AFM2	26A1H
		AO10	26AAH
		AO11	26ABH
23	Constant voltage output	Pr.03-32 and Pr.03-33 control the voltage output level	
		0-100% of Pr.03-32 corresponds to 0-10 V of AFM1.	
		0-100% of Pr.03-33 corresponds to 0-10 V of AFM2.	

$\varkappa$	03-21	AFM1 Analog Output Ga	in
-------------	-------	-----------------------	----

✓ 03-24 AFM2 Analog Output Gain

Default: 100.0

Settings 0.0-500.0%

Adjusts the voltage level outputted to the analog meter from the analog signal (Pr.03-20) output terminal AFM of the drive.

AFM1 Analog Output REV Direction


AFM2 Analog Output REV Direction

Default: 0

Settings 0: Absolute value in output voltage

1: Reverse output 0 V; forward output 0-10 V

2: Reverse output 5–0 V; forward output 5–10 V



Selections for the analog output direction

# ✓ 03-27 AFM2 Output Bias

Default: 0.00

Settings -100.00-100.00%

Example 1, AFM2 0–10 V is set to the output frequency, the output equation is:

10 V × (output frequency ÷ Pr.01-00) × Pr.03-24 + 10 V × Pr.03-27

Example 2, AFM2 0–20 mA is set to the output frequency, the output equation is:

20 mA × (output frequency ÷ Pr.01-00) × Pr.03-24 + 20 mA × Pr.03-27

#### Chapter 12 Description of Parameter Settings | CFP2000

- Example 3, AFM2 4–20 mA is set to the output frequency, the output equation is: 4 mA+16 mA × (output frequency ÷ Pr.01-00) × Pr.03-24 + 16 mA × Pr.03-27
- This parameter sets the corresponding voltage of the analog output 0.

## AVI1 Terminal Input Selection

Default: 0

Settings 0: 0-10 V

1: 0–20 mA 2: 4–20 mA

## ✓ 03-29 ACI Terminal Input Selection

Default: 0

Settings 0: 4–20 mA

1: 0–10 V 2: 0–20 mA


- When you change the input mode, verify that the external terminal switch (SW3, SW4) corresponds to the setting for Pr.03-28–Pr.03-29.
- When you change the setting, proportion to the corresponding ACI and ACI will change to default.

## 03-30 PLC Analog Output Terminal Status

Default: Read only


Settings Monitor the status of the PLC analog output terminals

Pr.03-30 displays the external multi-function output terminal that used by PLC.



#### For Example:

When Pr.03-30 displays 0002h (hex), it means that AFM2 is used by PLC.




**AFM2 Output Selection** AFM1 Output Selection Default: 0 Settings 0: 0–20 mA output 1: 4-20 mA output AFM1 DC Output Setting Level 03 - 33AFM2 DC Output Setting Level Default: 0.00 Settings 0.00-100.00% Pair with multi-function output: 23, Pr.03-32 and Pr.03-33 outputs constant AFM voltage. ☐ Set Pr.03-32 between 0–100.00% to correspond to 0–10 V of AFM1. ☐ Set Pr.03-33 between 0–100.00% to correspond to 0–10 V of AFM2. 03-35 **AFM1 Filter Output Time** AFM2 Filter Output Time Default: 0.01 Settings 0.00-20.00 sec. 03-44 Multi-Function Output (MO) by Al Level Source Default: 0 Settings 0: AVI1 1: ACI 2: AVI2 Al Upper Level 03-45 Default: 50.00 Settings -100.00-100.00% 03-46 Al Lower Level Default: 10.00 Settings -100.00-100.00% Multi-function output terminal 67 must work with Pr.03-44 to select input channels. Whan analog input level is higher than Pr.03-45, multi-function output acts; when analog input level is lower than Pr.03-46, multi-function output terminals stop outputting. When setting levels, Al upper level must be higher than Al lower level. 03-50 Analog Input Curve Selection Default: 7 Settings 0: Normal Curve 1: Three-point curve of AVI1 2: Three-point curve of ACI 3: Three-point curve of AVI1 & ACI 4: Three-point curve of AVI2 5: Three-point curve of AVI1 & AVI2 6: Three-point curve of ACI & AVI2

		7. THEO POINT COLVE OF THE	7101 071112					
Sets the	☐ Sets the calculation method for analog input.							
When P	□ When Pr.03-50 = 0, all analog input signal is calculated by bias and gain.							
When P	When Pr.03-50 = 1, AVI1 calculates by frequency and voltage / current (Pr.03-51–Pr.03-56),							
other ar	nalog input	signal calculates by bias and g	ain.					
When P	r.03-50 = 2	2, ACI calculates by frequency a	ind voltage / current (Pr.03-57–Pr.03-62), oth	her				
analog i	nput signa	l calculates by bias and gain.						
When P	r.03-50 = 3	3, AVI1 and ACI calculate by fre	quency and voltage / current (Pr.03-51–Pr.03	3-				
62), oth	er analog i	nput signal calculate by bias an	d gain.					
When P     ■	r.03-50 = 4	4, AVI2 calculates by frequency	and voltage (Pr.03-63–Pr.03-68), other analo	og				
input sig	gnal calcul	ates by bias and gain.						
When P	r.03-50 = 5	5, AVI1 and AVI2 calculate by fre	equency and voltage / current (Pr.03-51–Pr.0	)3-				
56 and I	Pr.03-63–F	Pr.03-68), other analog input sig	nal calculate by bias and gain.					
		·	quency and voltage / current (Pr.03-57–Pr.03	3-				
,.	J	nput signal calculates by bias a	•					
		7, all analog input signal calcula	te by frequency and voltage / current (Pr.03-	-				
51– Pr.0	03-68).							
03-51	AVI1 Lo	west Point						
			Default:					
	Settings	Pr.03-28 = 0, 0.00–10.00 V	0.00					
		Pr.03-28 = 1, 0.00–20.00 mA	0.00					
		Pr.03-28 = 2, 4.00–20.00 mA	4.00					
03-52	AVI1 Pro	oportional Lowest Point						
			Default: 0.00					
	Settings	-100.00–100.00%						
03-53	AVI1 Mi	d-Point						
			Default:					
	Settings	Pr.03-28 = 0, 0.00–10.00 V	5.00					
		Pr.03-28 = 1, 0.00–20.00 mA	10.00					
		Pr.03-28 = 2, 0.00–20.00 mA	12.00					
03-54	AVI1 Pro	oportional Mid-Point						
			Default: 50.00					
	Settings	-100.00-100.00%						
03-55	AVI1 Hi	ghest Point						
	<b>.</b>	5	Default:					
	Settings	Pr.03-28 = 0, 0.00–10.00 V	10.00					
		Pr.03-28 = 1, 0.00–20.00 mA	20.00					
( 02 EC	A) //4 D	Pr.03-28 = 2, 0.00–20.00 mA	20.00					
03-56	AVIT Pr	oportional Highest Point	Defenite 400.00					
	Cottings	100.00.100.000/	Default: 100.00					
	Settings	-100.00–100.00%						

7: Three-point curve of AVI1 & ACI & AVI2

- $\square$  When Pr.03-28 = 0, the AVI1 setting is 0–10 V and the unit is in voltage (V).
- When Pr.03-28  $\neq$  0, the AVI1 setting is 0–20 mA or 4–20 mA and the unit is in current (mA).
- When you set the analog input AVI1 to frequency command, 100% corresponds to Fmax (Pr.01-00 Maximum Operation Frequency).
- The requirement for these there parameters (Pr.03-51, Pr.03-53 and Pr.03-55) is Pr.03-51 < Pr.03-53 < Pr.03-55. The values for three proportional points (Pr.03-52, Pr.03-54 and Pr.03-56) have no limits. Values between two points are calculated by a linear equation. The ACI and AVI2 are the same as AVI1.
- The output percentage is 0% when the AVI1 input value is lower than the lowest point setting. Example: Pr.03-51 = 1 V, Pr.03-52 = 10%. The output is 0% when AVI1 input is lower than 1 V. If the AVI1 input varies between 1 V and 1.1 V, the drive's output frequency is between 0% and 10%.



<b>№</b> 03-57	ACI Lov	vest Point	
			Default:
	Settings	Pr.03-29 = 0, 4.00–20.0 mA	4.00
		Pr.03-29 = 1, 0.00–10.00 V	0.00
		Pr.03-29 = 2, 0.00–20.00 mA	0.00
<b>№</b> 03-58	ACI Pro	portional Low Point	
			Default: 0.00
	Settings	-100.00–100.00%	
<b>№</b> 03-59	ACI Mid	l-Point	
			Default:
	Settings	Pr.03-29 = 0, 0.00–20.00 mA	12.00
		Pr.03-29 = 1, 0.00–10.00 V	5.00
		Pr.03-29 = 2, 0.00–20.00 mA	10.00
<b>№</b> 03-60	ACI Pro	portional Mid-Point	
			Default: 50.00
	Settings	-100.00–100.00%	
<b>√</b> 03-61		hest Point	
00 01	/ (Of Fing	noot i omt	Default:
	Settings	Pr.03-29 = 0, 0.00–20.00 mA	20.00
	Octungs	Pr.03-29 = 1, 0.00–10.00 V	10.00
		Pr.03-29 = 2, 0.00–20.00 mA	20.00
<b>№</b> 03-62	ACI Dro	portional Highest Point	20.00
<b>7</b> 03-02	ACIFIC	portional riigilest roint	Default: 100.00
	Cottingo	100.00, 100.00%	Delault. 100.00
€ NA/I	Settings	-100.00–100.00%	11 0.0
		1, the ACI setting is 0–10 V and the unit is in v	<b>3</b> ( )
		1, the ACI setting is 0–20 mA or 4–20 mA, and	` ,
•		analog input ACI to the Frequency command,	100% corresponds to Fmax
•		m Operation Frequency).	
	•	or these three parameters (Pr.03-57, Pr.03-59	,
		61. The values for three proportional points (P	r.03-58, Pr.03-60 and Pr.03-62)
		ere is a linear calculation between two points.	
The ou	tput percen	tage % are the proportional lowest point wher	the ACI input value is lower
	e lowest po	•	
Examp	le: Pr.03-57	7 = 4  mA; Pr.03-58 = 10%, the outputs below (	(including) 4 mA are all 10%
output.			
<b>№</b> 03-63	Positive	AVI2 Voltage Lowest Point	
00-00	· John V	The voltage Lowoot Form	Default: 0.00
	Settings	0.00–10.00 V	Doladic 0.00
<i>№</i> 03-64		AVI2 Proportional Lowest Point	
/- 03=04	i Ositive	AVIZ I TOPOLIONAL LOWEST FOILIT	Default: 0.00
	Cottings	100.00, 100.00%	Delault. 0.00
	Settings	-100.00–100.00%	


×	03-65	Positive	AVI2 Voltage Mid-Point		
				Default: 5.00	
		Settings	0.00–10.00 V		
×	03-66	Positive	AVI2 Proportional Mid-Point		
				Default: 50.00	
		Settings	-100.00–100.00%		
×	03-67	Positive	AVI2 Voltage Highest Point		
				Default: 10.00	
		Settings	0.00–10.00 V		
×	03-68	Positive	AVI2 Proportional Highest Point		
				Default: 100.00	
		Settings	-100.00–100.00%		
	66				

- When you set the positive voltage AVI2 to the Frequency command, 100% corresponds to Fmax (Pr.01-00 Maximum Operation Frequency) and the motor runs in the forward direction.
- The requirement for these three parameters (Pr.03-63, Pr.03-65 and Pr.03-67) is Pr.03-63 < Pr.03-65 < Pr.03-67. The values for three proportional points (Pr.03-64, Pr.03-66 and Pr.03-68) have no limits. There is a linear calculation between two points.
- The output percentage becomes 0% when the positive voltage AVI2 input value is lower than the lowest point setting.

For example:

If Pr.03-63 = 1 V; Pr.03-64 = 10%, then the output becomes 0% when the input is lower than 1 V. If the AVI input swings between 1 V and 1.1 V, the drive's output frequency oscillates between 0% and 10%.

- When AVI1 Selection (Pr.03-28) is 0–10 V, the setting ranges for Pr.03-51, Pr.03-53, and Pr.03-55 must be 0.00–10.00 or 0.00–20.00.
- When ACI Selection (Pr.03-29) is 0–10 V, the setting ranges for Pr.03-57, Pr.03-59 and Pr.03-61 must be 0.00–10.00 or 0.00–20.00.
- Use Pr.03-51–Pr.03-68 to set the open circuit corresponding function of analog input value and maximum operation frequency (Pr.01-00), as shown in the figure below.



[This page is intentionally left blank]

### **04 Multi-Step Speed Parameters**


✓ You can set this parameter during operation.

×	04-00	1st Step Speed Frequency
×	04-01	2nd Step Speed Frequency
×	04-02	3rd Step Speed Frequency
×	04-03	4th Step Speed Frequency
×	04-04	5th Step Speed Frequency
×	04-05	6th Step Speed Frequency
×	04-06	7th Step Speed Frequency
×	04-07	8th Step Speed Frequency
×	04-08	9th Step Speed Frequency
×	04-09	10th Step Speed Frequency
×	04-10	11th Step Speed Frequency
×	04-11	12th Step Speed Frequency
×	04-12	13th Step Speed Frequency
×	04-13	14th Step Speed Frequency
×	04-14	15th Step Speed Frequency

Default: 0.00

Settings 0.00–599.00 Hz

- Use the multi-function input terminals (refer to setting 1–4 of Pr.02-01–Pr.02-08 and Pr.02-26–Pr.02-31 Multi-function Input Command) to select the multi-step speed command (the maximum is 15<sup>th</sup> step speed). Pr.04-00 to Pr.04-14 set the multi-step speed frequency as shown in the following diagram.
- The external terminal / digital keypad / communication controls the RUN and STOP commands with Pr.00-21.
- You can set each multi-step speed between 0.00–599.00 Hz during operation.
- Explanation for the timing diagram of the multi-step speed and external terminals. The related parameter settings are:
  - 1. Pr.04-00–04-14: sets the 1<sup>st</sup> to 15<sup>th</sup> multi-step speed (to set the frequency of each step speed)
  - 2. Pr.02-01–02-08 and Pr.02-26–02-31: sets the multi-function input terminals (multi-step speed command 1–4)
- Related parameters:
  - Pr.01-22 JOG Frequency
  - Pr.02-01 Multi-function Input Command 1 (MI1)
  - Pr.02-02 Multi-function Input Command 2 (MI2)
  - Pr.02-03 Multi-function Input Command 3 (MI3)
  - Pr.02-04 Multi-function Input Command 4 (MI4)



Multi-speed via External Terminals

×	04-50	PLC Buffer 0
×	04-51	PLC Buffer 1
×	04-52	PLC Buffer 2
×	04-53	PLC Buffer 3
×	04-54	PLC Buffer 4
×	04-55	PLC Buffer 5
×	04-56	PLC Buffer 6
×	04-57	PLC Buffer 7
×	04-58	PLC Buffer 8
×	04-59	PLC Buffer 9
×	04-60	PLC Buffer 10
×	04-61	PLC Buffer 11
×	04-62	PLC Buffer 12
×	04-63	PLC Buffer 13
×	04-64	PLC Buffer 14
×	04-65	PLC Buffer 15
×	04-66	PLC Buffer 16
×	04-67	PLC Buffer 17
×	04-68	PLC Buffer 18
×	04-69	PLC Buffer 19
		Default: 0

Default: 0

Settings 0–65535

You can combine the PLC buffer with the built-in PLC function for a variety of applications.

_		
×	04-70	PLC Application Parameter 0
×	04-71	PLC Application Parameter 1
×	04-72	PLC Application Parameter 2
×	04-73	PLC Application Parameter 3
×	04-74	PLC Application Parameter 4
×	04-75	PLC Application Parameter 5
×	04-76	PLC Application Parameter 6
×	04-77	PLC Application Parameter 7
×	04-78	PLC Application Parameter 8
$\mathcal{M}$	04-79	PLC Application Parameter 9
$\mathcal{M}$	04-80	PLC Application Parameter 10
$\mathcal{M}$	04-81	PLC Application Parameter 11
×	04-82	PLC Application Parameter 12
×	04-83	PLC Application Parameter 13
×	04-84	PLC Application Parameter 14
$\mathcal{M}$	04-85	PLC Application Parameter 15
×	04-86	PLC Application Parameter 16
×	04-87	PLC Application Parameter 17
×	04-88	PLC Application Parameter 18
×	04-89	PLC Application Parameter 19
×	04-90	PLC Application Parameter 20
×	04-91	PLC Application Parameter 21
×	04-92	PLC Application Parameter 22
×	04-93	PLC Application Parameter 23
×	04-94	PLC Application Parameter 24
×	04-95	PLC Application Parameter 25
×	04-96	PLC Application Parameter 26
×	04-97	PLC Application Parameter 27
×	04-98	PLC Application Parameter 28
×	04-99	PLC Application Parameter 29

Settings 0–65535

Pr.04-70–Pr.04-99 are user-defined parameters. You can combine these 30 PLC Application

Default: 0

Pr.04-70—Pr.04-99 are user-defined parameters. You can combine these 30 PLC Application Parameters with the PLC programming for a variety of applications.

[This page is intentionally left blank]

#### **05 Motor Parameters**

The following are abbreviations for different types of motors:

- IM: Induction motor
- PM: Permanent magnet synchronous AC motor
- IPM: Interior permanent magnet synchronous AC motor
- SPM: Surface permanent magnet synchronous AC motor
- SynRM: Synchronous reluctance motor

✓ You can set this parameter during operation.

### **05-00** Motor Parameter Auto-Tuning

Default: 0

Settings 0: No function

1: Simple rolling auto-tuning for induction motor (IM)

2: Static auto-tuning for induction motor (IM)

5: Rolling auto-tuning for PM (IPM / SPM)

11: SynRM parameter auto-tuning (applied to 230V / 460V models)

13: Static auto-tuning for PM (IPM / SPM)

Refer to Section 12-2 <Adjustment and Application> for details of motor adjustment process.

# **05-01** Full-Load Current for Induction Motor 1 (A)

Default: Depending on the

model power

Settings Depending on the model power

- Sets this value according to the rated current of the motor as indicated on the motor nameplate.
- The default is 90% of the drive's rated current.
- Example: The rated current for a 7.5 HP (5.5 kW) is 25 A. The default is 22.5 A. The setting range is between 2.5-30 A.  $(25 \times 10\% = 2.5$  A and  $25 \times 120\% = 30$  A)

# N 05-02 Rated Power for Induction Motor 1(kW)

Default: Depending on the

model power

Settings 0.00–655.35 kW

Sets the rated power for motor 1. The default is the drive's power value.

# N 05-03 Rated Speed for Induction Motor 1 (rpm)

Default: Depending on the number of motor poles

Settings 0–xxxx rpm (Depending on the number motor poles)

1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)

- Sets the rated speed for the motor as indicated on the motor nameplate.
- Pr.01-01 and Pr.05-04 determine the maximum rotor speed for IM.

For example: Pr.01-01 = 20 Hz, Pr.05-04 = 2, according to the equation  $120 \times 20$  Hz  $\div 2 = 1200$  rpm and take integers. Due to the slip of the IM, the maximum setting value for Pr.05-03 is 1199 rpm (1200 rpm - 1).

# 05-04 Number of poles for Induction Motor 1 Default: 4 Settings 2-64 Sets the number poles for the motor (must be an even number). Set up Pr.01-01 and Pr.05-03 before setting up Pr.05-04 to make sure motor operates normally. Pr.01-01 and Pr.05-03 determine the maximum set up number poles for the IM. For example: Pr.01-01 = 20 Hz and Pr.05-03 = 39 rpm, according to the equation 120 × 20 Hz / 39 rpm = 61.5 and take even number, the number of poles is 60. Therefore, Pr.05-04 can be set to the maximum of 60 poles. 05-05 No-Load Current for Induction Motor 1 (A) Default: Depending on the model power Settings 0.0-Pr.05-01 default The default is 10–40% of motor rated current. For model with 110 kW and above, default setting is 20% of motor rated current. 05-06 Stator Resistance (Rs) for Induction Motor 1 Default: Depending on the model power Settings $0.000-65.535 \Omega$ 05-07 Rotor Resistance (Rr) for Induction Motor 1 Default: 0.000 Settings $0.000-65.535 \Omega$ Magnetizing Inductance (Lm) for Induction Motor 1 05-08 05-09 Stator Inductance (Lx) for Induction Motor 1 Default: 0.0 Settings 0.0-6553.5 mH 05-13 Full-Load Current for Induction Motor 2 (A) Default: Depending on the model power Settings Depending on the model power Set this value according to the rated current of the motor as indicated on the motor nameplate. The default is 90% of the drive's rated current. Example: The rated current for a 7.5 HP (5.5 kW) motor is 25 A. The default is 22.5 A. The setting range is between 2.5–30 A. $(25 \times 10\% = 2.5 \text{ A})$ and $25 \times 120\% = 30 \text{ A}$

★ 05-14 Rated Power for Induction Motor 2 (kW)	
	Default: Depending on the
Cottings 0.00 CEE 25 IAM	model power
Settings 0.00–655.35 kW	
Set the rated power for motor 2. The default is the drive's power.	er value.
Note: 15 Rated Speed for Induction Motor 2 (rpm)	
	Default: Depending on the
	number of motor poles
Settings 0-xxxx rpm (Depending on the number of	motor poles)
1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles	s)
Sets the rated speed for the motor as indicated on the motor r	nameplate.
OF 4C Number of Dalag for Industrian Material	
<b>05-16</b> Number of Poles for Induction Motor 2	Defende 4
Cattings 2 04	Default: 4
Settings 2–64	L - A
Sets the number of poles for the motor (must be an even num	•
Set up Pr.01-35 and Pr.05-15 before setting up Pr.05-16 to ma	•
normally. Pr.01-35 and Pr.05-15 determine the maximum set u	•
For example: Pr.01-35 = 20 Hz and Pr.05-15 = 39 rpm, accord	
39 rpm = 61.5 and take even number, the number of poles is	60. Therefore, Pr.05-16 can be set
to the maximum of 60 poles.	
<b>05-17</b> No-Load Current for Induction Motor 2 (A)	
` , ,	Default: Depending on the
	model power
Settings 0.00-Pr.05-13 default	
The default is 10–40% of motor rated current.	
☐ For model with 110 kW and above, default setting is 20% of m	
·	notor rated current.
	notor rated current.
<b>05-18</b> Stator Resistance (Rs) for Induction Motor 2	
<b>05-18</b> Stator Resistance (Rs) for Induction Motor 2	Default: Depending on the
Settings 0.000–65.535 Ω	Default: Depending on the
	Default: Depending on the model power
Settings $0.000-65.535 \Omega$ Rotor Resistance (Rr) for Induction Motor 2	Default: Depending on the
Settings 0.000–65.535 Ω	Default: Depending on the model power
Settings $0.000-65.535 \Omega$ <b>05-19</b> Rotor Resistance (Rr) for Induction Motor 2  Settings $0.000-65.535 \Omega$	Default: Depending on the model power  Default: 0.000
Settings $0.000-65.535\Omega$ 05-19 Rotor Resistance (Rr) for Induction Motor 2  Settings $0.000-65.535\Omega$ 05-20 Magnetizing Inductance (Lm) for Induction M	Default: Depending on the model power  Default: 0.000
Settings $0.000-65.535 \Omega$ <b>05-19</b> Rotor Resistance (Rr) for Induction Motor 2  Settings $0.000-65.535 \Omega$	Default: Depending on the model power  Default: 0.000
Settings $0.000-65.535\Omega$ 05-19 Rotor Resistance (Rr) for Induction Motor 2  Settings $0.000-65.535\Omega$ 05-20 Magnetizing Inductance (Lm) for Induction M	Default: Depending on the model power  Default: 0.000

### 05-22 Induction Motor 1 / 2 Selection

Default: 1

Settings 1: Motor 1

2: Motor 2

Sets the motor currently operated by the AC motor drive.

# Frequency for Y-Connection / Δ-Connection Switch for an Induction Motor

Default: 60.00

Settings 0.00-599.00 Hz

### **05-24** Y-Connection / Δ-Connection Switch for Induction Motor

Default: 0

Settings 0: Disable


1: Enable

# Delay Time for Y-Connection / Δ-Connection Switch for an Induction Motor

Default: 0.200

Settings 0.000-60.000 sec.


- You can apply Pr.05-23–Pr.05-25 in a wide range of motors, and the motor coil executes the Y-connection /  $\Delta$ -connection switch as required. The wide range motors are related to the motor design. In general, the motor has higher torque with low speed Y-connection, and has higher speed with high speed  $\Delta$ -connection).
- $\square$  Pr.05-24 enables and disables the switch of Y-connection /  $\Delta$ -connection.
- When you set Pr.05-24 as 1, the drive uses the Pr.05-23 setting and current motor frequency and switches the current motor to Y-connection or  $\Delta$ -connection. You can switch the relevant motor parameter settings simultaneously.
- $\square$  Pr.05-25 sets the switch delay time of Y-connection /  $\triangle$ -connection.
- When the output frequency reaches Y-connection /  $\Delta$ -connection switch frequency, the drive delays according to Pr.05-25 before activating the multi-function output terminals.



Y- $\Delta$  connection switch: can be used for wide range motor

Y-connection for low speed: higher torque can be used for rigid tapping

Δ-connection for high speed: higher torque can be used for high-speed drilling



# 05-28 Accumulated Watt-Hour for a Running Motor (W-hour)

Default: Read only

Settings 0.0-999.9

# 05-29 Accumulated Kilowatt-Hour for a Running Motor (kW-hour)

Default: Read only

Settings 0.0-999.9

# **05-30** Accumulated Megawatt-Hour for a Running Motor (MW-hour)

Default: Read only

Settings 0–65535

- Pr.05-28–05-30 record the amount of power consumed by the motors. The accumulation begins when the drive is activated and the record is saved when the drive stops or turns OFF. The amount of consumed watts continues to accumulate when the drive is activated again. To clear the accumulation, set Pr.00-02 as 5 to return the accumulation record to 0.
- The accumulated total watts of the motor per hour = Pr.05-30 × 1000000 + Pr.05-29 × 1000 + Pr.05-28 Wh

#### Chapter 12 Description of Parameter Settings | CFP2000

Example: When Pr.05-30 = 76 MWh and Pr.05-29 = 999.9 kWh, Pr.05-28 = 999.9 Wh (or 0.9999) kWh), the accumulated total kilowatts of the motor per hour = 76 × 1000000 + 999.9 × 1000 + 999.9 = 76000000 + 999900 + 999.9 Wh = 77000899.9 Wh = 77000.8999 kWh Accumulated Motor Operation Time (Minutes) Default: 0 Settings 0-1439 05-32 Accumulated Motor Operation Time (Days) Default: 0 Settings 0-65535 Use Pr.05-31 and Pr.05-32 to record the motor operation time. To clear the operation time, set Pr.05-31 and Pr.05-32 as 00. An operation time shorter than 60 seconds is not recorded. Induction Motor (IM) or Permanent Magnet Synchronous AC Motor (PM) 05-33 Selection Default: 0 Settings 0: IM 1: SPM 2: IPM 3: SynRM (applied to 230V / 460V models) Full-Load Current for a Permanent Magnet Synchronous AC Motor / 05-34 Reluctance Motor Default: Depending on the model power Settings Depending on the model power Sets the full-load current for the motor according to motor's nameplate. The default is 90% of the drive's rated current. For example: The rated current of a 7.5 HP (5.5 kW) is 25 A. The default is 22.5 A. The setting range is between 2.5-30 A.  $(25 \times 10\% = 2.5 \text{ A})$  and  $25 \times 120\% = 30 \text{ A}$ Rated Power for a Permanent Magnet Synchronous AC Motor / Reluctance Motor Default: Depending on the motor power Settings 0.00-655.35 kW Sets the rated power for the permanent magnet synchronous AC motor. The default is the drive's power value. Rated Speed for a Permanent Magnet Synchronous AC Motor / 05-36 Reluctance Motor Default: 2000

Settings

0-65535 rpm

05-37

# Pole Number for a Permanent Magnet Synchronous AC Motor / Reluctance Motor

Default: 10

Settings 0-65535

05-38

# System Inertia for a Permanent Magnet Synchronous AC Motor / Reluctance Motor

Default: Depending on the

motor power

Settings 0.0-6553.5 kg-cm<sup>2</sup>

Default values for standard motors are as below:

Rated Power (kW)	0.4	0.75	1.5	2.2	3.7	5.5	7.5	9.3	11
Rotor Inertia (kg-cm²)	1.2	3.0	6.6	15.8	25.7	49.6	82.0	121.6	177.0

Rated Power (kW)	14.1	18.2	27	33	40	46	54	Above 54
Rotor Inertia (kg-cm²)	211.0	265.0	308.0	527.0	866.0	1082.0	1267.6	1515.0

Default values for high-speed motors are as below:

Rated	Power	Default
HP	kW	Delault
30	22	13.1
40	30	18.0
50	37	42.1
60	45	81.3
75	56	281.5
100	75	327.6

Rated	Power	Default
HP	kW	Delault
120	89	364.5
150	112	404.3
175	130	437.4
215	160	687.4
250	186	1000.0
300	224	1330.0

Rated	Power	Default
HP	kW	Delault
375	279	3330.0
420	313	3700.0
475	354	3848.5
535	399	5106.7

The switching of motor inertia default value between standard motor and high-speed motor is only applicable when Pr.00-11 (Speed Control Mode) = 6: PM Sensorless. In this case, the AC motor drive automatically determines and applies the corresponding motor inertia default value.

05-39

Stator Resistance for a Permanent Magnet Synchronous AC Motor / Reluctance Motor

Default: 0.000

Settings  $0.000-65.535 \Omega$ 

05-40 Permanen

Permanent Magnet Synchronous AC Motor / Reluctance Motor Ld

Default: 0.00

Settings 0.00-655.35 mH

05-41

Permanent Magnet Synchronous AC Motor / Reluctance Motor Lq

Default: 0.00

Settings 0.00-655.35 mH

#### 

Default: 0

	Settings	0-65535 (Unit: V/krpm)	
~ · ·			

- ☐ Ke parameter of a permanent magnet synchronous AC motor (V<sub>phase, rms</sub> / krpm).
- When Pr.05-00 = 5, the induction electromotive force Ke is measured according to the motor's actual operation.
- When Pr.05-00 = 13, the Ke is automatically calculated according to the motor power, current and rotor speed.

#### **06 Protection Parameters**


✓ You can set this parameter during operation.

# Default: Settings 230V models: 150.0–220.0 V<sub>DC</sub> Default:

460V models: 300.0–440.0 V<sub>DC</sub> 360.0 575V models: 420.0–520.0 V<sub>DC</sub> 470.0

- Sets the Low Voltage (Lv) level. When the DC bus voltage is lower than Pr.06-00, an Lv fault is triggered, and the drive stops output and the motor coasts to stop.
- If the Lv fault is triggered during operation, the drive stops output and the motor coasts to stop. There are three Lv faults: LvA (Lv during acceleration), Lvd (Lv during deceleration), and Lvn (Lv in constant speed) that are triggered according to the status of acceleration or deceleration. You must press RESET to clear the Lv fault. The drive automatically restarts if you set to restart after momentary power loss (refer to Pr.07-06 Restart after Momentary Power Loss and Pr.07-07 Allowed Power Loss Duration for details).
- If the Lv fault is triggered when the drive is in STOP status, the drive displays LvS (Lv during stop), which is not recorded, and the drive restarts automatically when the input voltage is higher than Pr.06-00 + Lv return level (as listed below).

Lv Return Level	230V	460V	575V
Frame A–D	30 V <sub>DC</sub>	60 V <sub>DC</sub>	100 V <sub>DC</sub>



#### 

Settings 0: Disabled 230V models: 0.0–450.0 V<sub>DC</sub>

Default:

- Setting Pr.06-01 to 0.0 disables the over-voltage stall prevention function (connected with braking unit or brake resistor). Use this setting when braking units or brake resistors are connected to the drive.
- Setting Pr.06-01 to a value > 0.0 enables the over-voltage stall prevention. This setting refers to the power supply system and loading. If the setting is too low, then over-voltage stall prevention is easily activated, which may increase the deceleration time.

- Related parameters:
  - Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 Deceleration Time 1-4
  - Pr.02-13–Pr.02-15 Multiple-function Output (Relay1–3)
  - Pr.06-02 Selection for Over-voltage Stall Prevention.

### ✓ 06-02 Selection for Stall Prevention

Default: 0

Settings 0: Traditional over-voltage and traditional over-current stall prevention

1: Smart over-voltage and traditional over-current stall prevention

2: Traditional over-voltage and smart over-current stall prevention

3: Smart over-voltage and smart over-current stall prevention

A comparison between traditional stall prevention and smart stall prevention:


Tuna	Over-voltage			Over-current				
Туре	Description	Action	Parameter	Description	Action	Parameter		
Traditional	Frequency maintains during	Deceleration	Pr.06-01	Frequency maintains during acceleration	Acceleration stops	Pr.06-03		
	deceleration stops	stops	P1.00-01	Frequency decreases at constant speed	Frequency gradually decreases	Pr.06-04		
Smart	Frequency increases during acceleration / gradually deceleration / increases		Pr.06-01	Frequency decreases during acceleration / deceleration	Frequency gradually decreases	Pr.06-03		
	deceleration / increases constant speed		Frequency decreases at constant speed	Frequency gradually decreases	Pr.06-04			

- Pr.06-02 (Selection for stall prevention) can be used with Pr.01-49 (Regenerative energy restriction control method), but Pr.06-02 cannot work with Pr.01-44 (Auto-acceleration and auto-deceleration setting).
- When Pr.06-02 or Pr.01-49 is enabled (setting value > 0), Pr.01-44 (Auto-acceleration and auto-deceleration setting) automatically disables (setting value = 0) and cannot be set; when Pr.01-44 is enabled (setting value > 0), Pr.06-02 and Pr.01-49 automatically disable and cannot be set.
- If you use smart over-voltage or smart over-current stall prevention for industries that require fast response, you can decrease the deceleration time when needed.
- When using smart over-voltage stall prevention, the drive decelerates to stop with the fastest deceleration time according to different working condition, rather than the first to fourth deceleration time (Pr.01-13–01-19).
- For 220V / 440V 160 kW models and above, the default for Pr.06-02 is automatically set to 1 (Smart over-voltage and traditional over-current stall prevention). If you need to set the deceleration time with Pr.01-13–01-19, set Pr.06-02 = 0.
- Related parameters:
  - Pr.06-01 Over-voltage stall prevention
  - Pr.06-03 Over-current stall prevention during acceleration
  - Pr.06-04 Over-current stall prevention during operation

- Pr.06-05 Acceleration / deceleration time selection for stall prevention at constant speed
- Pr.01-12-01-19 Acceleration / Deceleration time 1-4
- Pr.02-13-02-15 Multi-function output (Relay 1-3).


#### Traditional over-voltage stall prevention

- Used for uncertain load inertia. When it stops under normal load, the over-voltage does not occur during deceleration and fulfills the deceleration time setting. However, load regenerative inertia may occasionally increase and does not trip due to over-voltage when decelerating to stop. In this case, the drive automatically increases the deceleration time until it stops.
- Because of the motor load inertia, the motor may exceed the synchronous speed when the drive decelerates; in this case, the motor becomes generator. If the motor load inertia is larger, or the setting for drive's decelerating time is too small, the motor regenerates energy to the drive, and makes the DC bus voltage increase to the maximum allowable value. Thus, when traditional over-voltage stall prevention is enabled, the drive does not decelerate further and maintains the output frequency until the voltage drops below the setting value again.
- When the over-voltage stall prevention is enabled, the drive deceleration time is larger than the setting time.
- When there is a problem with the deceleration time, this function is disabled. See below for solution:
  - 1. Increase the deceleration time properly.
  - 2. Install a brake resistor (refer to Section 7-1 Brake Resistors and Brake Units Selection Chart for details) to dissipate the heat, that is, the electrical energy regenerating from the motor.



#### Smart over-voltage stall prevention

Adopts closed-loop control and takes the setting for Pr.06-01 over-voltage stall prevention as target command during acceleration, deceleration and constant speed. When the DC bus voltage is higher than the stall prevention level, the controller increases the output frequency gradually according to closed-loop response until the DC bus voltage drops below the stall prevention level, and returns to target frequency based on the previous setting for deceleration time when the DC bus voltage is lower than the stall prevention level. If the DC bus voltage is still higher than the stall prevention level during the adjustment, the output frequency increases to the maximum operation frequency (Pr.01-00).




#### **Traditional over-current stall prevention**

- When the output current exceeds the over-current stall prevention level (Pr.06-03) during acceleration, the output frequency stops accelerating. The output frequency continues to accelerate when the output current drops below the stall prevention level to protect the drive.
- When the output current exceeds the over-current stall prevention during operation (Pr.06-04), the output frequency decreases according to the setting for acceleration / deceleration time selection for over-current stall prevention at constant speed (Pr.06-05). When the output current drops below the stall prevention level, the output frequency accelerates to the target frequency according to its previous set acceleration time.

#### **Smart over-current stall prevention**

Adopts closed-loop control. It takes the setting for Pr.06-03 over-current stall prevention during acceleration as target command during acceleration and deceleration, and takes Pr.06-04 over-current stall prevention during operation as target command at constant speed. When the output current exceeds the stall prevention level, the controller decreases the output frequency gradually according to the closed-loop response until the current drops below the stall prevention level, and returns to target frequency based on the previous setting when the current is lower than the stall prevention level. If the output current is still higher than the stall prevention level during the adjustment, the output frequency decreases to the minimum output frequency at 0.5 Hz.



# 06-03 Over-Current Stall Prevention during Acceleration

Default: 120

Settings 230V / 460V models:

Light duty: 0-130% (100%: drive's rated current)


Normal duty: 0–160% (100%: drive's rated current)

575V models:


Light duty: 0–125% (100%: drive's rated current)

Normal duty: 0–150% (100%: drive's rated current)

- This parameter only works in VF and SVC control modes.
- If the motor load is too large or the drive's acceleration time is too short, the output current of the drive may be to too high during acceleration, and it may cause motor damage or trigger the drive's protection functions (oL or oc). Use this parameter to prevent these situations.
- During acceleration, the output current of the drive may increase abruptly and exceed the setting value of Pr.06-03. In this case, the drive stops accelerating and keeps the output frequency constant, and then continues to accelerate until the output current decreases.
- The lower limit for the over-current stall prevention is determined by the maximum value among 0.5 Hz, Pr.01-07 and Pr.01-11, and the over-current stall prevention function is effective before the output frequency is higher than the lower limit frequency.



Refer to Pr.06-16 for more details of stall level in flux weakening region. The protection curve is as following:



- When you enable the over-current stall prevention, the drive's acceleration time is longer than the setting.
- When the over-current stall prevention occurs because the motor capacity is too small or operates in the default, decrease the Pr.06-03 setting value.
- When you encounter any problem with the acceleration time, refer to the following guides for troubleshooting:
  - 1. Increase the acceleration time to a proper value.
  - 2. Setting Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting to 1, 3 or 4 (auto-acceleration).
- Related parameters:
  - Pr.01-12, Pr.01-14, Pr.01-16, Pr.01-18 Acceleration Time 1–4
  - Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting
  - Pr.02-13-02-15 Multi-function Output Relay1-3.

# 06-04 Over-current Stall Prevention during Operation

Default: 120


Settings 230V / 460V models:

Light load: 0–130% (100%: drive's rated current) Normal load: 0–160% (100%: drive's rated current)

575V models:

Light load: 0–125% (100%: drive's rated current)
Normal load: 0–150% (100%: drive's rated current)

- This parameter only works in VF and SVC control modes.
- This is a protection for the drive to decrease output frequency automatically when the motor over-loads abruptly during constant motor operation.
- If the output current exceeds the setting value for Pr.06-04 when the drive is operating, the drive decelerates according to the Pr.06-05 setting to prevent the motor from stalling. The lower limit for the over-current stall prevention is determined by the maximum value among 0.5 Hz, Pr.01-07 and Pr.01-11, and the over-current stall prevention function is effective before the output frequency is higher than the lower limit frequency.
- If the output current is lower than the setting value for Pr.06-04, the drive accelerates (according to Pr.06-05) again to the setting frequency.



Over-current stall prevention during operation

# **№** 06-05

# Acceleration / Deceleration Time Selection for Stall Prevention at Constant Speed

Default: 0

Settings 0: By current acceleration / deceleration time

1: By the first acceleration / deceleration time

2: By the second acceleration / deceleration time


3: By the third acceleration / deceleration time

4: By the fourth acceleration / deceleration time


5: By auto-acceleration / auto-deceleration

Sets the acceleration / deceleration time selection when stall prevention occurs at constant speed.

# Over-Torque Detection Selection (OT1) 06-06 Default: 0 Settings 0: No function 1: Continue operation after over-torque detection during constant speed operation 2: Stop after over-torque detection during constant speed operation 3: Continue operation after over-torque detection during RUN 4: Stop after over-torque detection during RUN 06-09 Over-Torque Detection Selection (OT2) Default: 0 Settings 0: No function 1: Continue operation after over-torque detection during constant speed operation 2: Stop after over-torque detection during constant speed operation 3: Continue operation after over-torque detection during RUN 4: Stop after over-torque detection during RUN When you set Pr.06-06 and Pr.06-09 to 1 or 3, a warning message displays, but there is not error record. When you set Pr.06-06 and Pr.06-09 to 2 or 4, an error message displays and there is an error record. 06-07 Over-Torque Detection Level (OT1) Default: 120 Settings 10–200% (100% corresponds to the light-duty rated current of the drive) 06-08 Over-Torque Detection Time (OT1) Default: 0.1 Settings 0.0-60.0 sec. 06-10 Over-Torque Detection Level (OT2) Default: 120 Settinas 10–200% (100% corresponds to the light-duty rated current of the drive) 06-11 Over-Torque Detection Time (OT2) Default: 0.1 Settings 0.0-60.0 sec. When the output current exceeds the over-torque detection level (Pr.06-07 or Pr.06-10) and exceeds the over-torque detection time (Pr.06-08 or Pr.06-11), the over-torque detection follows the setting of Pr.06-06 and Pr.06-09. When you set Pr.06-06 or Pr.06-09 to 1 or 3, an ot1 / ot2 warning displays while the drive keeps running after over-torque detection. The warning remains on until the output current is smaller than 5% of the over-torque detection level.



When you set Pr.06-06 or Pr.06-09 to 2 or 4, an ot1 / ot2 warning displays and the drive stops running after over-torque detection. The drive does not run until you manually reset it.



# ✓ 06-12 Current Limit

Default: 150

Settings 0–200% (100% corresponds to the rated current of the drive)

- Sets the maximum output current of the drive. Use Pr.11-17–Pr.11-20 to set the drive's output current limit. When setting the control mode to PMFOC and SynRM FOC, if the output frequency of the drive reaches this current limit, the output frequency decreases automatically. It works like the current stall prevention.
- This parameter is invalid in VF and SVC control mode.

Market Market 1 (Motor 1)
Market 1 (Motor 1)

M 06-27 Electronic Thermal Relay Selection 2 (Motor 2)

Default: 2

Settings 0: Inverter motor (with external forced cooling)

1: Standard motor (motor with fan on the shaft)

2: Disable

Prevents self-cooled motor from overheating under low speed. Use an electronic thermal relay to limit the drive's output power.


#### Chapter 12 Description of Parameter Settings | CFP2000


- Setting the parameter to 0 is suitable for an inverter motor (motor fan using independent power supply). For this kind of motor, there is no significant correlation between cooling capacity and motor speed. Therefore, the action of electronic thermal relays remains stable in low speed to ensure the load capability of the motor in low speed.
- Setting the parameter to 1 is suitable for standard motor (motor fan is fixed on the rotor shaft). For this kind of motor, the cooling capacity is lower in low speed; therefore, the action of electronic thermal relay reduces the action time to ensure the life of motor.
- When the power is cycled frequently, if the power is switched OFF, the electronic thermal relay protection is reset; therefore, even setting the parameter to 0 or 1 may not protect the motor well. If there are several motors connected to one drive, install an electronic thermal relay in each motor.
- O6-14 Electronic Thermal Relay Action Time 1 (Motor 1)
- ✓ 06-28 Electronic Thermal Relay Action Time 2 (Motor 2)

Default: 60.0

Settings 30.0–600.0 sec.

- Set the parameter to 150% of motor rated current and use with the setting of Pr.06-14 and Pr.06-28 to prevent motor damage due to overheating. When it reaches the setting, the drive displays EoL1 / EoL2, and the motor coasts to stop.
- Use this parameter to set the action time of electronic thermal relay. It works based on the I<sup>2</sup>t characteristic curve of electronic thermal relay, the output frequency and current of the drive, and the operation time to prevent motor from overheating.






Motor cooling curve with independent fan

- The action of electronic thermal relay depends on the setting for Pr.06-13 and Pr.06-27.
  - Pr.06-13 or Pr.06-27 is set to 0 (using inverter motor):
     When the output current of motor drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with independent fan), motor drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14 or 06-28.
  - 2. Pr.06-13 or Pr.06-27 is set to 1 (using standard motor): When the output current of the drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with shaft-fixed fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14 or 06-28
  - 3. If the motor's rated current (Pr.05-01) is not set, set 90% of the drive's rated current (Pr.00-01) as the default for this parameter.

The actual electronic thermal relay action time adjusts according to the drive output current (shown as the motor loading rate %). The action time is short when the current is high, and the action time is long when the current is low. Refer to following diagram: (The motor cooling curve with shaft-fixed fan and motor cooling curve with independent fan F = 50 Hz are the same one.) Operation time



# 7 06-15 Temperature Level Overheat (oH) Warning

Default: 105.0

Settings 0.0-110.0°C

- If Pr.06-15 is set to 110°C, when the temperature reaches 110°C, the drive stops with an IGBT overheat fault.
- For Frame C and above, when IGBT temperature is above Pr.06-15 minus 15°C, the cooling fan enhances performance to 100%; however, when IGBT temperature is below 35°C of Pr.06-15 and the temperature of capacitance is below 10°C of oH2 over-heat warning (Pr.06-51), the cooling fan resets. The temperature 35°C is the criterion if Pr.06-15 is set below to 35°C.

# Stall Prevention Limit Level (Weak Magnetic Area Current Stall Prevention Level)

Default: 50

Settings 0–100% (Refer to Pr.06-03)

- Sets the over-current stall prevention level when the motor's operation frequency is larger than Pr.01-01 (base frequency). This parameter only works during acceleration.
- Example: Pr.06-03 = 150%, Pr.06-04 = 100% and Pr.06-16 = 80%, when the operation frequency is larger than Pr.01-01, the lowest over-current stall prevention level during acceleration is:
  - $Pr.06-03 \times Pr.06-16 = 150 \times 80\% = 120\%$ . (Refer to Pr.06-03 diagram for the protection curve)
- Pr.06-16 is invalid when the over-current stall prevention activates according to Pr.06-04 at constant speed.

<b>06-17</b> Fault Record 1	
<b>06-18</b> Fault Record 2	
<b>06-19</b> Fault Record 3	

<b>06-20</b> Fault Record 4	
06-21 Fault Record 5	
06-22 Fault Record 6	

#### Settings 0: No fault record

- 1: Over-current during acceleration (ocA)
- 2: Over-current during deceleration (ocd)
- 3: Over-current during steady speed (ocn)
- 4: Ground fault (GFF)
- 5: IGBT short-circuit between upper bridge and lower bridge (occ)
- 6: Over-current at stop (ocS)
- 7: Over-voltage during acceleration (ovA)
- 8: Over-voltage during deceleration (ovd)
- 9: Over-voltage at constant speed (ovn)
- 10: Over-voltage at stop (ovS)
- 11: Low-voltage during acceleration (LvA)
- 12: Low-voltage during deceleration (Lvd)
- 13: Low-voltage at constant speed (Lvn)
- 14: Low-voltage at stop (LvS)
- 15: Phase loss protection (OrP)
- 16: IGBT overheating (oH1)
- 17: Heatsink overheating (oH2)
- 18: IGBT temperature detection failure (tH1o)
- 19: Capacitor hardware error (tH2o)
- 21: Over load (oL)
- 22: Electronic thermal relay 1 protection (EoL1)
- 23: Electronic thermal relay 2 protection (EoL2)
- 24: Motor overheating (oH3) (PTC / PT100)
- 26: Over torque 1 (ot1)
- 27: Over torque 2 (ot2)
- 28: Under current (uC)
- 30: EEPROM write error (cF1)
- 31: EEPROM read error (cF2)
- 33: U-phase error (cd1)
- 34: V-phase error (cd2)
- 35: W-phase error (cd3)
- 36: cc (current clamp) hardware error (Hd0)
- 37: oc (over-current) hardware error (Hd1)
- 38: ov (over-voltage) hardware error (Hd2)
- 39: occ hardware error (Hd3)
- 40: Auto-tuning error (AUE)
- 41: PID loss ACI (AFE)

- 48: ACI loss (ACE)
- 49: External fault (EF)
- 50: Emergency stop (EF1)
- 51: External Base Block (bb)
- 52: Enter wrong password three times and locked (Pcod)
- 53: Firmware version error (ccod)
- 54: Illegal command (CE1)
- 55: Illegal data address (CE2)
- 56: Illegal data value (CE3)
- 57: Data is written to read-only address (CE4)
- 58: Modbus transmission time-out (CE10)
- 60: Brake transistor error (bF)
- 61: Y-connection /  $\Delta$ -connection switch error (ydc)
- 63: Over slip error (oSL)
- 64: Electric valve switch error (ryF)
- 68: Reverse direction of the speed feedback (SdRv)
- 69: Over speed rotation feedback (SdOr)
- 70: Large deviation of speed feedback (SdDe)
- 71: Watchdog (WDTT)
- 72: STO loss 1 (STL1)
- 73: Emergency stop for external safety (S1)
- 74: FIRE mode output (Fire)
- 76: Safety Torque Off (STO)
- 77: STO loss 2 (STL2)
- 78: STO loss 3 (STL3)
- 82: Output phase loss U phase (OPHL)
- 83: Output phase loss V phase (OPHL)
- 84: Output phase loss W phase (OPHL)
- 87: Overload protection at low frequency (oL3)
- 89: Rotor position detection error (RoPd)
- 90: Forced to stop (FStp)
- 93: CPU error 0 (TRAP)
- 101: CANopen guarding error (CGdE)
- 102: CANopen heartbeat error (CHbE)
- 104: CANopen bus off error (CbFE)
- 105: CANopen index error (CidE)
- 106: CANopen station address error (CAdE)
- 107: CANopen memory error (CFrE)
- 111: InrCOM time-out error (ictE)
- 112: PM sensorless shaft lock error (SfLK)
- 113: Software over-current (SWOC)
- 142: Auto-tuning error 1 (no feedback current error) (AUE1)

- 143: Auto-tuning error 2 (motor phase loss error) (AUE2)
- 144: Auto-tuning error 3 (no-load current I<sub>0</sub> measuring error) (AUE3)
- 148: Auto-tuning error (leakage inductance Lsigma measuring error) (AUE4)
- The parameters record when the fault occurs and forces a stop.
- When low-voltage at stop fault (LvS) occurs, the fault is not recorded. When low-voltage during operation faults (LvA, Lvd, Lvn) occur, the faults are recorded.
- When dEb function is valid and enabled, the drive executes dEb and records fault code 62 to Pr.06-17–Pr.06-22 simultaneously.

×	06-23	Fault Output Option 1
×	06-24	Fault Output Option 2
×	06-25	Fault Output Option 3
N	06-26	Fault Output Option 4

Default: 0

Settings 0–65535 (Refer to bit table for fault code)

Use these parameters with multi-function output terminal (set Pr.06-23–Pr.06-26 to 35–38) for the specific requirement. When the fault occurs, the corresponding terminals are activated. Convert the binary value to decimal value before you enter the value for Pr.06-23–Pr.06-26).

	Gorivert the binary value to decimal value before you effect the value for 11.00 20 11.00 20.					
bit0	bit1	bit2	bit3	bit4	bit5	bit6
current	Volt.	OL	SYS	FBK	EXI	CE
•						
•						
•						
•						
•						
•						
	•					
	•					
	•					
	•					
	•					
	•					
	•					
	•					
	•					
		•				
		•				
		•				
		•				
		•				
	current	current Volt.	current Volt. OL	current Volt. OL SYS   OL SYS	current Volt. OL SYS FBK	current Volt. OL SYS FBK EXI

Fault Code	bit0	bit1	bit2	bit3	bit4	bit5	bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
22: Electronic thermal relay 1 protection (EoL1)			•				
23: Electronic thermal relay 2 protection (EoL2)			•				
24: Motor overheating (oH3) (PTC / PT100)			•				
26: Over torque 1 (ot1)			•				
27: Over torque 2 (ot2)			•				
28: Under current (uC)	•						
30: EEPROM write error (cF1)				•			
31: EEPROM read error (cF2)				•			
33: U-phase error (cd1)				•			
34: V-phase error (cd2)				•			
35: W-phase error (cd3)				•			
36: cc (current clamp) hardware error (Hd0)				•			
37: oc (over-current) hardware error (Hd1)				•			
38: ov (over-voltage) hardware error (Hd2)				•			
39: occ hardware error (Hd3)				•			
40: Auto-tuning error (AUE)				•			
41: PID loss ACI (AFE)					•		
48: ACI loss (ACE)					•		
49: External fault input (EF)						•	
50: Emergency stop (EF1)						•	
51: External Base Block (bb)						•	
52: Enter wrong password three times and							
locked (Pcod)				•			
53: Firmware version error (ccod)				•			
54: Illegal command (CE1)							•
55: Illegal data address (CE2)							•
56: Illegal data value (CE3)							•
57: Data is written to read-only address (CE4)							•
58: Modbus transmission time-out (CE10)							•
60: Brake transistor error (bF)						•	
61: Y-connection/∆-connection switch error (ydc)						•	
63: Over slip error (oSL)						•	
64: Electric valve switch error (ryF)						•	
68: Reverse direction of the speed feedback					_		
(SdRv)					•		
69: Over speed rotation feedback (SdOr)					•		
70: Large deviation of speed feedback (SdDe)					•		
71: Watchdog (WDTT)				•			
72: STO loss 1 (STL1)				•			
73: Emergency stop for external safety (S1)				•			
74: FIRE mode output (Fire)						•	

Chapter 12 Description of Parameter Settings | CFP2000

Fault Code	bit0	bit1	bit2	bit3	bit4	bit5	bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
76: Safety Torque Off (STO)				•			
77: STO loss 2 (STL2)				•			
78: STO loss 3 (STL3)				•			
82: Output phase loss U phase (OPHL)	•						
83: Output phase loss V phase (OPHL)	•						
84: Output phase loss W phase (OPHL)	•						
87: Overload protection at low frequency (oL3)			•				
89: Rotor position detection error (RoPd)				•			
90: Forced to stop (FStp)				•			
93: CPU error 0 (TRAP)				_			
(applied to 230V/460V models)				•			
101: CANopen guarding error (CGdE)							•
102: CANopen heartbeat error (CHbE)							•
104: CANopen bus off error (CbFE)							•
105: CANopen index error (CidE)							•
106: CANopen station address error (CAdE)							•
107: CANopen memory error (CFrE)							•
111: InrCOM time-out error (ictE)							•
112: PM sensorless shaft lock error (SfLK)					•		
113: Software over-current (SWOC)	•						
142: Auto-tuning error 1 (no feedback current							
error) (AUE1)	•						
143: Auto-tuning error 2 (motor phase loss error)							
(AUE2)							
144: Auto-tuning error 3 (no-load current I <sub>0</sub>							
measuring error) (AUE3)							
148: Auto-tuning error 4 (leakage inductance							
Lsigma measuring error) (AUE4)							1

# O6-29 PTC Detection Selection / PT100 Motion

Default: 0

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: No warning

Sets the operation mode of a drive after detecting PTC / PT100.

06-30 PTC Level	
	Default: 50.0
Settings 0.0–100.0%	
Sets AVI1 / ACI / AVI2 analog input function Pr.03-00-03-02 to	- , , ,
Use this to set the PTC level, the corresponding value for 100%	is the analog input maximum
value.	
<b>06-31</b> Frequency Command at Malfunction	
	Default: Read only
Settings 0.00–599.00 Hz	
When a malfunction occurs, check the current frequency comm	and. If it happens again, it
overwrites the previous record.	
<b>06-32</b> Output Frequency at Malfunction	
	Default: Read only
Settings 0.00–599.00 Hz	
When a malfunction occurs, check the current output frequency	/. If it happens again, it overwrites
the previous record.	
06-33 Output Voltage at Malfunction	
	Default: Read only
Settings 0.0–6553.5 V	
When a malfunction occurs, check the current output voltage. I	f it happens again, it overwrites
the previous record.	
06-34 DC bus Voltage at Malfunction	
	Default: Read only
Settings 0.0–6553.5 V	
When a malfunction occurs, check the current DC bus voltage.	If it happens again, it overwrites
the previous record.	
06-35 Output Current at Malfunction	
	Default: Read only
Settings 0.0–6553.5 Amp	
When a malfunction occurs, check the current output current. If	it happens again, it overwrites
the previous record.	
<b>06-36</b> IGBT Temperature at Malfunction	
	Default: Read only
Settings -3276.7-3276.7°C	
When a malfunction occurs, check the current IGRT temperature	re. If it hannens again, it

overwrites the previous record.

# Capacitance Temperature at Malfunction 06-37 Default: Read only Settings -3276.7-3276.7°C When a malfunction occurs, check the current capacitance temperature. If it happens again, it overwrites the previous record. 06-38 Motor Speed at Malfunction Default: Read only Settings -32767-32767 rpm When a malfunction occurs, check the current motor speed in rpm. If it happens again, it overwrites the previous record. 06-40 Status of the Multi-Function Input Terminal at Malfunction Default: Read only Settings 0000h-FFFFh Status of the Multi-Function Output Terminal at Malfunction 06-41 Default: Read only 0000h-FFFFh Settings When a malfunction occurs, check the current status of multi-function input / output terminals. If it happens again, it overwrites the previous record. Drive Status at Malfunction 06-42 Default: Read only Settings 0000h-FFFFh When a malfunction occurs, check the current drive status (communication address 2101H). If it happens again, it overwrites the previous record. 06-44 STO Latch Selection Default: 0 0: STO Latch Settings 1: STO No latch Pr.06-44 = 0: STO Alarm Latch. After you clear the cause of the STO Alarm, use a Reset command to clear the STO Alarm. 🚇 Pr.06-44 = 1: STO Alarm no Latch. After you clear the cause of the STO Alarm, the STO Alarm clears automatically. All of STL1-STL3 errors are Alarm Latch mode (in STL1-STL3 mode, the Pr.06-44 function is not available). 06-45 Output Phase Loss Detection Action (OPHL) Default: 3 Settings 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning The OPHL protection is enabled when Pr.06-45 is not set to 3.

06-46 Detection Time for Output Phase Loss

Default: 0.500

Settings 0.000-65.535 sec.

M 06-47 Current Detection Level for Output Phase Loss

Default: 1.00


Settings 0.00-100.00%

06-48 DC Brake Time for Output Phase Loss

Default: 0.000


Settings 0.000-65.535 sec.

- There are two situations for the output phase loss detection: "detect when the drive is in operation" and "detect before operation". Setting Pr.06-48 to 0 disables the OPHL detection function before operation.
- The status of output phase loss detection are as following:
  - Status 1: The drive is in operation
     When any phase current is less than the Pr.06-47 setting, and exceeds Pr.06-46 setting time, the drive executes according to the Pr.06-45 setting.




Status 2: The drive is in STOP; Pr.06-48 = 0; Pr.07-02 ≠ 0

After the drive starts, the DC brake operates according to Pr.07-01 and Pr.07-02. During this period, OPHL detection is not active. After the DC brake action is completed, the drive starts to run, and enables the OPHL protection as mentioned above for status 1.




Status 3: The drive is in STOP; Pr.06-48  $\neq$  0; Pr.07-02  $\neq$  0 When the drive starts, it executes Pr.06-48 first, and then executes Pr.07-02 (DC brake). The DC brake current level in this state includes two parts: one is 20 times the Pr.06-47 setting value in Pr.06-48 setting time; the other is the Pr.07-02 setting value in Pr.07-01 setting time. The total DC brake time is T = Pr.06-48 + Pr.07-02.

Status 3-1: Pr.06-48  $\neq$  0, Pr.07-02  $\neq$  0 (No OPHL detected before operation)




Status 3-2:  $Pr.06-48 \neq 0$ ,  $Pr.07-20 \neq 0$  (OPHL detected before operation) In this period, if an OPHL occurs within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.




Status 4: The drive is in STOP; Pr.06-48 ≠ 0; Pr.07-02 = 0
 When the drive starts, it executes Pr.06-48 as the DC brake. The DC brake current level is 20 times the Pr.06-47 setting value.

Status 4-1:  $Pr.06-48 \neq 0$ , Pr.07-02 = 0 (No OPHL detected before operation)



Status 4-2: Pr.06-48 ≠ 0, Pr.07-02 = 0 (OPHL detected before operation)

In this period, if an OPHL occurs within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.





#### 7 06-50 Time for Input Phase Loss Detection

Default: 0.20

Settings 0.00-600.00 sec.

Sets the time for input phase loss detection; setting 0.20 seconds means to check every 0.20 sec.

#### N 06-52 Ripple of Input Phase Loss

Default: 30.0 / 60.0 / 75.0

Settings 230V models: 0.0-160.0 V<sub>DC</sub>

460V models:  $0.0-320.0 \text{ V}_{DC}$ 575V models:  $0.0-400.0 \text{ V}_{DC}$ 

#### 

Default: 0

Settings 0: Fault and ramp to stop
1: Fault and coast to stop

- When the DC bus ripple voltage lasts for Pr.06-50 ripple time, the drive activates the Input Phase Loss protection according to the Pr.06-53 settings:
  - DC bus ripple frequency ≤ 166 Hz
  - The amplitude is higher than Pr.06-52 setting [default 30V (230V models), 60 V (460V models)]. It starts to count time after 20 consecutive times.
  - When the counting lasts for the following time conditions, an ORP occurs.
     (I)% is rated current percentage

(I)%	Actual Seconds
50	432
75	225
120	60

When any of the above condition is not met, the ORP protection recalculates.

#### N 06-55 Derating Protection

Default: 0

Settings 0: Auto-decrease carrier frequency and limit output current

1: Constant carrier frequency and limit output current

2: Auto-decrease carrier frequency

- Refer to Pr.00-01 (Maximum Operation Frequency) for allowable maximum output frequency in each control mode.
- The corresponded carrier frequency lower limit under each control mode:
  - VF, SVC: 599 Hz, 6K
  - FOC sensorless (IM): 300 Hz, 6K
  - FOC sensorless (PM): 500 Hz, 10K
- Refer to Section 9-6 Derating for Ambient Temperature, Altitude and Carrier Frequency for the derating ratio.

#### Setting 0:

- Actual over-current stall prevention level = derating ratio × over-current stall prevention level (Pr.06-03 and Pr.06-04).
- Rated current derating level: derating ratio × rated current (Pr.00-01).
- When the operating point is greater than the derating curve, the rated current is constant, and carrier frequency (Fc) output by the drive decreases automatically according to the ambient temperature, overload output current and time.
- Applicable conditions: If overloads are not frequent, the concern is only about the carrier frequency operating with the rated current for a long time, and changes to the carrier wave due to short overload are acceptable, set to 0.
- Take VFD007FP4EA-52 in Normal Duty for example: ambient temperature 50°C, UL Open Type, and independent installation. When the carrier frequency is set to 15 kHz, it corresponds to 72% of the derating ratio. When the output current is higher than the value, it automatically decreases the carrier frequency according to the ambient temperature, output current and overload time (for example, set Pr.06-03 to 200%). At this time, the over-current stall prevention level is 144% (= 72% × 200%) of the rated current (Pr.00-01).

#### Setting 1:

- When the operating point is greater than the derating curve 1, the carrier frequency (Fc) output by the drive is fixed to the default value.
- Applicable conditions: Select this mode if the change of carrier frequency and motor noise caused by ambient temperature and frequent overload are not acceptable. Refer to Pr.00-17.
- Take VFD007FP4EA-52 in Normal Duty for example: ambient temperature 50°C, UL Open Type, and independent installation. When the carrier frequency maintains at 15 kHz, it corresponds to 72% of the derating ratio. The oL protection executes when the current is 120% × 72% = 86% for one minute; therefore, it must operate by the curve to keep the carrier frequency.

#### Setting 2:

- The protection method and action are set to 0, but this disables the current limit when output current is the derating ratio × 160% of output current in normal load, and derating ratio × 130% of output current in light load.
- The advantage is that it can provide a higher starting output current (Pr.06-55 = 0) when the carrier frequency (Pr.00-17) setting is higher than the default value. The disadvantage is that the carrier frequency derates easily when it overloads.
  - For example, when Pr.06-55 = 0 or 1, the over-current stall prevention level = Ratio × Pr.06-03. When Pr.06-55 = 2, the over-current stall prevention level = Pr.06-03.
- Use with the settings for Pr.00-16 and Pr.00-17.

**06-56** PT100 Voltage Level 1

Default: 5.000

Settings 0.000-10.000 V

M 06-57 PT100 Voltage Level 2

Default: 7.000

Settings 0.000-10.000 V

Condition settings: PT100 voltage level Pr.06-57 > Pr.06-56.

O6-58 PT100 Level 1 Frequency Protection

Default: 0.00


Settings 0.00–599.00 Hz

O6-59 PT100 Activation Level 1 Protection Frequency Delay Time

Default: 60

Settings 0-6000 sec.

- PT100 operation instructions:
  - (1) Use voltage type analog input (AVI1, AVI2 and ACI voltage 0–10V) and select PT100 mode.
  - (2) Select one of the voltage type analog inputs below:
    - (a) AVI1(Pr.03-00 = 11)
    - (b) AVI2 (Pr.03-02 = 11)
    - (c) ACI (Pr.03-01 = 11 and Pr.03-29 = 1).
  - (3) When selecting Pr.03-01 = 11 and Pr.03-29 = 1, you must switch SW4 to 0–10 V for the external I/O board.
  - (4) The AFM2 outputs constant voltage or current, then Pr.03-23 = 23. You must switch AFM2 SW2 to 0–20 mA for the external I/O board, and set AFM2 output level to 45% (Pr.03-33 = 45%) of 20 mA = 9 mA.
  - (5) Use Pr.03-33 to adjust the constant voltage or constant current of the AFM2 output; the setting range is 0–100.00%.
  - (6) There are two types of action levels for PT100. The diagram below shows the PT100 protecting action:



#### (7) PT100 wiring diagram:




Figure 1

When Pr.06-58 = 0.00 Hz, PT100 function is disabled.

#### Case:

When using PT100, if the motor temperature is higher than 135°C (275°F), the drive starts to count the delay time for auto-deceleration (Pr.06-59). The drive decreases the motor frequency to the setting for Pr.06-58 when it reaches the delay time count value. The drive operates at the frequency set for Pr.06-58 until the motor temperature is lower than 135°C (275°F). If the motor temperature is higher than 150°C (302°F), the drive automatically decelerates to STOP and displays the warning oH3.

#### Set up process:

- 1. Switch AFM2 to 0–20 mA on the I/O control terminal block. (Refer to Figure 1, PT100 wiring diagram)
- 2. Wiring (Refer to Figure 1, PT100 wiring diagram):

Connect external terminal AFM2 to "+"

Connect external terminal ACM to "-"

Connect external terminals AFM2 and AVI1 to "short circuit"

- 3. Set Pr.03-00 = 11 or Pr.03-23 = 23 or Pr.03-33 = 45% (9 mA).
- 4. Refer to the RTD temperature and resistance comparison table Temperature = 135°C, resistance = 151.71  $\Omega$ ; input current: 9 mA, voltage: about 1.37  $V_{DC}$  Temperature = 150°C, resistance = 157.33  $\Omega$ ; input current: 9 mA, voltage: about 1.42  $V_{DC}$
- 5. When the RTD temperature is > 135°C, the drive decelerates to the specified operation frequency automatically. Then, Pr.06-56 = 1.37 and Pr.06-58 = 10 Hz. (When Pr.06-58 = 0, it disables the specified operation frequency.)
- 6. When the RTD temperature is > 150°C, the drive outputs a fault, decelerates to STOP, and displays the warning oH3. Then, Pr.06-57 = 1.42 V and Pr.06-29 = 1 (fault and ramp to stop).

#### ✓ 06-60 Software Detection GFF Current Level

Default: 60.0

Settings 0.0–6553.5% (100% corresponds to the light-load rated current of the drive)

#### ✓ 06-61 Software Detection GFF Filter Time

Default: 0.10

Settings 0.00-655.35 sec.

When the drive detects that the unbalanced three-phase output current is higher than the setting for Pr.06-60, GFF protection activates. The drive then stops output.

06-63	Operation Time of Fault Record 1 (Day)
06-65	Operation Time of Fault Record 2 (Day)
06-67	Operation Time of Fault Record 3 (Day)
06-69	Operation Time of Fault Record 4 (Day)

Default: Read only

Settings 0-65535 days

06-64	Operation Time of Fault Record 1 (Minutes)
06-66	Operation Time of Fault Record 2 (Minutes)
06-68	Operation Time of Fault Record 3 (Minutes)
06-70	Operation Time of Fault Record 4 (Minutes)

Default: Read only

Settings 0-1439 min

If there is any malfunctions when the drive operates, Pr.06-17–Pr.16-22 record the malfunctions and Pr.06-63–Pr.06-70 record the operation time for four sequential malfunctions. Check if there is any problem with the drive according to the interval of the recorded fault.

Example:

The first error: ocA occurs after motor drive operates for 1000 minutes.

The second error: ocd occurs after another 1000 minutes.

The third error: ocn occurs after another 1000 minutes.

The fourth error: ocA occurs after another 1000 minutes.

The fifth error: ocd occurs after another 1000 minutes.

The sixth error: ocn occurs after 1000 minutes.

Then Pr.06-17–Pr.06-22 and Pr.06-63–Pr.06-70 are recorded as follows:

	1 <sup>st</sup> fault	2 <sup>nd</sup> fault	3 <sup>rd</sup> fault	4 <sup>th</sup> fault	5 <sup>th</sup> fault	6 <sup>th</sup> fault
Pr.06-17	ocA	ocd	ocn	ocA	ocd	ocn
Pr.06-18	0	ocA	ocd	ocn	ocA	ocd
Pr.06-19	0	0	ocA	ocd	ocn	ocA
Pr.06-20	0	0	0	ocA	ocd	ocn
Pr.06-21	0	0	0	0	ocA	ocd
Pr.06-22	0	0	0	0	0	ocA
Pr.06-63	0	1	2	2	3	4
Pr.06-64	1000	560	120	1120	680	240
Pr.06-65	0	0	1	2	2	3
Pr.06-66	0	1000	560	120	1120	680
Pr.06-67	0	0	0	1	2	2
Pr.06-68	0	0	1000	560	120	1120
Pr.06-69	0	0	0	0	1	2
Pr.06-70	0	0	0	1000	560	120

**NOTE:** By examining the time record, you can see that the last fault (Pr.06-17) happened after the drive ran for 4 days and 240 minutes.

#### ✓ 06-71 Low Current Setting Level

Default: 0.0

Settings 0.0-100.0% (100% corresponds to the light-load rated current of the drive)

#### Modern Market Market

Default: 0.00

Settings 0.00-360.00 sec.

#### **06-73** Low Current Action

Default: 0

Settings 0: No function

1: Fault and coast to stop

2: Fault and ramp to stop by the second deceleration time

3: Warn and operation continue

- The drive operates according to the setting for Pr.06-73 when the output current is lower than the setting for Pr.06-71, and when the time of the low current exceeds the detection time for Pr.06-72. Use this parameter with the external multi-function output terminal 44 (for low current output).
- The low current detection function does not execute when the drive is in sleep or standby status.
- Sets Pr.06-71 low current level according to the drive's rated current, the equation is Pr.00-01 (drive's rated current) × Pr.06-71 (low current setting level)% = low current detection level (A). The drive changes the setting for Pr.00-01 (rated current) according to the setting for Pr.00-16 (load selection).

#### ✓ 06-76 dEb Motion Offset

		Default:	
Settings	230V models: 0.0–200.0 V <sub>DC</sub>	20.0	
	460V models: 0.0–200.0 V <sub>DC</sub>	40.0	
	575V models: 0.0–200.0 V <sub>DC</sub>	50.0	

#### 06-80 Fire Mode

Default: 0.00

Settings 0: Disable

1: Forward (counter clockwise) operation

2: Reverse (clockwise) operation

- Use this parameter with multi-function input terminal setting 58 or 59, and multi-function output terminal setting 53 or 54.
  - 0: Fire detection is invalid.
  - 1: The motor operates in a counterclockwise direction (U, V, W).
  - 2: The motor operates in a clockwise direction (U, W, V).
- The warranty will be void if Fire Mode is activated.

#### ✓ 06-81 Operating Frequency when running Fire Mode

Default: 60.00

Settings 0.00-599.00 Hz

Enables fire mode (Pr.06-80 = 1 or 2) and sets the operation frequency in fire mode (Pr.06-81). The drive operates with operation frequency in fire mode when the fire mode is enabled. Refer to Pr.06-86 Fire mode operating sequence for details.

#### 06-82 Enable Bypass in Fire Mode

Default: 0

Settings 0: Disable Bypass

1: Enable Bypass

- The Bypass function only enables in Fire mode.
- When the Bypass function enables and the fault listed in Table 1 occurs, the drive automatically switches to mains power for the motor's operation.

#### 

Default: 0.0

Settings 0.0-6550.0 sec.

- Conditions to enable the Bypass function (Pr.06-82 = 1):
  - (1) When a fault that can enable the Bypass function (as shown in Table 1) occurs in Fire mode, and the fire alarm lasts for Pr.06-83 setting time, the Bypass function enables and the Bypass fire mode indication (MOx = 54) is ON.
  - (2) When a fault that can be reset (as shown in Table 1) occurs in Fire mode, the automatic reset time is zero, and the fire alarm lasts for Pr.06-83 setting time, then the Bypass function enables and the Bypass fire mode indication (MOx = 54) is ON. If the fault is successfully reset (no fault) before the Bypass function enabled, the counter of bypass delay time returns to zero and waits for the next trigger.




Table 1: Fault detection under Normal mode, Fire mode and Bypass function in Fire mode. (V means detectable)

				E. L. D
Code	Fault name	Normal Mode	Fire Mode	Enable Bypass Function
1	Over-current during acceleration (ocA)	V(RS)	V(able to auto-reset)	V
2	Over-current during deceleration (ocd)	V(RS)	V(able to auto-reset)	V
3	Over-current during steady speed (ocn)	V(RS)	V(able to auto-reset)	V
4	Ground Fault (GFF)	V	V(able to auto-reset)	V
5	IGBT short-circuit between upper bridge and lower bridge (occ)	V(RS)	V(able to auto-reset)	V
6	Over-current at stop (ocS)	V(RS)	V(able to auto-reset)	V
7	Over-voltage during acceleration (ovA)	V(RS)	V(able to auto-reset)	V
8	Over-voltage during deceleration (ovd)	V(RS)	V(able to auto-reset)	V
9	Over-voltage at constant speed (ovn)	V(RS)	V(able to auto-reset)	V
10	Over-voltage at stop (ovS)	V(RS)	V(able to auto-reset)	V
11	Low-voltage during acceleration (LvA)	V	Not-detectable	Not-detectable
12	Low-voltage during deceleration (Lvd)	V	Not-detectable	Not-detectable
13	Low-voltage at constant speed (Lvn)	V	Not-detectable	Not-detectable
14	Low-voltage at Stop (LvS)	V	Not-detectable	Not-detectable
15	Phase loss protection (OrP)	V	V(able to auto-reset)	V
16	IGBT overheating (oH1)	V	V(able to auto-reset)	V
17	Heatsink overheating (oH2)	V	V(able to auto-reset)	V
18	IGBT temperature detection failure (tH1o)	V	V(able to auto-reset)	V
19	Capacitor hardware error (tH2o)	V	V(able to auto-reset)	V
21	Over load (oL) (150% 1Min, Inverter)	V	Not-detectable	Not-detectable
22	Electronic thermal relay 1 protection (EoL1)	V	Not-detectable	Not-detectable
23	Electronic thermal relay 2 protection (EoL2)	V	Not-detectable	Not-detectable
24	Motor overheating (oH3) (PTC / PT100)	V	V(able to auto-reset)	V
26	Over torque 1 (ot1)	V	Not-detectable	Not-detectable
27	Over torque 2 (ot2)	V	Not-detectable	Not-detectable
28	Under current (uC)	V	Not-detectable	Not-detectable
30	EEPROM write error (cF1)	V	Not-detectable	Not-detectable
31	EEPROM read error (cF2)	V	V	Not-detectable
33	U-phase error (cd1)	V	V	Not-detectable
34	V-phase error (cd2)	V	V	Not-detectable
35	W-phase error (cd3)	V	V	Not-detectable
36	cc (current clamp) hardware error (Hd0)	V	V	Not-detectable
37	oc (over-current) hardware error (Hd1)	V	V	Not-detectable
38	ov (over-voltage) hardware error (Hd2)	V	V	Not-detectable
39	occ hardware error (Hd3)	V	V	Not-detectable
40	Auto-tuning error (AUE)	V	Not-detectable	Not-detectable

Code	Fault name	Normal Mode	Fire Mode	Enable Bypass Function
41	PID loss ACI (AFE)	V	Not-detectable	Not-detectable
48	ACI loss (ACE)	V	Not-detectable	Not-detectable
49	External fault (EF)	V	Not-detectable	Not-detectable
50	Emergency stop (EF1)	V	Not-detectable	Not-detectable
51	External base block (bb)	V	Not-detectable	Not-detectable
52	Enter wrong password three times and locked (Pcod)	V	Not-detectable	Not-detectable
53	Firmware version error (ccod)	V	V	Not-detectable
54	Illegal command (CE1)	V	Not-detectable	Not-detectable
55	Illegal data address (CE2)	V	Not-detectable	Not-detectable
56	Illegal data value (CE3)	V	Not-detectable	Not-detectable
57	Data is written to read-only address (CE4)	V	Not-detectable	Not-detectable
58	Modbus transmission time-out (CE10)	V	Not-detectable	Not-detectable
60	Braking transistor error (bF)	V	Not-detectable	Not-detectable
61	Y-connection / △-connection switch error (ydc)	V	Not-detectable	Not-detectable
63	Over slip error (oSL)	V	Not-detectable	Not-detectable
64	Electric valve switch error (ryF)	V	Not-detectable	Not-detectable
68	Reverse direction of the speed feedback (SdRv)	٧	Not-detectable	Not-detectable
69	Over speed rotation feedback (SdOr)	V	Not-detectable	Not-detectable
70	Large deviation of speed feedback (SdDe)	V	Not-detectable	Not-detectable
71	Watchdog (WDTT)	Not detectable	Not-detectable	Not-detectable
72	STO loss 1 (STL1)	V	V	Not-detectable
73	Emergency stop for external safety (S1)	V	V	Not-detectable
74	Fire mode output (Fire)	V	V (keeps operating)	V (keeps operating)
76	Safety Torque Off (STO)	V	V	Not-detectable
77	STO loss 2 (STL2)	V	V	Not-detectable
78	STO loss 3 (STL3)	V	V	Not-detectable
82	Output phase loss U-phase (OPHL)	V	V(able to auto-reset)	V
83	Output phase loss V-phase (OPHL)	V	V(able to auto-reset)	V
84	Output phase loss W-phase (OPHL)	V	V(able to auto-reset)	V
87	Overload protection at low frequency (oL3)	V	Not-detectable	Not-detectable
89	Rotor position detection error (RoPd)	V	V	V
90	Forced to stop (FStp)	V	Not-detectable	Not-detectable
93	CPU error 0 (TRAP)	V	Not-detectable	Not-detectable
101	CANopen guarding error (CGdE)	V	Not-detectable	Not-detectable

Code	Fault name	Normal Mode	Fire Mode	Enable Bypass Function	
102	CANopen heartbeat error (CHbE)	V	Not-detectable	Not-detectable	
104	CANopen bus off error (CbFE)	V	Not-detectable	Not-detectable	
105	CANopen index error (CidE)	V	Not-detectable	Not-detectable	
106	CANopen station address error (CAdE)	V	Not-detectable	Not-detectable	
107	CANopen memory error (CFrE)	V	Not-detectable	Not-detectable	
111	InrCOM time-out error (ictE)	V	Not-detectable	Not-detectable	
112	PM sensorless shaft lock error (SfLK)	V	Not-detectable	Not-detectable	
113	Software over-current (SWOC)	V	V (able to auto-reset)	V	
142	Auto-tuning error 1 (no feedback current	Not	Not-detectable	Not dotostable	
142	error) (AUE1)	detectable	Not-detectable	Not-detectable	
143	Auto-tuning error 2 (motor phase loss error)	Not	Not-detectable	Not detected	
143	(AUE2)	detectable	Not-detectable	Not-detectable	
144	Auto-tuning error 3 (no-load current lo	Not	Not-detectable	Not detectable	
144	measuring error) (AUE3)	detectable	Not-detectable	Not-detectable	
148	Auto-tuning error 4 (leakage inductance	Not	Not-detectable	Not-detectable	
148	Lsigma measuring error) (AUE4)	detectable	Not-detectable	inot-detectable	

#### ✓ 06-84 Number of Times of Reset in Fire Mode

Default: 0

Settings 0–10

- When a fault occurs in fire mode, the drive attempts resetting the fault to prevent entering bypass mode. Use Pr.06-84 and Pr.06-85 to set this function.
- When this function is disabled (Pr.06-84 = 0) and a fault that listed in Table 1 occurs, the drive enters bypass mode (Pr.06-82 = 1, bypass function is enabled).

Example: If Pr.06-83 = 3, the drive attempts to reset the fault for three times at most. When the fourth fault occurs in the setting time for Pr.06-85, the drive will no longer attempt to reset the fault, and directly goes into Bypass mode after the setting delay time for Pr.06-83.

#### ✓ 06-85 Length of Time of Reset in Fire Mode

Default: 60.0

Settings 0.0–6000.0 sec.

The settings for Pr.06-82 to Pr.06-85 determine whether to switch the motor operation to mains power when in fire mode.

#### 06-86 Fire Mode Motion

Default: 0

Settings bit0: 0 = Open Loop; 1 = Close Loop (PID control)

bit1: 0 = Manual reset fire mode: 1 = Auto reset fire mode


0: Open loop control and manual reset fire mode

1: Close loop control and manual reset fire mode

2: Open loop control and auto reset fire mode

3: Close loop control and auto reset fire mode

The sequence of Fire mode operation is as the diagram below. Choose the operation mode [open-loop control or close-loop control (PID control)] according to the setting for Pr.06-86.



#### The Fire mode operating procedure:

#### • Pr.06-86 bit0 = 0:

When setting Pr.06-80 = 1 or 2, and the multi-functional input terminals MIx = 58 is ON, the drive enables the fire mode operation. The drive accelerates to the setting frequency for Pr.06-81, and the keypad KPC-CC01 displays a "Fire" warning. The drive outputs a RUN command for the fire mode when the multi-function output terminal MOx is set to 53. If you set Pr.06-82=1 to enable the Bypass function and the condition is established, the MOx = 54 Bypass fire mode indicates action and switches the motor power to the mains power, then the drive stops.

#### • Pr.06-86 bit0 = 1:

When setting the Pr.06-80 = 1 or 2, and the multi-functional input terminals MIx = 58 is ON, the drive enables the fire mode operation. The drive runs PID control with Pr.06-87 as PID set point, and the keypad KPC-CC01 displays a Fire warning. The drive outputs a RUN

command for the fire mode when the multi-function output terminal MOx is set to 53. If you set Pr.06-82 = 1 to enable the Bypass function and the condition is established, the MOx = 54 Bypass fire mode indicates action and switches the motor power to the mains power, then the drive stops.

• If an error occurs to the PID feedback signal, the drive switches to the open-loop control and runs according to the setting frequency for Pr.06-81.

#### Fire Mode PID Set Point Default: 0.00 Settings 0.00-100.00% Sets the PID target value in Fire mode. 06-88 Software Over-Current Level Default: 0.00 Settings Depending on the models The software over-current protection function is used to restrict abnormal current; it only applies to synchronous motors. The response time of existing output phase loss protection and ot1 protection are not fast enough. In actual applications, this could result in a large uncontrolled output current if the output wiring breaks, which may potentially demagnetize the motor. If the current in any phase exceeds the set level, the SWOC protection will be activated. When the level is set to 0, this function is disabled. LvS Low Voltage Error Enable 06-89 Default: 0


1: LvS always not detect

2: Lvs not detect only for the first power on

Pr.06-89 determines whether to detect the low voltage error (LvS) at stop.


#### The Fire mode reset procedure

When the terminal MIx = 58 changes from ON to OFF, the drive starts to run "fire mode reset procedure", and determines whether to "Manual reset" or "Auto reset" fire mode according to the selection of Pr.06-86 bit1.



#### **Wiring Diagram**

- 1. When AC power is ON, RB1 and RC1 are ON, and RA1 and RC1 are OFF.
- 2. When operating in fire mode and bypass indication function is disabled, RB1 and RC1 are ON, and the motor is driven by the drive.
- 3. When operating in fire mode and bypass indication function is enabled, RA1 and RC1 are ON, and the motor runs under mains electricity.



	•
Ор	eration Method of each Function / Command under Fire Mode
	When in fire mode, the running direction of the drive is based on Pr.06-80 = 1 (Forward /
	Counter clockwise operation) or Pr.06-80 = 2 (Reverse / Clockwise operation). Other running
	direction commands are invalid and Pr.00-23 Motor Operating Direction is not available when in
	fire mode.
	When in fire mode, all keypad command are ignored, including RUN, STOP, JOG and direction
	commands.
	When in fire mode, all RS-485 communication commands are ignored, including RUN, STOP,
	JOG and direction commands.
	When in fire mode, B.B. and EF are not activated, including external terminal B.B,
	communication B.B, external terminal EF, communication EF and external terminal EF1). Any
	activated B.B. is automatically invalid, including external terminal B.B. and communication B.B.,
	and the drive executes speed tracking.
	When in fire mode, activated EF and EF1 are automatically invalid, including external terminals
	EF & EF1 and communication EF).
	When in fire mode, the JOG command is not available (JOG command source: keypad, external
	terminals and communications). Any operating JOG command is automatically invalid.
	When in fire mode, the Acceleration / Deceleration Speed Inhibit function is not available. Any
	activated acceleration / deceleration speed inhibition is automatically invalid.
	When in fire mode, If you set $Pr.06-86$ to $bit0 = 0$ (open-loop control), the drive does not execute
	parameter group 08 PID function. Any operating PID function is automatically invalid.
	When in fire mode, the Hand-Off-Auto function is not available, including multi-function output
	terminals.
	When in fire mode, the drive does not execute the circulative control function, and all circulating
	control function parameters are cleared. The circulative control function is automatically invalid
	when in fire mode.
	When in fire mode, the drive does not execute the sleep function.
	When in fire mode, the drive does not execute the DC brake function. Any operating DC brake is
	automatically invalid when in fire mode.
	When in fire mode, the drive does not execute over-current stall prevention function. Any
	operating over-current stall prevention is automatically invalid when in fire mode.
	When in fire mode, over-torque detection function is not available.
	When in fire mode, oL1 / oL2 detection function is not available.
	(,,,,,,,,,,,,
	available.
	, , , , , , , , , , , , , , , , , , , ,
	errors cannot be cleared when in fire mode. The drive does not operate when in fire mode.
	Lv protection is not activated when in fire mode, so the drive keeps running or runs until the

☐ If bypass fire mode indication (MOx = 54) is activated, reboot the drive and deactivate the fire

the drive.

mode to turn off this terminal output.

power is lost. If the Lv error occurs before the fire mode warning, clear the Lv error to operate

# Chapter 12 Description of Parameter Settings | CFP2000 When in fire mode, the output stop function is not available. When in fire mode, the skip frequency function is not available. When in fire mode, the operating frequency for Pr.06-81 cannot be larger than Pr.01-00 Maximum Output Frequency. If Pr.06-81 > Pr.01-00, the maximum frequency is automatically set

to Pr.01-00.

#### **07 Special Parameters**

The following are abbreviations for different types of motors:

- IM: Induction motor
- PM: Permanent magnet synchronous AC motor
- IPM: Interior permanent magnet synchronous AC motor
- SPM: Surface permanent magnet synchronous AC motor
- SynRM: Synchronous reluctance motor

✓ You can set this parameter during operation.

895.0

## Default: Settings 230V models: 350.0–450.0 V<sub>DC</sub> 370.0 460V models: 700.0–900.0 V<sub>DC</sub> 740.0

575V models: 850.0-1116.0 V<sub>DC</sub>

- Sets the DC bus voltage at which the brake chopper is activated. Choose a suitable brake resistor to achieve the best deceleration. Refer to Chapter 7 Optional Accessories for information about brake resistors.
- This parameter is only valid for the models below 22 kW of 230V models and 30 kW of 460V series.

#### ✓ 07-01 DC Brake Current Level

Default: 0

Settings 0–100%

- 100% corresponds to the rated current of the drive (Pr.00-01).
- Sets the level of the DC brake current output to the motor at start-up and stop. It is recommended that you start with a low DC brake current level and then increase until you reach the proper holding torque. However, the DC brake current cannot exceed the motor's rated current to prevent the motor from burnout. Do NOT use the DC brake for mechanical retention, otherwise, injury or accident may occur.
- The PM has the magnetic field itself, using the DC brake may possibly cause the motor run in a reverse direction, therefore, it is not recommended to use DC brake for PM.

#### M 07-02 DC Brake Time at Start-up

Default: 0.0

Settings 0.0-60.0 sec.

- The motor may continue rotating after the drive stops output due to external forces or the inertia of the motor itself. If you use the drive with the motor rotating, it may cause motor damage or trigger drive protection due to over-current. This parameter outputs DC current, generating torque to force the motor to stop to get a stable start before more operation. This parameter determines the duration of the DC brake current output to the motor when the drive starts up. Setting this parameter to 0.0 disables the DC brake at start-up.
- The PM has the magnetic field itself, using the DC brake may possibly cause the motor run in a reverse direction, therefore, it is not recommended to use DC brake for PM. Use Pr.10-49 zero voltage command to force the motor decelerate or to stop.

#### ✓ 07-03 DC Brake Time at STOP

Default: 0.0

Settings 0.0-60.0 sec.


- The motor may continue rotating after the drive stops output due to external forces or the inertia of the motor itself. This parameter outputs DC current, generating torque to force the drive stop after the drive stops output to make sure that the motor stops.
- This parameter determines the duration of the DC brake current output to the motor when braking. To enable DC brake at STOP, you must set Pr.00-22 (Stop Method) to 0 (ramp to stop). Set this parameter to 0.0 to disable the DC brake at stop.
- Related parameters:
  - Pr.00-22 Stop Method
  - Pr.07-04 DC Brake Frequency at STOP

#### O7-04 DC Brake Frequency at STOP

Default: 0.00

Settings 0.00-599.00 Hz

Determines the start frequency of the DC brake before the drive ramps to stop. When this setting is less than Pr.01-09 (Start-up Frequency), the start frequency for the DC brake begins at the minimum frequency.



DC Brake Output Timing Diagram

- Use the DC brake before running the motor when the load is movable at stop, such as with fans and pumps. The motor is in free running status and in unknown rotation direction before the drive starts up. Execute the DC brake before you start the motor.
- Use the DC brake at STOP when you need to brake the motor quickly or to control the positioning, such as with cranes or cutting machines.

#### Voltage Increasing Gain

Default: 100


Settings 1-200%

When using speed tracking, adjust Pr.07-05 to slow down the increasing voltage gain if there are errors such as oL or oc; however, the speed tracking time will be longer.


✓	07-06 Restart	after Momentary Power Los	s
			Default: 0
	Settings	0: Stop operation	
		1: Speed tracking by the speed	before the power loss
		2: Speed tracking by the minim	um output frequency
	Determines the o	peration mode when the drive res	tarts from a momentary power loss.
	The power system	n connected to the drive may pow	er off momentarily due to many reasons. This
	function allows th drive to stop.	e drive to keep outputting after the	e drive is repowered and does not cause the
	1: Frequency trac	king begins before momentary po	wer loss and accelerates to the master
	Frequency comm	and after the drive output frequen	cy and motor rotator speed are synchronous.
	Use this setting w	hen there is a lot of inertia with lit	tle resistance on the motor load. For example
	in equipment with	a large inertia flywheel, there is N	IO need to wait until the flywheel stops
	completely after a	restart to execute the operation of	command; therefore, it saves time.
	2: Frequency trac	king starts from the minimum out	out frequency and accelerates to the master
	Frequency comm	and after the drive output frequen	cy and motor rotator speed are synchronous.
	•	hen there is little inertia and large	
	This function is or	nly valid when the RUN command	is enabled.
<b>~</b>	<b>07-07</b> Allowed	d Power Loss Duration	
			Default: 2.0
	Settings	0.0–20.0 sec.	
	Determines the m	naximum time of allowable power	oss. If the duration of a power loss exceeds
	•	tting, the AC motor drive stops ou	·
		·	er loss time is ≤ 20 seconds and the AC
	•	•	vered off due to overload, even if the
		ole power loss time is ≤ 20 second	ls, Pr.07-06 is invalid after the power
	recovers.		
<b>~</b>	<b>07-08</b> Base B	lock Time	
			Default: Depending on the
			model power
	Settings	( 1	. ,
	•	•	notor drive blocks its output and then waits for
	•	•	called Base Block Time) before resuming
	•		s the residual voltage at the output side to
		pefore activating the drive again.	and the same of the delication of the same
	•	•	o is the re-start delay time after free run.
		and after the delay time.	nemorized, and runs or stops with the last
	This delay time is	only applicable in "Re-start after	coast to stop" status, and does not limit ramp
	to stop. The coas	t to stop can be caused by various	s control command source, or by errors.
	M Following table is	the recommended setting for re-s	tart delay time of each model nower You

must set Pr. 07-08 according to this table (the default of each model power is based on this table as well).


kW	0.75	1.5	2.2	3.7	.7 4		5.5	7.5	11.0	15.0
HP	1	2	3	5	5 5.5		7.5	10	15	20
Delay time (sec.)	0.3	0.4	0.5	0.6	.6 0.7		0.7	0.8	0.9	1
kW	18.5	22.0	30.0	37	7.0	4:	5.0	55.0	75.0	90.0
HP	25	30	40	5	0	6	60	75	100	125
Delay time (sec.)	1.1	1.2	1.3	1	.4	1	.5	1.6	1.7	1.8



B.B. Search with last output frequency downward timing chart



 $B.B.\ Search\ with\ minimum\ output\ frequency\ upward\ timing\ chart$ 




B.B. Search with minimum output frequency upward timing chart

N	07-09 Current Limit of Speed Tracking
	Default: 100
	Settings 20–200% (100% corresponds to the light-duty rated current of the drive)
	The AC motor drive executes speed tracking only when the output current is greater than the value set in Pr.07-09.
	$\hfill\square$ The maximum current for speed tracking affects the synchronous time. The larger the parameter
	setting is, the faster the synchronization occurs. However, if the parameter setting is too large,
	the overload protection function may be activated.
×	07-10 Restart after Fault Action
	Default: 0
	Settings 0: Stop operation
	1: Speed tracking by current speed
	2: Speed tracking by the minimum output frequency
	Faults include bb, oc, ov, and occ. To restart after oc, ov and occ, you cannot set Pr.07-11 to 0.
×	07-11 Number of Times of Restart after Fault
	Default: 0
	Settings 0–10
	After fault (oc, ov, and occ) occurs, the AC motor drive can reset and restart automatically up to
	10 times. When Pr.07-11 is set to 0, the drive resets or restarts automatically after faults occur.
	The drive starts according to the Pr.07-10 setting after restarting after fault.
	If the number of faults exceeds the Pr.07-11 setting, the drive does not restart and reset until you
	press RESET manually and execute the operation command again.
×	07-12 Speed Tracking during Start-up
	Default: 0
	Settings 0: Disable
	1: Speed tracking by the maximum output frequency
	2: Speed tracking by the motor frequency start-up
	3: Speed tracking by the minimum output frequency
	Speed tracking is suitable for punch, fans and other large inertia loads. For example, a
	mechanical punch usually has a large inertia flywheel, and the general stop method is coast to
	stop. If it needs to be restarted again, the flywheel may take 2–5 minutes or longer to stop. This
	parameter setting allows you to start the flywheel operating again without waiting until the
	flywheel stops completely.
	When using PM, Pr.07-12 ≠ 0, the speed tracking function is enabled. When Pr.07-12 = 1, 2 or 3,
	the output frequency converts to the actual rotor speed from zero-speed.
	When using SynRM control mode, only Pr.07-12 = 3 (speed tracking by the minimum output
	frequency) is enabled.


#### 

	Default: 0		
Settings	0: Disable		
	1: dEb with auto-acceleration / auto-deceleration, the drive does not output		
	the frequency after the power is restored.		
	2: dEb with auto-acceleration / auto-deceleration, the drive outputs the		
	frequency after the power is restored		
	3: dEb low-voltage control, then the drive's voltage increases to 350 $V_{\text{DC}}/$		
	700 $V_{\text{DC}}$ and ramps to stop after low frequency		
	4: dEb high-voltage control of 350 $V_{\text{DC}}/700~V_{\text{DC}},$ and the drive ramps to stop		
dEb (Deceleration	Energy Backup) lets the motor decelerates to stop when momentary power		
loss occurs. When	the power loss is instantaneous, use this function to let the motor decelerate		
to zero speed. If th	e power recovers at this time, the drive restarts the motor after the dEb return		
time.			
Lv return level: De	fault value depends on the drive power model		
Models for Fran	me A, B, C, D = Pr.06-00 + 60V / 30V (230V models)		
Lv level: Default =	Pr.06-00		
During dEb operation, other protection such as ryF, ov, oc, occ and EF may interrupt it, and			
these error codes are recorded.			
The STOP (RESE	Γ) command does not work during the dEb auto-deceleration, and the drive		
continues decelerating to stop. To make the drive coast to stop immediately, use another			
function (EF) instead.			
The B.B. function of	does not work when executing dEb. The B.B. function is enabled after the dEb		
function finishes.			
Even though the Lv warning does not display during dEb operation, if the DC bus voltage is			
lower than the Lv le	evel, MOx = 10 (Low voltage warning) still operates.		
During dEb execut	ion, it refers to the output frequency lower limit (Pr.01-11) value for restriction.		
A warning messag	e will appear during dEb execution. When dEb is released, the warning		
message will be au	utomatically or manually eliminated according to the option settings.		
The following expla	ains the dEb action:		
When the DC volta	ige drops below the dEb setting level, the dEb function starts to work (soft		
start relay remains	closed) and the drive executes auto-deceleration.		

- Situation 1: Momentary power loss, or too low and unstable power voltage, or power supply sliding down because of sudden heavy load.
  - Pr.07-13 = 1, "dEb active, DC bus voltage returns, output frequency does not return" and power recovers. When the power recovers and DC bus voltage exceeds the dEb return level, the drive linearly decelerates to 0 Hz and stops. The keypad displays the dEb warning until you manually reset it, so that you can see the reason for the stop.




- Situation 2: Momentary power loss or too low and unstable power voltage, or power supply sliding down because of sudden heavy load.
  - Pr.07-13 = 2 "dEb active, DC bus voltage returns, output frequency returns" and power recovers. During the dEb deceleration time (includes 0 Hz run), if the power recovers to a voltage higher than dEb return level, the drive maintains the frequency for the set time of Pr.07-14 (default = 3 sec.) and then accelerates again. The dEb warning on the keypad is automatically cleared.



Situation 3: Unexpected power shut down or power loss
 Pr.07-13 = 1 "dEb active, DC bus voltage returns, the output frequency does not return" and the

power does not recover. The keypad displays the dEb warning and stops after decelerating to the lowest operating frequency. When the DC bus voltage is lower than the Lv level, the drive disconnects the soft start relay until the power completely runs out.



#### Situation 4:

Pr.07-13 = 2 "dEb active, DC bus voltage returns, the output frequency returns" and power does not recover. The drive decelerates to 0 Hz. The DC bus voltage continues to decrease until the voltage is lower than the Lv level, and then the drive disconnects the soft-start relay. The keypad displays dEb warning until the drive completely runs out of power.

#### • Situation 5:

Pr.07-13 = 3 "dEb low voltage control, when the speed is lower than  $\frac{1}{4}$  rated motor speed, DC bus voltage rises to 350 V<sub>DC</sub> / 700 V<sub>DC</sub>, the drive ramps to stop.

The drive decelerates to 0 Hz. The DC bus voltage continues to decrease until the voltage is lower than the Lv level, and then the drive disconnects the soft-start relay. The soft-start relay closes again after the power recovers and the DC bus voltage is higher than the Lv return level. When the DC bus voltage is higher than the dEb return level, the drive maintains the frequency for the set time of Pr.07-14 (default = 3 sec.) and starts to accelerate linearly, and the dEb warning on the keypad is automatically cleared.

#### Situation 6:

Pr.07-13 = 4, dEb high-voltage control

When dEb occurs, the DC bus voltage control level rises to  $350~V_{DC}$  /  $700~V_{DC}$  to ramp to stop. Even though the power recovers and the frequency does not return, dEb activates until the motor decelerates to 0~Hz.

(1) When dEb activates, it sends dEb warning. When the output frequency reaches to 0 Hz, the operation status is STOP and disables the dEb function, the dEb warning continues.

(2) If power does not recover, the DC bus voltage drops until it reaches the Lv level, the drive LvS error occurs (keypad displays LvS error that covers the dEb display), the Soft Start Relay will be OFF.

#### O7-15 Dwell Time at Acceleration

Default: 0.00

Settings 0.00-600.00 sec.

O7-16 Dwell Frequency at Acceleration

Default: 0.00

Settings 0.00-599.00 Hz

O7-17 Dwell Time at Deceleration

Default: 0.00


Settings 0.00-600.00 sec.

**07-18** Dwell Frequency at Deceleration

Default: 0.00

Settings 0.00-599.00 Hz

- In the heavy load situation, Dwell can make stable output frequency temporarily.
- When the load is heavier, use Pr.07-15–Pr.07-18 to avoid ov or oc protection.



#### N 07-19 Fan Cooling Control

Default: 0

Settings 0: Fan is always ON

- 1: Fan is OFF after the AC motor drive stops for one minute
- 2: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops
- 3: Fan turns ON when temperature (IGBT) reaches around 60°C
- 4: Fan is always OFF
- Use this parameter to control the fan.
- ① : Fan runs immediately when the drive power is turned ON.
- 1: Fan runs when the AC motor drive runs. One minute after the AC motor drives stops, the fan is OFF.
- 2: Fan runs when the AC motor drive runs and stops immediately when AC motor drive stops.
- 3: Fan is ON when IGBT or capacitance temperature is > 60°C

  Fan is OFF when IGBT and capacitance temperature are both < 40°C, and the drive stops running.


- Setting 4: Fan is always OFF
- Pr.07-19 only controls the external fan (heat sink fan) on CFP2000. The internal fan (capacitor fan) is ON whenever the drive is power on, and cannot be closed by this parameter.

#### 

Default: 0

Settings

- 0: Coast to stop
- 1: Stop by the first deceleration time
- 2: Stop by the second deceleration time
- 3: Stop by the third deceleration time
- 4: Stop by the fourth deceleration time
- 5: System deceleration
- 6: Automatic deceleration
- When the multi-function input terminal setting is set to 10 (EF input) or 18 (force to stop) and the terminal contact is ON, the drive stops according to the setting of this parameter.



deceleration time selection

#### 4 07-21 Automatic Energy-Saving (AES) Selection


Default: 0

Settings 0: Disable


- 1: Power factor energy-saving improvement (for VF and SVC control modes)
- 2: Automatic energy-saving optimization (for VF and SVC control modes)
- Different control modes for Pr.07-21:

Settings / Control Mode	Induction Motor (IM)		Permanent Magnet Synchronous Motor (PM)		Synchronous Reluctance Motor (SynRM)
	VF	SVC	PMSVC	PMFOC	FOC
1: Power factor energy-saving improvement	✓	✓			
2: Automatic energy- saving optimization	✓	✓			

- Power factor energy-saving improvement (Pr.07-21 = 1):
  - When the automatic energy-saving function is enabled, the drive runs with full-voltage during
    acceleration and deceleration, and runs with the optimal voltage that is automatically
    calculated by the load power during constant operation. It is not recommended to use this
    function for applications that require frequent load changes or when the load is close to fullload during operation.
  - The prerequisites for valid power factor energy-saving improvement (Pr.07-21 = 1) are:
    - A. Power factor angle is larger than Pr.07-43 (Targeted Power Factor Angle for AES)
    - B. Output frequency is larger than Pr.07-41 (Minimum Frequency for AES)
    - C. The drive is in a steady-state output frequency status
    - D. Time for steady-state output frequency is larger than Pr.07-42 (Delay Time for AES)
    - E. Output current is smaller than or equal to 90% of the drive's rated current
  - The prerequisites for invalid power factor energy-saving improvement (Pr.07-21 = 1) are:
    - 1. A changing output frequency
    - 2. Output current is larger than 90% of the drive's rated current




- Automatic energy-saving optimization (Pr.07-21 = 2):
  - Controls the output voltage to minimize the motor's losses for optimal energy-saving. The
    motor's losses are calculated by motor parameter auto-tuning and energy-saving coefficient.
  - Automatic energy-saving optimization control is according to the block diagram below:



Pr.07-21 Auto Energy-saving (AES) Selection Pr.07-41 Minimum Frequency for AES Pr.07-42 Delay Time for AES

- The prerequisites for valid automatic energy-saving optimization (Pr.07-21 = 2) are:
  - A. Output frequency is larger than Pr.07-41 (Minimum Frequency for AES)
  - B. The drive is in a steady-state output frequency status
  - C. Time for steady-state output frequency is larger than Pr.07-42 (Delay Time for AES)
- The prerequisites for invalid automatic energy-saving optimization (Pr.07-21 = 2) are:
  - 1. A changing output frequency
  - 2. The loss model automatically determines the voltage drops when the drive is in normal and heavy duty. If there is no more voltage that can be adjusted, that is, the voltage drop is already optimized, AES is invalid.



The energy-saving function is invalid during the drive's acceleration and deceleration. To make it valid, the prerequisites need to be verified again. 07-22 Energy-Saving Gain Default: 100 Settings 10–1000% When Pr.07-21 is set to 1, use this parameter to adjust the energy-saving gain. The default is 100%. If the result is not satisfactory, adjust it by decreasing the setting value. If the motor oscillates, then increase the setting value. In certain applications such as high-speed spindles, the temperature rise in the motor is a major concern. When the motor is not in working state, reduce the motor current to a lower level. Reduce this parameter setting to meet this requirement. Automatic Voltage Regulation (AVR) Function Default: 0 Settings 0: Enable AVR 1: Disable AVR 2: Disable AVR during deceleration The rated voltage of the motor is usually 200–240 V<sub>AC</sub> (380–480 V<sub>AC</sub>), 60 Hz / 50 Hz and the input voltage of the AC motor drive may vary between 170–264 V<sub>AC</sub> (323–528 V<sub>AC</sub>), 50 Hz / 60 Hz. Therefore, when the AC motor drive is used without AVR function, the output voltage is the same as the input voltage. When the motor runs at the voltage exceeding 12-20% of the rated voltage, it causes higher temperature, damaged insulation, and unstable torque output, which result in losses due to shorter motor lifetime. The AVR function automatically regulates the output voltage of the AC motor drive to the motor's rated voltage when the input voltage exceeds the motor's rated voltage. For example, if the V/F curve is set at 200 V<sub>AC</sub> / 50 Hz and the input voltage is at 200-264 V<sub>AC</sub>, then the drive automatically reduces the output voltage to the motor to a maximum of 200 V<sub>AC</sub> / 50 Hz. If the input voltage is at 170–200 V<sub>AC</sub>, the output voltage to motor is in direct proportion to the input voltage. © 0: when the AVR function is enabled, the drive calculates the output voltage according to the actual DC bus voltage. The output voltage does NOT change when the DC bus voltage changes. 1: when the AVR function is disabled, the drive calculates the output voltage according to the actual DC bus voltage. The output voltage changes with the DC bus voltage, and may cause insufficient current, over-current or shock. 2: the drive disables the AVR function only during deceleration to stop, and at this time, you can accelerate the braking to achieve the same result. When the motor ramps to stop, disable the AVR function to shorten the deceleration time. Then, use with the auto-acceleration and auto-deceleration functions to make the motor's deceleration more stable and quicker.

×	07-24	<b>07-24</b> Torque Command Filter Time (V/F and SVC Control Mode)			
					Default: 0.500
		Settings	0.001–10.000 sec		
	When t	the time co	nstant setting is too	large, the control is sta	ble but the control response is slow.
			•	•	onse is faster but the control may be
		-	mal setting, adjust th	ne setting based on the	control stability or the control
	respon	se.			
×	07-25 Slip Compensation Filter Time (V/F and SVC Control Mode)				C Control Mode)
Default: 0.100				Default: 0.100	
		Settings	0.001-10.000 sec	•	
	Change	e the comp	ensation response t	ime with Pr.07-24 and I	Pr.07-25.
	If you s	et Pr.07-24	l and Pr.07-25 to 10	seconds, the compens	ation response time is the slowest;
	howeve	er, the syste	em may be unstable	if you set the time too	short.
N	07-26	Torque	Compensation G	Gain	
					Default: 0
		Settings	IM: 0–10 (when P	r.05-33 = 0)	
			PM: 0-5000 (whe	n Pr.05-33 = 1 or 2)	
	Only approximation	oplicable in	IMVF and PMSVC	control modes.	
	With a	large motor	r load, a part of drive	e output voltage is abso	orbed by the stator-winding resistor;
	therefo	re, the air g	gap magnetic field is	insufficient. This cause	es insufficient voltage at motor
	induction	on and resu	ults in excessive out	put current but insufficie	ent output torque. Auto-torque
	•				cording to the load and keep the air
	•	•	ds stable to get the o	•	
			•		when decreasing frequency. The
	•		•	•	resistor and an unchanged DC
				n function increases th	e output voltage at low frequency to
	•	igher start t	•	a large it may says a	poter ever flux and regult in a tea
		•	•	•	notor over-flux and result in a too the drive's protection function.
	large o		in or the drive, moto	i overneating or trigger	the drive's protection function.
×	07-27	Slip Co	mpensation Gain		
					Default: 0.00
					(Default value is 1.00 in SVC
					mode)
	~ •	Settings	0.00–10.00		
	•	· •	IMVF and IMSVC c		
					agnetic torque. It can be ignored at
	•	•		speed or 2–3% of slip.	
		_	-	•	nous frequency are in reverse
		-			•
		-			slip is larger with the reduction of the synchronous frequency


	<del>-</del>	ecific value. Therefore, the slip seriously affect	s the motor speed accuracy at		
low spec		n, when you use an induction motor with the d	rive the clin increases when the		
		also affects the motor speed accuracy.	ive, the slip increases when the		
		r to set the compensation frequency, and redu	ce the clin to maintain the		
	•	d when the motor runs at the rated current in o	·		
•	•	e drive output current is higher than Pr.05-05 (	·		
		rive compensates the frequency according to			
	· //·	set to 1.00 automatically when Pr.00-11 (Spee	•		
-		vector mode. Otherwise, it is automatically set	,		
		r load and acceleration. Increase the compens			
•		output frequency to the [motor rated slip × Pr.	•		
· ·	•	otor is at the rated load. If the actual speed rate	` ' '		
		neter setting value; otherwise, decrease the se			
	•	•	yamig varae.		
07-29	Slip Dev	viation Level			
			Default: 0.0		
	Settings	0.0–100.0%			
07.00	O	0: No detection			
07-30	Over-Sil	p Deviation Detection Time	Defended 0		
	Cottings	0.0.40.0	Default:1.0		
07-31	Settings Over Sti	0.0–10.0 sec.			
07-31	Over-Sil	p Deviation Treatment	Default: 0		
	Settings	0: Warn and continue operation	Delault. 0		
	Settings	·			
		Fault and ramp to stop     Fault and coast to stop			
		3: No warning			
M Dr ∩7 20		31 set the allowable slip level / time and the ov	er slip treatment when the drive		
is runnir		or set the allowable slip level / time and the ov	er-siip treatment when the drive		
	<u>-</u>				
07-32	Motor O	scillation Compensation Factor			
			Default: 1000		
	Settings	0–10000			
		0: Disable			
		wave motions that cause severe motor oscilla	•		
_	setting this parameter can effectively improve this situation. (When running with high frequency,				
	set this parameter to 0. When the current wave motion occurs in low frequency and high power,				
increase	e the value	for Pr.07-32.)			
07-33	Auto-Re	estart Interval of Fault			
			Default: 60.0		
	Settings	0.0-6000.0 sec.			

#### Chapter 12 Description of Parameter Settings | CFP2000

When a reset / restart occurs after a fault, the drive uses Pr.07-33 as a timer and starts counting the numbers of faults within this time period. Within this period, if the number of faults does not exceed the setting for Pr.07-11, the counting clears and starts from 0 when the next fault occurs. 07-38 PMSVC Voltage Feed Forward Gain Default: 1.00 Settings 0.00-2.00 Adjusts the PMSVC voltage feedback forward gain, and to meet the demand of rapid feedback application. Pr.07-38 = 1.00 means forward feedback = Ke × motor rotor speed Refer to Section 12-2 PMSVC Adjustment for details. 07-4<u>1</u> Minimum Frequency for AES Default: 10.00 Settings 0.00–40.00 Hz The drive's output frequency must be larger than Pr.07-41 to make the drive determine whether to run in a steady-state output frequency. 🕮 In general, larger power and voltage can give more energy-savings; lower power and voltage produce less energy-savings. However, too low power and voltage are not suitable for low-speed operation because it needs a larger starting current. Pr.07-41 is the parameter that limits the minimum frequency when AES is enabled (Pr.07-41 to Pr.01-00 is the frequency range – from minimum to maximum – that you can use for the AES function). 07-42 Delay Time for AES Default: 5 Settings 0–600 sec. When the drive runs in a steady-state output frequency, and exceeds Pr.07-42 setting time, the drive enters the energy-saving mode. Targeted Power Factor Angle for AES Default: 40.00 Settings 0.00-65.00° Use this function when Pr.07-21 = 1. If the power factor angle is larger than Pr.07-43, the drive continuously adjusts the energy-saving until it is smaller than Pr.07-43.  $\square$  Pr.07-43 is the angle  $\varphi$  between active power and reactive power. The smaller COS  $\theta$ , the lower the reactive power, and the lower the loss. Maximum Voltage Drop for AES Default: 60.00 Settings 0.00-70.00% Defines the maximum allowed voltage drop when the drive is in energy-saving mode. 🚇 The drive has bigger energy-saving efficiency when running in no-load or light-load. But the output voltage drop is not unlimited. Use Pr.07-44 to limit the maximum ratio (%) of the output voltage drop.

#### Example:

- (1) If Pr.01-01 = 60 Hz, Pr.01-02 = 380  $V_{AC}$ , the frequency command is 60 Hz and the actual voltage output is 371.2  $V_{AC}$ , and Pr.07-44 = 60%, then the maximum voltage drop = 380V (the voltage command corresponding to the frequency command in the VF table: 60 Hz corresponds to 380V) × 60% = 228  $V_{AC}$ .
- (2) If the frequency command is 30 Hz, the corresponding voltage is 200  $V_{AC}$  in the VF table, and Pr.07-44 = 60%, then the maximum voltage drop = 200V × 60% = 120  $V_{AC}$ .




#### 


Default: 100

#### Settings 0–10000%

- Defines the motor power loss constant. Default 100% corresponds to the drive's iron loss constant that is calculated by motor parameter auto-tuning or motor nameplate information.
- Pr.07-45 affects the final steady-state output voltage value for the energy-saving control. The larger the Pr.07-45 setting value, the higher the steady-state output voltage (smaller voltage drop). The smaller the Pr.07-45 setting value, the lower the steady-state output voltage (larger voltage drop).
- See below for the flowchart of AES adjustment with motor parameter auto-tuning (recommended):



See below for the flowchart of AES adjustment without motor parameter auto-tuning (not recommended):



#### O7-50 PWM Fan Speed

Default: 60

Settings 60-100%

- For different application and environment, adjust the fan speed to expedite the heat dissipation of the drive.
- Default for 460V models (45 kW, 55 kW, 75 kW and 90 kW) is 80%; default for other models are 60%.
- 230V models: 18.5 kW and above models are controlled by PWM fan speed control, and Pr.07-50 is available.
- 460V models: 22kW and above models are controlled by PWM fan speed control, and Pr.07-50 is available.
- ☐ 575V models is controlled by PWM, and Pr.07-50 is available.

#### **√ 07-62** dEb Gain (Kd)

Default: 3000

Settings 0-65535

#### 

Default: 30

Settings 0-65535

- Sets the gain of DC bus voltage controller when dEb function activates.
- If the DC bus voltage drops too fast, or the speed oscillation occurs during deceleration after dEb function activates, adjust Pr.07-62 and Pr.07-63.
- ☐ Kd: Increase the Kd settings to quicken the control response, but the oscillation may occur if the setting is too large.
- Kp: Use Kp parameter to decrease the steady-state error to zero, increase the setting to quicken the response speed.

#### **08 High-function PID Parameters**


✓ You can set this parameter during operation.

#### ✓ 08-00 Terminal Selection of PID Feedback

Default: 0

Settings 0: No function

- 1: Negative PID feedback: by analog input (Pr.03-00–03-02)
- 4: Positive PID feedback: by analog input (Pr.03-00-03-02)
- $\square$  Pr.08-00  $\neq$  0 enables the PID function.
- Negative feedback:
- Error = +Target value (set point) Feedback. Use negative feedback when the detection value increases if the output frequency increases.
- Positive feedback:
- Error = -Target value (set point) + Feedback. Use positive feedback when the detection value decreases if the output frequency increases.
- $\square$  When Pr.08-00  $\neq$  0, the related applicable parameters include:
  - Pr.00-20 (Master frequency command source (AUTO) / Source selection of PID target)
  - Pr.03-00–03-02 (Analog input selection)
     When Pr.00-20 = 2 (External analog input), set Pr.03-00–03-02 = 4 (PID target value)
     When Pr.08-00 = 2 or 4, set Pr.03-00–03-02 = 5 (PID feedback signal)
- Refer to the following description for details.



00-20

### Master Frequency Command Source (AUTO) / Source Selection of the PID Target

Default: 0

Settings 0: Digital keypad

1: RS-485 communication input

2: External analog input (Refer to Pr.03-00–03-02)

3: External UP / DOWN terminal

6: CANopen communication card


8: Communication card (does not include CANopen card)

$\varkappa$	03-00	Analog	Input Selection (AVI1)		
				Default: 1	
×	03-01	Analog	Input Selection (ACI)		
_				Default: 0	
×	03-02	Analog	Input Selection (AVI2)		
_				Default: 0	
		Settings	4: PID target value		
			5: PID feedback signal		

#### Common applications for PID control

- 1. Flow control: Use a flow sensor to feedback the flow data and perform accurate flow control.
- 2. Pressure control: Use a pressure sensor to feedback the pressure data and perform precise pressure control.
- 3. Air volume control: Use an air volume sensor to feedback the air volume data to achieve excellent air volume regulation.
- 4. Temperature control: Use a thermocouple or thermistor to feedback temperature data for comfortable temperature control.
- 5. Speed control: Use a speed sensor feedback motor shaft speed or input another machine speed as a target value for synchronous control.

#### PID control loop:



K<sub>p</sub>: Proportional gain (P) T<sub>i</sub>: Integral time (I) T<sub>d</sub>: Derivative control (D) S: Operator

#### Concept of PID control

#### Proportional gain (P):

The output is proportional to input. With only proportional gain control, there is always a steady-state error.

Adjustment: Turn off the Ti and Td, or remain Ti and Td in constant value, then adjust the proportional gain (P).

Increase: Faster status feedback, but excessive adjustment increases the overshoot.

Decrease: Smaller overshoot, but excessive adjustment slows down the transient response.

#### Integral time(I):

The controller output is proportional to the integral of the controller input. When an automatic control system is in a steady state and a steady-state error occurs, the system is called a System with Steady-state Error. To eliminate the steady-state error, add an "integral part" to the controller. The integral time controls the relation between integral part and the error. The integral part increases over time even if the error is small. It gradually increases the controller output to eliminate the error until it is zero. This stabilizes the system without a steady-state error by using

proportional gain control and integral time control.

Adjustment: The integral time (I) accumulates from the time difference, if the vibration cycle is longer than the setting for integral time, the integration enhances. Increase the integral time (I) to reduce the vibration.

Increase: Reduce the overshoot, excessive adjustment causes worse transient response.

Decrease: Faster transient response, but the transient time will be longer, and takes more time to achieve the steady state. Excessive adjustment causes larger overshoot.


#### Differential control (D):

The controller output is proportional to the differential of the controller input. During elimination of the error, oscillation or instability may occur. Use the differential control to suppress these effects by acting before the error. That is, when the error is near zero, the differential control should be zero. Use proportional gain (P) and differential control (D) to improve the system state during PID adjustment.

Adjustment: When the vibration cycle is shorter and continuous, it means that the differential time setting is too large, and causes excessive output. Decrease the setting of D gain to reduce the vibration. If the D gain is set to 0, adjust the PID control again.

#### Using PID control in a constant pressure pump feedback application:

Set the application's constant pressure value (bar) to be the set point of PID control. The pressure sensor sends the actual value as the PID feedback value. After comparing the PID set point and PID feedback, an error displays. The PID controller calculates the output by using proportional gain (P), integral time (I) and differential time (D) to control the pump. It controls the drive to use a different pump speed and achieves constant pressure control by using a 4–20 mA signal corresponding to 0–10 bar as feedback to the drive.



- Pr.00-04 = 10 (Display PID feedback (b) (%))
- Pr.01-12 Acceleration Time is set according to actual conditions.
- Pr.01-13 Deceleration Time is set according to actual conditions.

#### Chapter 12 Description of Parameter Settings | CFP2000

- Pr.00-21 = 0 to operate through the digital keypad
- Pr.00-20 = 0, the digital keypad controls the set point.
- Pr.08-00 = 1 (Negative PID feedback from analog input)
- ACI analog input Pr.03-01 = 5, PID feedback signal.
- Pr.08-01–08-03 is set according to actual conditions:
- If there is no vibration in the system, increase Pr.08-01 (Proportional Gain (P))
- If there is no vibration in the system, reduce Pr.08-02 (Integral Time (I))
- If there is no vibration in the system, increase Pr.08-03 (Differential Time (D))
- Refer to Pr.08-00–08-21 for PID parameter settings.

#### 

Default: 1.0

Settings 0.0–100.0%

- 1.0: Kp gain is 100%; if the setting is 0.5, Kp gain is 50%.
- Sets the proportional gain to determine the deviation response speed. The higher the proportional gain, the faster the response speed. Eliminates the system deviation; usually used to decrease the deviation and get faster response speed, it also reduces the steady-state error. If you set the value too high, overshoot occurs and it may cause system oscillation and instability.
- If you set the other two gains (I and D) to zero, proportional control is the only effective parameter.

### ✓ 08-02 Integral Time (I)

Default: 1.00

Settings 0.00–100.00 sec.

0.00: No integral

- Use the integral controller to eliminate the deviation during stable system operation. The integral control does not stop working until the deviation is zero. The integral is affected by the integral time. The smaller the integral time, the stronger integral action. It is helpful to reduce overshoot and oscillation for a stable system. Accordingly, the speed to lower the steady-state deviation decreases. The integral control is often used with the other two controls for the PI controller or PID controller.
- Sets the integral time of the I controller. When the integral time is long, there is a small I controller gain, with slower response and slow external control. When the integral time is short, there is a large gain of I controller gain, with faster response and rapid external control.
- When the integral time is too short, it may cause overshoot or oscillation for the output frequency and system.
- Set integral time to 0.00 to disable the I controller.

# 08-03 Differential Time (D) Default: 0.00 Settings 0.00–1.00 sec. Use the differential controller to show the system deviation change, as well as to preview the change in this deviation. You can use the differential controller to eliminate the deviation in order to improve the system state. Using a suitable differential time can reduce overshoot and shorten adjustment time; however, the differential operation increases noise interference. Note that a too large differential causes more noise interference. In addition, the differential shows the change and the output is 0 when there is no change. Note that you cannot use the differential control independently. You must use it with the other two controllers for the PD controller or PID controller. Sets the D controller gain to determine the deviation change response. Using a suitable differential time reduces the P and I controllers overshoot to decrease the oscillation for a stable system. A differential time that is too long may cause system oscillation. The differential controller acts on the change in the deviation and cannot reduce the interference. Do not use this function when there is significant interference. 08-04 Upper Limit of Integral Control Default: 100.0 Settings 0.0–100.0% Defines an upper bound for the integral gain (I) and therefore limits the master frequency. The formula is: Integral upper bound = Maximum Output Frequency (Pr.01-00) × Pr.08-04 %. An excessive integral value causes a slow response due to sudden load changes and may cause motor stall or machine damage. If so, decrease it to a proper value. 08-05 PID Output Command Limit Default: 100.0 Settings 0.0-110.0% Defines the percentage of the output command limit during the PID control. The formula is Output Command Limit = Maximum Output Frequency (Pr.01-00 × Pr.08-05 %). 08-06 PID Feedback Value Display Default: Read only Settings -200.00-200.00% 08-07 **Delay Time** Default: 0.0 Settings 0.0-35.0 sec. 08-20 PID Mode Selection Default: 0 Settings 0: Serial connection 1: Parallel connection

© 0: Serial connection, use conventional PID control structure.

#### Chapter 12 Description of Parameter Settings | CFP2000

- 1: Parallel connection, the proportional gain, integral gain and differential gain are independent.

  You can customize the P, I and D value to fit your application.
- Pr.08-20 determines the primary low pass filter time when in PID control. Setting a large time constant may slow down the drive's response speed.
- PID control output frequency is filtered with a primary low pass function. This function can filter a mix frequency. A long primary low pass time means the filter degree is high and a short primary low pass time means the filter degree is low.
- Inappropriate delay time setting may cause system oscillation.
- PI Control:

Controlled only by the P action, so the deviation cannot be entirely eliminated. In general, to eliminate residual deviations, use the P + I control. When you use the PI control, it eliminates the deviation caused by the targeted value changes and the constant external interferences. However, if the I action is too powerful, it delays the response when there is rapid variation. You can use the P action by itself to control the loading system with the integral components.


#### PD Control:

When deviation occurs, the system immediately generates an operation load that is greater than the load generated only by the D action to restrain the deviation increment. If the deviation is small, the effectiveness of the P action decreases as well. The control objects include applications with integral component loads, which are controlled by the P action only. Sometimes, if the integral component is functioning, the whole system may vibrate. In this case, use the PD control to reduce the P action's vibration and stabilize the system. In other words, this control is useful with no brake function's loading over the processes.


#### PID Control:

Use the I action to eliminate the deviation and the D action to reduce oscillation; then combine this with the P action for the PID control. Use the PID method for a control process with no deviations, high accuracies and a stable system.

#### **Serial connection**



#### Parallel connection



# ✓ 08-08 Feedback Signal Detection Time

Default: 0.0

Settings 0.0-3600.0 sec.

- □ Valid only when the feedback signal is ACI (4–20 mA).
- This parameter sets the detection time for abnormal PID feedback. You can also use it when the system feedback signal response is extremely slow. (Setting the detection time to 0.0 disables the detection function.)

# N 08-09 Feedback Signal Fault Treatment

Default: 0

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: Warn and operate at last frequency

- □ Valid only when the feedback signal is ACI (4–20 mA).
- Sets the treatments when the PID feedback signal is abnormal.

# N 08-10 Sleep Level

Default: 0.00

Settings 0.00-599.00 Hz or 0-200.00%

Determines the sleep level, and if the sleep time and the wake-up level are enabled or disabled. When Pr.08-10 = 0: Disabled; when  $Pr.08-10 \neq 0$ : Enable.

# ✓ 08-11 Wake-up Level

Default: 0.00

Settings 0.00–599.00 Hz or 0–200.00%

When Pr.08-18 = 0, the unit for Pr.08-10 and that for Pr.08-11 switch to frequency. The settings become 0.00–599.00 Hz.

# Chapter 12 Description of Parameter Settings | CFP2000 When Pr.08-18 = 1, the unit for Pr.08-10 and that for Pr.08-11 switch to percentage. The settings are between 0-200.00%. The percentage is based on the current command value, not the maximum value. For example, if the maximum value is 100 kg, and the current value is 30 kg, then if Pr.08-11 = 40%, the value is 12 kg. Pr.08-10 uses the same logic for calculation. Sleep Delay Time Default: 0.0 Settings 0.0–6000.0 sec. When the frequency command is smaller than the sleep frequency and less than the sleep time, the frequency command is equal to the sleep frequency. However, the frequency command remains at 0.00 Hz until the frequency command becomes equal to or larger than the wake-up frequency. PID Feedback Signal Error Deviation Level Default: 10.0 Settings 1.0–50.0% PID Feedback Signal Error Deviation Detection Time Default: 5.0 Settings 0.1–300.0 sec. When the PID control function is normal, it should calculate the value within a period of time that is close to the target value. Refer to the PID control diagram for details. When executing PID feedback control, if |PID reference target value – detection value > Pr.08-13 PID Feedback Signal Error Deviation Level and exceeds Pr.08-14 setting, it is judged as a PID control fault, and the multi-function output terminal setting 15 (PID feedback error) activates. 08-16 PID Compensation Selection Default: 0 0: Parameter setting (Pr.08-17) Settings 1: Analog input © 0: The setting for Pr.08-17 gives the PID compensation value. 1: Set the analog input (Pr.03-00–Pr.03-02) to 13, then the PID compensation value of analog input is displayed on Pr.08-17. At this time, Pr.08-17 is read only.

# № 08-17 PID Compensation

Default: 0.0

Settings -100.0-100.0%

The PID compensation value = maximum PID target value × Pr.08-17. For example, if the maximum operation frequency Pr.01-00 = 60.00 Hz, Pr.08-17 = 10.0%, the PID compensation value increases the output frequency 6.00 Hz. 60.00 Hz × 100.00% × 10.0% = 6.00 Hz.


# Sleep Mode Function Setting 08-18 Default: 0 0: Refer to PID output command Settings 1: Refer to PID feedback signal © 1: The unit for Pr.08-10 and that for Pr.08-11 switch to frequency. The settings are between 0.00-599.00 Hz. 1: The unit for Pr.08-10 and that for Pr.08-11 switch to percentage. The settings are between 0-200.00%. 08-19 Wake-up Integral Limit Default: 50.0 Settings 0.0–200.0% The wake-up integral limit for the drive prevents suddenly running at high speed when the drive wakes up. Defines the wake-up integral frequency limit = (Pr.01-00 × Pr.08-19%) Reduces the reaction time from sleep to wake-up. 08-21 Enable PID to Change the Operation Direction Default: 0 0: Operation direction cannot be changed Settings 1: Operation direction can be changed Wake-up Delay Time Default: 0.00 Settings 0.00-600.00 sec.

Refer to Pr.08-18 for more information.

There are three scenarios for the sleep and wake-up frequency. Refer to following explanations:

Frequency Command (PID is not in use, Pr.08-00 = 0. Works only in VF mode)
 When the output frequency is ≤ the sleep frequency, and the drive reaches the preset sleep time, then the drive is in sleep mode (0 Hz).

When the frequency command reaches the wake-up frequency, the drive starts to count the wake-up delay time. When the drive reaches the wake-up delay time, it starts to catch up to reach the Frequency command by the acceleration time.




2. Internal PID Calculation Frequency Command (PID is in use, Pr.08-00 ≠ 0 and Pr.08-18 = 0)

When the PID calculation Frequency command reaches the sleep frequency, the drive starts to

count the sleep time and the output frequency starts to decrease. If the drive exceeds the preset sleep time, then the drive is in sleep mode (0 Hz). If the drive does not reach the preset sleep time, it remains at the lower frequency limit (if there is a preset of lower limit), or it remains at the minimum output frequency set at Pr.01-07 and waits until it reaches the sleep time before it goes into sleep mode (0 Hz).

When the PID calculated Frequency command reaches the wake-up frequency, the drive starts to count the wake-up delay time. Once it reaches the wake-up delay time, the drive starts to catch up to reach the PID Frequency command value by the acceleration time.



#### 3. PID Feedback Value Rate Percentage (PID is in use, Pr.08-00 ≠ 0 and Pr.08-18 = 1)

When the PID feedback value reaches the sleep level percentage, the drive starts to count the sleep time and the output frequency starts to decrease. If the drive exceeds the preset sleep time, then the drive is in sleep mode (0 Hz). If the drive does not reach the preset sleep time, it remains at the lower frequency limit (if there is a preset of lower limit.), or it remains at the minimum output frequency set for Pr.01-07 and waits until it reaches the sleep time before going into sleep mode (0 Hz).

When the PID feedback value reaches the wake-up percentage, the drive starts to count the wake-up delay time. Once it reaches the wake-up delay time, the drive starts to catch up to reach the PID Frequency command value by the acceleration time.

Example 01: PID negative feedback

- Pr.08-10 must > Pr.08-11
- 30 kg is the reference
- Set the parameter:

Pr.03-00 = 5 (AVI1 is PID feedback)

Pr.08-00 = 1 (PID negative feedback: AVI1

simulation input function select)

Pr.08-10 = 40% (Sleep level:

 $12 \text{ kg} = 40\% \times 30 \text{ kg}$ 

Pr.08-11 = 20% (Wake-up level:

 $6 \text{ kg} = 20\% \times 30 \text{ kg}$ 


Case 01: If feedback > 12 kg, frequency

decreases.

Case 02: If feedback < 6 kg, frequency

increases.

Area	PID Physical Qquantity
	>12 kg, the drive goes into
Sleep Area	sleep, the motor goes into
	sleep
Excessive	between 6 kg and 12 kg,
Area	the drive remains in current
Area	state
Wake-UP	< 6 kg, the drive wakes-up,
Area	the motor wakes-up



Example 02: PID positive feedback

- Pr.08-10 must < Pr.08-11
- 30 kg is the reference
- Set the parameter:

Pr.03-00 = 5 (AVI1 is PID feedback)

Pr.08-00 = 4 (PID positive feedback: AVI1

simulation input function select)

Pr.08-10 = 110% (Sleep level:

 $33 \text{ kg} = 110\% \times 30 \text{ kg}$ 

Pr.08-11 = 120% (Wake-up level:

 $36 \text{ kg} = 120\% \times 30 \text{ kg}$ 


Case 01: If feedback < 33 kg, frequency

decreases.

Case 02: If feedback > 36 kg, frequency

increases.


Area	PID	
Alea	Physical Quantity	
	> 36 kg, the drive goes	
Sleep Area	into sleep, the motor	
	goes into sleep	
Excessive	between 33 kg and 36	
Area	kg, the drive remains in	
Alea	the current state	
Wake-Up	< 33 kg, the drive wakes-	
Area	up	



#### **09 Communication Parameters**

When using the communication interface, the diagram on the right shows the communication port pin definitions. We recommend that you connect the AC motor drive to your PC by using Delta IFD6530 or IFD6500 as a communication converter.

Refer to Appendix A. Modbus Protocol for more details.



Refer to Appendix A. Modbus Protocol for more details.

### ✓ You can set this parameter during operation. 09-00 **Modbus Communication Address** Default: 1 Settings 1–254 ☐ Sets the communication address for the drive if the AC motor drive is controlled through RS-485 serial communication. The communication address for each AC motor drive must be unique. 09-01 COM1 Modbus Transmission Speed Default: 9.6 Settings 4.8-115.2 Kbps Sets the transmission speed between the computer and the AC motor drive. Options are 4.8 Kbps, 9.6 Kbps, 19.2 Kbps, 38.4 Kbps, 57.6 Kbps and 115.2 Kbps; otherwise, the transmission speed is set to the default 9.6 Kbps. 09-02 COM1 Modbus Transmission Fault Treatment Default: 3 0: Warn and continue operation Settings 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning, no fault and continue operation Determines the treatment when an error is detected that the host controller does not continuously transmit data to the AC motor drive during Modbus communication. The detection time is based on the Pr.09-03 setting. 09-03 COM1 Modbus Time-out Detection Default: 0.0 Settings 0.0-100.0 sec. Sets the communication transmission time-out value. COM1 Modbus Communication Protocol 09-04 Default: 1 Settings 1: 7, N, 2 (ASCII) 2: 7, E, 1 (ASCII)

3: 7, O, 1 (ASCII) 4: 7, E, 2 (ASCII) 5: 7, O, 2 (ASCII)

#### Chapter 12 Description of Parameter Settings | CFP2000

6: 8, N, 1 (ASCII)

7: 8, N, 2 (ASCII)

8: 8, E, 1 (ASCII)

9: 8, O, 1 (ASCII)

10: 8, E, 2 (ASCII)

11: 8, O, 2 (ASCII)

12: 8, N, 1 (RTU)

13: 8, N, 2 (RTU)

14: 8, E, 1 (RTU)

15: 8, O, 1 (RTU)

16: 8, E, 2 (RTU)

17: 8, O, 2 (RTU)

- Control by PC (Computer Link)
- When using the RS-485 serial communication interface, you must specify each drive's communication address in Pr.09-00. The computer then implements control using the drives' individual addresses.
- Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

### Modbus Control bit ■ Modbus Contr

Default: 0.0

Settings bit0: 0x2104 Decimal digits of output current

bit0 = 0: The number of decimal places depends on the size of the value

bit0 = 1: Fixed 1 decimal place


Reads the output current information of the drive 0x2104 through Modbus, the decimal places of the output current can be changed by parameter settings. When the decimal place of output current needs to be fixed to 1 bit, set bit0 = 1.

# 09-09 Communication Response Delay Time

Default: 2.0

Settings 0.0–200.0 ms

If the host controller does not finish the transmitting / receiving process, you can use this parameter to set the response delay time after the AC motor drive receives communication command as shown in the following picture.



# **09-10** Communication Main Frequency

Default: 60.00

Settings 0.00-599.00 Hz

When you set Pr.00-20 to 1 (RS-485 serial communication), the AC motor drive saves the last frequency command into Pr.09-10 when there is abnormal power off or momentary power loss. When power is restored, the AC motor drive operates with the frequency in Pr.09-10 if no new Frequency command input. When a Frequency command of RS-485 changes (the frequency command source must be set as Modbus), this parameter also changes.

×	09-11	Block Transfer 1
×	09-12	Block Transfer 2
×	09-13	Block Transfer 3
×	09-14	Block Transfer 4
×	09-15	Block Transfer 5
×	09-16	Block Transfer 6
×	09-17	Block Transfer 7
×	09-18	Block Transfer 8
×	09-19	Block Transfer 9
×	09-20	Block Transfer 10
×	09-21	Block Transfer 11
×	09-22	Block Transfer 12
×	09-23	Block Transfer 13
×	09-24	Block Transfer 14
×	09-25	Block Transfer 15
*	09-26	Block Transfer 16
•		Default: 0000h

Settings 0000-FFFFh

- There is a group of block transfer parameters available in the AC motor drive (Pr.09-11 to Pr.09-26). Using communication code 03H, you can store the parameters (Pr.09-11–Pr.09-26) that you want to read.
- For example: according to the Address List (as shown in the table below), Pr.01-42 is shown as 012A. Set Pr.09-11 to 012Ah (the minimum voltage of Pr.01-42 M2 is 2.0 V), and use Pr.09-11 (communication address 090B) to read the communication parameter, the read value is 2.0.

AC motor drive	GGnnH	GG is the parameter group, nn is the parameter number; for
parameters	GGIIIII	example, the address of Pr.04-10 is 040AH.

Mind if the transfer parameters are read only. If the data is written to read-only parameters from the upper unit, a communication error may occur.

Default: 1

Settings 0: Decoding Method 1 (20xx)

1: Decoding Method 2 (60xx)

#### Chapter 12 Description of Parameter Settings | CFP2000

		Decoding Method 1	Decoding Method 2	
	Digital Keypad	Digital keypad controls the drive action regardless of decoding method 1 or 2.		
Course of	External Terminal	External terminal controls the drive action regardless of decoding method 1 or 2.		
Source of Operation	RS-485	The address for reference is 2000h–20FF	regardless of decoding method 1 or 2.	
Control	CANopen	Refer to index: 2020-01h-2020-FFh	Refer to index: 2060-01h-2060-FFh	
	Communication Card	Refer to address: 2000h–20FFh	Refer to address: 6000h–60FFh	
	PLC	PLC commands controls the drive action	regardless of decoding method 1 or 2.	

### 09-31 Internal Communication Protocol

Default: 0

Settings 1: BACnet

0: Modbus 485

- -1: Internal Communication Slave 1
- -2: Internal Communication Slave 2
- -3: Internal Communication Slave 3
- -4: Internal Communication Slave 4
- -5: Internal Communication Slave 5
- -6: Internal Communication Slave 6
- -7: Internal Communication Slave 7
- -8: Internal Communication Slave 8
- -10: Internal Communication Master
- -12: Internal PLC Control
- When it is defined as internal communication, refer to Section 16-10 for Main Control Terminal of Internal Communication.
- When it is defined as internal PLC control, refer to Section 16-12 for Remote IO Control Application (using MODRW).

# ✓ 09-33 PLC Command Force to 0

Default: 0

Setting bit0: Before PLC scan, set the PLC target frequency = 0

Defines whether the Frequency command or the Speed command must be cleared to zero or not before the PLC starts the next scan.

# 09-35 PLC Address

Default: 2

Settings 1–254

### 09-36 CANopen Slave Address

Default: 0

Settings 0: Disable

0-127

### 09-37 CANopen Speed

Default 0

Settings 0: 1 Mbps

1: 500 Kbps

2: 250 Kbps

3: 125 Kbps

4: 100 Kbps (Delta only)

5: 50 Kbps

### 09-39 CANopen Warning Record

Default: Ready only

Settings bit0: CANopen guarding time-out

bit1: CANopen heartbeat time-out bit2: CANopen SYNC time-out

bit3: CANopen SDO time-out

bit4: CANopen SDO buffer overflow

bit5: CANopen hardware disconnection warning (Can Bus Off)

bit6: Error protocol of CANopen

bit8: The setting values of CANopen indexes are fail bit9: The setting value of CANopen address is fail

bit10: The checksum value of CANopen indexes is fail

### 09-40 CANopen Decoding Method

Default: 1

Settings 0: Disable (Delta-defined decoding method)

1: Enable (CANopen DS402 Standard protocol)

### **09-41** CANopen Communication Status

Default: Read only

Settings 0: Node reset state

1: Com reset state

2: Boot up state

3: Pre-operation state

4: Operation state

5: Stop state

# 09-42 CANopen Control Status

Default: Read only

Settings 0: Not ready for use state

1: Inhibit start state

2: Ready to switch on state

3: Switched on state

4: Enable operation state

7: Quick stop active state

13: Error reaction activation state

14: Error state

09-45	CANope	en Master Function	
			Default: 0
	Settings	0: Disable	
		1: Enable	
09-46	CANope	en Master Address	
			Default: 100
	Settings	0–127	
09-49	CANope	en Extension Setting	
			Default: 0002h
	Settings	bit0: Update Index 604F and 6050 to Accele	ration / Deceleration time 1
		bit0 = 0: Enabled (default)	
		bit0 = 1: Disabled	
		bit1: Distinguish the CANopen identity code	by models or by series
		bit1 = 0: Distinguish the CANopen ident	ity code by models
		bit1 = 1: Distinguish the CANopen ident	ity code by series
$\square$ bit0 = 0	), the drive	directly controls Acceleration time 1 (Pr.01-12)	and Deceleration time 1 (Pr.01-
13).			
$\square$ bit1 = 0	each mod	lel of different series of drives has its own EDS	S file, this setting is more
complic	cated to use	e.	
bit1 = 1	: distinguis	h the CANonen identity eads by the drive's as	· · · · · · · · · · · · · · · · · · ·
	-	h the CANopen identity code by the drive's se	ries, which requires only one
EDS file	-	in the CANOPER Identity code by the drive's se	ries, which requires only one
	e. 		ries, which requires only one
09-50	e. 	MS / TP Node Address	ries, which requires only one  Default: 10
	e. 		
	BACnet Settings	MS / TP Node Address	
09-50	BACnet Settings	MS / TP Node Address 0–127	
09-50	BACnet Settings BACnet	MS / TP Node Address 0–127	Default: 10
09-50	BACnet Settings BACnet Settings	MS / TP Node Address  0–127  Baud Rate	Default: 10
09-50 09-51	BACnet Settings BACnet Settings	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps	Default: 10
09-50 09-51	BACnet Settings BACnet Settings BACnet	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps	Default: 10  Default: 38.4
09-50 09-51	BACnet Settings BACnet Settings BACnet Settings BACnet	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L	Default: 10  Default: 38.4
09-50 09-51 09-52	BACnet Settings BACnet Settings BACnet Settings BACnet	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L  0–65535	Default: 10  Default: 38.4
09-50 09-51 09-52	BACnet Settings BACnet Settings BACnet Settings BACnet	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L  0–65535  Device Index H	Default: 10  Default: 38.4  Default: 10
09-50 09-51 09-52	BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L  0–65535  Device Index H	Default: 10  Default: 38.4  Default: 10
09-50 09-51 09-52	BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L  0–65535  Device Index H  0–63	Default: 10  Default: 38.4  Default: 10
09-50 09-51 09-52	BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L  0–65535  Device Index H  0–63	Default: 10  Default: 38.4  Default: 10  Default: 0
09-50 09-51 09-52 09-53	BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet Settings	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L  0–65535  Device Index H  0–63  Max Address  0–127	Default: 10  Default: 38.4  Default: 10  Default: 0
09-50 09-51 09-52	BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet Settings	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L  0–65535  Device Index H  0–63  Max Address	Default: 10  Default: 38.4  Default: 10  Default: 0
09-50 09-51 09-52 09-53	BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet Settings BACnet Settings	MS / TP Node Address  0–127  Baud Rate  9.6–76.8 Kbps  Device Index L  0–65535  Device Index H  0–63  Max Address  0–127	Default: 10  Default: 38.4  Default: 10  Default: 10

### 09-60 **Communication Card Identifications** Default: Read only Settings 0: No communication card 1: DeviceNet Slave 2: Profibus-DP Slave 3: CANopen Slave / Master 5: EtherNet / IP Slave 8: BACnet IP 12: PROFINET 09-61 Firmware Version of Communication Card Default: Read only Settings Read only 09-62 **Product Code** Default: Read only Settings Read only 09-63 **Error Code** Default: Read only Settings Read only Communication Card Address (for DeviceNet or PROFIBUS) 09-70 Default: 1 Settings DeviceNet: 0-63 Profibus-DP: 1-125 09-71 Communication Card Speed Setting (for DeviceNet) Default: 2 Settings Standard DeviceNet: 0: 125 Kbps 1: 250 Kbps 2: 500 Kbps 3: 1 Mbps (Delta only) Non standard DeviceNet: (Delta only) 0: 10 Kbps 1: 20 Kbps 2: 50 Kbps 3: 100 Kbps 4: 125 Kbps 5: 250 Kbps 6: 500 Kbps 7: 800 Kbps 8: 1 Mbps

### Additional Settings for Communication Card Speed (for DeviceNet) 09-72 Default: 0 Settings 0: Standard DeviceNet In this mode, the baud rate can only be 125 Kbps, 250 Kbps, and 500 Kbps in standard DeviceNet speed. 1: Non-standard DeviceNet In this mode, the baud rate of DeviceNet can be the same as that for CANopen (0-8). Use this parameter with Pr.09-71. © 0: The baud rate can only be set to 125 Kbps, 250 Kbps and 500 Kbps as a standard DeviceNet speed. 1: The DeviceNet communication rate can be the same as that for CANopen (setting 0-8). 09-74 Communication Card Control Flag Default: 0 bit0: set the EDS identity definition of EIP card Settings bit0 = 0: identify EIP card by the drive's family (EDS, old) bit0 = 1: identify EIP card by the drive's series (EDS, new) Defines the EDS identification method of EIP cards. The definition is as below: bit0: EDS identity definition of EIP card bit0 = 0: Identify EIP card by the drive's family, for example, M300 family and C2000 family. bit0 = 1: Identify EIP card by the drive's series, for example, C2000, CH2000, C2000-HS, CP2000, etc. 09-75 Communication Card IP Configuration (for Modbus TCP) Default: 0 Settings 0: Static IP 1: Dynamic IP (DHCP) 0: Set the IP address manually. 1: IP address is automatically set by the host controller. 09-76 Communication Card IP Address 1 (for Modbus TCP) Communication Card IP Address 2 (for Modbus TCP) 09-77 Communication Card IP Address 3 (for Modbus TCP) 09-78 Communication Card IP Address 4 (for Modbus TCP) Default: 0 Settings 0-65535 Use Pr.09-76–09-79 with a communication card.

N	09-80	Commu	unication Card Address Mask 1 (for Modbus TCP)
×	09-81	Commu	unication Card Address Mask 2 (for Modbus TCP)
M	09-82	Commu	unication Card Address Mask 3 (for Modbus TCP)
N	09-83	Commu	unication Card Address Mask 4 (for Modbus TCP)
			Default: 0
		Settings	0–65535
×	09-84	Commu	ınication Card Gateway Address 1 (for Modbus TCP)
×	09-85	Commu	inication Card Gateway Address 2 (for Modbus TCP)
N	09-86	Commu	inication Card Gateway Address 3 (for Modbus TCP)
N	09-87	Commu	inication Card Gateway Address 4 (for Modbus TCP)
			Default: 0
		Settings	0–65535
×	09-88	Commu	unication Card Password (Low word) (for Modbus TCP)
×	09-89	Commu	unication Card Password (High word) (for Modbus TCP)
			Default: 0
		Settings	0–99
×	09-90	Reset C	Communication Card (for Modbus TCP)
			Default: 0
		Settings	0: Disable
			4. Deart material to defect
N	00.04		1: Reset, return to default
	09-91	Addition	nal Settings for the Communication Card (for Modbus TCP)
	09-91	Addition	
	09-91	Addition Settings	nal Settings for the Communication Card (for Modbus TCP)
	09-91		nal Settings for the Communication Card (for Modbus TCP)  Default: 1
	09-91		nal Settings for the Communication Card (for Modbus TCP)  Default: 1  bit0: Enable IP Filter
	09-91		nal Settings for the Communication Card (for Modbus TCP)  Default: 1  bit0: Enable IP Filter  bit1: Enable internet parameters (1bit)
	09-91		Default: 1 bit0: Enable IP Filter bit1: Enable internet parameters (1bit) When IP address is set, this bit is enabled. After updating the
	09-91		Default: 1 bit0: Enable IP Filter bit1: Enable internet parameters (1bit) When IP address is set, this bit is enabled. After updating the communication card parameters, this bit changes to disabled.
	09-91		Default: 1 bit0: Enable IP Filter bit1: Enable internet parameters (1bit) When IP address is set, this bit is enabled. After updating the communication card parameters, this bit changes to disabled. bit2: Enable login password (1bit)
	09-91	Settings	Default: 1 bit0: Enable IP Filter bit1: Enable internet parameters (1bit) When IP address is set, this bit is enabled. After updating the communication card parameters, this bit changes to disabled. bit2: Enable login password (1bit) When you enter the login password, this bit is enabled. After updating
		Settings	Default: 1 bit0: Enable IP Filter bit1: Enable internet parameters (1bit) When IP address is set, this bit is enabled. After updating the communication card parameters, this bit changes to disabled. bit2: Enable login password (1bit) When you enter the login password, this bit is enabled. After updating the communication card parameters, this bit is enabled. After updating the communication card parameters, this bit changes to disable.
		Settings	Default: 1  bit0: Enable IP Filter  bit1: Enable internet parameters (1bit)  When IP address is set, this bit is enabled. After updating the communication card parameters, this bit changes to disabled.  bit2: Enable login password (1bit)  When you enter the login password, this bit is enabled. After updating the communication card parameters, this bit changes to disable.  unication Card Status (for Modbus TCP)
		Settings	Default: 1  bit0: Enable IP Filter  bit1: Enable internet parameters (1bit)  When IP address is set, this bit is enabled. After updating the communication card parameters, this bit changes to disabled.  bit2: Enable login password (1bit)  When you enter the login password, this bit is enabled. After updating the communication card parameters, this bit changes to disable.  Inication Card Status (for Modbus TCP)  Default: 0

[This page is intentionally left blank]

#### 10 Sensorless Motor Control Parameters

✓ You can set this parameter during operation.

10-08

# Treatment for Speed Observer Feedback Fault

(applied to 230V / 460V models)

Default: 2

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

10-09

# Detection Time of Speed Observer Feedback Fault

(applied to 230V / 460V models)

Default: 1.0

Settings 0.0–10.0 sec.

0: Disable

When speed observer outputs an abnormal signal, or the rotation direction is different with the detected direction from speed observer, and the fault time exceeds the detection time of speed observer feedback fault (Pr.10-09), a reverse direction of the speed feedback (SdRv) fault occurs. Refer to Chapter 14 for solutions.

### 10-10 Speed Observer Stall Level (applied to 230V / 460V models)

Default: 115

Settings 0-120%

0: Disable

Determines the fault level of feedback signal. The maximum operation frequency for Pr.01-00 = 100%

# M 10-11 Detection Time of Speed Observer Stall (applied to 230V / 460V models)

Default: 0.1

Settings 0.0–2.0 sec.

# 10-12 Speed Observer Stall Action (applied to 230V / 460V models)

Default: 2

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

When the drive output frequency exceeds the speed observer stall level (Pr.10-10), the drive starts to count the time. When the error time exceeds the speed observer stall detection time (Pr.10-11), an over speed rotation feedback (SdOr) fault occurs. Refer to Chapter 14 for solutions.

# Speed Observer Slip Range (applied to 230V / 460V models)

Default: 50

Settings 0–50%

0: Disable

# Detection Time of Speed Observer Slip (applied to 230V / 460V models) 10-14 Default: 0.5 Settings 0.0–10.0 sec. 10-15 Speed Observer Stall and Slip Error Action (applied to 230V / 460V models) Default: 2 Settings 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop When the value of (rotation speed – motor frequency) exceeds the Pr.10-13 setting, and the detection time exceeds Pr.10-14; the drive starts to count the time. If the detection time exceeds Pr.10-14, a large deviation of speed feedback (SdDe) fault occurs. Refer to Chapter 14 for solutions. 10-31 I/F Mode, Current Command Default: 40 Settings 0–150% of motor rated current Sets the current command for the drive in low speed area (low speed area: frequency command < Pr.10-39). When the motor stalls on heavy-duty start-up or forward / reverse with load, increase the parameter value. If the inrush current is too high and causes oc stall, then decrease the parameter value. When Pr.00-11 is set to 8 (SynRM Sensorless), the maximum setting value for I/F mode Current command is 15%. The application for this parameter extends to high-speed zone and fluxweakening zone. When Pr.00-11 is set to 8 (SynRM Sensorless) and the drive operates in flux-weakening zone, if the speed is restricted and cannot accelerate, even causes the observer lost control, adjust the setting for Pr.10-31. PM FOC Sensorless Speed Estimator Bandwidth (High Speed) Default: 5.00 Settings 0.00-600.00 Hz Sets the speed estimator bandwidth. Adjust the parameter to change the stability and the accuracy of the motor speed. If there is low frequency vibration (the waveform is similar to the sine wave) during the process, then increase the bandwidth. If there is high frequency vibration (the waveform shows extreme vibration and is like a spur), then decrease the bandwidth. PM FOC Sensorless Speed Estimator Bandwidth (Low Speed) 10-33 (applied to 230V/460V models) Default: 1.00 Settings 0.00–600.00 Hz Works only when Speed mode is set as IPM sensorless / SRM sensorless (Pr.00-11 = 8). Increase this parameter to enhance the loading performance during start-up and low-speed

When the motor speed during start-up or operation is lower than the frequency to switch from	/F
mode to PM sensorless mode (Pr.10-39), and the motor speed oscillates, adjust the setting for	
this parameter.	
When Pr.05-33 is set to 3 (SynRM), the unit changes to Pu, the setting upper and lower limit for	r
Pr.10-33 change to 3.00–0.01 and the default is 1.0.	
10-34 PM Sensorless Speed Estimator Low-pass Filter Gain	
Default: 1.00	
Settings 0.00–655.35	
Changes the response speed of the speed estimator.	
If there is low frequency vibration (the waveform is similar to the sine wave) during the process	
then increase the gain. If there is high frequency vibration (the waveform shows extreme	٠,
vibration and is like a spur), then decrease the gain.	
When Pr.05-33 is set to 3 (SynRM), the setting upper limit is 10.00.	
10-35 AMR (Kp) Gain (applied to 230V / 460V models)	
Default: 1.00	
Settings 0.00–3.00	
When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 0.40.	
<b>10-36</b> AMR (Ki) Gain (applied to 230V / 460V models)	
Default: 0.20	
Settings 0.00–3.00	
☐ When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 2.00.	
<ul><li>When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 2.00.</li><li>□ AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of</li></ul>	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.	
<ul> <li>AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.</li> <li>If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden</li> </ul>	of
<ul> <li>AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.</li> <li>If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden</li> </ul>	
<ul> <li>AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.</li> <li>If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the ld value of the contraction of the contracti</li></ul>	
<ul> <li>AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.</li> <li>If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the ld value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.</li> </ul>	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the ld value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the Id value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode  Default: 20.00	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the Id value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode  Default: 20.00  Settings 0.00–599.00 Hz	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the ld value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode  Default: 20.00  Settings 0.00–599.00 Hz  The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency).	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the Id value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode  Default: 20.00  Settings 0.00–599.00 Hz  The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency).  Sets the frequency for switching from low frequency to high frequency, and sets the switch points.	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the Id value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode  Default: 20.00  Settings 0.00–599.00 Hz  The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency).  Sets the frequency for switching from low frequency to high frequency, and sets the switch point for high and low frequencies of the speed observer.	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the Id value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode  Default: 20.00  Settings 0.00–599.00 Hz  The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency).  Sets the frequency for switching from low frequency to high frequency, and sets the switch point for high and low frequencies of the speed observer.	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the ld value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode  Default: 20.00  Settings 0.00–599.00 Hz  The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency).  Sets the frequency for switching from low frequency to high frequency, and sets the switch point for high and low frequencies of the speed observer.  If the switch frequency is too low, the motor does not generate enough back-EMF to let the speed observer measure the right position and speed of the rotor, causing stall and oc when	
AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone.  If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the Id value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed.  10-39 Frequency to Switch from I/F Mode to PM Sensorless Mode  Default: 20.00  Settings 0.00–599.00 Hz  The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency).  Sets the frequency for switching from low frequency to high frequency, and sets the switch point for high and low frequencies of the speed observer.	nt

	makes the drive continue to output with Pr.10-31 setting value.)  When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 10.00 Hz.
/	10-40 Frequency to Switch from PM Sensorless Mode to I/F Mode
•	Default: 20.00
	Settings 0.00–599.00 Hz
	The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency).  Sets the frequency for switching from high frequency to low frequency, and sets the switch point for high and low frequencies of the speed observer.  If the switch frequency is too low, the motor does not generate enough back-EMF to let the speed observer measure the right position and speed of the rotor when running at the switch frequency.  If the switch frequency is too high, the active range of I/F is too wide, which generates a larger
	current without energy saving. (If the current value for Pr.10-31 is too high, the high switch
	frequency makes the drive continue to output with Pr.10-31 setting value.)
<b>/</b>	10-41 I/F Mode, Id Current Low-Pass Filter Time
	Default: 0.2
	Settings 0.0–6.0 sec.
	<ul> <li>Sets the filter time for Pr.10-31. Smoothly increases the magnetic field to the current command setting value under the I/F mode.</li> <li>If you want to slowly increase the size of Id, increase the filter time to avoid a Step phenomenon</li> </ul>
	occurs when starting current output. When decrease the filter time (minimum value is 0), the current rises faster, then a Step phenomenon occurs.
/	10-42 Initial Angle Detection Pulse Value
	Default: 1.0
	Settings 0.0–3.0 times of motor's rated current
	The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).
	The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).  The parameter influences the value of the pulse during the angle detection. The larger the pulse,
	☐ The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection). ☐ The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.
	<ul> <li>The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).</li> <li>The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.</li> <li>Increase the parameter when the running direction and the command are opposite during start-</li> </ul>
	<ul> <li>The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).</li> <li>The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.</li> <li>Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.</li> </ul>
	<ul> <li>The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).</li> <li>The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.</li> <li>Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.</li> <li>Refer to Section 12-2 Adjustment &amp; Application for detailed motor adjustment procedure.</li> </ul>
	<ul> <li>□ The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).</li> <li>□ The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.</li> <li>□ Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.</li> <li>□ Refer to Section 12-2 Adjustment &amp; Application for detailed motor adjustment procedure.</li> <li>10-49 Zero Voltage Time during Start-up</li> </ul>
<b>✓</b>	<ul> <li>□ The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).</li> <li>□ The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.</li> <li>□ Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.</li> <li>□ Refer to Section 12-2 Adjustment &amp; Application for detailed motor adjustment procedure.</li> <li>10-49 Zero Voltage Time during Start-up</li> </ul>
<b>✓</b>	<ul> <li>□ The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).</li> <li>□ The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.</li> <li>□ Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.</li> <li>□ Refer to Section 12-2 Adjustment &amp; Application for detailed motor adjustment procedure.</li> <li>10-49 Zero Voltage Time during Start-up</li> <li>Default: 0.000</li> <li>Settings 0.000-60.000 sec.</li> </ul>
<b>✓</b>	<ul> <li>The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).</li> <li>The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.</li> <li>Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.</li> <li>Refer to Section 12-2 Adjustment &amp; Application for detailed motor adjustment procedure.</li> <li>10-49 Zero Voltage Time during Start-up</li> <li>Default: 0.000</li> <li>Settings 0.000-60.000 sec.</li> <li>This parameter is valid only when the setting for Pr.07-12 (Speed Tracking during Start-up) = 0.</li> </ul>
<b>✓</b>	The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).  The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.  Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.  Refer to Section 12-2 Adjustment & Application for detailed motor adjustment procedure.  10-49  Zero Voltage Time during Start-up  Default: 0.000  Settings 0.000–60.000 sec.  This parameter is valid only when the setting for Pr.07-12 (Speed Tracking during Start-up) = 0.  When the motor is in static status at start-up, this increases the accuracy when estimating
•	<ul> <li>The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).</li> <li>The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.</li> <li>Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.</li> <li>Refer to Section 12-2 Adjustment &amp; Application for detailed motor adjustment procedure.</li> <li>10-49 Zero Voltage Time during Start-up</li> <li>Default: 0.000</li> <li>Settings 0.000-60.000 sec.</li> <li>This parameter is valid only when the setting for Pr.07-12 (Speed Tracking during Start-up) = 0.</li> </ul>
•	The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).  The parameter influences the value of the pulse during the angle detection. The larger the pulse, the higher the accuracy of rotator's position. A larger pulse might cause oc.  Increase the parameter when the running direction and the command are opposite during start-up. If oc occurs at start-up, then decrease the parameter.  Refer to Section 12-2 Adjustment & Application for detailed motor adjustment procedure.  10-49 Zero Voltage Time during Start-up  Default: 0.000  Settings 0.000−60.000 sec.  This parameter is valid only when the setting for Pr.07-12 (Speed Tracking during Start-up) = 0.  When the motor is in static status at start-up, this increases the accuracy when estimating angles. In order to put the motor in static status, set the three-phase drive output to 0 V to the

setting time, increase the setting value appropriately.

☐ If Pr.10-49 is too high, the start-up time is longer. If it is too low, the braking performance is weak.

### ✓ 10-51 Injection Frequency

Default: 500

Settings 0–1200 Hz

- This parameter is a high frequency injection command in IPM sensorless control mode and usually you do not need to adjust it. If a motor's rated frequency (for example, 400 Hz) is too close to the frequency setting for this parameter (that is, the default of 500 Hz), it affects the accuracy of the angle detection. Refer to the setting for Pr.01-01 before you adjust this parameter.
- ☐ If the setting value for Pr.00-17 is lower than Pr.10-51 × 10, then increase the frequency of the carrier wave.
- $\square$  Pr.10-51 is valid only when Pr.10-53 = 2.
- When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 400.

### 10-52 Injection Magnitude

Default:

Settings 0.0–200.0 V

230V models: 0.0–100.0 V 15.0 460V models: 0.0–200.0 V 30.0 575V models: 0.0–200.0 V 30.0

- The parameter is the magnitude command for the high frequency injection signal in PM Sensorless control mode.
- Increasing the parameter can increase the accuracy of the angle estimation, but the electromagnetic noise might be louder if the setting value is too high.
- The system uses this parameter when the motor's parameter is "Auto". This parameter influences the angle estimation accuracy.
- When the ratio of the salient pole (Lq/Ld) is lower, increase Pr.10-52 to make the angle detection more accurate.
- $\square$  Pr.10-52 is valid only when Pr.10-53 = 2.
- When Pr.05-33 is set to 3 (SynRM), the unit is percentage (%); the setting lower limit and upper limit is 10–50%, and the default is 30%.

### M 10-53 PM Initial Rotor Position Detection Method

Default: 0

Settings 0: Disable

1: Using I/F current command (Pr.10-31) to attract the rotor to zero degrees

2: High frequency injection

3: Pulse injection

- When the Speed mode is set to PMSVC (Pr.00-11 = 2) or PM Sensorless (Pr.00-11 = 6):
  - For IPM application, set Pr.10-53 = 2.

### Chapter 12 Description of Parameter Settings | CFP2000

		• For SPM application, set Pr.10-53 = 3.
		If the above settings cause problems, then set this parameter to 1.
		When the Speed mode is set to SynRM Sensorless (Pr.00-11 = 8), you do not need to set this
		parameter.
		Magnetic Flux Linkage Estimate Low-Speed Gain
~		(applied to 230V / 460Vmodels)
		Default: 100
		Settings 10–1000%
		This parameter is valid only when the speed mode is set to PM SensorIss control mode (Pr.00-
		11 = 6).
		Increase this parameter to enhance the loading capacity during start-up.
		Low-speed zone means motor speed under 1/5 of motor's rated speed; high-speed zone means
		speed beyond 1/5 of motor's rated speed.
,		Magnetic Flux Linkage Estimate High-Speed Gain
~		(applied to 230V / 460V models)
		Default: 100
		Settings 10–1000%
		This parameter is valid only when the speed mode is set to PM Sensorless (Pr.00-11 = 6) /
		SynRM Sensorless control modes (Pr.00-11 = 8).
		Increase this parameter to enhance the loading performance in high-speed zone and improve
		the response.
		Decrease this parameter when there is a speed oscillation in the flux-weakening zone.
		When Pr.05-33 is set to 3 (SynRM), the unit is Pu; the setting lower and upper limits are 0.1–3.0
		and the default is 1.0.
~		10-56 Kp of Phase-Locked Loop (applied to 230V / 460V models)
		Default: 100
		Settings 10–1000%
		Increase this parameter to enhance the loading performance in high-speed zone and improve
		the response.
		Decrease this parameter when there is a high frequency vibration in the speed output frequency.
		When Pr.05-33 is set to 3 (SynRM), the unit is Hz; the setting lower and upper limits are 5–50
		and the default is 30.
~	1	10-57 Ki of Phase-Locked Loop (applied to 230V / 460V models)
		Default: 100
		Settings 10–1000%
		Increase this parameter to increase the speed response during acceleration and deceleration.

Mutual Inductance Gain Compensation (applied to 230V / 460V models)

Default: 100

Settings 0.00-655.35

- This parameter is valid only when the speed mode is set to SynRM sensorlss control mode (Pr.00-11 = 8).
- ☐ If the motor's loading performance during start-up is poor or the speed is lower than the frequency switch from I/F mode to PM sensorless mode (Pr.10-39), adjust this parameter to improve the loading performance.

[This page is intentionally left blank]

#### 11 Advanced Parameters (applied to 230V / 460V models)

In this parameter group, ASR stands for Adjust Speed Regulator

✓ You can set this parameter during operation.

### 11-00 System Control

Default: 0000h


Settings bit0: Auto-tuning for ASR and APR

bit6: 0 Hz linear-cross

bit7: Save or not saving the frequency

bit0 = 0: Manual adjustment for ASR gain, Pr.11-06–Pr.11-11 are valid and Pr.11-03–Pr.11-05 are invalid.


bit0 = 1: Auto-adjustment for ASR gain, the system automatically generates an ASR setting, Pr.11-06–Pr.11-11 are invalid and Pr.11-03–Pr.11-05 are valid.



When the drive needs to keep a certain torque at zero-speed, or it needs a steady frequency output at extreme low speed, increase Pr.11-05 zero-speed bandwidth appropriately. If there is serious output current vibration that cause the drive vibrates in high-speed area, then decrease the high-speed bandwidth.

#### For example:


Manual gain	Response:
	[Pr.11-10, Pr.11-11] > [Pr.11-06, Pr.11-07] > [Pr.11-08, Pr.11-09]
Auto gain	Pr.11-05 = 15 Hz, Pr.11-03 = 10 Hz, Pr.11-04 = 8 Hz



ASR adjustment- manual gain

ASR adjustment- auto gain

- bit6 0 Hz linear-cross function: keeps the S-Curve in linear-cross the 0 Hz point when the S-curves for acceleration / deceleration time (Pr.01-24–Pr.01-27) are set, and the forward / reverse run cross 0 Hz.
  - bit6 = 1: The S-curves for acceleration / deceleration time (Pr.01-24–Pr.01-27) do NOT affect the drive starts and stops. Forward / reverse rotation crosses the zero point in linear.
  - bit6 = 0: The S-curves for acceleration / deceleration time (Pr.01-24–Pr.01-27) affect the drive starts and stops. Forward / reverse rotation crosses the zero point after the S-Curve.



- bit 7 = 0: Save the frequency before power is OFF. The keypad displays the saved frequency after cycle the power.
  - bit7 = 1: Do not save the frequency before power is OFF. The keypad displays 0.00 Hz after cycle the power.
- Pr.11-00 bit7 is valid when Pr.00-20 (Master frequency command source) is set to 0 (digital keypad), 1 (RS-485 communication input) or 3 (External UP / DOWN terminal), other frequency commands are invalid.

# 11-01 Per-Unit of System Inertia

Default: 256

Settings 1–65535 (256 = 1PU)

When Pr.11-01 = 256, it is 1PU. So if you use a 2 HP motor, the 2 HP motor inertia is 6.6 kg-cm<sup>2</sup> according to the rotor inertia table in Pr.05-38. If Pr.11-01 = 10000 after tuning, the system inertia is  $(10000 \div 256) \times 6.6 \text{ kg-cm}^2$ . If the Ig current command from ASR has high-frequency glitch, then decrease the setting. If the response time of sudden loading is too slow, then increase the setting. 11-02 ASR1 / ASR2 Switch Frequency Default: 7.00 Settings 5.00-599.00 Hz Sets the low-speed and high-speed ASR switching point in the FOC area. Provides flexibility to meet two needs: in the high-speed region of the estimator switch point it has a high response, and in the low-speed region of the estimator switch point it has a lower response. The recommended switching point is higher than Pr.10-39. A low setting does not cover Pr.10-39. If the setting is too high, the high-speed range is too narrow. When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 10.00 Hz. **11-03** ASR1 Low-Speed Bandwidth Default: 10 Settings 1–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (SynRM) 11-04 ASR2 High-Speed Bandwidth Default: 10 Settings 1–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (SynRM) 11-05 Zero-Speed Bandwidth Default: 10 Settings 1–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (SynRM) After estimating inertia and setting Pr.11-00 bit0 = 1 (auto-tuning), you can adjust Pr.11-03, Pr.11-04 and Pr.11-05 separately by speed response. The larger the setting value, the faster the response. Pr.11-02 is the switch frequency between the low-speed / high-speed bandwidth.  $\square$  When Pr.00-11 = 8 (SynRM), the setting upper limit is 30, and the default is 5. 11-06 ASR 1 Gain Default: 10 Settings 0–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (SynRM) 11-07 ASR 1 Integral Time Default: 0.100 Settings 0.000-10.000 sec. 11-08 ASR 2 Gain Default: 10 Settings 0–40 Hz (IM) / 0–100 Hz (PM) / 1–30 Hz (SynRM) 11-09 ASR 2 Integral Time Default: 0.100

0.000-10.000 sec.

Settings

# 11-10 ASR Gain of Zero Speed

Default: 10

Settings 0–40 Hz (IM) / 0–100 Hz (PM) / 1–30 Hz (SynRM)

### A 11-11 ASR Integral Time of Zero Speed

Default: 0.100


Settings 0.000-10.000 sec.

# ASR Speed Feed Forward Gain

Default: 0

Settings 0-200%

- ☐ This function enables when Pr.11-00 bit0 = 1.
- Increase the setting for Pr.11-12 to reduce the command tracking difference, and improve the speed response. Use this function for speed tracking applications.
- Set Pr.11-01 correctly to get excellent improvement of the speed response.




### PDFF Gain Value

Default: 30

Settings 0–200%

- This parameter is invalid when Pr.05-24 = 1.
- This parameter is valid only when Pr.11-00 bit0 = 1.
- After you estimate and set Pr.11-00 bit0 = 1 (auto-tuning), use Pr.11-13 to reduce overshoot. However, a shift of the curve may occur earlier. In this case, you can set Pr.11-13 = 0 first, and then increase the setting value to "a condition with best acceleration and without overshoot" when the acceleration time meets your application but overshoot occurs.
- ☐ Increasing Pr.11-13 improves the overshoot of speed tracking, but an excessive value may reduce the transient response.
- ☐ Increasing Pr.11-13 enhances the system stiffness in high-speed steady state, and reduce the speed transient fluctuation at a sudden loading.
- Ensure that you set Pr.11-01 system inertia correctly to get excellent improvement of the speed response.



11-14 ASR Output Low Pass Filter Time

Default: 0.008

Settings 0.000-0.350 sec.

Sets the ASR command filter time.

Notch Filter Depth

Default: 0

Settings 0-100 dB

11-16 Notch Filter Frequency

Default: 0.00

Settings 0.0-6000.0 Hz

- A notch filter is a filter that attenuates a signal in a specific frequency band.
- The notch filter also slows down the response speed in the frequency band to avoid mechanical resonance.
- The higher the setting value for Pr.11-15, the better the mechanical resonance is suppressed.
- The notch filter frequency should be equal to the mechanical frequency resonance.
- Forward Motor Torque Limit Quadrant I
- 11-18 Forward Regenerative Torque Limit Quadrant II
- 7 11-19 Reverse Motor Torque Limit Quadrant III
- 7 11-20 Reverse Regenerative Torque Limit Quadrant IV


Default: 500

Settings 0-500%

- ☐ VF and SVC mode:
- Pr.11-17—Pr.11-20 limit the output current, the percentage base value is the drive's rated current (not the motor's rated current). The minimum value between Pr.11-17–11-20 and Pr.06-12 becomes the current output limit. In acceleration and steady state operation, when the output current reaches the limit, the ocA (over-current during acceleration) protection or over-current stall prevention under steady-state operation acts. The output frequency drops, and recovers when the output current is lower than the limit value.
- Calculation equation for the motor rated torque:

Motor rated torque =  $T(N.M) = \frac{P(W)}{\omega(rad/s)}$ ; P(W) value = Pr.05-02 (Pr.05-14);

$$ω$$
(rad/s) value = Pr.05-03 (Pr.05-15);  $\frac{RPM \times 2\pi}{60} = rad/s$ 



- All control mode is based on 100% of the motor rated current except for these four modes: IM: VF, SVC and PM: PMSVC modes.
- When Pr.00-11 = 8 (SynRM), the default for Pr.11-17-Pr.11-20 is 200.

# Flux Weakening Curve for Motor 1 Gain Value

Default: 90


Settings 0–200%

# Flux Weakening Curve for Motor 2 Gain Value

Default: 90

Settings 0–200%

- Adjusts the output voltage for the flux-weakening curve.
- For the spindle application, use this adjustment method:
  - 1. Run the motor to the highest frequency.
  - 2. Observe the output voltage.
  - 3. Adjust the Pr.11-21 (motor 1) or Pr.11-22 (motor 2) setting to make the output voltage reach the motor rated voltage.
  - 4. The larger the setting value, the greater the output voltage.



# Flux Weakening Area Speed Response

Default: 65

Settings 0: Disable 0–150%

Controls the speed in the flux weakening area. The larger the value, the faster the acceleration/ deceleration. In normal condition, you do not need to adjust this parameter.

### 11-24 Droop Rate Percentage

Default: 0.00

Settings 0.00–10.00%

- The Droop Function is used for multiple motors driving the same load system and must be operated based on speed mode. When output torque mismatch occurs between different motors, the short frequency adjustment behaviors (either increasing or decreasing frequency) can achieve the balance between individual output torques.
- The Droop compensation frequency will not take effect when it is below the minimum operating frequency of the over-current stall prevention level (which is the maximum value among 0.5 Hz, Pr.01-07 and Pr.01-11). This ensures that the drive is not reduced to 0 Hz by this function.
- When using the Droop function, the rated frequency, rated power, speed, current, etc. of each motor must be equal.
- When using the Droop function, the control parameters of each drive must be the same, including the Droop rate, acceleration/ deceleration timed, control mode, and inner loop control gain.
- Each motor must disable slip compensation and over-current stall prevention functions when using the Droop function.
- Droop Rate Frequency ( $\triangle \omega$ ) = Motor rated frequency (Hz) × Droop rate percentage (%) × Estimated output torque (%)
- Estimated output torque: 100% corresponds to the motor rated torque

  For example, Motor rated frequency = 60.00 Hz, Pr.11-24 = 1.00%, Estimated output torque = 100%, Droop frequency = 60.00 Hz × 1.00% × 100% = 0.6 Hz

# 11-25 Droop Function Start Frequency

Default: 0.00

Settings 0.00–599.00%

Pr.11-25 is the starting frequency for the Droop control function. If the frequency is below this value, the Droop function will be disabled.

[This page is intentionally left blank]

### 12 Pump Parameters

✓ You can set this parameter during operation.

### 12-00 Circulation Control

Default: 0

Settings 0: No operation

1: Fixed Time Circulation (by time)

2: Fixed Quantity Circulation

3: Fixed Quantity Control

4: Fixed Time Circulation + Fixed Quantity Circulation

5: Fixed Time Circulation + Fixed Quantity Control

In this mode, the CFP2000 can control up to eight motors at a time. The total number of motors is determined by Pr.12-01. In accordance with the Fixed Time Circulation (Pr.12-02), you can adjust the switching time between Start and Stop for each motor. When an operating motor reaches the time setting for Pr.12-02, the CFP2000 stops that motor according to the setting for Pr.00-22 (Stop method). After the delay time setting for Pr.12-03, next motor starts operating. See diagram below.




Diagram 12-1: Sequential Diagram of Fixed Time Free Runs Circulation (by time)

#### Disable Motors' Output

Setting the multi-function input commands as Disable Motors' Output can stop the corresponding motors. The following table lists the settings:

Pr.02-01–Pr.02-06 =	60	61	62	63	64	65	66	67	68
Disable Motors' Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor coasts to stop.

Wiring: Fixed Time Circulation (by time) can control up to eight motors. Diagram 12-2 shows an example of controlling four motors at the same time.




Diagram 12-2: Wiring

### 12-01 Number of Motors to be Connected

Default: 1

Settings 1–8

Number of Motors: maximum of eight motors. After setting the number of connected motors, the multi-function output terminals automatically follow the setting as shown in the table below.

Pr.12-01	01	02	03	04	05	06	07	08
Pr.02-13	55	55	55	55	55	55	55	55
Pr.02-14		56	56	56	56	56	56	56
Pr.02-15			57	57	57	57	57	57
Pr.02-36				58	58	58	58	58
Pr.02-37					59	59	59	59
Pr.02-38						60	60	60
Pr.02-39							61	61
Pr.02-40								62

Table 1: Setting of Multi-function Output Terminal for Circulating Motors

# **12-02** Operating Time for Each Motor (minutes)

Default: 0

Settings 0-65500 minutes

Sets the fixed time for circulation. If Pr.12-02 = 0, stop the timing. The currently running motors continue operating until a Stop command is given.

12-03

Delay Time due to the Acceleration (or the Increment ) at Motor Switching (seconds)

Default: 1.0

Settings 0.0–3600.0 seconds

Sets the delay time when switching motors. When the currently running motors reach the time setting for Pr.12-02, the CFP2000 uses the delay time setting for Pr.12-03 and then switches to run the next motors.

12-04

Delay Time due to the Deceleration (or the Decrement) at Motor Switching (seconds)

Default: 1.0

Settings 0.0–3600.0 seconds

- Sets the delay time of motor switching during the acceleration, the unit is second.
- Note: 12-05 Delay time due to Fixed Quantity Circulation at Motor Switching (seconds)

Default: 10.0

Settings 0.0–3600.0 seconds

Sets the fixed quantity circulation with PID

#### **Sequential Diagram**

In this mode, the CFP2000 can control up to four motors to increase flow quantity and pressure range control. When controlling the flow quantity, the motors are in parallel connection. When controlling the pressure range, the motors are in series connection.

To increase the flow quantity or pressure range, the CFP2000 increases the first motor's pressure from 0 Hz to the largest operating frequency. If the output frequency reaches the frequency setting for Pr.12-06 and delay time for Pr.12-05, the CFP2000 delays the time setting for Pr.12-03. CFP2000 then switches to the next motor to use mains electricity and delays the time setting for Pr.12-03 to run the next motor. If necessary, other motors are activated in sequence. See sequential diagram of 12-3 and 12-4.




Diagram 12-3: Sequence of Fixed quantity circulation with PID – Increasing Demand




Diagram 12-4: Sequence of switching motors at Fixed Quantity Circulation with PID

— Increasing Demands

However, if the decreasing demands for flow quantity and pressure are too big, the CFP2000 stops the current operating motors and waits for the delay time setting for Pr.12-04. It continues doing this until the last motor stops using mains electricity. See sequential diagram 12-5 and 12-6 below.




Diagram 12-5: Sequence of Fixed Quantity Circulation with PID – Decreasing Demands




Diagram 12-6: Sequence of switching motors at Fixed Quantity Circulation with PID

— Decreasing Demands

### Parameter Setting

Parameter Setting	Description									
Pr.12-00 = 2	Choose Fixed Quantity Circulation with PID									
	connected the setting	Number of Motors: maximum four motors. After you set the number of motors to be connected at the same time, the multi-function output terminals automatically follow the setting as shown in the table below.								
	Pr.12-01 01 01 02 02 03 03 04 04 Pr.02-13 55 55 55 55 55 55 55 55 Motor 1 by Drive							Motor 1 by Drive		
	Pr.02-13	55	56	56	56	56	56	56	56	Motor 1 by Mains
Pr.12-01 = X	Pr.02-15			57	57	57	57	57	57	Motor 2 by Drive
	Pr.02-36				58	58	58	58	58	Motor 2 by Mains
	Pr.02-37					59	59	59	59	Motor 3 by Drive
	Pr.02-38						60	60	60	Motor 3 by Mains
	Pr.02-39							61	61	Motor 4 by Drive
	Pr.02-40								62	Motor 4 by Mains
	Table 2: Se	tting	of M	ulti-fu	ınctio	n Ou	tput <sup>-</sup>	Гегті	nal o	n Circulating Motors
Pr.12-03 = X	Delay Time	due	to th	e Acc	elera	ation	(or th	e Inc	reme	ent) at Motor Switching (unit: sec.)
Pr.12-04 = X	Delay Time	due	to th	e De	celer	ation	(or th	ne De	crem	nent) at Motor Switching (unit: sec.)
Pr.12-05 = X	Delay time	Delay time while Fixed Quantity Circulation at Motor Switching with PID (unit: sec.)								
Pr.12-06 = X	Frequency	Frequency when switching motors at Fixed Quantity Circulation (Hz)								
Pr.12-09 = X	Delay Time	for t	he ne	ext m	otor o	outpu	t whe	n the	e den	nand increases.

Disable Motor Output

Set the multi-function input commands to Disable Motors' Output can stop corresponding motors. The settings are:

Pr.02-01–Pr.02-06 =	60	61	62	63	64	65	66	67	68
Disable Motor's Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor coasts to stop.

Fixed Quantity Circulation with PID can control up to four motors. Diagram 12-7 below shows an example of controlling 4 motors.




Diagram 12-7

# Frequency when Switching Motors at Fixed Quantity Circulation (Hz)

Default: 60.00

Settings 0.0-599.00 Hz

Sets the drive's output frequency at which the system prepares to switch motors.

# 12-07 Action when Fixed Quantity Circulation Breaks Down

Default: 0

Settings 0: Turn off all output

1: Motors powered by mains electricity continues to operate

# 12-08 Frequency for Stopping Auxiliary Motor (Hz)

Default: 0.00

Settings 0.00–599.00 Hz

- When the output frequency is smaller than the Pr.12-08 and remains at the time setting for Pr.12-04, the CFP2000 shuts down the motors one by one.
- Fixed Quantity Control with PID
  In this mode, the CFP2000 can control up to eight motors to increase flow quantity and pressure range control.

The CFP2000 connects directly to a main motor while the rest of the motors use mains electricity and are controlled by a relay. When controlling flow quantity, the motors are in parallel connection. When controlling pressure range, the motors are in series connection.

To increase the flow quantity or pressure range, the CFP2000 increases the main motor's pressure from 0 Hz to the largest operating frequency. If necessary, the CFP2000 switches the motors to use mains electricity in sequence. See sequential diagram 12-8 and 12-9.




Diagram 12-8: Sequence of Fixed Quantity Control with PID - Increasing Demand




Diagram 12-9: Sequence of switching motors at Fixed Quantity Control with PID

— Increasing Demand

However, if the flow quantity or pressure is too large, the CFP2000 stops, one by one, the motors use mains electricity until the CFP2000 decreases the main motor's frequency to 0 Hz. See Diagram 12-10 and Diagram 12-11.




Diagram 12-10: Sequence of Fixed Quantity Control with PID – Decreasing Demand




Diagram 12-11: Sequence of switching motors at Fixed Quantity Control with PID

— Decreasing Demand

### Parameter setting:

Parameter Setting	Description									
Pr.12-00 = 3	Choose Fixed Quantity Control									
Pr.12-01 = X	Number of	Moto mult	rs: m	axim	um o	f eigl				Motor 3 by Mains Motor 5 by Mains Motor 5 by Mains Motor 6 by Mains Motor 7 by Mains Motor 7 by Mains Motor 8 by Mains
<b>-</b>										n Circulating Motors
Pr.12-05 = X	Delay time	for F	ixed	Quar	itity C	Circul	ation	at M	otor S	Switching (seconds)
Pr.12-06 = X	Frequency	for s	witch	ing m	notors	at F	ixed	Quar	ntity C	Circulation (Hz)

Disable Motor's Output

Set the multi-function input commands to Disable Motors' Output can stop the corresponding motors.

### The settings are:

Pr.02-01–Pr.02-06 =	60	61	62	63	64	65	66	67	68
Disable Motor's Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor coasts to stop.

Wiring: Fixed Quantity Control can control up to eight motors. Diagram 12-12 is an example of controlling four motors at the same time.




Diagram 12-12

Fixed Time circulation and Fixed quantity circulation with PID

This mode combines Fixed Time Circulation and Fixed Quantity Circulation with PID. This is to prevent motors from becoming rusty if they are not in use for a long period of time. If some motors are not activated, set the fixed time circulation to run the motors one by one to make sure each of them is running.

If all the motors are running and the water pressure is sufficient, the fixed time circulation is not enabled. If motor 1 and motor 2 run to reach a balance in water pressure and the time reaches the setting for Pr.12-02, motor 1 runs without using mains electricity (runs by the motor drive) and motor 2 decelerates to stop.

When the motor 2 reaches the frequency setting at Pr.12-06 and the time setting for Pr.12-05, it separates from the motor drive (runs on mains electricity). When time reaches the setting for Pr.12-03, motor 2 runs using the mains electricity. Then when the time exceeds the setting for Pr.12-03, motor 3 is enabled by the motor drive. The time sequence Diagram 12-13 is shown as below.




Diagram 12-13 Fixed Time Circulation and Fixed Quantity Control with PID

Fixed Time Circulation and Fixed Quantity Control with PID

This mode combines Fixed Time Circulation and Fixed Quantity Control with PID. This is to prevent motors from becoming rusty if they are not in use for a long period of time. If some motors are not activated, set the fixed time circulation to run the motors one by one to make sure each of them is running.

When all the motors are running and water pressure is sufficient, the fixed time circulation is not enabled. If motor 1 and motor 2 reach a balance in water pressure and when the time reaches the setting for Pr.12-02, motor 1 operates without mains electricity (run by the motor drive). When the time reaches the setting for Pr.12-03, motor 3 operates with mains electricity, and the operating time of each motor resets. Once it reaches the time setting for Pr.12-02 again, motor 2 runs without mains electricity. When the time reaches the setting for Pr.12-03, motor 4 runs with mains electricity. The time sequence Diagram 12-14 is as shown below




Diagram 12-14: Fixed Time Circulation under Fixed Amount Control Balance

# Fixed Quantity Circulation Output Delay

Default: 1.0

Settings 1.0-3600.0 sec.

Under Fixed Quantity Circulation (Increment) mode, the first motor of the drive switches to the supply mains through the setting time for Pr.12-03, then switches to the second motor through the setting delay time for Pr.12-09.




Diagram 12-15 Sequence of Output Delay for Fixed Quantity Circulation

12-10	Motor 1 Operation Record (min. /sec.)
12-12	Motor 2 Operation Record (min. /sec.)
12-14	Motor 3 Operation Record (min. /sec.)
12-16	Motor 4 Operation Record (min. /sec.)
12-18	Motor 5 Operation Record (min. /sec.)
12-20	Motor 6 Operation Record (min. /sec.)
12-22	Motor 7 Operation Record (min. /sec.)
12-24	Motor 8 Operation Record (min. /sec.)

Default: Read only

	Settings	Read only
2-11	Motor 1	Operation

12-11	Motor 1 Operation Record (hour)
12-13	Motor 2 Operation Record (hour)
12-15	Motor 3 Operation Record (hour)
12-17	Motor 4 Operation Record (hour)
12-19	Motor 5 Operation Record (hour)
12-21	Motor 6 Operation Record (hour)

12-23	Motor 7	Operation	Record	(hour)
12-25	Motor 8	Operation	Record	(hour)

Default: Read only

### Settings Read only

- These parameters record the operation time for Motor 1 to Motor 8. For examples, Pr.12-10 and Pr.12-11 both record the operation time for Motor 1. Pr.12-10 records the operation time in minutes and seconds, whereas Pr.12-11 records the operation time in hours. When Pr.12-10 displays 5959, it means the motor has operated for 59 minutes and 59 seconds. When the motor operates for an hour, Pr.12-11 displays 1 and Pr.12-10 displays 0.
- When circulation control Pr.12-00 = 1–5, the output frequency is > 0 Hz and output current is > 0 A, the motor operation time is recorded.
- When the record reaches the upper limit 65535 hours 59 minutes and 59 seconds, clear the motor operation time manually to keep tracking the operation status of each motor, and the service life of the motor.

Motor No. /			Clear
Motor Operation Time	Hour	Min./Sec.	Motor Operation Time
	Pr.12-11 = 65535	Pr.12-10 = 5959	
Motor 1	<b>\</b>	$\downarrow$	Pr.12-26=1
	65535 hour	59 min.: 59 sec.	
Motor 2	Pr.12-13	Pr.12-12	Pr.12-26=2
Motor 3	Pr.12-15	Pr.12-14	Pr.12-26=3
Motor 4	Pr.12-17	Pr.12-16	Pr.12-26=4
Motor 5	Pr.12-19	Pr.12-18	Pr.12-26=5
Motor 6	Pr.12-21	Pr.12-20	Pr.12-26=6
Motor 7	Pr.12-23	Pr.12-22	Pr.12-26=7
Motor 8	Pr.12-25	Pr.12-24	Pr.12-26=8
All motors	N/A	N/A	Pr.12-26=10

# **12-26** Clear Motor's Operation Time

Default: 0

Settings 0: No function

1: Clear operation time for motor 1

2: Clear operation time for motor 2

3: Clear operation time for motor 3

4: Clear operation time for motor 4

5: Clear operation time for motor 5

6: Clear operation time for motor 6

7: Clear operation time for motor 7

8: Clear operation time for motor 8

10: Clear operation time for all motors

Clear the operation time for single motor or all motors as needed.

- 1: The operation time for Motor 1 returns to zero, including operation records in Pr.12-11 (hour) and Pr.12-10 (min. /sec.).
- 10: The operation time for Motor 1–8 (Pr.12-10–Pr.12-25) all return to zero.

### **12-27** Priority for Circulated Operation

Default: 0

Settings 0: Terminal order

1: Minimum operation time

- Terminal order: the multi-function output terminals corresponded to each circulation control mode (Pr.12-00 = 1–5).
- Minimum operation time: starts in the order from the motor with the minimum operating hours among all running motors.
- The minimum operation time is only applicable for operation time record under fixed time circulation mode (Pr.12-00 = 1), as listed in the circulation mode comparison table below.
- A comparison for each circulation mode

Function / Circulation Control Mode	Pr.12-00 = 1	Pr.12-00 = 2-5
Motor operation time record	V	V
Terminal order	V	V
Minimum operation time	V*1	х

**NOTE:** \* When the drive resumes and starts running after stopping (or turning off) after operating for a period of time, the motor operates according to the minimum operation time. However, the first operating motor after resuming is the previous running motor before stop or turn-off. If you need to start the motors according to the minimum operation time in sequence immediately after resuming, close the minimum operation time (Pr.12-27 = 0) first and start (Pr.12-27 = 1) again.

- When Pr.12-00 = 1–5, the terminal order (Pr.12-27 = 0) is applicable for the operation time record under all the circulated control modes.
- When Pr.12-00 = 2–5, the terminal order (Pr.12-27 = 0) is the only available selection, and the minimum operation time (Pr.12-27 = 1) is invalid.
- When the minimum operation time (Pr.12-27 = 1) is enabled, the drive sorts the operation hours according to the amount of running motors at the moment, and then choose the motor that has the minimum operation hour to start after RUN command.

As Example 1 below shows, the drive starts Motor 2, which having a minimum operation time among all eight motors.

As Example 2 below shows, Motor 8 does not start though it has the minimum operation time, because only Motor 1 to Motor 5 are started. Moreover, if more than one motors have the same minimum operation hour, the number of the motor takes the priority. Therefore, Motor 3 starts rather than Motor 5.

# Chapter 12 Description of Parameter Settings | CFP2000

# Motor operation time-Example 1

Motor No. / Motor Status	Status	Operating Hour	Operating Min./ Sec.
Motor 1	ON	0	59 59
Motor 2	ON	0	12 12
Motor 3	ON	2	00 00
Motor 4	ON	0	43 11
Motor 5	ON	1	33 00
Motor 6	ON	3	50 05
Motor 7	ON	1	05 22
Motor 8	ON	10	20 21

# Motor operation time-Example 2

Motor No. / Motor status	Status	Operating Hour	Operating Min./ Sec.
Motor 1	ON	0	59 59
Motor 2	ON	5	12 12
Motor 3	ON	0	33 00
Motor 4	ON	0	43 11
Motor 5	ON	0	33 00
Motor 6	OFF	3	50 05
Motor 7	OFF	1	05 22
Motor 8	OFF	0	00 01

# 13 Application Parameters by Industry

✓ You can set this parameter during operation.

# 13-00 Industry-Specific Parameter Application

Default: 0

Settings 0: Disabled

1: User-defined Parameter

2: Compressor IM

3: Fan

4: Pump

10: Air Handling Unit, AHU

After you select the macro,	some of the default	values adjust	automatically	according to the	ne
application selection.					

- Each setting varies with different application selection, and its value is different as well.
- Refer to Section 10-2 for more operation details.
- ☐ Group settings: 2: Compressor IM

The following table lists the relevant compressor application parameters.

Pr.	Explanation	Settings
00-11	Speed control mode	0: VF (IM V/F control)
00-16	Load selection	0: Light load
00-17	Carrier frequency	Default setting
00-20	Master frequency command source (AUTO)	2: External analog input
00-20	/ Source selection of the PID target	2. External analog input
00-21	Operation command source (AUTO)	1: External terminals.
00-22	Stop method	0: Ramp to stop
00-23	Control of motor direction	1: Disable reverse
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default setting
01-02	Output voltage of motor 1	Default setting
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-11	Output frequency lower limit	20 (Hz)
01-12	Acceleration time 1	20 (s)
01-13	Deceleration time 1	20 (s)
03-00	Analog input selection (AVI1)	0: No function
03-01	Analog input selection (ACI)	1: Frequency command
05-01	Full-load current for induction motor 1 (A)	Default setting
05-03	Rated speed for induction motor 1 (rpm)	Default setting

Pr.	Explanation	Settings
05-04	Number of poles for induction motor 1	Default setting

### ☐ Group setting 03: Fan

The following table lists the relevant fan setting application parameters.

Pr.	Explanation	Settings
00-11	Speed control mode	0 (V/F control)
00-16	Load selection	0: Light load
00-17	Carrier frequency	Default setting
00-20	Master frequency command source (AUTO) / Source selection of the PID target	2: External analog input
00-21	Operation command source (AUTO)	1: External terminals.
00-22	Stop method	1: Coast to stop
00-23	Control of Motor Direction	1: Disable reverse
00-30	Master frequency command (HAND) source	0: Digital keypad
00-31	Operation command (HAND) source	0: Digital keypad
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default setting
01-02	Output voltage of motor 1	Default setting
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-10	Output frequency upper limit	50 (Hz)
01-11	Output frequency lower limit	35 (Hz
01-12	Acceleration time 1	15 (s)
01-13	Deceleration time 1	15 (s)
01-43	V/F curve selection	2: 2 <sup>nd</sup> V/F curve
02-05	Multi-function input command 5 (MI5)	16: Rotating speed command from ACI
03-00	Analog input selection (AVI1)	1: Frequency command
03-01	Analog input selection (ACI)	1: Frequency command
03-28	AVI1 terminal input selection	0 (0–10 V)
03-29	ACI terminal input selection	1 (0–10 V)
03-31	AFM output selection	0 (0–10 V)
03-50	Analog input curve selection	1: three-point curve of AVI1
07-06	Restart after momentary power loss	Speed tracking by minimum output frequency
07-11	Number of times of restart after fault	5 (times)
07-33	Auto-restart interval of fault	60 (s)

### ☐ Group setting 04: Pump

The following table lists the relevant pump setting application parameters.

Pr.	Explanation	Settings
00-11	Speed control mode	0 (V/F mode)
00-16	Load selection	0: Light load
00-20	Master frequency command source (AUTO)	2: External analog input
00 20	/ Source selection of the PID target	2. External analog input
00-21	Operation command source (AUTO)	1: External terminals.
00-23	Control of motor direction	1: Disable reverse
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default setting
01-02	Output voltage of motor 1	Default setting
01-03	Mid-point frequency 1 of motor 1	Default setting
01-04	Mid-point voltage 1 of motor 1	Default setting
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-10	Output frequency upper limit	50 (Hz)
01-11	Output frequency lower limit	35 (Hz)
01-12	Acceleration time 1	15 (s)
01-13	Deceleration time 1	15 (s)
01-43	V/F curve selection	2: 2 <sup>nd</sup> V/F curve
07-06	Postart after memortary newer loss	2: Speed tracking by minimum output
07-00	Restart after momentary power loss	frequency
07-11	Number of times of restart after fault	5 (times)
07-33	Auto-restart interval of fault	60 (s)

### Group setting 10: Air Handling Unit, AHU

The following table lists the relevant AHU setting application parameters.

Pr.	Explanation	Settings	
00-04	Content of multi-function display	2	
00-11	Speed control mode	0 (V/F control)	
00-16	Load selection	0: Light load	
00-20	Master frequency command source (AUTO)	2 or 0 (External analog input)	
00-20	/ Source selection of the PID target	2 of 6 (External analog input)	
00-21	Operation command source (AUTO)	1 or 0 (External terminals)	
00-22	Stop method	1: Coast to stop	
00-23	Control of motor direction	1: Disable reverse	
00-30	Master frequency command (HAND) source	0: Digital keypad	
00-31	Operation command (HAND) source	0: Digital keypad	

Chapter 12 Description of Parameter Settings | CFP2000

Pr.	Explanation	Settings
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default setting
01-02	Output voltage of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-10	Output frequency upper limit	50 (Hz)
01-11	Output frequency lower limit	35 (Hz)
01-34	Zero-speed mode	2
01-43	V/F curve selection	2: 2 <sup>nd</sup> V/F curve
02-05	Multi-function input command 5 (MI5)	16 or 17
02-13	Multi-function output 1 RLY1	11
02-14	Multi-function output 2 RLY2	1
03-00	Analog input selection (AVI1)	1
03-01	Analog input selection (ACI)	1: Frequency command
03-02	Analog input selection (AVI2)	1: Frequency command
03-28	AVI1 terminal input selection	0 (0–10 V)
03-29	ACI terminal input selection	1 (0–10 V)
03-20	Multi-function output 1 (AFM1)	0
03-23	Multi-function output 2 ( AFM2 )	0
03-31	AFM1 current selection	0 or 1
03-34	AFM2 current selection	0 or 1
03-50	Analog input curve selection	4
07-06	Restart after momentary power loss	2 (Speed tracking by minimum output frequency)
07-11	Number of times of restart after fault	5 (times)
07-33	Auto-restart interval of fault	60 (s)

13-01	
12.00	

# Application Parameter 1–99

Default: 0.00

Settings 0.00–655.35

# **14 Extension Card Parameters**

	✓ You can set this parameter during operation
N	14-00 Extension Card Input Terminal Selection (Al10)
N	14-01 Extension Card Input Terminal Selection (AI11)
	Default: 0
	Settings 0: Disable
	1: Frequency command
	4: PID target value
	5: PID feedback signal
	6: Thermistor (PTC) input value
	11: PT100 thermistor input value
	13: PID compensation amount
	When the setting for Pr.14-00 and Pr.14-01 are the same, the Al10 is selected first.
N	14-08 Analog Input Filter Time (Al10)
N	14-09 Analog Input Filter Time (AI11)
	Default: 0.01
	Settings 0.00–20.00 sec.
	stability of the control. Use these input delays to filter a noisy analog signal.  When the setting for the time constant is too large, the control is stable but the control response is slow. When the setting for time constant is too small, the control response is faster but the control may be unstable. For optimal setting, adjust the setting according to the control stability or the control response.
	14-10 Analog Input 4–20 mA Signal Loss Selection (Al10)
	14-11 Analog Input 4–20 mA Signal Loss Selection (Al11)
	Default: 0
	Settings 0: Disable
	1: Continue operation at the last frequency
	2: Decelerate to 0 Hz
	3: Stop immediately and display ACE
	4: Operate with output frequency lower limit
	☐ This parameter determines the treatment when the 4–20 mA signal is lost, when Pr.14-18 = 2,
	Pr.14-19 = 2.
	When the setting for Pr.14-18 or Pr.14-19 are 0 or 1, the voltage input to AVI and ACI terminal is
	0–10 V or 4–20 mA. At this moment, Pr.14-10 and Pr.14-11 are invalid.
	☐ Setting 1, 2 or 4: When ACI loss, the keypad displays the warning code "ANL". If this parameter
	is set to 4, the drive operates with output frequency lower limit (Pr.01-11). It continues blinking
	until the lost ACI signal is recovered.
	When the motor drive stops, the warning condition does not continue to exist, so the warning disappears.

When the signal loss detection function is enabled and the analog input signal is lower than the

loss level 3.6 mA, the drive executes a loss alarm until the analog input signal is larger than the 4.0 mA recovery level, and the drive stops the alarm. Refer to the diagram in Pr.03-68.

14-12 Extension Card Output Terminal Selection (AO10)
 14-13 Extension Card Output Terminal Selection (AO11)

Default: 0

Settings 0–23

Refer to the function chart below for details setting.

### **Function Chart**

Settings	Functions		Descriptions		
0	Output frequency (Hz)	Maximum frequency P	Maximum frequency Pr.01-00 is processed as 100%.		
1	Frequency command (Hz)	Maximum frequency P	Maximum frequency Pr.01-00 is processed as 100%.		
2	Motor speed (Hz)	Maximum frequency Pr.01-00 is processed as 100%.			
3	Output current (rms)	(2.5 × rated current) is	processed as 100%		
4	Output voltage	(2 × rated voltage) is p	rocessed as 100%		
5	DC bus voltage	450V (900V)=100%			
6	Power factor	-1.000–1.000=100%			
7	Power	(2 × rated power) is pro	ocessed as 100%		
9	AVI1 proportional	0–10 V = 0–100%			
10	ACI proportional	4–20 mA = 0–100%			
11	AVI2 proportional	0–10 V = 0–100%			
		For CANopen communication analog output			
		Terminal	Corresponding Address		
20		AFM1	2026-A1		
20	CANopen analog output	AFM2	2026-A2		
		AO10	2026-AB		
		AO11	2026-AC		
	RS-485 analog output	For RS-485 (InnerCOM	M / Modbus) analog output		
		Terminal	Corresponding Address		
04		AFM1	26A0H		
21		AFM2	26A1H		
		AO10	26AAH		
		AO11	26ABH		
		For communication an	alog output (CMC-EIP01, CMC-		
		PN01, CMC-DN01)			
	Communication card	Terminal	Corresponding Address		
22	analog output	AFM1	26A0H		
	analog output	AFM2	26A1H		
		AO10	26AAH		
		AO11 26ABH			
23	Constant voltage output	Pr.14-20 and Pr.14-21 control voltage output level 0–100% of Pr.14-20 corresponds to 0–10 V of AO10. 0–100% of Pr.14-21 corresponds to 0–10 V of AO11.			

Analog Output 1 Gain (AO10)

A 14-15 Analog Output 1 Gain (AO11)

Default: 100.0

Settings 0.0-500.0%

Adjusts the voltage level outputted to the analog meter from the analog signal (Pr.14-12, Pr.14-13) output terminal AFM of the drive.

Analog Output 1 in REV Direction (AO10)

A 14-17 Analog Output 1 in REV Direction (AO11)


Default: 0

Settings 0: Absolute output voltage value

1: Reverse output 0 V; forward output 0-10 V

2: Reverse output 5-0 V; forward output 5-10 V

Determines the voltage reverse output when AO10 and AO11 are set as 0-10 V (Pr.14-36 = 0, Pr.14-37 = 0).



# 14-18 Extension Card Input Selection (AI10)

Default: 0

Settings 0: 0–10 V (AVI10)

1: 0-20 mA (ACI10)

2: 4-20 mA (ACI10)

14-19 Extension Card Input Selection (AI11)

Default: 0

Settings 0: 0–10 V (AVI11)

1: 0-20 mA (ACI11)

2: 4-20 mA (ACI11)

When you change the input mode, verify that the switch position of external terminal (Al10, Al11) is correct.

AO10 DC Output Setting Level

★ 14-21 AO11 DC Output Setting Level

Default: 0.00

Settings 0.00-100.00%

# Chapter 12 Description of Parameter Settings | CFP2000

×	14-22	AO10 Fi	ilter Output Time		
×	14-23	AO11 Fi	Iter Output Time		
				Default: 0.01	
		Settings	0.00-20.00 sec.		
×	14-36	AO10 O	utput Selection		
×	14-37	AO11 Output Selection			
				Default: 0	
		Settings	0: 0–10 V		
			1: 0–20 mA		
			2: 4–20 mA		

# 12-2 Adjustment & Application


The followings are abbreviations for different types of motors:

- IM: Induction motor
- PM: Permanent magnet synchronous AC motor
- IPM: Interior permanent magnet synchronous AC motor
- SPM: Surface permanent magnet synchronous AC motor
- SynRM: Synchronous reluctance motor

### 12-2-1 Permanent Magnet Motor Space Vector Control (PM SVC) Pr.00-11 = 2


### 12-2-1-1 Control Diagram

PM SVC control diagram



### 12-2-1-2 PM SVC Adjustment Procedure

- (\* The number marked on the procedure corresponds to the number of following adjustment explanations)
- (1) PM SVC motor parameters adjustment



#### Motor Parameters Adjustment

1. Parameter reset:

Reset Pr.00-02 = 10 (60 Hz) to the default value.

2. Select PM motor type:

Pr.05-33 = 1 (SPM) or 2 (IPM)

3. Motor nameplate parameter setting:

Parameter	Description	
Pr.01-01	Rated frequency (Hz)	
Pr.01-02	Rated voltage (V <sub>AC</sub> )	
Pr.05-34	Rated current (A)	
Pr.05-35	Rated power (kW)	
Pr.05-36	Rated rotor speed (rpm)	
Pr.05-37	Number of poles for the motor (poles)	

### 4. PM parameter auto-tuning:

Set Pr.05-00 = 5 (Rolling auto-tuning for PM) or 13 (Static auto-tuning for PM) and press "RUN" key to finish motor auto-tuning, then you will get the following parameters:

Parameter	Description		
Pr.05-39	Stator resistance for a permanent magnet motor (Ω)		
Pr.05-40	Permanent magnet motor Ld (mH)		
Pr.05-41 Permanent magnet motor Lq (mH)			
Pr.05-43	Ke parameter of a permanent magnet motor (V <sub>phase · rms</sub> / krpm)  (When Pr.05-00 = 5, the Ke parameter is measured based on the actual motor rotation.)  (When Pr.05-00 = 13, the Ke parameter is automatically calculated based on the motor power, current and rotor speed.)		

If an auto-tuning error (AUE) occurs, refer to Section 14 "Fault Codes and Descriptions" for further treatment.

AUE Error (code)	Description
AUE (40)	Auto-tuning error
AUE1 (142)	Auto-tuning error 1 (No feedback current error)
AUE2 (143)	Auto-tuning error 2 (Motor phase loss error)

#### 5. Set control mode

Control mode for the motor: Pr.00-11 = 2: PM SVC mode


- 6. Re-power the drive after powering off.
- 7. Measure the initial magnetic pole angle of PM

Set Pr.10-53 PM initial rotor position detection method

- 0: Disable
- 1: Using I/F current command (Pr.10-31) to attract the rotor to zero degrees
- 2: High frequency injection
- 3: Pulse injection

(Set to 2 for IPM; set to 3 for SPM. If these settings cause problems, then set the parameter to 1.)

### (2) PMSVC Adjustment for Operation without Load / with Light-load




- Adjustment for Operation with Light-load
  - 8. Start the motor with no-load / light-load, and operates to 1/2 of the rated rotor speed A1. Start operation direction:
    - a. If the start operation direction is wrong
       SPM: increase the current proportion for Pr.10-42 (Initial angle detection pulse value) to improve the accuracy of the angle detection.
      - IPM: Increase the voltage for Pr.10-52 (Injection magnitude) to improve the accuracy of the angle detection.
    - b. If an ocA error occurs when pressing RUN to start the motor, decrease the current proportion for Pr.10-42 (Initial angle detection pulse value). An excessive pulse current may cause ocA error easily.
  - A2. Operates the motor in 1/2 of the rated rotor speed, adjust the no-load operating current If the no-load operating current exceeds 20% of the rated current, increase Pr.07-26 (Torque compensation gain) and observe the no-load operating current.
  - A3. Accelerate to rated frequency and observe if the motor operates stably.
    - a. If the motor output rotor speed presents periodic low-frequency wave, increase Pr.10-34 (PM sensorless speed estimator low-pass filter gain), or increase Pr.10-32 (PM FOC sensorless speed estimator bandwidth).
    - b. If the output frequency reflects high frequency vibration, decrease Pr.10-34 or decrease Pr.10-32.
  - A4. Accelerate the motor to the maximum rotor speed and observe if it operates stably.

    If the motor stalls when accelerating to the maximum rotor speed, then increase Pr.10-34

    PM Sensorless Speed Estimator Low-pass Filter Gain, or increase Pr.00-17 Carrier

    Frequency (you must set the carrier frequency larger than 10 times of the maximum output frequency)

### (3) PM SVC Carrier Start-up Adjustment



#### Heavy Load Operation Adjustment

- 9. Load operating test
- B1. Low-frequency loading performance is below 1/10 of rated frequency:
  - a. If the low-frequency loading performance is insufficient, or the rotor speed is not smooth, increase Pr.10-31 (Current command of I/F mode).
  - b. If the low-frequency current is large, decrease Pr.10-31 (Current command of I/F mode).
- B2. Test the with-load accelerating performance:

When the motor operates in 1/10 of rotor speed and above, if the speed cannot follow the acceleration time during accelerating, or the current stalls, increase Pr.07-38 (PMSVC voltage feedback forward gain).

- 10. Stability test at constant speed operation: if the motor operates stably at constant speed
  - a. If the motor output rotor speed presents periodic low-frequency wave, increase Pr.10-34 (PM sensorless speed estimator low-pass filter gain), or increase Pr.10-32 (PM FOC sensorless speed estimator bandwidth).
  - b. If the output frequency reflects high frequency vibration, decrease Pr.10-34 or decrease Pr.10-32.

#### 12-2-1-3 PMSVC Related Parameters


Refer to Section 12-1 Description of Parameter Settings for more details.

Parameter	Description	Unit	Default	Settings					
Pr.07-24	Torque command filter time		0.5	0.001–10					
Pr.07-26	Torque compensation gain	N/A	0	0–5000					
Pr.07-38	PMSVC voltage feedback forward gain		1.0	0.5–2.0					
Pr.10-31	10-31 I/F mode, current command		40	0–150					
Pr.10-32	.10-32 PM FOC sensorless speed estimator bandwidth		5.00	0.00-600.00					
Pr.10-34	PM sensorless speed estimator low-pass filter gain	N/A	1.00	0.00-655.35					
Pr.10-39	Frequency point to switch from I/F mode to PM sensorless mode	Hz	20.00	0.00-599.00					
Pr.10-40	Frequency point to switch from PM sensorless mode to V/F mode	Hz	20.00	0.00-599.00					
Initial Angle Estimating Parameters									
Pr.10-42	Initial angle detection pulse value	N/A	1.0	0.0-3.0					
Pr.10-51	Injection frequency	Hz	500	0–1200					
Pr.10-52	Injection magnitude		15.0 / 30.0	0.0–200.0					
Pr.10-53	PM initial rotor position detection method 0: Disable 1: Using I/F current command (Pr.10-31) to attract the rotor to zero degrees 2: High frequency injection 3: Pulse injection	N/A	0	0–3					

12-2-2 PM Sensorless Adjustment (Pr.00-11 = 6)

## 12-2-2-1 Control Diagram


PM Sensorless FOC mode (applicable for CFP2000 V1.07 and above)



**NOTE:** PM Sensorless FOC control is the control method dedicated for PM; it uses the high salient pole characteristic of PM to detect positions of NS magnetic poles. By doing this, it calculates the motor's rotor position at low-speed frequency.

#### 12-2-2 PM Sensorless FOC Control Adjustment

- (X The number marked on the procedure corresponds the number of following explanations)
- (1) Adjustment for PM Sensorless FOC Mode Motor Parameters



#### Motor Parameters Adjustment

1. Parameter reset:

Pr.00-02 = 10, reset parameter to the default value.

2. Select motor type:

Pr.05-33 = 1 or 2 (SPM or IPM)

3. Motor nameplate parameter setting:

Parameter	Description	
Pr.01-01	Rated frequency (Hz)	
Pr.01-02	Rated voltage (V <sub>AC</sub> )	
Pr.05-34	Rated current (A)	
Pr.05-35	Rated power (kW)	
Pr.05-36	Rated rotor speed (rpm)	
Pr.05-37	Number of motor poles (poles)	
Pr.05-38	System inertia for PM (kg-cm²)	

#### 4. PM parameter auto-tuning:

Set Pr.05-00 = 5 [Rolling auto-tuning for PM (without load)] or 13 (Static auto-tuning for PM), and press "RUN" key to finish motor auto-tuning, then you get the following parameters:

Parameter	Description		
Pr.05-39	Stator resistance for a permanent magnet motor ( $\Omega$ )		
Pr.05-40	Permanent magnet motor Ld (mH)		
Pr.05-41	Permanent magnet motor Lq (mH)		
Pr.05-43	Ke parameter of a permanent magnet motor (V <sub>phase · rms</sub> / krpm) (When Pr.05-00 = 5, the Ke parameter is measured based on the actual motor rotation.) (When Pr.05-00 = 13, the Ke parameter is automatically calculated based on the motor power, current and rotor speed.)		

If an auto-tuning error (AUE) occurs, refer to Section 14 "Error Codes and Descriptions" for further treatment.

AUE Fault (code)	Description	
AUE (40)	Auto-tuning error	
AUE 1 (142)	Auto-tuning error 1 (no feedback current error)	
AUE 2 (143)	Auto-tuning error 2 (motor phase loss error)	

### 5. Set control mode

Set Pr.00-11 = 6 PM Sensorless FOC control mode


- 6. After auto-tuning, cycle the power.
- 7. Measure the initial magnetic pole angle of PM

Set Pr.10-53 PM initial rotor position detection method:


- 0: Disable
- 1: Using I/F current command (Pr.10-31) to attract the rotor to zero degrees
- 2: High frequency injection
- 3: Pulse injection

(Set "2" for IPM; set "3" for SPM; set "1" when setting "2" and "3" are not enough)

#### (2) PM Sensorless FOC Mode - No load / Light-load Adjustment




- No-load / Light-load Operation Adjustment
  - 8. Start the motor without load
    - (1) Set Pr.11-00 = 1 Auto-tuning for ASR and APR
    - (2) Start the motor without load, and operates the motor to 1/2 of rated rotor speed
      - A1. If the start direction is wrong or starting rotation is not smooth (ocA), adjust system inertia (Pr.11-01). When the Ke parameter (Pr.05-43) is < 25 V, increase the current command of I/F mode (Pr.10-31) or switch the frequency from I/F mode to PM Sensorless mode (Pr.10-39, Pr.10-40).
      - A2. If the motor starts up with a reverse direction, but operates with a correct direction, adjust injection magnitude (Pr.10-52) when using High frequency injection to detect the PM initial rotor position (Pr.10-53 = 2); increase initial angle detection pulse value (Pr.10-42) to improve the accuracy of angle detection when using Pulse injection to detect the PM initial rotor position (Pr.10-53 = 3).
  - 9. Acceleration test with no-load / light-load
    - A3. Accelerate the motor to the rated frequency, and check if it operates stably.
    - a. If the motor output frequency presents steady state speed wave, increase ASR2 high-speed bandwidth (Pr.11-04) or Per-unit of system inertia (Pr.11-01).
    - b. If the motor output frequency presents large fluctuations or diverges, increase the magnetic flux linkage estimate high-speed gain (Pr.10-55) or decrease the Kp of phase-locked loop (Pr.10-56).
    - A4. Accelerate the motor to the maximum frequency, and check if it operates stably. If the motor stalls at the maximum operation speed, increase the magnetic flux linkage estimate high-speed gain (Pr.10-55) and the carrier frequency (Pr.00-17), or decrease the Kp of phase-locked loop (Pr.10-56).
    - Setting curve for speed regulator (ASR) and related parameters:



ASR adjustment- auto gain

Parameter	Description	Default
Pr.11-00	System control	0
Pr.11-01	Per-unit of system inertia	256
Pr.11-02	ASR1 / ASR2 switch frequency (set the switch frequency > Pr.10-39)	7 Hz
Pr.11-03	ASR1 low-speed bandwidth	10 Hz
Pr.11-04	ASR2 high-speed bandwidth	10 Hz
Pr.11-05	Zero-speed bandwidth	10 Hz

#### (3) PM Sensorless FOC Mode - Load Starting Adjustment



- Load Operation Adjustment and Steady State Adjustment at Constant Speed
  - 11. Load operation test
    - B1. Low-frequency carrier capacity test (the output frequency is < 20% of rated speed):
      - a. If the frequency switch from I/F mode to PM Sensorless is zero (Pr.10-39 = 0 Hz), increase the magnetic flux linkage estimate low-speed gain (Pr.10-54).
      - b. If the output frequency is less than the frequency switch from I/F mode to PM Sensorless (Pr.10-39), increase the current command of I/F mode (Pr.10-31).
    - B2. Carrier capacity test during acceleration

In heavy load operation, accelerate the motor to rated speed according to the acceleration time:

If the motor responds too slowly or an over current occurs during the acceleration, increase Ki phase-locked loop (Pr.10-57).

- 12. Steady state test at constant speed, check if the motor operates stably at constant speed.
  - a. If the motor's output frequency presents periodic low-frequency wave, increase PM sensorless speed estimator low-pass filter gain (Pr.10-34), or adjust the ASR parameters.
  - b. If the motor's output frequency presents extreme vibration, decrease PM sensorless speed estimator low-pass filter gain (Pr.10-34) or Kp phase-locked loop (Pr.10-56).

## 12-2-2-3 PM Sensorless FOC Mode Adjustment Parameters

Refer to Section 12-1 Description of Parameter Settings for more details.


Parameter	Description	Unit	Default	Settings
Pr.10-31	I/F mode, current command		40	150
Pr.10-34	PM sensorless speed estimator low-pass filter gain	NA	1.00	0.00-655.35
Pr.10-39	Frequency to switch from I/F mode to PM sensorless mode	Hz	20.0	0.0–599.0
Pr.10-40	Frequency to switch from PM sensorless mode to I/F mode	Hz	20.0	0.0–599.0
Pr.10-54	Magnetic flux linkage estimate low-speed gain (applied to 230V / 460V models)	%	100	10–1000
Pr.10-55	Magnetic flux linkage estimate high-speed gain (applied to 230V / 460V models)	%	100	10–1000
Pr.10-56	Kp of phase-locked loop (applied to 230V / 460V models)	%	100	10–1000
Pr.10-57	.10-57 Ki of phase-locked loop (applied to 230V / 460V models)		100	10–1000
	Initial Angle Estimating Parameters			
Pr.10-42	Initial angle detection pulse value	NA	0.5	0.0-3.0
Pr.10-51	Injection frequency (applicable when Pr.10-53 = 2)	Hz	500	0–1200
Pr.10-52	Injection magnitude (applicable when Pr.10-53 = 2)	>	15.0/30.0	0.0–200.0
Pr.10-53	PM initial rotor position detection method 0: Disable	NA	0	0–3

# Chapter 12 Description of Parameter Settings | CFP2000

Parameter	Description	Unit	Default	Settings
	1: Force attracting the rotor to zero degrees			
	2: High frequency injection			
	3: Pulse injection			
	Motor Performance Control Parameter	s		
Pr.11-00	System control	bit	0	0–8
Pr.11-02	ASR1 / ASR2 switch frequency	Hz	7.0	5.0-599.0
Pr.11-03	ASR1 low-speed bandwidth	Hz	10	1–100 (PM) 1–40 (IM)
Pr.11-04	ASR2 high-speed bandwidth	Hz	10	1–100 (PM) 1–40 (IM)
Pr.11-05	Zero-speed bandwidth	Hz	10	1–100 (PM) 1–40 (IM)


# 12-2-3 SynRM FOC Sensorless Vector Control Mode (SynRM Sensorless) Pr.00-11 = 8 12-2-3-1 Control diagram

SynRM Sensorless (applied to CFP2000 V1.07 and above)



### 12-2-3-2 SynRM Sensorless Adjustment Procedure

- (\* The number marked on the procedure corresponds to the number of following explanations)
- (1) Adjustment for SynRM Sensorless Parameters



#### **Chapter 12 Description of Parameter Settings | CFP2000**

#### Motor Parameters Adjustment

1. Parameter reset:

Pr.00-02 = 9 (50 Hz) or 10 (60 Hz), reset parameter to the default value

2. Select motor type:

Pr.05-33 = 3 (SynRM)

3. Motor nameplate parameter setting:

Parameter	Description	
Pr.01-01	Rated frequency (Hz)	
Pr.01-02	Rated voltage (V <sub>AC</sub> )	
Pr.05-34	Rated current (A)	
Pr.05-35	Rated power (kW)	
Pr.05-36	Rated rotor speed (rpm)	
Pr.05-37	Number of motor poles (poles)	

4. Motor parameter auto-tuning:

Set Pr.05-00 = 11 [SynRM parameter auto-tuning (without load)] and press "RUN" key to finish motor auto-tuning, then you get the following parameters:

Parameter	Description	
Pr.05-39	Stator resistance for a permanent magnet motor (Ω)	
Pr.05-40	Permanent magnet motor Ld (mH)	
Pr.05-41	Permanent magnet motor Lq (mH)	

5. Set control mode:


Set Pr.00-11 = 8 (SynRM Sensorless)

6. After auto-tuning, cycle the power.

#### (2) SynRM Sensorless No-load Adjustment Procedure



- No-load Operation Adjustment
  - 7. Start the motor without load
    - A1. Start the motor without load, refer to the following adjustment before the operation frequency reaches 1/5 or motor's rated frequency:
      - a. If the motor starts in a wrong direction, the starting rotation is not smooth (ocA) or there is motor shaft lock, adjust Pr.10-31 (I/F current command) and Pr.10-33 (PM FOC sensorless low-speed estimator bandwidth).
      - b. When there is an extreme vibration of the motor speed, adjust Pr.11-01 (Per-unit of system inertia) and Pr.11-03 (ASR1 low-speed bandwidth) depending on whether the motor departs from the load.
      - Setting curve for speed regulator (ASR) and related parameters:




ASR adjustment- auto gain

Parameter	Description	
Pr.11-00	System control	201h
Pr.11-01	Per-unit of system inertia	256
Pr.11-02	ASR1 / ASR2 switch frequency (set the switch frequency > 1/5 of motor's rated frequency)	10 Hz
Pr.11-03	ASR1 low-speed bandwidth	5 Hz
Pr.11-04	ASR2 high-speed bandwidth	5 Hz
Pr.11-05	Zero-speed bandwidth	5 Hz

- A2. The operation frequency exceeds the switch frequency for Pr.10-39
  - a. If there is an extreme vibration of speed and current when switching frequency, or a fault occurs during the switching process, adjust Pr.10-56 (Kp of phase-locked loop).
  - b. Both of adjustments for Pr.10-55 (Magnetic flux linkage estimate high-speed gain) and Pr.10-56 (Kp of phase-locked loop) affect the performance of the speed estimator. Adjust only Pr.10-56 in no-load operation.
  - c. When there is a low-frequency vibration of speed during motor's operation, adjust Pr.11-01 (Per-unit of system inertia) and Pr.11-04 (ASR2 high-speed bandwidth) depending on whether the motor departs from the load.
- A3. Observe whether the motor operates stably when accelerates to the maximum frequency

If the motor stalls at the maximum operation speed, decrease Pr.10-56 (Kp phase-locked loop)

#### (3) SynRM Sensorless Start-up with Load Adjustment



#### Load Operation Adjustment

- 8. Operation test with load
  - B1. Low-frequency loading capacity test
    - a. If the low-frequency loading performance is low, increase Pr.10-31 (I/F mode current command) and Pr.10-58 (mutual inductance compensation gain).
    - b. If the low-frequency loading speed presents large plummet, or the output frequency presents low-frequency vibration, adjust Pr.11-03 (ASR1 low-speed bandwidth) and Pr.10-33 (PM FOC sensorless speed estimator bandwidth). Increase the setting to improve the response when the speed drops too much at transient load. Decrease the setting if the frequency presents an extreme vibration at stable load.

## B2. High frequency loading capacity test

- a. If the high frequency loading performance is insufficient, increase Pr.10-55 (Magnetic flux linkage estimate high-speed gain) and Pr.10-56 (Kp of phase-locked loop).
- b. If there is large plummet of loading speed, or the output frequency vibrates, adjust Pr.11-04 (ASR2 high-speed bandwidth), Pr.10-55 (Magnetic flux linkage estimate high-speed gain) and Pr.10-56 (Kp of phase-locked loop). Increase the setting to improve the response when the speed drops too much at transient load. Decrease the setting if the frequency presents an extreme vibration at stable load.

#### B3. Operation frequency exceeds the rated frequency

When there is a waveform of speed and current in the flux-weakening zone, and an oc or ov fault occurs during the deceleration, adjust Pr.01-51 (Flux-weakening overload stall prevention time) and Pr.10-31 (I/F mode current command).

## 12-2-3-3 SynRM Sensorless Mode Adjustment Parameters

Refer to Section 12-1 Description of Parameter Settings for more details.

Parameter	Description	Unit	Default	Settings
00-11	Speed control mode		0	0–8
00-17	Carrier frequency	kHz	4	4–8
01-51	Flux-weakening overload stall prevention time	sec.	1.00	0.00-600.00
05-00	Motor parameter auto-tuning		0	0–13
05-33	Induction motor or permanent magnet synchronous AC motor selection		3	0–3
05-34	Full-load current for a permanent magnet synchronous AC motor / reluctance motor	Amps	NA	NA
05-35	Rated power for a permanent magnet synchronous AC motor / reluctance motor	kW	NA	0–655.35
05-36	Rated speed for a permanent magnet synchronous AC motor / reluctance motor	rpm	NA	0–65535
05-37	Number of poles for a permanent magnet synchronous AC motor / reluctance motor		NA	0–65535
05-38	System inertia for a permanent magnet synchronous AC motor / reluctance motor	kg-cm <sup>2</sup>	NA	0.0–6553.5
05-39	Stator resistance for a permanent magnet synchronous AC motor / reluctance motor	ohm	0.000	0.000–65.535

Parameter	Description	Unit	Default	Settings
05-40	Permanent magnet synchronous AC motor / reluctance motor Ld	mH	0.00	0.00–655.35
05-41	Permanent magnet synchronous AC motor / reluctance motor Lq	mH	0.00	0.00–655.35
07-12	Speed tracking during start-up		0	0–3
10-08	Treatment for speed observer feedback fault		2	0–2
10-09	Detection time of speed observer feedback fault	sec.	1.0	0.0–10.0
10-10	Speed observer stall level	%	115	0–120
10-11	Detection time of speed observer stall	sec.	0.1	0.0–2.0
10-12	Speed observer stall action		2	0–2
10-13	Speed observer slip range	%	50	0–0
10-14	Detection time of speed observer slip	sec.	0.5	0.0-10.0
10-15	Speed observer stall and slip error action		2	0–2
10-31	I/F mode, current command	%	15	0–150
10-33	PM FOC sensorless speed estimator bandwidth (low speed)		1.00	0.01–3.00
10-34	PM sensorless speed estimator low-pass filter gain		1.00	0.00-10.00
10-35	AMR (Kp) gain		0.4	0.00-3.00
10-36	AMR (Ki) gain		2.00	0.00-3.00
10-39	Frequency to switch from I/F mode to PM sensorless mode	Hz	10.00	0.0–599.00
10-51	Injection frequency	Hz	400	0–1200
10-52	Injection magnitude	%	30	10–50
10-55	PM initial rotor position detection method		1.0	0.1–3.0
10-56	Kp of phase-locked loop	Hz	10	5–50
10-58	Mutual inductance gain compensation		1.00	0.00-655.35
11-00	System control		0x201h	0–65535
11-01	Per-unit of system inertia	pu	256	0–65535
11-02	ASR1 / ASR2 switch frequency	Hz	10.00	5.00-599.00
11-03	ASR1 low-speed bandwidth	Hz	5	1–30
11-04	ASR2 high-speed bandwidth	Hz	5	1–30
11-05	Zero-speed bandwidth	Hz	5	1–30
11-17	Forward motor torque limit Quadrant I	%	200	0–500
11-18	Forward regenerative torque limit Quadrant II	%	200	0–500
11-19	Reverse motor torque limit Quadrant III	%	200	0–500
11-20	Reverse regenerative torque limit Quadrant IV	%	200	0–500

[This page is intentionally left blank]

# Chapter 13 Warning Codes

# **Summary of Warning Codes**

ID No.	Warning Name	ID No.	Warning Name
0	No record	49	Keypad RTC time-out (PLrt)
1	Communication error 1 (CE1)	50	PLC opposite defect (PLod)
2	Communication error 2 (CE2)	51	PLC save memory error (PLSv)
3	Communication error 3 (CE3)	52	Data defect (PLdA)
4	Communication error 4 (CE4)	53	Function defect (PLFn)
5	Communication error 10 (CE10)	54	PLC buffer overflow (PLor)
7	Save error 1 (SE1)	55	Function defect (PLFF)
8	Save error 2 (SE2)	56	Checksum error (PLSn)
9	IGBT overheating warning (oH1)	57	No end command (PLEd)
10	Board-level component overheat warning (oH2)	58	PLC MCR error (PLCr)
11	PID feedback error (PID)	59	PLC download fail (PLdF)
12	ACI analog signal loss (AnL)	60	PLC scan time fail (PLSF)
13	Under current (uC)	61	CAN/M guarding error (PCGd)
17	Over speed warning (oSPd)	62	CAN/M BUS off (PCbF)
18	Deviation Warning (dAvE)	63	CAN/M node lack (PCnL)
20	Over-torque 1 (ot1)	64	CAN/M cycle time-out (PCCt)
21	Over-torque 2 (ot2)	65	CAN/M SDO over (PCSF)
22	Motor overheating (oH3) PTC / PT100	66	CAN/M SDO time-out (PCSd)
24	Over slip error (oSL)	67	CAN/M address error (PCAd)
25	Auto tuning (tUn)	68	CAN/M time-out (PCTo)
28	Output phase loss (OPHL)	70	ExCom ID fail (ECid)
30	Copy model error 3 (SE3)	71	ExCom power loss (ECLv)
36	CANopen guarding time-out (CGdn)	72	ExCom test mode (ECtt)
37	CANopen heartbeat error (CHbn)	73	ExCom BUS off (ECbF)
39	CANopen bus off error (CbFn)	74	ExCom no power (ECnP)
40	CANopen index error (Cldn)	75	ExCom factory defect (ECFF)
41	CANopen station address error (CAdn)	76	ExCom inner error (ECiF)
42	CANopen memory error (CFrn)	77	ExCom IO Net break (ECio)
43	CANopen SDO time-out (CSdn)	78	ExCom Parameter data error (ECPP)
44	CANopen SDO receives register overflow (CSbn)	79	ExCom configuration data error (ECPi)
46	CANopen format error (CPtn)	80	Ethernet link fail (ECEF)
47	RTC adjust (PLrA)	81	Communication time-out (ECto)
48	InnerCOM error (PLiC)	82	Checksum error (ECCS)
84	Modbus TCP over (Eco0)	92	Copy PLC: Write mode (CPL1)

ID No.	Warning Name	ID No.	Warning Name
85	EtherNet/IP over (ECo1)	93	Copy PLC: version error (CPLv)
86	IP fail (ECiP)	94	Copy PLC: size error (CPLS)
87	Mail fail (EC3F)	95	Copy PLC: PLC function (CPLF)
88	ExCom busy (ECbY)	96	Copy PLC: time-out (CPLt)
89	ExCom card break (ECCb)	101	InrCOM time-out (ictn)
90	Copy PLC: password error (CPLP)	105	Estimated speed reverse (SpdR)
91	Copy PLC: Read mode error (CPL0)	123	Deceleration energy backup (dEb)
83	Return defect (ECrF)		



- ① Display error signal
- 2 Abbreviate error code
- 3 Display error description

ID No.	Display on LCD Keypad	Warning Name	Description	
1	Warning CE1 Comm. Error 1	Communication error 1 (CE1)	RS-485 Modbus illegal function code	
		Action and	Reset	
	Action Condition	When the function code	is not 03, 06, 10 and 63	
	Action Time	Immediately act		
War	ning Setting Parameter	N/A		
Reset Method		"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct function code.		
Reset Condition		Immediately reset		
Record		N/A		
Cause			Corrective Actions	
Incorrect communication command from upper unit		Check if the communication command is correct.		
Malfunct interfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	t communication setting upper unit	Check if the setting for Pr.09-04 is the same as the setting for the upper unit.		
Disconn of the ca	ection or bad connection	Check the cable and replace it if necessary.		

Display on LCD Keypad	Warning Name	Description		
Аито Warning CK1 Comm Command Er	command error 1	Keypad communication data, illegal function code (Keypad auto-detects this error and displays it.)		
	Action and Reset			
Action Condition	When the function code is not 03, 06, 10 and 63			
Action Time	Immediately act			
Warning Setting Parameter	N/A			
Reset Method	Remove the keypad and then reconnect it to the motor drive.			
Reset Condition	Immediately reset			
Record	N/A			

Cause	Corrective Actions	
Incorrect communication	Keypad and the motor drive don't communicate properly. It is recommended to	
command from keypad	remove the keypad and then reconnect it to the motor drive.	
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.	
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.	
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.	

ID No.	Display on LCD Keypad	Warning Name	Description	
2	Warning CE2 Comm. Error 2	Communication error 2 (CE2)	RS-485 Modbus illegal data address	
		Action and	l Reset	
	Action Condition	When the input data ad	dress is incorrect	
	Action Time	Immediately act		
War	ning Setting Parameter	N/A		
Reset Method		"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct data address.		
Reset Condition		Immediately reset		
Record		N/A		
Cause			Corrective Actions	
Incorrect communication command from upper unit		Check if the communication command is correct.		
Malfunctinterfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	ent communication setting Check if the setting for Pr.09-04 is the same as the setting for the upper unit		Pr.09-04 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable		Check the cable and replace it if necessary.		

Display on LCD Keypad	Warning Name	Description	
Warning CK2 Comm Address Er	Communication address error (CK2)	Keypad communication data, illegal data address (Keypad auto-detects this error and displays it.)	
	Action and	d Reset	
Action Condition	When the input data address is incorrect		
Action Time	Immediately act		
Warning Setting Parameter	N/A		
Reset Method	Remove the keypad and then reconnect it to the motor drive.		
Reset Condition	Immediately reset		
Record	N/A		
Cause	Corrective Actions		
Incorrect communication	Keypad and the motor drive don't communicate properly. It is recommended to		
command from keypad	remove the keypad and then reconnect it to the motor drive.		

Cause	Corrective Actions
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.

ID No.	Display on LCD Keypad	Warning Name	Description	
3	Warning CE3 Comm. Error 3	Communication error 3 (CE3)	RS-485 Modbus illegal data value	
		Action and	d Reset	
	Action Condition	When the length of com	munication data is too long	
	Action Time	Immediately act		
Warı	ning Setting Parameter	N/A		
Reset Method		"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct communication data value.		
Reset Condition		Immediately reset		
Record		N/A		
Cause			Corrective Actions	
Incorrect communication command from upper unit		Check if the communication command is correct.		
Malfunct interfere	Verify the wiring and grounding of the communication circuit. It is recomme to separate the communication circuit from the main circuit, or wire in 90 do for effective anti-interference performance.		nication circuit from the main circuit, or wire in 90 degree	
	t communication setting upper unit	Check if the setting for Pr.09-04 is the same as the setting for the upper unit.		
Disconnection or bad connection of the cable  Check the cable and replace it if necessary.		place it if necessary.		

Display on LCD Keypad	Warning Name	Description	
Аито Warning CK3 Comm Data Error	Communication data error (CK3)	Keypad communication data, illegal data value (Keypad auto-detects this error and displays it.)	
	Action and	d Reset	
Action Condition	When the length of communication data is too long		
Action Time	Immediately act		
Warning Setting Parameter	N/A		
Reset Method	Remove the keypad and then reconnect it to the motor drive.		
Reset Condition	Immediately reset		
Record	N/A		
Cause	Corrective Actions		
Incorrect communication	Keypad and the motor drive don't communicate properly. It is recommended to		
command from keypad	remove the keypad and then reconnect it to the motor drive.		

Cause	Corrective Actions
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.

ID No.	Display on LCD Keypad	Warning Name	Description	
4	Warning CE4 Comm. Error 4	Communication error 4 (CE4)	RS-485 Modbus data is written to read-only address	
		Action and	l Reset	
	Action Condition	When the data is writter	n to read-only address	
	Action Time	Immediately act		
Warı	ning Setting Parameter	N/A		
Reset Method		"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct written address of communication data.		
Reset Condition		Immediately reset		
Record		N/A		
Cause			Corrective Actions	
Incorrect communication command from upper unit		Check if the communication command is correct.		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication setting from the upper unit Check if the setting for Pr.09-04 is the same as the setting for the		Pr.09-04 is the same as the setting for the upper unit.		
Disconnection or bad connection of the cable and replace it if is necessary.		place it if is necessary.		

Display on LCD Keypad	Warning Name	Description	
Warning  CK4  Comm Slave Error	Communication slave error (CK4)	Keypad communication data is written to read-only address. (Keypad auto-detects this error and displays it.)	
Action and Reset			
Action Condition	When the data is written to read-only address		
Action Time	Immediately act		
Warning Setting Parameter	N/A		
Reset Method	Remove the keypad and then reconnect it to the motor drive.		
Reset Condition	Immediately reset		
Record	N/A		

Cause	Corrective Actions
Incorrect communication command from keypad	Keypad and the motor drive don't communicate properly. It is recommended to remove the keypad and then reconnect it to the motor drive. If the problem persists after reconnecting the keypad, pay attention to the motor drive status. For example: Motor drive might reset to default setting during operation or while enabling PLC function.
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.
Disconnection or bad connection of the cable	Check the cable and replace it if is necessary.

ID No.	Display on LCD Keypad	Warning Name	Description			
5	Warning CE10 Comm. Error 10	Communication error 10 (CE10)	RS-485 Modbus transmission time-out			
		Action and	Reset			
	Action Condition	When the communication communication time-out	time exceeds the detection time of Pr.09-03			
	Action Time	Setting for Pr.09-03				
Warı	ning Setting Parameter	N/A				
"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps runni drive resets automatically when receiving the next communication pa						
	Reset Condition	Immediately reset				
	Record	N/A				
Cause Corrective Actions						
the com	per unit does not transmit munication command r.09-03 setting time	Check if the upper unit transmits the communication command within the setting time for Pr.09-03.				
Malfunct interfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.				
	t communication setting upper unit	Check if the setting for Pr.09-04 is the same as the setting for the upper unit.				
Disconn of the ca	ection or bad connection	Check the cable and replace it if necessary.				

Display on LCD Keypad	Warning Name	Description		
Аито Warning CK10 KpdComm Time Out	Keypad communication time out (CK10)	Keypad communication data, transmission time-out (Keypad auto-detect this error and display it.)		
	Action and	d Reset		
Action Condition	When the communication time exceeds the detection time of Pr.09-03 communication time-out			
Action Time	Setting for Pr.09-03			
Warning Setting Parameter	N/A			
Reset Method	Remove the keypad and then reconnect it to the motor drive.			
Reset Condition	Immediately reset			
Record	N/A			

Cause	Corrective Actions
Incorrect communication	Keypad and the motor drive don't communicate properly. It is recommended to
command from keypad	remove the keypad and then reconnect it to the motor drive.
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.

ID No.	Display on LCD Keypad	Warning Name	Description			
7	Warning SE1 Save Error 1	Save error 1 (SE1)	Keypad COPY error 1: Keypad copy time-out			
		Action and	d Reset			
		"SE1" warning occurs w	then the keypad does not transmit the COPY command			
	Action Condition	to the drive, and does n	ot transmit any data to the drive again in 10 ms at the			
		time you copy the parameters to the drive.				
	Action Time 10 ms					
War	ning Setting Parameter	N/A				
	Reset Method	Manual reset				
	Reset Condition	Immediately reset				
	Record	N/A				
	Cause		Corrective Actions			
Commu	nication connection error	SE1: The causes of error are mostly communication problems between the				
		keypad and control board. Potential causes include communication signal				
Keypad	error	interference and the una	acceptable communication command to the Slave.			
		Check if the error occurs randomly, or only occurs when copying certain				
Control I	board error	parameters (the error displays on the upper right corner of the copy page). If				
		you cannot clear the error, contact Delta.				

ID No.	Display on LCD Keypad	Warning Name	Description		
8	Warning SE2 Save Error 2	Save error 2 (SE2)	Keypad COPY error 2: parameter writing error		
		Action and	d Reset		
		"SE2" warning occurs w	hen writing the parameters incorrectly at the time you		
	Action Condition	copy parameters to the	drive. For example, you copy the new firmware version		
		with added parameters	to the drive with old firmware version.		
	Action Time	N/A			
War	ning Setting Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Immediately reset			
	Record N/A				
	Cause		Corrective Actions		
		SE2: In this stage, the copied data has been transmitted to the Slave.			
		The Slave compares and processes the copied data, and then saves the data			
		to the Data ROM. During the process, the data error (should be attribution			
Add nev	v parameters to the new	error) may occur, or the data cannot be saved to EEPROM. At this time, the			
firmware	e version.	warning occurs.			
		It is suggested to check the status of Data ROM and remove the error causes			
		first.			
		If you cannot clear the error, contact Delta.			
Malfunc	tion caused by	Verify the wiring and grounding of the main circuit, control circuit and the			
interference encoder for effective anti-interference performance.					

ID No.	Display on LCD Keypad	Warning Name	Description			
9	Warning OH1 Over heat 1 warn	IGBT overheating warning (oH1)	The AC motor drive detects overheating of IGBT, and over the protection level of oH1 warning. (When Pr.06-15 is higher than the IGBT over-heating level, the drive shows oH1 error without displaying oH1 warning.)			
		Action and	, , , ,			
	Action Condition	Pr.06-15				
	Action Time	"oH1" warning occurs w	hen IGBT temperature is higher than Pr.06-15 setting			
Warı	ning Setting Parameter	N/A				
	Reset Method	Auto-reset				
	Reset Condition	The drive auto-resets w minus (–) 5°C.	The drive auto-resets when IGBT temperature is lower than oH1 warning level			
	Record	N/A				
	Cause	Corrective Actions				
or tempe is too hiç obstructi	the ambient temperature erature inside the cabinet gh, or if there is ion in the ventilation hole ontrol cabinet.	Change the installer resistors, in the surrent control of the	ne ventilation hole of the control cabinet.  d place if there are heating objects, such as braking			
	there is any obstruction eat sink or if the fan is	Remove the obstruction or replace the cooling fan.				
Insufficie	ent ventilation space	Increase ventilation space of the drive.				
	the drive matches the onded loading	<ol> <li>Decrease loading.</li> <li>Decrease the carrie</li> <li>Replace with a drive</li> </ol>	er. e with larger capacity.			
	e has run 100% or more of d output for a long time	of Replace with a drive with larger capacity.				

ID No.	Display on LCD Keypad	Warning Name	Description	
10	Warning  oH2 Over heat 2 warn	Board-level overheat warning (oH2)	The drive has detected overheat of the board-level component	
		Action and	l Reset	
	Action Condition	oH2 error level minus (-	-) 5°C	
	Action Time	The oH2 warning occur higher than oH2 warnin	s when the board-level component temperature is g level	
Warr	ing Setting Parameter	N/A		
	Reset Method	Auto-reset		
		The drive auto-resets w than oH2 error level mir N/A	hen the board-level component temperature is lower nus (–) 10°C	
	Cause	Corrective Actions		
or tempe is too hig obstruction	the ambient temperature rature inside the cabinet h, or if there is on in the ventilation hole ntrol cabinet.	<ol> <li>Check the ambient temperature.</li> <li>Regularly inspect the ventilation hole of the control cabinet.</li> <li>Change the installed place if there are heating objects, such as braking resistors, in the surroundings.</li> <li>Install / add cooling fan or air conditioner to lower the temperature inside the cabinet.</li> </ol>		
	there is any obstruction eat sink or if the fan is	Remove the obstruction	or replace the cooling fan.	
Insufficie	nt ventilation space	Increase ventilation spa	ce of the drive.	
Check if the drive matches the corresponded loading		<ol> <li>Decrease loading.</li> <li>Decrease the carrier.</li> <li>Replace with a drive with larger capacity.</li> </ol>		
The drive has run 100% or more of Replace with a drive with larger capacity.			h larger capacity.	
Unstable	power	Install reactor(s).		
The load	changes frequently	Reduce the changes of the load.		

oH1/ oH2 warning level

Model	oH1	oH2	oH warning oH1 warning = (Pr. 06-15)
VFD007FP2EA-41/52/52S	440		
VFD015FP2EA-41/52/52S	110		-114 Wessiss
VFD022FP2EA-41/52/52S		85	oH1 Warning = Pr.06-15
VFD037FP2EA-41/52/52S	100		oH2 Warning = oH2 – 5
VFD055FP2EA-41/52/52S			

Model	oH1	oH2	oH warning oH1 warning = (Pr. 06-15)
VFD075FP2EA-41/52/52S			orri warming (i i. oo io)
VFD110FP2EA/41/52/52S	105	90	
VFD150FP2EA-41/52/52S			
VFD185FP2EA-41/52/52S	95	97	
VFD220FP2EA-41/52/52S			
VFD300FP2EA-41/52/52S	100	90	
VFD370FP2EA-41/52/52S			
VFD450FP2EA-41/52/52S	95	85	
VFD007FP4EA-41/52/52S	440		
VFD015FP4EA-41/52/52S	110		
VFD022FP4EA-41/52/52S			
VFD037FP4EA-41/52/52S		85	
VFD040FP4EA-41/52/52S	100		
VFD055FP4EA-41/52/52S			
VFD075FP4EA-41/52/52S			
VFD110FP4EA-41/52/52S			
VFD150FP4EA-41/52/52S	105	90	
VFD185FP4EA-41/52/52S			
VFD220FP4EA-41/52/52S	105	90	
VFD300FP4EA-41/52/52S	110	97	oH1 Warning = Pr.06-15
VFD370FP4EA-41/52/52S	110	97	oH2 Warning = oH2 – 5
VFD450FP4EA-41/52/52S	100	90	
VFD550FP4EA-41/52/52S	100	90	
VFD750FP4EA-41/52/52S	95	85	
VFD900FP4EA-41/52/52S	95	65	
VFD015FP5EA-41/52/52S	110		
VFD022FP5EA-41/52/52S			
VFD037FP5EA-41/52/52S	100	85	
VFD055FP5EA-41/52/52S	100		
VFD075FP5EA-41/52/52S			
VFD110FP5EA-41/52/52S			
VFD150FP5EA-41/52/52S	105	90	
VFD185FP5EA-41/52/52S			
VFD220FP5EA-41/52/52S			
VFD300FP5EA-41/52/52S	110	97	
VFD370FP5EA-41/52/52S			
VFD450FP5EA-41/52/52S	100	90	
VFD550FP5EA-41/52/52S	100		
VFD750FP5EA-41/52/52S	95	85	
VFD900FP5EA-41/52/52S			

Unit: °C

ID No.	Display on LCD Keypad	Warr	ning Name	Description	
11	Warning PID PID FBK Error		edback error (PID)	PID feedback loss (warning for analog feedback signal; works only when PID enables)	
			Action and	l Reset	
	Action Condition	When the	e analog input i	s lower than 4 mA (only detects analog input of 4–20	
	Action Condition	mA)			
	Action Time	Pr.08-08			
		Pr.08-09			
		0: Warn and keep operation			
Warı	ning Setting Parameter	1: Fault and ramp to stop			
		2: Fault and coast to stop			
		3: Warn and operate at last frequency			
	Reset Method	"Warning" occurs when Pr.08-09 = 0 or 3. The "Warning" automatically clears when the feedback signal is larger than 4 mA.			
		Manual "Error" occurs when Pr.08-09 = 1 or 2. You must reset manually.			
	Reset Condition	Immediat	tely reset		
	Record	Records	when Pr.08-09	= 1 or 2 ("Error").	
	Record	Does not	record when F	Pr.08-09 = 3 ("Warning").	
	Cause			Corrective Actions	
Loose or	r broken PID feedback	Tighten the terminals again.			
wiring		Replace with a new cable.			
Feedbac	ck device malfunction	Replace with a new feedback device.			
Hardwar	re error	If the PID error still occurs after checking all the wiring, return to the factory for repair.			

ID No.	Display on LCD Keypad	Warr	ning Name	Description			
12	Warning ANL Analog loss	ACI anal		Analog input current loss (including all analog 4–20 mA signals)			
			Action and	l Reset			
	Action Condition	When the	e analog input i	s lower than 4 mA (only detects analog input 4–20 mA)			
	Action Time	Immedia	tely act				
		Pr.03-19					
		0: Disable					
War	ning Setting Parameter	1: Continue operation at the last frequency (warning, keypad displays ANL)					
		2: Decelerate to 0 Hz (warning, keypad displays ANL)					
		3: Stop immediately and display ACE					
		"Warning" occurs when Pr.03-19 = 1 or 2. The "Warning automatical					
	Reset Method	Auto clears when the		ne analog input signal is larger than 4 mA.			
		Manual "Error" occurs when Pr.03-19 = 3. You must reset manually.					
	Reset Condition	Immedia	tely reset				
	Record	Does not	record when F	Pr.03-19 = 1 or 2 ("Warning").			
	Cause			Corrective Actions			
	n broken ACI wining	Tighten the terminals again.					
Loose o	Loose or broken ACI wiring		Replace with a new cable.				
External	I device error	Replace new device.					
Hardwa	re error	If the AnL	error still occu	urs after checking all the wiring, return to the factory for			

ID No.	Display on LCD Keypad	Warr	ning Name	Description
13	Warning  uC  Under Current	Und	er current (uC)	Low current
			Action and	d Reset
	Action Condition	Pr.06-71		
	Action Time	Pr.06-72		
		Pr.06-73 0: No fun	ction	
War	ning Setting Parameter	1: Fault and coast to stop		
		2: Fault and ramp to stop by the second deceleration time		
		3: Warn and operation continue		
Reset Method		Auto "Warning" occurs when Pr.06-73 = 3. The "Warning" automatically clears when the output current is > (Pr.06-71 + 0.1 A).		
		Manual "Error" occurs when Pr.06-73 = 1 and 2. You must reset manually.		
	Reset Condition	Immedia	tely reset	
	Record	Does not	record when F	Pr.06-73 = 3 and uC displays "Warning".
	Cause	Corrective Actions		
Broken	motor cable	Exclude the connection issue of the motor and its load.		
	er setting for the low protection	Set the proper settings for Pr.06-71, Pr.06-72 and Pr.06-73.		
Low load	d	Check the loading status.		
LOW IDA	u	Make sure the loading matches the motor capacity.		

ID No.	Display on LCD Keypad	Warning Name	Description	
17	Warning oSPD Over Speed Warn	Over speed warning (oSPd)	Over speed warning	
		Action and	d Reset	
	Action Condition	The encoder feedback	speed > Pr.10-10	
	Action Time	Pr.10-11		
10/		Pr.10-12 = 0		
vvari	ning Setting Parameter	0: Warn and keep operation		
Reset Method		"Warning" automatically clears when the drive stops		
Reset Condition		"Warning" automatically clears when the drive stops		
Record		N/A		
	Cause	Corrective Actions		
Improper bandwidth setting for		Increase the bandwidth setting for ASR speed controller.		
ASR speed controller				
Incorrec	t motor parameter setting	Reset motor parameter	and run parameter tuning.	
Malfunct	tion caused by	Verify wiring of the control circuit, and wiring/grounding of the main circuit to		
interfere	nce	prevent interference.		

ID No.	Display on LCD Keypad	Warning Name	Description		
18	Warning  dAvE  Deviation Warn	Deviation Warning (dAvE)	Over speed deviation warning		
		Action and Reset			
	Action Condition	Pr.10-13			
	Action Time	Pr.10-14			
Warr	ning Setting Parameter	Pr.10-15 = 0			
vvaii	iing Setting Farameter	0: Warn and keep opera	ation		
	Reset Method	"Warning" automatically	clears when the drive stops		
	Reset Condition	After the drive stops	After the drive stops		
	Record	N/A			
Cause		Corrective Actions			
Improper parameter setting for the slip error		Reset proper value for Pr.10-13 and Pr.10-14.			
Improper setting for ASR parameter and acceleration/ deceleration		Reset ASR parameters.  Set proper accel./ decel. time.			
Accel./ D	ecel. time is too short	Reset proper accel./ decel. time.			
Motor lo	cked	Remove the causes of motor locked.			
Mechani	cal brake is not released	Check the active timing of the system.			
Incorrect	parameter setting of				
torque lir	nit	Adjust to proper setting value.			
(Pr.06-12	2, Pr.11-17–20)				
Malfunction caused by Ve		Verify wiring of the control circuit, and wiring / grounding of the main circuit to			
interfere	nce	prevent interference.			

ID No.	Display on LCD Koypad	Warning Name	Description	
ID NO.	Display on LCD Keypad	warning Name	Description	
20	Warning ot1 Over Torque 1	Over-torque 1 (ot1)	Over-torque 1 warning	
		Action and	d Reset	
	Action Condition	Pr.06-07		
	Action Time	Pr.06-08		
		Pr.06-06 = 1 or 3		
		0: No function		
		1: Continue operation a	fter over-torque detection during constant speed	
War	ning Setting Parameter	operation		
		2: Stop after over-torqu	e detection during constant speed operation	
		3: Continue operation a	fter over-torque detection during RUN	
		4: Stop after over-torqu	e detection during RUN	
	Reset Method	When input current < (F	Pr.06-07 – 5%), the Ot1 warning automatically clears	
	Reset Condition	When input current < (Pr.06-07 – 5%), the Ot1 warning automatically clears		
	Record	N/A		
	Cause		Corrective Actions	
Incorrect parameter setting Configure the settings for Pr.06-07 and Pr.06-08 again.		or Pr.06-07 and Pr.06-08 again.		
Mechanical error (e.g. mechanical lock due to over-torque)		Remove the causes of malfunction.		
The lead	d in too lorge	Decrease the loading.		
The load	d is too large	Replace with a motor with larger capacity.		
Accel./ Decel. time and working cycle is too short		Increase the setting values for Pr.01-12–01-19 (accel./ decel. time)		
		Adjust the settings for Pr.01-01-08 (V/F curve), especially the setting value		
V/F volta	age is too high	for the mid-point voltage (if the mid-point voltage is set too small, the load		
		capacity decreases at low-speed).		
The mot	tor capacity is too small	Replace with a motor w	ith larger capacity.	
Over-loa	ad during low-speed	Decrease the loading d	uring low-speed operation.	
operatio	n	Increase the motor capa	acity.	
The torc	ue compensation is too	Adjust the torque compensation value (Pr.07-26 torque compensation gain)		
large		until the output current	decreases and the motor does not stall.	
Imprope	r parameter settings for	Correct the personator	cattings for speed tracking	
the spee	ed tracking function	•	settings for speed tracking.	
(includin	ng restart after momentary	Start the speed tracking		
power loss and restart after fault)		Adjust the maximum current for Pr.07-09 speed tracking.		

ID No.	Display on LCD Keypad	Warning Name	Description	
21	Warning ot2 Over Torque 2	Over-torque (ot2)	Over-torque 2 warning	
		Action and	d Reset	
	Action Condition	Pr.06-10		
Action Time		Pr.06-11		
Warning Setting Parameter		Pr.06-09 = 1 or 3  0: No function  1: Continue operation after over-torque detection during constant speed operation  2: Stop after over-torque detection during constant speed operation  3: Continue operation after over-torque detection during RUN  4: Stop after over-torque detection during RUN		
	Reset Method	When output current < (	(Pr.06-10 – 5%), the Ot2 warning automatically clears	
	Reset Condition	When output current < (	(Pr.06-10 – 5%), the Ot2 warning automatically clears	
	Record	N/A		
	Cause	Corrective Actions		
Incorrect	t parameter setting	Configure the settings for Pr.06-10 and Pr.06-11.		
Mechanical error (e.g. mechanical lock due to over-torque)		Remove the causes of malfunction.		
The load	l is too large	Decrease the loading.  Replace with a motor with larger capacity.		
	Decel. time and working too short	Increase the setting values for Pr.01-12–01-19 (accel./ decel. time)		
V/F volta	age is too high	Adjust the V/F curve (Motor 2, Pr.01-35–01-42), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed).		
The mot	or capacity is too small	Replace with a motor w	ith larger capacity.	
Over-loa	nd during low-speed	Decrease the loading d	uring low-speed operation.	
operatio	n	Increase the motor capa	acity.	
The torq	ue compensation is too	Adjust the torque comp	ensation value (Pr.07-26 torque compensation gain) until	
large		the output current decre	eases and the motor does not stall.	
Improper parameter settings for the speed tracking function (including restart after momentary power loss and restart after fault)		Start speed tracking fur	settings for speed tracking. action. rrent for Pr.07-09 speed tracking.	

ID No.	Display on LCD Keypad	Warning Name	Description	
22_1	Warning  OH3  Motor Over Heat	Motor over-heating (oH3) PTC	Motor over-heating warning.  The AC motor drive detects the temperature inside the motor is too high	
	Action and Reset		d Reset	
	Action Condition	Pr.03-00 = 6 (PTC), PTC input level > Pr.06-30 (default = 50%)		
	Action Time	Immediately act		
		Error treatment: Pr.06-2	29	
		0: Warn and keep operating		
		1: Fault and ramp to sto	рр	
\\/or	ning Cotting December	2: Fault and coast to sto	рр	
vvar	ning Setting Parameter	3: No warning		
		When Pr.06-29 = 0 and	when the temperature is ≤ Pr.06-30 level, the oH3	
		warning automatically c	lears.	
		When Pr.06-29 = 0 ("Wa	arning"), it automatically resets.	
	Dood Mathad	When Pr.06-29 = 0, oH	3 displays "Warning". When the temperature is ≤ Pr.06-	
	Reset Method	30 level, the oH3 warnir	ng automatically clears.	
	Reset Condition	When the temperature i	is ≤ Pr.06-30 level, the oH3 warning automatically clears.	
	Record	N/A		
Cause Corrective Actions				
	Cause		Corrective Actions	
Motor Io		Clear the motor lock sta	-	
	ocked	Clear the motor lock sta	-	
			atus.	
The load	d is too large	Decrease the loading. Replace with a motor w	atus.	
The load	ocked	Decrease the loading. Replace with a motor w Change the installed pla	ith larger capacity.	
The load	d is too large	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan o	ith larger capacity.  ace if there are heating devices in the surroundings.	
The load	d is too large temperature is too high	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan o	rith larger capacity.  ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature.	
The load Ambien Motor co	d is too large temperature is too high	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan c Check the cooling syste	atus.  with larger capacity.  ace if there are heating devices in the surroundings.  or air conditioner to lower the ambient temperature.  where the make it work normally.	
The load Ambien Motor co	d is too large temperature is too high	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan o Check the cooling syste Replace the fan.	eith larger capacity.  ace if there are heating devices in the surroundings.  or air conditioner to lower the ambient temperature.  em to make it work normally.	
The load Ambien Motor co	temperature is too high cooling system error	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan o Check the cooling syste Replace the fan. Decrease low-speed op	atus.  with larger capacity.  ace if there are heating devices in the surroundings.  or air conditioner to lower the ambient temperature.  em to make it work normally.  peration time.  otor for the drive.	
Ambien  Motor co	temperature is too high cooling system error	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan o Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated modernease the motor capa	atus.  with larger capacity.  ace if there are heating devices in the surroundings.  or air conditioner to lower the ambient temperature.  em to make it work normally.  peration time.  otor for the drive.  acity.	
The load Ambien  Motor co  Motor fa  Operate  Accel./ [	temperature is too high cooling system error an error	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan o Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated modernease the motor capa	atus.  with larger capacity.  ace if there are heating devices in the surroundings.  or air conditioner to lower the ambient temperature.  em to make it work normally.  peration time.  otor for the drive.	
The load Ambien  Motor co  Motor fa  Operate  Accel./ [	temperature is too high cooling system error an error es at low-speed too long Decel. time and working	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan o Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated modernease the motor capa Increase setting values	atus.  with larger capacity.  ace if there are heating devices in the surroundings.  or air conditioner to lower the ambient temperature.  em to make it work normally.  peration time.  otor for the drive.  acity.	
Ambien  Motor co  Motor fa  Operate  Accel./ I  cycle is	temperature is too high cooling system error an error es at low-speed too long Decel. time and working	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan of Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated modernease the motor capa Increase setting values Adjust settings for Pr.01	atus.  with larger capacity.  ace if there are heating devices in the surroundings.  or air conditioner to lower the ambient temperature.  The method is the more and it work normally.  The peration time.  The otor for the drive.  The acity.  The peration time is a conditional properties of the drive.  The peration time is a conditional properties of the drive.  The peration time is a conditional properties of the drive.  The peration time is a conditional properties of the drive.  The peration time is a conditional properties of the drive.  The peration time is a conditional properties of the drive.  The peration time is a conditional properties of the drive.  The peration time is a conditional properties of the drive.  The peration time is a conditional properties of the drive is a conditional properties of the drive.  The peration time is a conditional properties of the drive is a conditional properties of the drive.  The peration time is a conditional properties of the drive is a conditional properties	
Ambien  Motor co  Motor fa  Operate  Accel./ I  cycle is	temperature is too high cooling system error an error es at low-speed too long Decel. time and working too short	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan of Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated modernease the motor capa Increase setting values Adjust settings for Pr.01	with larger capacity.  In acce if there are heating devices in the surroundings.  In air conditioner to lower the ambient temperature.  In accent to make it work normally.  In accent to the drive.  In accent to the drive to the drive to the drive.  In accent to the drive to the drive to the drive.  In accent to the drive to the drive to the drive to the drive to the drive.  In accent to the drive to the drive to the drive to the drive to the drive.  In accent to the drive to the	
The load Ambien  Motor co  Motor fa  Operate  Accel./ I  cycle is	temperature is too high cooling system error an error es at low-speed too long Decel. time and working too short	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan of Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated modern and Increase the motor capa Increase setting values Adjust settings for Pr.01 the mid-point voltage (if decreases at low-speed	ith larger capacity.  ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally.  peration time. otor for the drive. acity.  for Pr.01-12–01-19 (accel./ decel. time).  1-01–01-08 (V/F curve), especially the setting value for it the mid-point voltage is set too small, the load capacity it).	
Ambien  Motor co  Motor fa  Operate  Accel./ I  cycle is  V/F volta	temperature is too high cooling system error an error es at low-speed too long Decel. time and working too short age is too high	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan of Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated modern and Increase the motor capa Increase setting values Adjust settings for Pr.01 the mid-point voltage (if decreases at low-speed	with larger capacity.  In acce if there are heating devices in the surroundings.  In air conditioner to lower the ambient temperature.  In accent to make it work normally.  In accent to the drive.  In accent to the drive to the drive to the drive.  In accent to the drive to the drive to the drive.  In accent to the drive to the drive to the drive to the drive to the drive.  In accent to the drive to the drive to the drive to the drive to the drive.  In accent to the drive to the	
Ambien  Motor co  Motor fa  Operate  Accel./ I  cycle is  V/F volta  Check if matches	temperature is too high cooling system error an error es at low-speed too long Decel. time and working too short age is too high	Decrease the loading. Replace with a motor w Change the installed pla Install/ add cooling fan of Check the cooling syste Replace the fan. Decrease low-speed op Change to dedicated modernease the motor capa Increase setting values Adjust settings for Pr.01 the mid-point voltage (if decreases at low-speed Configure the correct range	ith larger capacity.  ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature. em to make it work normally.  peration time. otor for the drive. acity.  for Pr.01-12–01-19 (accel./ decel. time).  1-01–01-08 (V/F curve), especially the setting value for it the mid-point voltage is set too small, the load capacity is.	

Cause	Corrective Actions	
Check if the setting for stall	Set the stell provention to the proper value	
prevention is correct	Set the stall prevention to the proper value.	
Unbalance three-phase	Danless the master	
impedance of the motor	Replace the motor.	
Harmonics is too high	Use remedies to reduce harmonics.	

ID No.	Display on LCD Keypad	Warning Name	Description	
22_2	Warning oH3 Motor Over Heat	Motor overheating (oH3) PT100	Motor overheating warning.  The AC motor drive detects the temperature inside the motor is too high.	
		Action and	d Reset	
Action Condition		Pr.03-00 = 11 (PT100), PT100 input level > Pr.06-57 (default = 7 V)		
	Action Time	Immediately act		
		Error treatment: Pr.06-2 0: Warn and keep opera 1: Fault and ramp to sto	ating	
Warr	ning Setting Parameter	2: Fault and coast to sto 3: No warning	op	
		When Pr.06-29 = 0 and when the temperature is < Pr.06-56 level, the oH3 warning automatically clears.  If the temperature is between Pr.06-56 and Pr.06-57, the frequency outputs according to the operating frequency setting for Pr.06-58.		
	Reset Method	When Pr.06-29 = 0, oH: 56 level, the oH3 warni	3 displays "Warning". When the temperature is < Pr.06-ng automatically clears.	
	Reset Condition	When the temperature clears.	is < Pr.06-56 level, the oH3 warning automatically	
	Record	N/A		
	Cause	Corrective Actions		
Motor lo	cked	Clear the motor lock status.		
The load	l is too large	Decrease loading.  Replace with a motor with larger capacity.		
Ambien	temperature is too high		ace if there are heating devices in the surroundings. or air conditioner to lower the ambient temperature.	
Motor co	ooling system error	Check the cooling syste	em to make it work normally.	
Motor fa	n error	Replace the fan.		
Operate	s at low-speed too long	Decrease low-speed operation time.  Change to dedicated motor for the drive.  Increase the motor capacity.		
	Decel. time and working soo short	Increase the setting values for Pr.01-12–01-19 (accel./ decel. time).		
V/F volta	age is too high	Adjust the settings for Pr.01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed)		
	the motor rated current the motor nameplate	Configure the correct rated current value of the motor again.		

Cause	Corrective Actions	
Check if the PT100 is properly set	Check the connection between PT100 thermistor resistor and the heat	
and wired	protection.	
Check if the setting for stall	Set the stall prevention to the proper value.	
prevention is correct		
Unbalance three-phase	Danless the mater	
impedance of the motor	Replace the motor.	
Harmonics is too high	Use remedies to reduce harmonics.	

ID No.	Display on LCD Keypad	Warning Name	Description	
24	Warning  oSL  Over Slip Warn	Over slip warning (oSL)	Over slip warning.  When the drive outputs at constant speed, and the F>H or F <h 100%="" and="" exceeds="" level="" pr.07-29="Pr.10-29.&lt;/td" pr.07-30="" setting="" time,=""></h>	
		Action and	d Reset	
	Action Condition	When the drive outputs Pr.07-29 level	at constant speed, and F > H or F < H exceeds the	
	Action Time	Pr.07-30		
Warning Setting Parameter		Pr.07-31 = 0 Warning 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
Reset Method			when the drive outputs at constant speed, and F > H or s the Pr.07-29 level, the oSL warning automatically	
	Reset Condition	N/A		
	Record	N/A		
	Cause		Corrective Actions	
Check if the motor parameter is correct		Check the motor parameter.		
The load	d is too large	Decrease the loading.		
	the settings for Pr.07-29, and Pr.10-29 are properly	<u> </u>		

ID No.	Display on LCD Keypad	Warning Name	Description	
25	Warning tUn Auto tuning	Auto tuning (tUn)	Parameter auto-tuning is processing. When running auto-tuning, the keypad displays "tUn".	
		Action and	d Reset	
	Action Condition	When running Pr.05-00	motor parameter auto-tuning, the keypad displays	
	Action Condition	"tUn".		
Action Time		N/A		
Warning Setting Parameter		N/A		
Reset Method		When auto-tuning is fini clears.	shed and no error occurs, the warning automatically	
	Reset Condition	When auto-tuning is finished and no error occurs.		
	Record	N/A		
Cause		Corrective Actions		
The motor parameter is running auto-tuning		When the auto-tuning is	s finished, the warning automatically clears.	

ID No.	Display on LCD Keypad	Warning Name	Description	
28	Warning OPHL Output PHL Warn	Output phase loss (OPHL)	Output phase loss	
		Action and	l Reset	
	Action Condition	Pr.06-47		
	Action Time	N/A		
Warr		Pr.06-45  0: Warn and keep operating  1: Fault and ramp to stop  2: Fault and coast to stop  3: No warning		
	Reset Method	If Pr.06-45 is set to 0, th	e OPHL warning automatically clears after the drive	
	Reset Condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
	ced three-phase ce of the motor	Replace the motor.		
Check if	the wiring is incorrect	Check the cable.  Replace the cable.		
Check if phase m	the motor is a single- otor	Choose a three-phase motor.		
Check if broken	the current sensor is	Check if the control board cable is loose. If yes, reconnect the cable and run the drive to test. If the error still occurs, return to the factory for repair.  Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the OPHL error still shows on the display, return to the factory for repair.		
If capaci	ty of the drive is larger motor	Choose the matches ca	pacity of the drive and motor.	

ID No.	Display on LCD Keypad	Warning Name	Description		
30	Warning SE3 Copy Model Err 3	Copy model error 3 (SE3)	Keypad COPY error 3: copy model error		
		Action and	d Reset		
	Action Condition	"SE3" warning occurs when different drive identity codes are found during			
	Action Condition	copying parameters.			
	Action Time	Immediately act when the error is detected			
War	ning Setting Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	N/A			
	Record	N/A			
Cause		Corrective Actions			
Keypad copy between different power range drives		It is mainly to prevent parameter copies between different HP/models.			

ID No.	Display on LCD Keypad	Warning Name	Description	
36	Warning CGdn Guarding T-out	CANopen guarding time-out (CGdn)	CANopen guarding time-out 1	
		Action and	l Reset	
		When CANopen Node (	Guarding detects that one of the slaves does not	
	Action Condition	response, the CGdn err	or displays.	
		The upper unit sets factor and time during configuration.		
	Action Time	The time that upper unit sets during configuration		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	The upper unit sends a	reset package to clear this fault.	
	Record	N/A		
	Cause	Corrective Actions		
The guarding time is too short, or less detection times		Increase the guarding time (Index 100C) and detection times.		
		Verify the wiring and grounding of the communication circuit. It is		
Malfunc	tion caused by	recommended to se	eparate the communication circuit from the main circuit,	
interfere	·	or wire in 90 degree for effective anti-interference performance.		
Interiere	HICE	2. Make sure the com	munication circuit is wired in series.	
		3. Use CANopen cable	e or add terminating resistance.	

ID No.	Display on LCD Keypad	Warning Name	Description	
37	Warning CHbn Heartbeat T-out	CANopen heartbeat error (CHbn)	CANopen heartbeat error	
		Action and	d Reset	
Action Condition		When CANopen Heartbeat detects that one of the slaves does not response, the CHbn error shows.  The upper unit sets the confirming time of producer and consumer during configuration.		
Action Time		The upper unit sets the confirming time of producer and consumer during configuration.		
Warı	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	The upper unit sends a	reset package to clear this fault	
	Record	When Pr.00-21 ≠ 3, CHbn is a "Warning", and the warning is not recorded		
	Cause	Corrective Actions		
The hea	rtbeat time is too short	Increase heartbeat time	(Index 1016).	
1. Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main or wire in 90 degree for effective anti-interference performance.  2. Make sure the communication circuit is wired in series.  3. Use CANopen cable or add terminating resistance.		eparate the communication circuit from the main circuit, e for effective anti-interference performance.  munication circuit is wired in series.		
	nunication cable is broken or Check or replace the communication cable.			

ID No.	Display on LCD Keypad	Warnir	ng Name	Description
39	Warning CbFn Can Bus Off	•	bus off error bFn)	CANopen BUS off error
			Action and	d Reset
		Hardware	When CANo	pen card is not installed, CbFn fault occurs.
Action Condition		Software	fault occurs. Too much in	terference on BUS
				AN_H and CAN_L communication cable is short, the
				ves wrong package, and CbFn fault occurs.
	Action Time	Immediately act when the fault is detected		
Warr	ning Setting Parameter	N/A		
Reset Method		Manual Reset		
	Reset Condition	Cycle the p	oower	
	Record	When Pr.00-21 ≠ 3, CbFn is a "Warning", and the warning is not recorded		
	Cause	Corrective Actions		
Check if installed	the CANopen card is	Make sure	the CANope	n card is installed.
Check if correct	the CANopen speed is	Reset CANopen speed (Pr.09-37).		
Malfunct interfere		<ol> <li>Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.</li> <li>Make sure the communication circuit is wired in series.</li> <li>Use CANopen cable or add terminating resistance.</li> </ol>		
Commur	nication cable is broken or nected	·		

ID No.	Display on LCD Keypad	Warning Name	Description	
40	Warning Cldn CAN/S ldx exceed	CANopen index error (Cldn)	CANopen Index error	
		Action and	d Reset	
	Action Condition	CANopen communication Index error		
	Action Time	Immediately act when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	Manual Reset		
	Reset Condition	Upper unit sends a reset package to clear this fault		
	Record	When Pr.00-21 ≠ 3, Cldn is a "Warning", and the warning is not recorded		
Cause		Corrective Actions		
Incorrect setting of CANopen index		Reset CANopen Index (Pr.00-02 = 7).		

ID No.	Display on LCD Keypad	Warning Name	Description	
41	Warning CAdn CAN/S Addres set	CANopen station address error (CAdn)	CANopen station address error (only supports 1–127)	
		Action and	d Reset	
	Action Condition	CANopen station address error		
	Action Time	Immediately act when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	Manual Reset		
	Reset Condition	Pr.00-02 = 7		
	Record	When Pr.00-21 ≠ 3, CAdn is a "Warning", and the warning is not recorded		
	Cause	Corrective Actions		
Incorrect setting of CANopen station address		<ol> <li>Disable CANopen (Pr.09-36 = 0).</li> <li>Reset CANopen (Pr.00-02 = 7).</li> <li>Reset CANopen station address (Pr.09-36).</li> </ol>		

ID No.	Display on LCD Keypad	Warning Name	Description		
42	Warning  CFrn  CAN/S FRAM fail	CANopen memory error (CFrn)	CANopen memory error		
		Action and	d Reset		
	Action Condition	When the user update f	irmware version of the control board, the FRAM internal		
	Action Condition	data will not be changed, then CFrn fault occurs.			
	Action Time	Immediately act when the fault is detected			
Warning Setting Parameter		N/A			
	Reset Method	Manual Reset			
	Reset Condition	Pr.00-02 = 7			
	Record	When Pr.00-21 ≠ 3, CFrn is a "Warning", and the warning is not recorded			
Cause		Corrective Actions			
		1. Disable CANopen (Pr.09-36 = 0).			
CANope	en internal memory error	2. Reset CANopen (P	r.00-20 = 7).		
		Reset CANopen station address (Pr.09-36).			

ID No.	Display on LCD Keypad	Warning Name	Description	
43	Warning CSdn SDO T-out	CANopen SDO time-out (CSdn)	SDO transmission time-out (only shows on master station)	
		Action and	d Reset	
	Action Condition	When the CANopen ma "time-out", CSdn warnin	ster transmits SDO command, and the Slave response ag occurs.	
	Action Time	Immediately act when the	ne fault is detected	
War	ning Setting Parameter	N/A		
Reset Method		When the master resends a SDO command and receives the response, the warning automatically clears.		
	Reset Condition	N/A		
Record		N/A		
	Cause		Corrective Actions	
Slave is	not connected	Connect slave and CANopen BUS.		
The synchronize cycle is set too short Increase the synchronization time (Index 1006).		ration time (Index 1006).		
1. Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main or wire in 90 degree for effective anti-interference performance.  2. Make sure the communication circuit is wired in series.  3. Use CANopen cable or add terminating resistance.		eparate the communication circuit from the main circuit, e for effective anti-interference performance. munication circuit is wired in series.		
	ection or bad connection	Check the status of the	cable, or replace the cable.	

ID No.	Display on LCD Keypad	Warning Name	Description	
44	Warning CSbn Buf Overflow	CANopen SDO receives register overflow (CSbn)	CANopen SDO receives register overflow	
		Action and	d Reset	
	Action Condition	The upper unit sends too much SDO and causes buffer overflow		
	Action Time	Immediately act when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	The upper unit sends a reset package to clear the warning.		
	Reset Condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
Too much SDO from the upper unit		Check if the master sends too much SDO command. Make sure the master sends SDO command according to the command format.		

ID No.	Display on LCD Keypad	Warning Name	Description		
46	Warning CPtn Error Protocol	CANopen format error (CPtn)	CANopen protocol format error		
		Action and	d Reset		
	Action Condition	The slave detects that data from the upper unit cannot be recognized, and then			
	Action Condition	shows CPtn warning			
	Action Time	Immediately displays when the fault is detected			
War	ning Setting Parameter	N/A			
	Reset Method	The upper unit sends a reset packet to clear the warning			
	Reset Condition	N/A			
	Record	N/A			
Cause		Corrective Actions			
The upper unit sends incorrect		Make sure the master sends the packet based on CANopen DS301 standard			
communication packet		command format.			

ID No.	Display on LCD Keypad	Warning Name	Description	
47	Warning PLrA RTC Adjust	RTC adjust (PLrA)	PLC (RTC) is not adjusted	
		Action and	l Reset	
	Action Condition	When using RTC function	on for PLC program, and PLC detects unreasonable g displays.	
	Action Time	Immediately displays wl	nen the fault is detected	
Warı	ning Setting Parameter	N/A		
	Reset Method	Auto Stops the PLC and runs again, the warning automatically clears  Manual Manual reset to clear this warning		
	Reset Condition	Cycle the power		
Record		N/A		
	Cause	Corrective Actions		
program over 7 d not conn time, the the inter	sing RTC function for PLC, and the drive is power off ays or KPC-CC01 does nect to the drive for a long a RTC time is different with nal calculated time when ect the keypad to the drive.	1. Stop the PLC program and restart it.  2. Adjust the RTC time and cycle the power.		
KPC-CC	01 does not adjust the e	Adjust the RTC time and cycle the power.		
PLC det	ects unreasonable RTC	<ol> <li>Stop the PLC program and restart it.</li> <li>Cycle the power.</li> </ol>		
Replace with a new KPC-CC01 1.				

ID No.	Display on LCD Keypad	Warning Name	Description		
48	Warning PLiC InnerCOM error	InnerCOM error (PLiC)	InnerCOM error		
		Action and	d Reset		
	Action Condition	N/A			
Action Time		N/A			
War	ning Setting Parameter	N/A			
	Reset Method	N/A			
	Reset Condition	When InnerCOM is back to normal condition, the warning automatically clears			
	Record	N/A			
	Cause	Corrective Actions			
Commu	nication cable is loose	Check the connection of the communication cable.			
		Verify the wiring and grounding of the communication circuit. It is recommended			
Malfina	tion coursed by	to separate the communication circuit from the main circuit, or wire in 90 degree			
	tion caused by	for effective anti-interference performance.			
interfere	ence	It recommended to install terminal resistor(s) on the first and the last unit of the			
		communication circuit.			

ID No.	Display on LCD Keypad	Warning Name	Description	
49	Warning PIrt Keypad RTC T-out	Keypad RTC time-out (PLrt)	PLC (RTC) error	
		Action and	d Reset	
	Action Condition	N/A		
	Action Time	N/A		
Warı	ning Setting Parameter	N/A		
	Reset Method	N/A		
	Reset Condition	Cycle the power		
	Record	N/A		
Cause		Corrective Actions		
KPC-CC01 is not connected to the				
control b	poard while using the RTC	Do not remove the KPC-CC01 keypad while using RTC function.		
function				

ID No.	Display on LCD Keypad	Warning Name	Description	
50	Warning PLod Opposite Defect	PLC opposite defect (PLod)	PLC download error warning	
		Action and	Reset	
	Action Condition	During PLC downloadin	g, the program source code detects incorrect address	
	Action Condition	(e.g. the address exceeds the range), then the PLod warning shows.		
Action Time		Immediately displays when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
Record		N/A		
Cause		Corrective Actions		
Incorrect component number is				
found when downloading the PLC		Use the correct component number.		
program				

ID No.	Display on LCD Keypad	Warning Name	Description	
51	Warning PLSv Save mem defect	PLC save memory error (PLSv)	Data error during PLC operation	
		Action and	l Reset	
Action Condition		The program detects incorrect written address (e.g. the address has exceeds the range) during PLC operation, then the PLSv warning shows.		
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	N/A		
Reset Method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
Record		N/A		
Cause		Corrective Actions		
An incorrect written address is detected during PLC operation		Make sure the write-in a	address is correct and re-download the program.	

ID No.	Display on LCD Keypad	Warning Name	Description	
52	Warning PLdA Data defect	Data defect (PLdA)	Data error during PLC operation	
		Action and	l Reset	
	Action Condition	The program detects ind source code, then PLdA	correct write-in address when translating the program warning acts.	
	Action Time	Immediately displays wi	nen the fault is detected	
Warı	ning Setting Parameter	N/A		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
Reset Condition		N/A		
Record		N/A		
	Cause		Corrective Actions	
During F	PLC operation, the external			
Modbus has written / read incorrect data to internal PLC program		Check if the upper unit transmits the correct command.		
During PLC operation, the drive's				
Modbus has set the same Modbus		Set the drive's Modbus address to a different address from the built-in PLC		
address in the built-in PLC (Pr.09-		address.		
35)				

ID No.	Display on LCD Keypad	Warning Name	Description	
53	Warning PLFn Function defect	Function defect (PLFn)	PLC download function code error	
		Action and	l Reset	
	Action Condition	The program detects in	correct command (unsupported command) during PLC	
	Action Condition	downloading, then PLFn warning acts.		
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
Record		N/A		
Cause		Corrective Actions		
Unsupported command has used while downloading the program		Check if the firmware of	f the drive is the old version. If yes, contact Delta.	

ID No.	Display on LCD Keypad	Warning Name	Description	
54	Warning PLor Buf overflow	PLC buffer overflow (PLor)	PLC register overflow	
		Action and	Reset	
	Action Condition	When PLC runs the last	command and the command exceeds the maximum	
	Action Condition	capacity of the program, the PLor warning shows.		
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
		1. Disable PLC.		
The program detects source code		2. Delete PLC program (Pr.00-02 = 6).		
error during PLC operation		3. Enable PLC.		
		4. Re-download PLC program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
55	Warning PLFF Function defect	Function defect (PLFF)	Function code error during PLC operation	
		Action and	d Reset	
	Action Condition	The program detects in	correct command (unsupported command) during PLC	
	Action Condition	operation, then PLFF warning shows.		
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	NA		
Reset Method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
The PLC runs an incorrect		When starting the PLC function and there is no program in the PLC, the PLFF		
command during operation		warning shows. This is a normal warning, download the program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
56	Warning PLSn Check sum error	Checksum error (PLSn)	PLC checksum error	
		Action and	l Reset	
	Action Condition	PLC checksum error is	detected after power on, then PLSn warning shows	
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	NA		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
		1. Disable PLC.		
The prog	gram detects checksum	2. Remove PLC program (Pr.00-02 = 6).		
error during PLC operation		3. Enable PLC.		
		4. Re-download PLC program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
57	Warning PLEd No end command	No end command (PLEd)	PLC end command is missing	
		Action and	d Reset	
Action Condition		The "End" command is missing until the last command is executed, the PLEd warning shows		
Action Time		Immediately displays when the fault is detected		
War	ning Setting Parameter	NA		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
There is no "END" command during PLC operation		<ol> <li>Disable PLC.</li> <li>Remove PLC program (Pr.00-02 = 6).</li> <li>Enable PLC.</li> <li>Re-download PLC program.</li> </ol>		

ID No.	Display on LCD Keypad	Warning Name	Description	
58	Warning PLCr PLC MCR error	PLC MCR error (PLCr)	PLC MCR command error	
		Action and	l Reset	
	Action Condition	The MC command is de	etected during PLC operation, but there is no	
	Action Condition	corresponded MCR command, then the PLCr warning shows.		
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	NA		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
Record		N/A		
Cause		Corrective Actions		
The MC command is continuously		The MC command cannot be used continuously for 9 times. Check and reset		
used for more than 9 times		the program, then re-download the program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
59	Warning PLdF Download fail	PLC download fail (PLdF)	PLC download fail	
		Action and	d Reset	
	Action Condition	PLC download fail due	to momentary power loss during the downloading, when	
	Action Condition	power is ON again, PLdF warning shows.		
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	NA		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
Record		N/A		
Cause		Corrective Actions		
PLC download is forced to stop, so the program write-in is incomplete		Check if there is any err	ror in the program and re-download the PLC program.	

ID No.	Display on LCD Keypad	Warning Name	Description	
60	Warning PLSF Scan time fail	PLC scan time fail (PLSF)	PLC scan time exceeds the maximum allowable time	
		Action and	d Reset	
Action Condition		When the PLC scan time exceeds the maximum allowable time (400 ms), PLSF warning shows.		
Action Time		Immediately displays when the fault is detected		
War	ning Setting Parameter	NA		
	Reset Method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
Record		N/A		
Cause		Corrective Actions		
The PLC scan time exceeds the maximum allowable time (400ms)		Check if the source cod	e is correct and re-download the program.	

ID No.	Display on LCD Keypad	Warning Name	Description	
61	Warning PCGd CAN/M Guard err	CAN/M guarding error (PCGd)	CANopen Master guarding error	
		Action and	d Reset	
	Action Condition	When CANopen Master response, the PCGd wa	Node Guarding detects that one of the Slaves does not arning displays	
	Action Time	Immediately displays wl	nen the fault is detected	
War	ning Setting Parameter	NA		
Reset Method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset Condition	N/A		
Record		N/A		
Cause			Corrective Actions	
Slave is not connected or  CANopen BUS cable is not  connected  Connect the S		Connect the Slave and	CANopen BUS.	
Malfunci interfere	tion caused by nce	Verify wiring/grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.      Make sure the communication circuit is wired in series.      Use CANopen cable or add terminating resistance.		
Communication cable is broken or bad connected Check or replace the communication cable.		ommunication cable.		

ID No.	Display on LCD Keypad	Warning Name	Description	
62	Warning PCbF CAN/M bus off	CAN/M BUS off (PCbF)	CANopen Master BUS off	
		Action and	d Reset	
Action Condition		When the CANopen master detects error packets more than 255 during the BUS off detection, or when the CANopen card is not installed, the PCbF warning displays.  If the BUS cable is not connected, the drive will not receive issues packet, and		
		the PCbF warning will not display.		
	Action Time	Immediately displays when the fault is detected		
Warning Setting Parameter		NA		
Reset Method		Cycle the power		
	Reset Condition	N/A		
	Record	N/A		
	Cause		Corrective Actions	
1. Verify wiring / grounding of the communication circuit. It is recomme separate the communication circuit from the main circuit, or wire in 9 degree for effective anti-interference performance.  2. Make sure the communication circuit is wired in series.  3. Use CANopen cable or add terminating resistance.		unication circuit from the main circuit, or wire in 90 anti-interference performance. munication circuit is wired in series.		
Commui	nication cable is broken or nected	Check or replace the communication cable.		

ID No.	Display on LCD Keypad	Warning Name	Description	
63	Warning PCnL CAN/M Node Lack	CAN/M node lack (PCnL)	CANopen Master node error	
		Action and	d Reset	
	Action Condition	When the CANopen ma	ster configures different setting nodes from the actual	
	Action Condition	nodes, the PCnL warning displays.		
	Action Time	Immediately displays when the fault is detected		
Warning Setting Parameter		N/A		
	Reset Method	When connect BUS to t	he original slave, or change the configured node	
	Reset Method	numbers to meet the actual node quantity, the warning automatically clears.		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
The configured node quantity is		Connect BUS to the original slave, or change the configured node numbers to		
different from the actual nodes		meet the actual node quantity.		
Commu	nication cable is broken or	Check or replace the communication cable.		
bad con	nected			

ID No.	Display on LCD Keypad	Warning Name	Description	
64	Warning PCCt CAN/M Cycle Time	CAN/M cycle time-out (PCCt)	CANopen Master cycle time-out	
		Action and	d Reset	
	Action Condition	·	acket from CANopen master exceeds the maximum certain time, the PCCt warning displays.	
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	The warning automatically clears when changing the configuration and re- executing the program.		
	Reset Condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
When the transmitted packet from				
CANope	en master exceeds the	Increase the time setting of D1090 synchronization cycle.		
maximu	m allowable quantity in a			
certain t	ime			

ID No.	Display on LCD Keypad	Warning Name	Description	
65	Warning PCSF CAN/M SDO over	CAN/M SDO over (PCSF)	CANopen Master SDO overflow	
		Action and	d Reset	
	Action Condition	When the CANopen ma	When the CANopen master transmits too much SDO that causes buffer	
	Action Condition	overflow, the PCSF warning displays		
Action Time		Immediately displays when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	Cycle the power, or stop the PLC and run the PLC again		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
Internal	PLC transmits too much	The PLC program needs to confirm receiving the SDO feedback data before		
SDO at once		sending another SDO command.		

ID No.	Display on LCD Keypad	Warning Name	Description	
66	Warning PCSd CAN/M Sdo Tout	CAN/M SDO time-out (PCSd)	CANopen Master SDO time-out	
		Action and	d Reset	
	Action Condition	When the CANopen ma	ster sends a SDO command, and the BUS is too busy to	
	Action Condition	transmit the command, PCSd warning displays.		
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	The warning automatically clears when the SDO transmits normally.		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
When th	ne CANopen master	Check if the Slave responds within 1 second.		
transmit	s a SDO command, and			
does no	t receive feedback from			
the Slav	e within 1 sec.			

ID No.	Display on LCD Keypad	Warning Name	Description	
67	Warning PCAd CAN/M Addres set	CAN/M address error (PCAd)	CANopen Master station address error	
		Action and	d Reset	
	Action Condition	When the CANopen ma	ster detects an incorrect or repeated station address	
		from the Slave, the PCAd warning displays.		
	Action Time	Immediately displays when the fault is detected		
War	ning Setting Parameter	N/A		
	Reset Method	The warning automatically clears when reset the station address and run the program again.		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
When the CANopen master				
detects an incorrect or repeated		Set the correct slave station address.		
station address from the Slave				

ID No.	Display on LCD Keypad	Warning Name	Description	
	AUTO		When the drive receives an incorrect packet, it means	
00	Warning	CAN/M time-out	that there is interference or the command from the	
68	РСТо	(PCTo)	upper unit does not meet the CANopen command	
	CAN/M T-Out		format.	
		Action and	d Reset	
	Action Condition	N/A		
	Action Time	Immediately acts when	receiving the command	
War	ning Setting Parameter	N/A		
	Reset Method	The warning automatically clears after receives another normal packet		
	Reset Condition	N/A		
Record		N/A		
	Cause		Corrective Actions	
		Verify wiring/grounding of the communication circuit. It is recommended to		
Malfuna	tion covered by	separate the communication circuit from the main circuit, or wire in 90		
	tion caused by	degree for effective anti-interference performance.		
interfere	ence	2. Make sure the communication circuit is wired in series.		
		Use CANopen cable or add terminating resistance.		
The command from the upper unit				
does no	t meet the CANopen	Contact Delta for furthe	r confirmation.	
format				

ID No.	Display on LCD Keypad	Warning Name	Description	
70	Warning  ECid  ExCom ID failed	ExCom ID fail (ECid)	Duplicate MAC ID error  Node address setting error	
		Action and	d Reset	
	Action Condition	Duplicate setting of MA	C ID	
	Action Condition	Node address setting error		
	Action Time	N/A		
War	ning Setting Parameter	N/A		
Reset Method		Correct the setting and cycle the power		
	Reset Condition	N/A		
	Record	N/A		
	Cause		Corrective Actions	
The sett	ing address exceeds the	Charly the address actting of the communication card (Dr.00.70)		
range (0–63)		Check the address setting of the communication card (Pr.09-70).		
The speed setting exceeds the		Standard: 0–2, non-standard: 0–7.		
range				
The address is duplicated with		Reset the address.		
other nodes on the BUS		Neset tile audiess.		

ID No.	Display on LCD Keypad	Warning Name	Description	
71	Warning  ECLv  ExCom pwr loss	ExCom power loss (ECLv)	Low voltage of communication card	
		Action and	l Reset	
	Action Condition	The 5V power that drive	provides to communication card is too low	
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Re-power		
	Reset Condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
The 5V power that drive provides to communication card is to low		<ol> <li>Switch the communication card to other CFP2000 drives and observe if there is ECLv warning shown. If yes, replace with a new communication card; if not, replace the drive.</li> <li>Use another communication card to test if the ECLv warning has shown as well. If not, replace the card; if yes, replace the drive.</li> </ol>		
The card is loose		Make sure the communication card is well inserted.		

ID No.	Display on LCD Keypad	Warning Name	Description		
72	Warning  ECtt  ExCom Test Mode	ExCom test mode (ECtt)	Communication card is in the test mode		
	Action and Reset				
Action Condition		Communication card is in the test mode			
Action Time		Immediately acts			
War	ning Setting Parameter	N/A			
	Reset Method	Cycle the power and enter the normal mode			
Reset Condition		N/A			
Record		N/A			
Cause		Corrective Actions			
Communication command error		Cycle the power.			

ID No.	Display on LCD Keypad	Warning Name	Description	
73	Warning  ECbF  ExCom Bus off	ExCom Bus off (ECbF)	The communication card detects too much errors in the BUS, then enters the BUS-OFF status and stop communicating	
		Action and	d Reset	
	Action Condition	When the drive detects BUS-off (for DeviceNet)		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Cycle the power		
	Reset Condition	N/A		
	Record	N/A		
Cause			Corrective Actions	
Poor connection of the cable		Re-connect the cable.		
Bad quality of the cable		Replace the cable.		

ID No.	Display on LCD Keypad	Warning Name	Description	
74	Warning ECnP ExCom No power	ExCom no power (ECnP)	There is no power supply on the DeviceNet	
		Action and	d Reset	
	Action Condition	There is no power supply on the DeviceNet		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Re-power		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
The drive detects that DeviceNet has no power		Check if the cable and power is normal. If yes, return to the factory for repair.		

ID No.	Display on LCD Keypad	Warning Name	Description	
75	Warning  ECFF  ExCom Facty def	ExCom factory defect (ECFF)	Factory default setting error	
		Action and	d Reset	
Action Condition		Factory default setting error		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Cycle the power		
	Reset Condition	N/A		
Record		N/A		
	Cause	Corrective Actions		
Factory default setting error		Use DCISoft to reset to the default value.		

ID No.	Display on LCD Keypad	Warning Name	Description	
76	Warning  ECiF  ExCom Inner err	ExCom inner error (ECiF)	Serious internal error	
		Action and	d Reset	
	Action Condition	Internal memory saving	error	
	Action Time	Immediately acts		
Warning Setting Parameter		N/A		
Reset Method		Cycle the power		
Reset Condition		N/A		
Record		N/A		
	Cause		Corrective Actions	
		Verify wiring of the control circuit, and wiring / grounding of the main circuit to		
Noise interference		prevent interference.		
		Cycle the power.		
The memory is broken		Reset to the default value and check if the error still exists. If yes, replace the		
		communication card.		

ID No.	Display on LCD Keypad	Warning Name	Description	
77	Warning  ECio  ExCom IONet brk	ExCom IO Net break (ECio)	IO connection break off	
		Action and	d Reset	
	Action Condition	IO connection between the communication card and the master is broken off		
Action Time		Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	N/A		
	Cause	Corrective Actions		
The cable is loose		Re-install the cable.		
Incorrect parameter setting for master communication		Check the setting for master communication parameter.		

ID No.	Display on LCD Keypad	Warning Name	Description	
78	Warning  ECPP  ExCom Pr data	ExCom Parameter data error (ECPP)	Profibus parameter data error	
Action and Reset				
	Action Condition	N/A		
	Action Time	N/A		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
Record		N/A		
Cause		Corrective Actions		
The GSD file is incorrect		Get the correct GSD file from the software.		

ID No.	Display on LCD Keypad	Warning Name	Description	
79	Warning  ECPi  ExCom Conf data	ExCom configuration data error (ECPi)	Profibus configuration data error	
		Action and	d Reset	
	Action Condition	N/A		
	Action Time	N/A		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
Record		N/A		
Cause		Corrective Actions		
The GSD file is incorrect		Get the correct GSD file from the software.		

ID No.	Display on LCD Keypad	Warning Name	Description	
80	Warning  ECEF  ExCom Link fail	Ethernet link fail (ECEF)	Ethernet cable is not connected	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
Ethernet cable is loose		Re-connect the cable.		
Bad quality of Ethernet cable		Replace the cable.		

ID No.	Display on LCD Keypad	Warning Name	Description	
81	Warning  ECto  ExCom Inr T-out	Communication time- out (ECto)	Communication time-out for communication card and the upper unit	
		Action and	d Reset	
	Action Condition	N/A		
	Action Time	N/A		
Warı	ning Setting Parameter	N/A		
	Reset Method	N/A		
	Reset Condition	CMC-EC01: auto resets when the communication with the upper unit is back to normal		
	Record	N/A		
	Cause	Corrective Actions		
Communication card is not connected with the upper unit		Check if the connection of the communication cable is correct.		
Communication error of the upper unit Check if t		Check if the communica	ation of the upper unit is normal.	

ID No.	Display on LCD Keypad	Warning Name	Description	
82	Warning  ECCS  ExCom Inr CRC	Checksum error (ECCS)	Checksum error for communication card and the drive	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	N/A		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately resets		
	Record	N/A		
Cause		Corrective Actions		
Noise interference		Verify wiring of the control circuit, and wiring/grounding of the main circuit to prevent interference.		

ID No.	Display on LCD Keypad	Warning Name	Description	
83	Warning  ECrF  ExCom Rtn def	Return defect (ECrF)	Communication card returns to the default setting	
		Action and	d Reset	
	Action Condition	Communication card returns to the default setting		
Action Time		N/A		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately resets		
	Record	N/A		
Cause		Corrective Actions		
Communication card is returning to default setting		No actions.		

ID No.	Display on LCD Keypad	Warning Name	Description	
84	Warning ECo0 ExCom MTCP over	Modbus TCP over (Eco0)	Modbus TCP exceeds maximum communication value	
		Action and	Reset	
	Action Condition	Hardware detection		
	Action Time	Immediately acts		
Warı	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately resets		
	Record	N/A		
Cause			Corrective Actions	
The Master communication value				
is more	than the allowable quantity	Reduce Master communication value.		
of the co	ommunication card			
The upp	er unit is online without			
commun	nicating, and does not	Revise program of upper unit, the communication should be break off when it is		
break of	f the Modbus TCP link,	not used for a long time.		
causes occupy connection				
A new M	lodbus TCP connection is			
built eve	ery time when the upper	Revise program of uppe	er unit: use the same Modbus TCP connection when	
unit is co	onnected to the	connected to the same communication card.		
commun	nication card, which	connected to the same communication card.		
caused occupy connection				

ID No.	Display on LCD Keypad	Warning Name	Description	
85	Warning  ECo1  ExCom EIP over	EtherNet/IP over (ECo1)	Ethernet/IP exceeds maximum communication value	
		Action and	l Reset	
	Action Condition	Hardware detection		
	Action Time	Immediately acts		
Warı	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately resets		
	Record	N/A		
Cause		Corrective Actions		
The Master communication value				
is more	than the allowable quantity	Reduce Master commu	nication value.	
of the co	ommunication card			
The upp	er unit is online without			
commun	nicating, and does not	Revise program of upper unit, the communication should be break off when it is		
break of	f the Modbus TCP link,	not used for a long time.		
causes occupy connection				
A new Modbus TCP connection is				
built every time when the upper		Revise program of uppe	er unit: use the same Modbus TCP connection when	
unit is co	onnected to the	Revise program of upper unit: use the same Modbus TCP connection when connected to the same communication card.		
communication card, which		connected to the same communication card.		
caused o	occupy connection			

ID No.	Display on LCD Keypad	Warning Name	Description	
86	Warning  ECiP  ExCom IP fail	IP fail (ECiP)	IP setting error	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediate reset		
	Record	N/A		
Cause		Corrective Actions		
IP conflict		Reset IP.		
DHCP IP configuration error		MIS check if DHCP Server works normally.		

ID No.	Display on LCD Keypad	Warning Name	Description	
87	Warning  EC3F  ExCom Mail fail		Mail warning: Alarm mail will be sent when the communication card establishes alarm conditions	
		Action and	d Reset	
	Action Condition	Communication card establishes alarm conditions		
Action Time		Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately resets		
	Record	N/A		
Cause		Corrective Actions		
Communication card establishes alarm conditions		No actions.		

ID No.	Display on LCD Keypad	Warning Name	Description	
88	Warning  Ecby  ExCom Busy	ExCom busy (ECbY)	Communication card busy: too much packets are received	
		Action and	d Reset	
	Action Condition	Software detection	Software detection	
	Action Time	N/A		
Warı	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
Communication packets are too				
much for the communication card		Reduce communication packets.		
to proce	ss			

ID No.	Display on LCD Keypad	Warning Name	Description	
89	Warning  ECCb  ExCom Card break	ExCom card break (ECCb)	Communication card break off warning	
		Action and	d Reset	
	Action Condition	Communication card br	eak off	
		The time between communication card break off and ECCb displays:		
		1. EtherNet/IP: 3 sec.		
	Action Time	2. Modbus TCP: 3 sec.		
		3. DeviceNet: 1 sec.		
		4. PROFIBUS: 1 sec.		
War	ning Setting Parameter	N/A		
	Reset Method	Auto resets after communication card is re-installed		
	Reset Condition	Immediately resets		
Record		N/A		
	Cause	Corrective Actions		
Communication card break off Re-install communication card.		on card.		

ID No.	Display on LCD Keypad	Warning Name	Description	
90	Warning CPLP Copy PLC Pass Wd	Copy PLC: password error (CPLP)	Copy PLC password error.  When KPC-CC01 is processing PLC copy and the PLC password is incorrect, the CPLP warning shows.	
		Action and	d Reset	
Action Condition		PLC password is incorrect		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Directly resets		
Record		N/A		
Cause			Corrective Actions	
PLC password is incorrect		Reset and enter correct PLC password.		

ID No.	Display on LCD Keypad	Warning Name	Description	
91	Warning CPL0 Copy PLC Mode Rd	Copy PLC: Read mode error (CPL0)	Copy PLC Read mode error	
		Action and	d Reset	
	Action Condition	When copy PLC read mode with incorrect process		
	Action Time	Immediately acts		
Warı	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Directly resets		
	Record	N/A		
Cause		Corrective Actions		
When copy PLC read mode and the process is incorrect		Cycle the power and copy PLC read mode again.		

ID No.	Display on LCD Keypad	Warning Name	Description	
92	Warning CPL1 Copy PLC Mode Wt	Copy PLC: Write mode (CPL1)	Copy PLC write mode error	
		Action and	d Reset	
	Action Condition	Copy PLC write mode with incorrect process		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Directly resets		
	Record	N/A		
Cause		Corrective Actions		
When copy PLC write mode and the process is incorrect		Cycle the power and copy PLC read mode again.		

ID No.	Display on LCD Keypad	Warning Name	Description	
93	Warning CPLv Copy PLC Version	Copy PLC: version error (CPLv)	Copy PLC version error.  When non-CFP2000 built-in PLC is copied to CFP2000 drive, the CPLv warning shows	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Directly resets		
	Record	N/A		
Cause		Corrective Actions		
Non-CFP2000 PLC program is		Check if the copied PLC program is for CFP2000.		
copied to CFP2000		Use the correct CFP2000 PLC program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
94	Warning CPLS Copy PLC Size	Copy PLC: size error (CPLS)	Copy PLC Capacity size error	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Directly resets		
	Record	N/A		
Cause		Corrective Actions		
The PLC copied to CFP2000		Check if the copied PLC program is for CFP2000.		
exceeds the allowable capacity		Use CFP2000 PLC program with correct capacity.		

ID No.	Display on LCD Keypad	Warning Name	Description	
95	Warning CPLF Copy PLC Func		KPC-CC01 Copy PLC function should be executed when PLC is off	
		Action and	d Reset	
	Action Condition	Software detection		
Action Time		Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Directly resets		
	Record	N/A		
Cause		Corrective Actions		
PLC function is enabled when KPC-CC01 is running copy PLC		Disable PLC function first, then run the PLC copy function again.		

ID No.	Display on LCD Keypad	Warning Name	Description	
96	Warning CPLt Copy PLC Time Out	Copy PLC: time-out (CPLt)	Copy PLC time out	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately acts		
War	ning Setting Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Directly resets		
Record		N/A		
Cause		Corrective Actions		
KPC-CC01 is removed while copying PLC program		The KPC-CC01 cannot be removed during the PLC copy process.		

ID No.	Display on LCD Keypad	Warning Name	Description	
101	Warning ictn InrCOM Time Out	InrCOM time-out (ictn)	Internal communication time-out	
		Action and	l Reset	
	Action Condition	When Pr.09-31= (-1) – (	-10) (no -9) and the internal communication between	
	Action Condition	Master and Slave is abr	normal, the ictn warning shows.	
	Action Time	Immediately acts		
Warı	ning Setting Parameter	N/A		
	Reset Method	Auto-reset		
Reset Condition		The warning automatically clears when the communication is back to normal condition		
	Record	N/A		
	Cause		Corrective Actions	
Malfunction caused by interference		Verify wiring / grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	t communication	Check if the setting for Pr.09-04 is the same as the setting for upper unit.		
Communication cable break off or not connected well		Check the cable status or replace the cable.		

### Chapter 13 Warning Codes | CFP2000

ID No.	Display on LCD Keypad	Warning Name	Description	
105	Warning SpdR Est-Speed REV	Estimated speed reverse (SpdR)	Estimated speed is in a reverse direction with motor actual running direction	
		Action and	l Reset	
	Action Condition	Software detection		
	Action Time	Pr.10-09		
Warning Setting Parameter		Pr.10-08  0: Warn and keep operation  1: Fault and coast to stop  2: Fault and ramp to stop		
Reset Method		Manual reset		
Reset Condition		Immediately resets		
Record		N/A		
	Cause		Corrective Actions	
The motor runs in reverse direction at start		Check if the motor is ho	ld when started, or start the motor with speed source.	
The diffe	erence between motor	Normally the Rr value of IM is Rs × 0.7. If there is much difference of the		
parameter measured Rr and Rs		measured value (e.g. Rr = Rs × 0.3), proceed the motor parameter auto-tuning		
value is	too large	again.		
Insufficient output torque is				
dragged	to the reverse direction by	Increase the current lim	it of Pr.06-12, so as to increase the output torque.	
the load				


ID No.	Display on LCD Keypad	Warı	ning Name	Description
123	Маrning dEb Dec. Energy backup		ration energy o error (dEb)	When Pr.07-13 is not set to 0 and the power is suddenly off, causing the DC bus voltage lower than the dEb action level, the dEb function activates and the motor ramps to stop. Then dEb displays on the keypad.
			Action and	d Reset
	Action Condition	When Pr	:.07-13 ≠ 0 an	d DC bus voltage is lower than dEb level
	Action Time	Immedia	tely act	
War	ning Setting Parameter	N/A		
Reset Method		Auto Hand	automatically cleared.  When Pr.07-13 = 1 (dEb with auto-acceleration / auto-deceleration, the drive does not output the frequency after the power is restored):	
	Reset Condition		-	tomatically cleared. lecelerates to 0 Hz.
	Record	Yes		
	Cause	Corrective Actions		
	Unstable power source or the power is off		e power syster	m.
There is other large load operation 1. Replace the power			•	
in the po	ower system	Use a different power system from the large load system.		

[This page is intentionally left blank]

# **Summary of Fault Codes**

ID No.	Fault Name	ID No.	Fault Name
0	No fault record	34	V-phase error (cd2)
1	Over-current during acceleration (ocA)	35	W-phase error (cd3)
2	Over-current during deceleration (ocd)	36	cc hardware failure (Hd0)
3	Over-current during steady operation (ocn)	37	oc hardware error (Hd1)
4	Ground fault (GFF)	38	ov hardware error (Hd2)
5	IGBT short circuit between upper bridge	39	occ hardware error (Hd3)
	and lower bridge (occ)		occ nardware error (rido)
6	Over-current at stop (ocS)	40	Auto-tuning error (AUE)
7	Over-voltage during acceleration (ovA)	41	PID loss ACI (AFE)
8	Over-voltage during deceleration (ovd)	48	ACI loss (ACE)
9	Over-voltage at constant speed (ovn)	49	External fault (EF)
10	Over-voltage at stop (ovS)	50	Emergency stop (EF1)
11	Low-voltage during acceleration (LvA)	51	External base block (bb)
12	Low-voltage during deceleration (Lvd)	52	Password is locked (Pcod)
13	Low-voltage at constant speed (Lvn)	53	SW Code Error (ccod)
14	Low-voltage at stop (LvS)	54	Illegal command (CE1)
15	Phase loss protection (OrP)	55	Illegal data address (CE2)
16	IGBT overheating (oH1)	56	Illegal data value (CE3)
17	Internal key parts overheating (oH2)	57	Data is written to read-only address (CE4)
18	IGBT temperature detection failure (tH1o)	58	Modbus transmission time-out (CE10)
19	Capacitor hardware error (tH2o)	60	Brake transistor error (bF)
21	Over load (oL)	61	Y-connection / D-connection switch error (ydc)
22	Electronic thermal relay 1 protection	63	Over slip error (oSL)
	<u>(EoL1)</u>	03	Over slip error (OSE)
23	Electronic thermal relay 2 protection (EoL2)	64	Electric valve switch error (ryF)
24	Motor overheating (oH3) PTC / PT100	68	Reverse direction of the speed feedback (SdRv)
26	Over torque 1 (ot1)	69	Over speed rotation feedback (SdOr)
27	Over torque 2 (ot2)	70	Large deviation of speed feedback (SdDe)
28	Under current (uC)	71	Watchdog (WDTT)
30	EEPROM write error (cF1)	72	STO Loss 1 (STL1)
31	EEPROM read error (cF2)	73	Emergency stop for external safety (S1)
33	U-phase error (cd1)	74	Fire mode output (Fire)
- 55	O phase citor (out)	7 4	I no mode odiput (i ne)

ID No.	Fault Name	ID No.	Fault Name
76	STO (STO)	104	CANopen bus off error (CbFE)
77	STO Loss 2 (STL2)	105	CANopen index error (CidE)
78	STO Loss 3 (STL3)	106	CANopen station address error (CAdE)
82	Output phase loss U phase (OPHL)	107	CANopen memory error (CFrE)
83	Output phase loss V phase (OPHL)	111	InrCOM time-out error (ictE)
84	Output phase loss W phase (OPHL)	112	PMLess shaft lock (SfLK)
87	Overload protection at low frequency (oL3)	113	Software over-current (SWOC)
89	Rotor position detection error (RoPd)	142	Auto-tune error 1 (AUE1)
90	Force to stop (FStp)	143	Auto-tune error 2 (AUE2)
93	CPU error 0 (TRAP)	144	Auto-tune error 3 (AUE3)
101	CANopen guarding error (CGdE)	148	Auto-tune error 4 (AUE4)
102	CANopen heartbeat error (CHbE)		



- ① Display error signal
- 2 Abbreviate error code
- 3 Display error description

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
			Output current exceeds 2.4 times of rated current during		
	Fault	Over-current during	acceleration.		
1	ocA	acceleration	When ocA occurs, the drive closes the gate of the		
	Oc at accel	(ocA)	output immediately, the motor runs freely, and the		
			display shows an ocA error.		
		Action and	d Reset		
	Action Condition	240% of rated current			
	Action Time	Immediately act			
Faul	t Treatment Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Reset in 5 sec. after the	e fault is cleared		
	Record	Yes			
	Cause		Corrective Actions		
		1. Increase the accele	eration time.		
		2. Increase the acceleration time of S curve.			
Accelera	ation time is too short	3. Set auto-acceleration and auto-deceleration parameter (Pr.01-44).			
		4. Set over-current stall prevention function (Pr.06-03).			
		<ol><li>Replace the drive w</li></ol>	vith a larger capacity model.		
Short cir	cuit at motor output due to	Check the motor cable and remove causes of the short circuits or replace the			
poor inst	ulation wiring	cable before turning on the power.			
Check fo	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the			
aging ins	sulation of the motor	insulation is poor.			
		Check if the output curr	ent during the whole working process exceeds the AC		
The load	l is too large.	motor drive's rated curre	ent. If yes, replace the AC motor drive with a larger		
		capacity model.			
Impulsiv	e change of the load	Reduce the load or incr	ease the capacity of AC motor drive.		
Use spe	cial motor or motor with	Check the motor capaci	ity (the rated current on the motor's nameplate should ≤		
larger ca	pacity than the drive	the rated current of the drive).			
Use ON/OFF controller of an electromagnetic contactor at the		Check the action timing	of the contactor and make sure it is not turned ON/OFF		
		Check the action timing of the contactor and make sure it is not turned ON/OFF when the drive outputs the voltage.			
output (l	J/V/W) of the drive	when the drive outputs	the voltage.		
V/F curv	e setting error	Adjust V/F curve setting and frequency/voltage. When the fault occurs, and the			
v,i Guiv	o county offer	frequency voltage is too high, reduce the voltage.			
Torque o	compensation is too large	Adjust the torque compo	ensation (refer to Pr.07-26 torque compensation gain)		
101940	simportoation to too large	until the output current i	reduces and the motor does not stall.		

Cause	Corrective Actions	
Malfunction caused by	Verify the wiring of the control circuit and wiring/grounding of the main circuit to	
interference	prevent interference.	
The motor starts when in free run	Enable the speed tracking during start-up of Pr.07-12.	
Improper parameter settings for the speed tracking function (including restart after momentary power loss and restart after fault)	Correct the parameter settings for speed tracking.  1. Start the speed tracking function.  2. Adjust the maximum current for Pr.07-09 speed tracking.	
Incorrect combination of control mode and used motor	Check the settings for Pr.00-11 control mode:  1. For IM, Pr.00-11 = 0, 1, 2, 3, 5  2. For PM, Pr.00-11 = 4, 6, or 7	
The length of motor cable is too	Increase AC motor drive's capacity.	
long	Install AC reactor(s) on the output side (U/V/W).	
Hardware failure	The ocA occurs due to short circuit or ground fault at the output side of the drive. Check for possible short circuits between terminals with the electric meter:  B1 corresponds to U, V and W; DC- corresponds to U, V and W; © corresponds to U, V and W.  If short circuit occur, return to the factory for repair.	
Check if the setting for stall prevention is correct	Set the stall prevention to the proper value.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
	, , , , , , , , , , , , , , , , , , , ,		Output current exceeds 2.4 times of rated current		
	AUTO	Over-current during	during deceleration.		
2	Fault ocd	deceleration	When ocd occurs, the drive closes the gate of the		
	Oc at decel	(ocd)	output immediately, the motor runs freely, and the		
			display shows an ocd error.		
		Action and	d Reset		
	Action Condition	240% of rated current			
Action Time		Immediately act			
Fau	t Treatment Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Reset in 5 sec. after the	e fault is cleared		
	Record	Yes			
	Cause		Corrective Actions		
		Increase the decele	eration time.		
		Increase the deceleration time of S-curve.			
Decelera	ation time too short	3. Set auto-acceleration and auto-deceleration parameter (Pr.01-44).			
		4. Set over-current stall prevention function (Pr.06-03).			
		5. Replace the drive with a larger capacity model.			
Check if the mechanical brake of		Check the action timing of the mechanical brake.			
the motor activates too early					
Short-circuit at motor output due to		Check the motor cable and remove causes of the short circuits or replace the			
poor insulation wiring		cable before turning on the power.			
Check for	or possible burnout or	Check the motor insula	tion value with megger. Replace the motor if the		
aging in	sulation of the motor	insulation is poor.			
		Check if the output current during the whole working process exceeds the AC			
The load	d is too large	motor drive's rated current. If yes, replace the AC motor drive with a larger			
		capacity model.			
Impulsiv	e change of the load	Reduce the load or incr	ease the capacity of AC motor drive.		
Use spe	cial motor or motor with	Check the motor capac	ity (the rated current on the motor's nameplate should ≤		
larger ca	apacity than the drive	the rated current of the	drive).		
Use ON	OFF controller of an	Check the action timing	of the contactor and make sure it is not turned ON/OFF		
	nagnetic contactor at the	Check the action timing of the contactor and make sure it is not turned ON/OFF when the drive outputs the voltage.			
output (U/V/W) of the drive					
V/F curv	ve setting error	Adjust V/F curve settings and frequency/voltage. When the fault occurs, and the			
		frequency voltage is too high, reduce the voltage.			
Torque o	compensation is too large	Adjust the torque compensation (refer to Pr.07-26 torque compensation gain)			
	· ·	until the output current reduces and the motor does not stall.			
Malfunction caused by		Verify the wiring of the control circuit and wiring/grounding of the main circuit to			
interfere	ence	prevent interference.			

Cause	Corrective Actions	
The length of motor cable is too	Increase AC motor drive's capacity.	
long	Install AC reactor(s) on the output side (U/V/W).	
	The ocd occurs due to short circuit or ground fault at the output side of the	
	drive.	
Hardwara arrar	Check for possible short circuits between terminals with the electric meter:	
Hardware error	B1 corresponds to U, V and W; DC- corresponds to U, V and W;	
	corresponds to U, V and W.	
	If short circuits occur, return to the factory for repair.	
Check if the setting of stall	Set the stell was continued the proposition	
prevention is correct	Set the stall prevention to the proper value.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
	, ,, p.a.		Output current exceeds 2.4 times of the rated current	
	AUTO	Over-current during	during constant speed.	
3	Fault ocn	steady operation	When ocn occurs, the drive closes the gate of the	
	Oc at normal SPD	(ocn)	output immediately, the motor runs freely, and the	
	ocathornia or b	(,	display shows an ocn error.	
		Action and		
	Action Condition	240% of rated current		
Action Time		Immediately act		
Fau	It Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Reset in 5 sec. after the	e fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
Short-ci	rcuit at motor output due to	Check the motor cable	and remove causes of the short circuits or replace the	
poor ins	ulation wiring	cable before turning on	the power.	
Check for	or possible shaft lock,	Troubleshoot the motor	shaft lock.	
burnout	or aging insulation of the	Check the motor insulation value with megger. Replace the motor if the		
motor		insulation is poor.		
Impulsiv	e change of the load	Reduce the load or increase the capacity of AC motor drive.		
Use special motor or motor with		Check motor capacity (the rated current on the motor's nameplate should ≤ the		
larger capacity than the drive		rated current of the drive).		
Use ON/OFF controller of an		Check the action timing of the contactor and make sure it is not turned ON/OFF when the drive outputs the voltage.		
electromagnetic contactor at the				
output (U/V/W) of the drive				
V/F curv	e setting error	Adjust V/F curve settings and frequency/voltage. When the fault occurs, and the		
V/I GGIV		frequency voltage is too high, reduce the voltage.		
Over-tor	que offset value too high	Adjust over-torque offse	et value (Refer to Pr.07-26 torque compensation gain),	
		•	is reduced and not motor stall.	
Torque o	compensation is too large.		ensation (refer to Pr.07-26 torque compensation gain)	
'	1 3	until the output current	reduces and the motor does not stall.	
	tion caused by		control circuit and wiring/grounding of the main circuit to	
interfere	ence	prevent interference.		
The leng	gth of motor cable is too	Increase the AC motor drive's capacity.		
long			the output side (U/V/W).	
			short circuit or ground fault at the output side of the	
		drive.		
Hardwa	re failure	Check for possible short circuit between terminals with the electric meter:		
		B1 corresponds to U, V and W; DC- corresponds to U, V, and W;		
		corresponds to U, V, and W.		
		If short circuits occur, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
4	Fault  GFF  Ground fault	Ground fault (GFF)	When (one of) the output terminal(s) is grounded, short circuit current is larger than Pr.06-60 setting value, and the detection time is longer than Pr.06-61 time setting, GFF occurs.  NOTE: the short circuit protection is provided for AC motor drive protection, not to protect the user.	
		Action and	d Reset	
	Action Condition	Pr.06-60 (Default = 60%	6)	
	Action Time	Pr.06-61 (Default = 0.10	) sec.)	
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Reset in 5 sec. after the fault is cleared		
Record		Yes		
	Cause		Corrective Actions	
Motor b	urnout or aging insulation	Check the motor insulation value with megger. Replace the motor if the		
occurred		insulation is poor.		
Short cir	rcuit due to broken cable	Troubleshoot the short circuit.		
SHOILCH	cuit due to brokeri cable	Replace the cable.		
l arger s	stray capacitance of the	If the motor cable length	n exceeds 100 m, decrease the setting value for carrier	
	nd terminal	frequency.		
cable ar	nd terminal 🗢	Take remedies to reduce stray capacitance.		
Malfunc	tion caused by	Verify the grounding and wiring of the communication circuit. It is recommended		
interfere	_	to separate the commu	nication circuit from the main circuit, or wire in 90 degree	
interiore	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	for effective sufficient ar	nti-interference performance.	
Hardwa	re failure	Cycle the power after checking the status of motor, cable and cable length. If		
iaiuwa	io idiluio	GFF still exists, return to	o the factory for repair.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
5	Fault occ Short Circuit	IGBT short circuit between upper bridge and lower bridge (occ)	Short-circuit is detected between upper bridge and lower bridge of the IGBT module	
		Action and	d Reset	
	Action Condition	Hardware protection		
	Action Time	Immediately act		
Faul	It Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Reset in 5 sec. after the fault is cleared		
	Record	Yes		
Cause		Corrective Actions		
IGBT en	ror	Check the motor wiring.		
Short-cii	rcuit detecting circuit error	Cycle the power, if occ still exists, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
6	Fault ocS Oc at stop	Over-current at stop (ocS)	Over-current or hardware failure in current detection at stop.  Cycle the power after ocS occurs. If the hardware failure occurs, the display shows cd1, cd2 or cd3.	
		Action and	d Reset	
	Action Condition	240% of rated current		
	Action Time	Immediately act		
Fault Treatment Parameter		N/A		
Reset Method		Manual reset		
	Reset Condition	Reset in 5 sec. after the fault is cleared		
	Record	Yes		
	Cause	Corrective Actions		
Malfunc	tion caused by	Verify the wiring of the control circuit and wiring / grounding of the main circuit		
interference		to prevent interference.		
Hardwa	re failure	Check if other error code such as cd1–cd3 occur after cycling the power. If yes, return to the factory for repair.		

No. Display on LCD Keypad	Fault Name	Fault Descriptions		
АИТО		DC bus over-voltage during acceleration.		
Fault	Over-voltage during	When ovA occurs, the drive closes the gate of the		
7 ovA	acceleration	output, the motor runs freely, and the display shows an		
Ov at accel	(ovA)	ovA error.		
	Action and	d Reset		
	230V models: 410 V <sub>DC</sub>			
Action Condition	460V models: 820 V <sub>DC</sub>			
	575V models: 1116 V <sub>D</sub>	oc		
Action Time	Immediately act when	DC bus voltage is higher than the level		
Fault Treatment Parameter	N/A			
Reset Method	Manual reset			
Reset Condition	Reset only when DC b	ous voltage is lower than 90% of the over-voltage level		
Record	Yes			
Cause		Corrective Actions		
Acceleration is too slow (e.g. lifting	Decrease the accelera	ation time.		
load decreases acceleration time)	Use brake unit or DC	bus.		
,	Replace the drive with	a larger capacity model.		
The setting for stall prevention level is smaller than no-load current	The setting for stall prevention level should be larger than no-load current.			
Power voltage is too high	Check if the input voltage is within the rated AC motor drive input voltage			
r ower voltage is too nigh	range, and check for possible voltage spikes.			
ON/OFF switch action of phase-in	If the phase-in capacitor or active power supply unit acts in the same power			
capacitor in the same power system	system, the input voltage may surge abnormally in a short time. In this case,			
	install an AC reactor.			
Regenerative voltage of motor	Use over-voltage stall prevention function (Pr.06-01).			
inertia	Use auto-acceleration	and auto-deceleration setting (Pr.01-44).		
	Use a brake unit or DC bus.			
	Check if the over-voltage warning occurs after acceleration stops.			
	When the warning occurs, do the following:			
Acceleration time is too short	Increase the acceleration time.			
		-voltage stall prevention.		
		alue for Pr.01-25 S-curve acceleration arrival time 2.		
	The ground short circuit current charges the capacitor in the main circuit			
Motor ground fault	through the power. Check if there is ground fault on the motor cable, wiring			
	box and its internal terminals.			
	Troubleshoot the ground fault.			
Incorrect wiring of brake resistor or brake unit	Check the wiring of br	Check the wiring of brake resistor and brake unit.		
Malfunction caused by interference	Verify the wiring of the control circuit and wiring/grounding of the main circuit			
manufaction oddsod by interiorelide	to prevent interference.			

No. Display on LCD Keypad	Fault Name	Fault Descriptions	
Fault Auto	Over-voltage during	DC bus over-voltage during deceleration.  When ovd occurs, the drive closes the gate of the	
8 ovd	deceleration	output immediately, the motor runs freely, and the	
Ov at decel	(ovd)	display shows an ovd error.	
	Action and		
	230V models: 410 V <sub>DC</sub>		
Action Condition	460V models: 820 V <sub>DC</sub>		
	575V models: 1116 V <sub>DC</sub>		
Action Time	Immediately act when D	OC bus voltage is higher than the level	
Fault Treatment Parameter	N/A		
Reset Method	Manual reset		
Reset Condition	Reset only when DC bu	us voltage is lower than 90% of the over-voltage level	
Record	Yes		
Cause		Corrective Actions	
Deceleration time is too short, causing too large regenerative energy of the load	<ol> <li>Increase the setting value of Pr.01-13, Pr.01-15, Pr.01-17 and Pr.01-19 (deceleration time).</li> <li>Connect brake resistor, brake unit or common DC bus on the drive.</li> <li>Reduce the brake frequency.</li> <li>Replace the drive with a larger capacity model.</li> <li>Use S-curve acceleration/deceleration.</li> <li>Use over-voltage stall prevention (Pr.06-01).</li> </ol>		
	<ul><li>7. Use auto-acceleration and auto-deceleration (Pr.01-44).</li><li>8. Adjust braking level (Pr.07-01 or the jumper of the brake unit).</li></ul>		
The setting for stall prevention	je i isjani i i i i i i i i i i i i i i i i i i	, ( the contract of the contra	
level is smaller than no-load current	The setting for stall pre	vention level should be larger than no-load current.	
Power voltage is too high	Check if the input voltage and check for possible	ge is within the rated AC motor drive input voltage range, voltage spikes.	
ON/OFF switch action of phase-in	If the phase-in capacito	r or active power supply unit acts in the same power	
capacitor in the same power	system, the input voltag	ge may surge abnormally in a short time. In this case,	
system	install an AC reactor.		
The ground short circuit current charges the capacite through the power. Check if there is ground fault on and its internal terminals.  Troubleshoot the ground fault.		eck if there is ground fault on the motor cable, wiring box is.	
Incorrect wiring of brake resistor or brake unit	Check the wiring of brake resistor or brake unit.		
Malfunction caused by	Verify the wiring of the	control circuit and wiring/grounding of the main circuit to	
interference	prevent interference.		

No. Display on LCD Keypad	Fault Name	Fault Descriptions	
Fault ovn Ov at normal SPD	Over-voltage at constant speed (ovn)	DC bus over-voltage at constant speed.  When ovn occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ovn error.	
	Action and	d Reset	
Action Condition	230V models: 410 V <sub>DC</sub> 460V models: 820 V <sub>DC</sub> 575V models: 1116 V <sub>DC</sub>		
Action Time	Immediately act when D	OC bus voltage is higher than the level	
Fault Treatment Parameter	N/A		
Reset Method	Manual reset		
Reset Condition	Reset only when DC bu	s voltage is lower than 90% of over-voltage level	
Record	Yes		
Cause		Corrective Actions	
Impulsive change of the load	<ol> <li>Connect brake resistor, brake unit or DC bus to the drive.</li> <li>Reduce the load.</li> <li>Replace to drive with a larger capacity model.</li> <li>Adjust braking level (Pr.07-01 or bolt position of the brake unit).</li> </ol>		
The setting for stall prevention level is smaller than no-load current	The setting of stall prevention level should be larger than no-load current.		
Regenerative voltage of motor	Use over-voltage stall p	revention function (Pr.06-01).	
inertia	Use a brake unit or DC bus.		
Power voltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range, and check for possible voltage spikes.		
ON/OFF switch action of phase-in	If the phase-in capacito	r or active power supply unit acts in the same power	
capacitor in the same power	system, the input voltag	e may surge abnormally in a short time. In this case,	
system	install an AC reactor.		
Incorrect wiring of brake resistor or brake unit.  Check the wiring of brake resistor or brake unit.		ke resistor or brake unit.	
Malfunction caused by	Verify the wiring of the o	control circuit and wiring/grounding of the main circuit to	
interference prevent interference.			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
10	Fault ovS Ov at stop	Over-voltage at stop (ovS)	Over-voltage at stop		
		Action and	d Reset		
		230V models: 410 V <sub>DC</sub>			
	Action Condition	460V models: 820 V <sub>DC</sub>			
		575V models: 1116 V <sub>DC</sub>			
	Action Time	Immediately act when D	OC bus voltage is higher than the level		
Faul	It Treatment Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Reset only when DC bu	s voltage is lower than 90% of over-voltage level		
Record Yes		Yes	es		
Cause		Corrective Actions			
Power v	Check if the input voltage is within the rated AC motor drive input voltage routing voltage is too high and check for possible voltage spikes.				
ON/OFF	switch action of phase-in	If the phase-in capacito	r or active power supply unit activates in the same		
capacito	or in the same power	power system, the input voltage may surge abnormally in a short time. In this			
system		case, install an AC reac	tor.		
Incorrec brake ur	t wiring of brake resistor or nit	Check the wiring of bral	ke resistor or brake unit.		
Malfunct	tion caused by	Verify the wiring of the o	control circuit and wiring/grounding of the main circuit to		
interfere	ence	prevent interference.			
Hardwai	re failure in voltage	Check if other error cod	e such as cd1–cd3 occur after cycling the power. If yes,		
detection	n	return to the factory for repair.			
		The ground short circuit current charges the capacitor in the main circuit			
Motor ar	ound fault	through the power. Check if there is ground fault on the motor cable, wiring box			
o.o. gi		and its internal terminal			
		Troubleshoot the ground	d fault.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
11	Fault LvA Lv at accel	Low-voltage during acceleration (LvA)	DC bus voltage is lower than Pr.06-00 setting value during acceleration	
		Action and	d Reset	
	Action Condition	Pr.06-00 (Default = dep	ending on the model)	
	Action Time	Immediately act when D	OC bus voltage is lower than Pr.06-00	
Fau	It Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Reset when DC bus voltage is higher than Pr.06-00 + 30 V (Frame A–D)		
	Record	Yes		
Cause			Corrective Actions	
Power-off		Improve power supply of	condition.	
Power v	Ower voltage changes Adjust voltage to the power range of the drive		wer range of the drive	
Start up	the motor with large	Check the power system.		
capacity	•	Increase the capacity of	f power equipment.	
		Reduce the load.		
The load	d is too large	Increase the drive capacity.		
		Increase the acceleration time.		
DC bus		Install DC reactor(s).		
Check if there is short-circuit plate or any DC reactor installed		Connect short circuit pla	nnect short circuit plate or DC reactor between terminal +1 and +2.	
between terminal +1 and +2  If the error still exists, return to the factory for repair.			eturn to the factory for repair.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
12	Fault Lvd Lv at decel	Low-voltage during deceleration (Lvd)	DC bus voltage is lower than Pr.06-00 setting value during deceleration	
		Action and	d Reset	
	Action Condition	Pr.06-00 (Default = dep	ending on the model)	
	Action Time	Immediately act when D	OC bus voltage is lower than Pr.06-00	
Faul	t Treatment Parameter	NA		
Reset Method		Manual reset		
Reset Condition		Reset when DC bus voltage is higher than Pr.06-00 + 30 V (Frame A–D)		
Record		Yes		
	Cause	Corrective Actions		
Power-o	off	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the po	wer range of the drive.	
Start up the motor with large Check the power system.		Check the power syster	n.	
capacity		Increase the capacity of power equipment.		
Sudden		Reduce the load.		
Suddell	IUau	Increase the drive capacity.		
DC bus Install DC reactor(s).				

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
13	Fault Lvn Lv at normal SPD	Low-voltage at constant speed (Lvn)	DC bus voltage is lower than Pr.06-00 setting value at constant speed	
		Action and	d Reset	
	Action Condition	Pr.06-00 (Default = dep	ending on the model)	
	Action Time	Immediately act when D	OC bus voltage is lower than Pr.06-00	
Fau	It Treatment Parameter	NA		
Reset Method Manual		lanual reset		
Reset Condition		Reset when DC bus voltage is higher than Pr.06-00 + 30 V (Frame A–D)		
Record		Yes		
	Cause	Corrective Actions		
Power-o	off	Improve power supply of	condition.	
Power v	oltage changes	Adjust voltage to the po	wer range of the drive	
Start up	Start up the motor with large Check the power system		n.	
capacity Increase th		Increase the capacity of	rease the capacity of power equipment.	
Sudden load		Reduce the load.		
Sudden	IUau	Increase the drive capacity.		
DC bus		Install DC reactor(s).		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
14	Fault LvS Lv at stop	Low-voltage at stop (LvS)	<ol> <li>DC bus voltage is lower than Pr.06-00 setting value at stop</li> <li>Hardware failure in voltage detection</li> </ol>	
		Action and	l Reset	
	Action Condition	Pr.06-00 (Default = dep	ending on the model)	
	Action Time	Immediately act when D	C bus voltage is lower than Pr.06-00	
Fau	It Treatment Parameter	N/A		
	Reset Method	Manual / auto: $230V \text{ models:}$ $Frame A-D = Lv \text{ level} + 30 \text{ V}_{DC} + 500 \text{ ms}$ $460V \text{ models:}$ $Frame A-D = Lv \text{ level} + 60 \text{ V}_{DC} + 500 \text{ ms}$ $575V \text{ models:}$ $Frame A-D = Pr.06-00 + 100.0 \text{ V}_{DC}$		
	Reset Condition	500 ms		
	Record	Yes		
	Cause		Corrective Actions	
Power-c	off	Improve power supply of	ondition.	
Incorrec	t drive models	Check if the power spec	rification matches the drive.	
Power v	oltage changes	Adjust voltage to the power range of the drive.  Cycle the power after checking the power. If LvS error still exists, return to the factory for repair.		
Start up	the motor with large	Check the power system.		
capacity	,	Increase the capacity of power equipment.		
DC bus		Install DC reactor(s).		

No.	Display on LCD Keypad	Fault Name Fault Descriptions		
15	Fault OrP Phase lacked	Phase loss protection (OrP)	Phase loss of power input	
		Action and	l Reset	
	Action Condition	DC bus is lower than Pr	:07-00, and DC bus ripple is higher than Pr.06-52	
	Action Time	N/A		
Fau	It Treatment Parameter	Pr.06-53		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset when	DC bus is higher than Pr.07-00	
	Record	Yes		
	Cause	Corrective Actions		
Phase lo	oss of input power	Correctly install the wiri	ng of the main circuit power.	
Single phase power input to three- phase model		Choose the model whose power matches the voltage.		
Power voltage changes		If the main circuit power works normally, verify the main circuit.  Cycle the power after checking the power, if OrP error still exists, return to the factory for repair.		
Loose w	viring terminal of input	Tighten the terminal screws according to the torque described in the user		
power		manual.		
The input cable of three-phase		Wire correctly.		
power is	power is cut off Replace the cut off cable.		e.	
Input po	wer voltage changes too	Verify the setting value for Pr.06-50 Time for Input Phase Loss Detection and		
much Pr.06-52 Ripple of Input Phase Loss.		Phase Loss.		
Unbalanced three-phase of input power  Check the power three-phase status.			phase status.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
16	Fault oH1	IGBT overheating (oH1)	IGBT temperature exceeds the protection level	
		Action and	l Reset	
	Action Condition	When Pr.06-15 is highe occurs instead of oH1 w	r than the IGBT overheating protection level, oH1 error varning.	
	Action Time	IGBT temperature exceloccurs.	eds the protection level for more than 100 ms, oH1 error	
Faul	t Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Reset only when IGBT t	emperature is lower than oH1 error level minus (-) 10°C	
	Record	Yes		
	Cause	Corrective Actions		
or tempe cabinet i	erature inside the control is too high, or if there is ion in the ventilation hole	<ol> <li>Regularly inspect the ventilation hole of the control cabinet.</li> <li>Change the installed place if there are heating objects, such as braking resistors, in the surroundings.</li> <li>Install/ add cooling fan or air conditioner to lower the temperature inside the</li> </ol>		
		Remove the obstruction or replace the cooling fan.		
Insufficie	ent ventilation space	Increase ventilation spa	ce of the drive.	
	the drive matches the onding load	<ol> <li>Reduce the load.</li> <li>Reduce the carrier.</li> <li>Replace the drive with a larger capacity model.</li> </ol>		
	·	a Replace the drive with a larger capacity model.		

No. Display on LCD Keypad	Fault Name	Fault Descriptions	
Fault oH2 Heat Sink oH		Board-level component temperature exceeds the protection level	
	Action and	l Reset	
Action Condition	Refer to the table below	for oH2 level of each models	
Action Time	When the board-level comore than 100 ms, oH2	error occurs	
Fault Treatment Parameter	N/A		
Reset Method	Manual reset		
Reset Condition	Reset when the board-le	evel component temperature is lower than oH2 error level	
Record	Yes		
Cause		Corrective Actions	
Check if the ambient temperature or temperature inside the control cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet.	<ol> <li>Check ambient temperature.</li> <li>Regularly inspect the ventilation hole of the control cabinet.</li> <li>Change the installed place if there are heating objects, such as braking resistors, in the surroundings.</li> <li>Install / add cooling fan or air conditioner to lower the temperature inside the cabinet.</li> </ol>		
Check if there is any obstruction on the heat sink or if the fan is running.	Remove the obstruction or replace the cooling fan.		
Insufficient ventilation space	Increase ventilation spa	ce of the drive.	
Check if the drive matches the corresponding load	<ol> <li>Reduce the load.</li> <li>Reduce the carrier.</li> <li>Replace the drive with a larger capacity model.</li> </ol>		
The drive has run 100% or more than 100% of the rated output for a long time	a Replace the drive with a larger capacity model.		
Unstable power	Install reactor(s).		
Load changes frequently	Reduce load changes.		

oH1/ oH2 warning level

This is a second of the second				
Model	oH1	oH2	oH warning oH1 warning = (Pr. 06-15)	
VFD007FP2EA-41/52/52S	110			
VFD015FP2EA-41/52/52S	110			
VFD022FP2EA-41/52/52S		85		
VFD037FP2EA-41/52/52S	100			
VFD055FP2EA-41/52/52S				
VFD075FP2EA-41/52/52S	405	00		
VFD110FP2EA/41/52/52S	105	90		
VFD150FP2EA-41/52/52S	0.5	0.7		
VFD185FP2EA-41/52/52S	95	97		
VFD220FP2EA-41/52/52S	400			
VFD300FP2EA-41/52/52S	100	90		
VFD370FP2EA-41/52/52S				
VFD450FP2EA-41/52/52S	95			
VFD007FP4EA-41/52/52S	4	1		
VFD015FP4EA-41/52/52S	110			
VFD022FP4EA-41/52/52S		85		
VFD037FP4EA-41/52/52S				
VFD040FP4EA-41/52/52S	100			
VFD055FP4EA-41/52/52S				
VFD075FP4EA-41/52/52S				
VFD110FP4EA-41/52/52S				
VFD150FP4EA-41/52/52S				
VFD185FP4EA-41/52/52S	105	90	oH1 Warning = Pr.06-15 oH2 Warning = oH2 – 5	
VFD220FP4EA-41/52/52S				
VFD300FP4EA-41/52/52S	110	97		
VFD370FP4EA-41/52/52S	110	97		
VFD450FP4EA-41/52/52S				
VFD550FP4EA-41/52/52S	100	90		
VFD750FP4EA-41/52/52S				
VFD900FP4EA-41/52/52S	95	85		
VFD015FP5EA-41/52/52S	110			
VFD022FP5EA-41/52/52S	110	1		
VFD037FP5EA-41/52/52S		85		
VFD057FP5EA-41/52/52S	100			
VFD075FP5EA-41/52/52S				
VFD110FP5EA-41/52/52S				
VFD150FP5EA-41/52/52S	105	90		
VFD185FP5EA-41/52/52S	100			
VFD220FP5EA-41/52/52S				
VFD300FP5EA-41/52/52S	110	97		
VFD370FP5EA-41/52/52S	97			
VFD450FP5EA-41/52/52S				
VFD550FP5EA-41/52/52S	100	90		
VFD750FP5EA-41/52/52S				
VFD900FP5EA-41/52/52S	95	85		
VI D3001 F 3EA-41/32/323		1		

Unit: °C

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
18	Fault tH1o Thermo 1 open	IGBT temperature detection failure (tH1o)	IGBT hardware failure in temperature detection	
		Action and	d Reset	
	Action Condition	NTC broken or wiring failure		
Action Time		When the IGBT temperature is higher than the protection level, and detection time exceeds 100 ms, the tH1o protection activates.		
Fault Treatment Parameter		N/A		
Reset Method		Manual reset		
	Reset Condition	Immediately reset		
Record		Yes		
Cause		Corrective Actions		
Hardware failure		Wait for 10 minutes, and then cycle the power. Check if tH1o protection still exists. If yes, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions
19	Fault tH2o Thermo 2 open	Capacitor hardware error (tH2o)	Hardware failure in capacitor temperature detection
		Action and	I Reset
Action Condition		NTC broken or wiring failure	
Action Time		When the IGBT temperature is higher than the protection level, and detection time exceeds 100 ms, the tH2o protection activates.	
Fault Treatment Parameter		N/A	
Reset Method		Manual reset	
Reset Condition		Immediately reset	
Record		Yes	
Cause		Corrective Actions	
Hardware failure		Wait for 10 minutes, and then cycle the power. Check if tH2o protection still exists. If yes, return to the factory for repair.	

No. D	Display on LCD Keypad	Fault Name	Fault Descriptions	
	AUTO		The AC motor drive detects excessive drive output	
	Fault	Over load	current. The overload capacity sustains for 1 minute	
21	oL	(oL)	when the drive outputs 150% of the drive's rated output	
	Over load		current.	
		Action and Reset		
Λ.	ction Condition	Based on over load curve and derating curve. (The overload capacity sustains		
A	Clion Condition	for 1 minute when the drive outputs 150% of the drive's rated output current.)		
	Action Time	When the load is higher than the protection level and exceeds allowable time,		
	Action fille	the oL protection activates.		
Fault T	reatment Parameter	N/A		
F	Reset Method	Manual reset		
R	eset Condition	Reset in 5 sec. after the	e fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
The load is	too large	Reduce the load.		
Accel./Dec	el. time or the working	Increase the setting val	ue for Pr 01-12-01-19 (accel /decel time)	
cycle are to	oo short	Increase the setting value for Pr.01-12–01-19 (accel./decel time).		
		Adjust the settings for Pr.01-01-08 (V/F curve), especially the setting value		
V/E voltage	e is too high	for the mid-point voltage (if the mid-point voltage is set too low, the load		
V/I Voltage	e is too nign	capacity decreases at low speed).		
		Refer to the V/F curve selection of Pr.01-43.		
The capacity of the drive is too small		Replace the drive with a larger capacity model.		
0		Reduce the load during low-speed operation.		
	luring low-speed	Increase the drive capacity.		
operation		Decrease the carrier frequency of Pr.00-17.		
Torque con	proportion is too large	Adjust the torque compensation (refer to Pr.07-26 Torque Compensation Gain)		
Torque con	npensation is too large	until the output current reduces and the motor does not stall.		
	e setting for stall	Set the stall prevention	to the proper value.	
prevention	is correct.			
Output phase loss		Check the status of three-phase motor.		
		Check if the mater three phase impedance is equaled, or whether the agrees		
Input phase loss		Check if the motor three-phase impedance is equaled, or whether the screws are loosened.		
Improper pa	arameter settings for	Correct the personator	cottings for speed tracking	
the speed t	tracking function	Correct the parameter settings for speed tracking.  1. Start the speed tracking function.		
(including r	estart after momentary	-	m current for Pr.07-09 speed tracking.	
power loss and restart after fault)		iz. Aujust tile maximul	in current for 1 1.07-09 speed tracking.	

No. Display on LCD Keypad	Fault Name	Fault Descriptions	
Fault EoL1 Thermal relay 1	Electronics thermal relay 1 protection (EoL1)	Electronics thermal relay 1 protection. The drive coasts to stop once it activates.	
	Action and	d Reset	
Action Condition	Start counting when output current > 105% of motor 1 rated current		
Action Time	Pr.06-14 (if the output current is larger than 105% of motor 1 rated current again within 60 sec., the counting time reduces and is less than Pr.06-14)		
Fault Treatment Parameter	N/A		
Reset Method	Manual reset		
Reset Condition	Reset in 5 sec. after the	e fault is cleared	
Record	Yes		
Cause		Corrective Actions	
The load is too large	Reduce the load.		
Accel./Decel. time or the working cycle is too short	Increase the setting values for Pr.01-12–01-19 (Accel./Decel. time).		
V/F voltage is too high	Adjust the settings for Pr.01-01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).  Refer to the V/F curve selection of Pr.01-43.		
Overload during low-speed			
operation.  When using a general motor, even it operates below rated current, an overload may still occur during	Decrease low-speed operation time.  Replace the drive with a dedicated to VFD model.  Increase the motor capacity.		
low-speed operation.			
When using VFD dedicated motors, Pr.06-13=0 (electronic thermal relay selection motor 1 = standard motor thermal relay selection motor 1 = with fan on the shaft).		thermal relay selection motor 1 = standard motor (motor	
Incorrect value of electronic thermal relay	Reset to the correct motor rated current.		
The maximum motor frequency is set too low	Reset to the correct motor rated frequency.		
One drive to multiple motors	Set Pr.06-13 = 2 electronic thermal relay selection motor 1 = disable, and install thermal relay on each motor.		
Check if the setting for stall prevention is correct.	Set the stall prevention	to the proper value.	
Adjust the torque compensation (refer to Pr.07-26 torque compensation until the current reduces and the motor does no stall.			

Cause	Corrective Actions	
Motor fan error	Check the status of the fan, or replace the fan.	
Unbalanced three-phase	Deplete the meter	
impedance of the motor	Replace the motor.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
23	Fault EoL2 Thermal relay 2	Electronic thermal relay 2 protection (EoL2)	Electronic thermal relay 2 protection. The drive coasts to stop once it activates.	
		Action and	d Reset	
	Action Condition	Start counting when out	tput current > 105% of motor 2 rated current	
Action Time		Pr.06-28 (If the output current is larger than 105% of motor 2 rated current again within 60 sec., the counting time reduces and is less than Pr.06-28)		
Faul	t Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Reset in 5 sec. after the	e fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
The load	l is too large	Reduce the load.		
	ecel. time or the working e too short	Increase the setting val	ues for Pr.01-12–01-19 (accel./decel. time).	
V/F voltage is too high		Adjust the settings for Pr.01-01–01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).  Refer to the V/F curve selection setting of Pr.01-43.		
Overload during low-speed				
operation.  When using general motor, even it operates below rated current, an overload may still occur during low-speed operation.		Decrease low-speed op Replace the drive with a Increase the motor cap	a dedicated to VFD model.	
	sing VFD dedicated			
motors,	Pr.06-27=0 (electronic	Pr.06-27 = 1 Electronic thermal relay selection motor 2 = standard motor (motor		
thermal	relay selection motor 2 = 0 motor)	with fan on the shaft).		
Incorrect	t value of electronic relay	Reset to the correct motor rated current.		
The max	kimum motor frequency is	Reset to the correct motor rated frequency.		
One driv	re to multiple motors	Set Pr.06-27 = 2 Electronic thermal relay selection motor 2 = disable, and install thermal relay on each motor.		
	the setting for stall on is correct.	Set the stall prevention to the proper value.		
Torque compensation is too large		Adjust the torque compensation (refer to Pr.07-26 torque compensation gain) until the current reduces and the motor does no stall.		

Cause	Corrective Actions	
Motor fan error	Check the status of the fan, or replace the fan.	
Unbalanced three-phase	Deplete the meter	
impedance of the motor	Replace the motor.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
24_1	Fault oH3 Motor over heat	Motor overheating (oH3) PTC	Motor overheating (PTC) (Pr.03-00–Pr.03-02 = 6 PTC), when PTC input > Pr.06-30, the fault treatment acts according to Pr.06-29.	
L		Action and	d Reset	
	Action Condition	PTC input value > Pr.06	6-30 setting (Default = 50%)	
	Action Time	Immediately act		
		Pr.06-29		
		0: Warn and keep opera	ation	
Faul	t Treatment Parameter	1: Fault and ramp to sto	рр	
		2: Fault and coast to sto	рр	
		3: No warning		
	Reset Method	When Pr.06-29 = 0, oH	3 is a "Warning". The "Warning" is automatically cleared.	
	Reset Method	When Pr.06-29 = 1 or 2	, oH3 is a "Fault". You must reset manually.	
	Reset Condition	Immediately reset		
	Record	When Pr.06-29 = 1 or 2, oH3 is a "Fault", and the fault is recorded.		
	Cause	Corrective Actions		
Motor shaft lock		Remove the shaft lock.		
The leas	lia tao larga	Reduce the load.		
The load	l is too large	Increase the motor capacity.		
Ambient	tomporature is too high	Change the installed place if there are heating devices in the surroundings.		
Ambient temperature is too high		Install/ add cooling fan or air conditioner to lower the ambient temperature.		
Motor co	ooling system error	Check the cooling system to make it work normally.		
Motor fan error		Replace the fan.		
		Decrease low-speed operation time.		
Operate	at low-speed too long.	Replace the motor with a dedicated to VFD model.		
		Increase the motor capacity.		
	ecel. time and working too short	Increase the setting values for Pr.01-12–01-19 (accel./decel. time).		
		Adjust settings for Pr.01-01-08 (V/F curve), especially the setting value for		
V/F volta	age is too high	the mid-point voltage (if the mid-point voltage is set too low, the load capacity		
		decreases at low speed).		
Check if	the motor rated current			
matches that on the motor		Reset to the correct motor rated current.		
namepla	te.			
Check if	the PTC is properly set	Check the connection between PTC thermistor and the heat protection.		
and wire	d			
Check if	the setting for stall	Set the stall provention	to the proper value	
prevention is correct.		Set the stall prevention to the proper value.		

Cause	Corrective Actions	
Unbalanced three-phase	Replace the motor.	
impedance of the motor		
Harmonics are too high.	Use remedies to reduce harmonics.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
24_2	Fault oH3 Motor over heat	Motor overheating (oH3) PT100	Motor overheating (PT100) (Pr.03-00–Pr.03-02 = 11 PT100). When PT100 input > Pr.06-57 (default = 7 V), the fault treatment acts according to Pr.06-29.	
		Action and	l Reset	
Action Condition		PT100 input value > Pr.06-57 setting (default = 7 V)		
	Action Time	Immediately act		
		Pr.06-29		
		0: Warn and keep operation		
Fault	Treatment Parameter	1: Fault and ramp to sto	р	
		2: Fault and coast to sto	рр	
		3: No warning		
	Reset Method	cleared.	the temperature < Pr.06-56, oH3 is automatically	
		When Pr.06-29 = 1 or 2, oH3 is a "Fault". You must reset manually.		
	Reset Condition	Immediately reset		
Record		When Pr.06-29 = 1 or 2, oH3 is a "Fault", and the fault is recorded.		
Cause		Corrective Actions		
Motor shaft lock		Remove the shaft lock.		
The load	is too large	Reduce the load.		
		Increase the motor capacity.		
Ambient	temperature is too high	Change the installed place If there are heating devices in the surroundings.		
		Install/ add cooling fan or air conditioner to lower the ambient temperature.		
	oling system error	Check the cooling system to make it work normally.		
Motor fai	n error	Replace the fan.		
		Decrease low-speed operation time.		
Operate	at low-speed too long	Replace the motor with a dedicated to VFD model.		
		Increase the motor capacity.		
Accel./Decel. time and working cycle are too short		Increase the setting values for Pr.01-12–Pr.01-19 (accel./decel. time).		
		Adjust settings for Pr.01-01-08 (V/F curve), especially the setting value for		
V/F volta	ge is too high	the mid-point voltage (if the mid-point voltage is set too low, the load capacity		
		decreases at low speed).		
Check if the motor rated current		Reset to the correct motor rated current.		
matches that on the motor				
nameplate.				
Check if the PT100 is properly set		Check connection of PT100 thermister		
and wire	d	Check connection of PT100 thermistor.		
Check if	the setting for stall	Set the stall prevention to the proper value.		
prevention	on is correct.			

Cause	Corrective Actions	
Unbalanced three-phase	Replace the motor.	
impedance of the motor		
Harmonics are too high	Use remedies to reduce harmonics.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
	AUTO		When output current exceeds the over-torque detection	
00	Fault	Over torque 1	level (Pr.06-07) and exceeds over-torque detection	
26	ot1	(ot1)	time (Pr.06-08), and when Pr.06-06 or Pr.06-09 is set to	
	Over torque 1		2 or 4, the ot1 error displays.	
		Action and Reset		
	Action Condition	Pr.06-07		
	Action Time	Pr.06-08		
		Pr.06-06		
		0: No function		
		1: Continue operation a	Ifter Over-torque detection during constant speed	
Faul	It Treatment Parameter	operation		
		2։ Stop after Over-torqւ	ue detection during constant speed operation	
		3: Continue operation a	fter Over-torque detection during RUN	
		4։ Stop after Over-torqւ	ue detection during RUN	
		When Pr.06-0	6 = 1 or 3, ot1 is a "Warning". The warning is	
	Reset Method		cleared when the output current < (Pr.06-07 – 5%)	
		Manual When Pr.06-0	6 = 2 or 4, ot1 is a "Fault". You must reset manually.	
	Reset Condition	Immediately reset		
	Record	When Pr.06-06 = 2 or 4, ot1 is a "Fault", and the fault is recorded.		
Cause				
	Cause		Corrective Actions	
Incorrec	Cause t parameter setting	Reset Pr.06-07 and Pr.		
Mechan		Reset Pr.06-07 and Pr.0	06-08.	
Mechan torque, ı	it parameter setting ical failure (e.g. over-mechanical lock)		06-08.	
Mechan torque, ı	t parameter setting ical failure (e.g. over-	Remove the causes of Reduce the load.	06-08.	
Mechan torque, i	it parameter setting ical failure (e.g. over-mechanical lock)	Remove the causes of Reduce the load. Replace the motor with	o6-08.  malfunction.  a larger capacity model.	
Mechan torque, I	t parameter setting ical failure (e.g. over- mechanical lock) d is too large	Remove the causes of Reduce the load. Replace the motor with	06-08. malfunction.	
Mechan torque, I	t parameter setting ical failure (e.g. over- mechanical lock) d is too large	Remove the causes of Reduce the load. Replace the motor with Increase the setting val	o6-08.  malfunction.  a larger capacity model.	
Mechan torque, I	t parameter setting ical failure (e.g. over- mechanical lock) d is too large	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.0	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).	
Mechan torque, I	t parameter setting ical failure (e.g. over- mechanical lock) d is too large lecel. time and working e too short	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.0	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity	
Mechan torque, in The load Accel./Dicycle are V/F voltage.	t parameter setting ical failure (e.g. over- mechanical lock) d is too large lecel. time and working e too short	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.07 the mid-point voltage (if decreases at low speed	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity	
Mechan torque, in The load Accel./Docycle are V/F volta	t parameter setting ical failure (e.g. over- mechanical lock) d is too large lecel. time and working e too short age is too high	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.07 the mid-point voltage (if decreases at low speed	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity d).  a larger capacity model.	
Mechan torque, in The load Accel./Docycle are V/F volta	t parameter setting ical failure (e.g. over- mechanical lock) d is too large lecel. time and working e too short age is too high tor capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.07 the mid-point voltage (if decreases at low speed	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity d).  a larger capacity model.  peration time.	
Mechan torque, in The load Accel./Dicycle and V/F volta The modification operation	t parameter setting ical failure (e.g. over- mechanical lock) d is too large ecel. time and working e too short age is too high tor capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.07 the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed or Increase the motor cap	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity d).  a larger capacity model.  peration time.	
Mechan torque, in The load Accel./Dicycle and V/F volta The modification operation	t parameter setting ical failure (e.g. over- mechanical lock) d is too large lecel. time and working e too short age is too high tor capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.07 the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed or Increase the motor cap Adjust the torque comp	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity d).  a larger capacity model.  peration time.  acity.	
Mechan torque, in The load Accel./Dicycle are V/F volta The mot Overload operation	t parameter setting ical failure (e.g. over- mechanical lock) d is too large ecel. time and working e too short age is too high tor capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.07 the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed or Increase the motor cap Adjust the torque comp until the current reduce	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity d).  a larger capacity model.  peration time.  acity.  ensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.	
Mechan torque, I The load Accel./D cycle are V/F volta The mot Overload operatio Torque of	t parameter setting ical failure (e.g. over- mechanical lock) d is too large lecel. time and working e too short age is too high tor capacity is too small d during low-speed in	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.07 the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed or Increase the motor cap Adjust the torque comp until the current reduce Correct the parameter s	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity d).  a larger capacity model.  peration time.  acity.  ensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.	
Mechan torque, in The load Accel./Dicycle and V/F volta The moleon operation Torque of Improperspeed tr	t parameter setting ical failure (e.g. over- mechanical lock) d is too large lecel. time and working e too short age is too high tor capacity is too small d during low-speed in compensation is too large	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust settings for Pr.07 the mid-point voltage (if decreases at low speed Replace the motor with Decrease low-speed or Increase the motor cap Adjust the torque comp until the current reduce Correct the parameter s 1. Start the speed tra	malfunction.  a larger capacity model.  ues for Pr.01-12–Pr.01-19 (accel./decel. time).  1-01–01-08 (V/F curve), especially the setting value for f the mid-point voltage is set too low, the load capacity d).  a larger capacity model.  peration time.  acity.  ensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
	AUTO		When output current exceeds the over-torque	
	Fault	Over torque 2	detection level (Pr.06-10) and exceeds over-torque	
27	ot2	(ot2)	detection time (Pr.06-11), and when Pr.06-09 is set to 2	
	Over torque 2		or 4, the ot2 error displays.	
		Action and Reset		
	Action Condition	Pr.06-10		
	Action Time	Pr.06-11		
		Pr.06-09		
		0: No function		
		1: Continue operation a	fter Over-torque detection during constant speed	
Fault	t Treatment Parameter	operation		
		2: Stop after Over-torqu	ue detection during constant speed operation	
		3: Continue operation a	fter Over-torque detection during RUN	
		4։ Stop after Over-torqւ	ue detection during RUN	
		When Pr.06-0	9 = 1 or 3, ot2 is a "Warning". The warning is	
	Reset Method	Auto automatically	cleared when the output current < (Pr.06-10 – 5%).	
		Manual When Pr.06-09 = 2 or 4, ot2 is a "Fault". You must reset manually.		
	Reset Condition	Immediately reset		
	Record	When Pr.06-09 = 2 or 4	, ot2 is a "Fault", and the fault is recorded.	
		Corrective Actions		
	Cause		Corrective Actions	
Incorrect	Cause parameter setting	Reset Pr.06-07 and Pr.0	-	
			06-08.	
Mechani	parameter setting	Reset Pr.06-07 and Pr.	06-08.	
Mechani torque, n	cal failure (e.g. over- nechanical lock)		06-08.	
Mechani torque, n	parameter setting	Remove the causes of Reduce the load.	06-08.	
Mechani torque, n	cal failure (e.g. over- nechanical lock)	Remove the causes of Reduce the load. Replace the motor with	one-08.  malfunction.  a larger capacity model.	
Mechani torque, n The load Accel./De	cal failure (e.g. over- nechanical lock)	Remove the causes of Reduce the load. Replace the motor with	06-08. malfunction.	
Mechani torque, n The load Accel./De	cal failure (e.g. over- nechanical lock)  I is too large.  ecel. time and working	Remove the causes of Reduce the load. Replace the motor with Increase the setting val	one-08.  malfunction.  a larger capacity model.	
Mechani torque, n The load Accel./Do	cal failure (e.g. over- nechanical lock)  I is too large.  ecel. time and working	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F	one-08.  malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).	
Mechani torque, n The load Accel./Do	cal failure (e.g. over- nechanical lock)  I is too large.  ecel. time and working	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F	malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).  Pr.01-01–01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load	
Mechani torque, n The load Accel./Decycle are	cal failure (e.g. over- nechanical lock)  I is too large.  ecel. time and working	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F for the mid-point voltage capacity decreases at least	malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).  Pr.01-01–01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load	
Mechani torque, n The load Accel./De cycle are V/F volta	cal failure (e.g. over- nechanical lock)  I is too large.  ecel. time and working e too short  age is too high	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F for the mid-point voltage capacity decreases at least	malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).  Pr.01-01–01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load ow speed).  a larger capacity model.	
Mechani torque, n The load Accel./De cycle are V/F volta	cal failure (e.g. over- nechanical lock)  l is too large. ecel. time and working e too short  age is too high or capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F for the mid-point voltage capacity decreases at I Replace the motor with Decrease low-speed or Increase the motor cap	malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).  Pr.01-01–01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load ow speed).  a larger capacity model.  peration time.  acity.	
Mechani torque, n The load Accel./Decycle are V/F volta The mote Overload operation	cal failure (e.g. over- nechanical lock)  I is too large.  ecel. time and working e too short  age is too high  or capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F for the mid-point voltage capacity decreases at I Replace the motor with Decrease low-speed or Increase the motor cap	malfunction.  a larger capacity model.  ues for Pr.01-12-01-19 (accel./decel. time).  Pr.01-01-01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load ow speed).  a larger capacity model.  peration time.	
Mechani torque, n The load Accel./Decycle are V/F volta The mote Overload operation	cal failure (e.g. over- nechanical lock)  l is too large. ecel. time and working e too short  age is too high or capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F for the mid-point voltage capacity decreases at In Replace the motor with Decrease low-speed op Increase the motor cap Adjust the torque comp	malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).  Pr.01-01–01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load ow speed).  a larger capacity model.  peration time.  acity.	
Mechani torque, n The load Accel./Decycle are V/F volta The moto Overload operation Torque c	cal failure (e.g. over- nechanical lock)  I is too large.  ecel. time and working e too short  age is too high  or capacity is too small d during low-speed	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F for the mid-point voltage capacity decreases at In Replace the motor with Decrease low-speed or Increase the motor cap Adjust the torque componential the current reduce	malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).  Pr.01-01–01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load ow speed).  a larger capacity model.  peration time.  acity.  ensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.	
Mechani torque, n The load Accel./Do cycle are V/F volta The moto Overload operation Torque co	cal failure (e.g. over- nechanical lock)  I is too large. ecel. time and working e too short  age is too high or capacity is too small d during low-speed n ompensation is too large	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F for the mid-point voltage capacity decreases at In Replace the motor with Decrease low-speed op Increase the motor cap Adjust the torque comp until the current reduce Correct the parameter s	malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).  Pr.01-01–01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load ow speed).  a larger capacity model.  peration time.  acity.  ensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.	
Mechani torque, n The load Accel./Do cycle are V/F volta The moto Overload operation Torque co Improper speed tra	cal failure (e.g. over- nechanical lock)  l is too large. ecel. time and working e too short  age is too high or capacity is too small d during low-speed n ompensation is too large r parameter settings for	Remove the causes of Reduce the load. Replace the motor with Increase the setting val Adjust the settings for F for the mid-point voltage capacity decreases at In Replace the motor with Decrease low-speed or Increase the motor cap Adjust the torque comp until the current reduce Correct the parameter s 1. Start the speed tra	malfunction.  a larger capacity model.  ues for Pr.01-12–01-19 (accel./decel. time).  Pr.01-01–01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load ow speed).  a larger capacity model.  peration time.  acity.  ensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.	

No.	Display on LCD Keypad	Fau	ult Name	Fault Descriptions	
28	Fault  uC  Under current	Und	er current (uC)	Low current detection	
			Action and	d Reset	
	Action Condition	Pr.06-71			
	Action Time	Pr.06-72			
		Pr.06-73			
		0: No fun	ction		
Fau	lt Treatment Parameter	1: Fault and coast to stop			
		2: Fault and ramp to stop by second deceleration time			
		3: Warn and operation continue			
		When Pr.06-73 = 3, uC is a "Warning". The warning is automatically		3 = 3, uC is a "Warning". The warning is automatically	
	Reset Method	Auto	cleared when	the output current > (Pr.06-71 + 0.1 A).	
		Manual When Pr.06-73 = 1 or 2, uC is a "Fault". You must reset manually.			
	Reset Condition	Immedia	tely reset		
	Record	When Pr	.06-71 = 1 or 2	, uC is a "Fault", and the fault is recorded.	
	Cause	Corrective Actions			
Motor ca	able disconnection	Troubleshoot the connection between the motor and the load.			
Imprope protection	er setting of low-current	Reset Pr.06-71, Pr.06-72 and Pr.06-73 to proper settings.			
The less	d is too low	Check th	e load status.		
The load	d is too low	Check if the motor capacity matches the load.			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
30	Fault cF1 EEPROM write err	EEPROM write error (cF1)	Internal EEPROM cannot be programmed	
		Action and	d Reset	
	Action Condition	Firmware internal detec	tion	
	Action Time	cF1 acts immediately when the drive detects the fault		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Internal EEPROM cannot be programmed		Press "RESET" key or reset the parameter to the default setting, if cF1 still exists, return to the factory for repair.  Cycle the power, if cF1 still exists, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
31	Fault cF2 EEPROM read err	EEPROM read error (cF2)	Internal EEPROM cannot be read	
		Action and	d Reset	
	Action Condition	Firmware internal detec	tion	
	Action Time	cF2 acts immediately when the drive detects the fault		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
		Press "RESET" key or reset the parameter to the default setting, if cF2 still		
Internal	EEPROM cannot be read	exists, return to the factory for repair.		
		Cycle the power, if cF2 error still exists, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
33	Fault cd1 las sensor err	U-phase error (cd1)	U-phase current detection error when power is ON	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	cd1 acts immediately when the drive detects the fault		
Fau	It Treatment Parameter	N/A		
	Reset Method	Power-off		
	Reset Condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Hardwa	re failure	Cycle the power.  If cd1 still exists, return	to the factory for repair.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
34	Fault cd2	V-phase error (cd2)	V-phase current detection error when power ON	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	cd2 acts immediately when the drive detects the fault		
Fau	It Treatment Parameter	N/A		
	Reset Method	Power-off		
	Reset Condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Hardware failure		Cycle the power.  If cd2 still exists, return	to the factory for repair.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
35	Fault cd3	W-phase error (cd3)	W-phase current detection error when power ON	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	cd3 acts immediately when the drive detects the fault		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Power-off		
	Reset Condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Hardwa	re failure	Cycle the power.  If cd3 still exists, return	to the factory for repair.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
36	Fault Hd0 cc HW error	cc hardware failure (Hd0)	cc (current clamp) hardware protection error when power is ON	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	Hd0 acts immediately when the drive detects the fault		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Power-off		
	Reset Condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Hardware failure		Cycle the power.  If Hd0 still exists, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
37	Fault Hd1 Oc HW error	oc hardware error (Hd1)	oc hardware protection error when power is ON	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	Hd1 acts immediately when the drive detects the fault		
Fau	It Treatment Parameter	N/A		
	Reset Method	Power-off		
	Reset Condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardware failure		Cycle the power.  If Hd1 still exists, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
38	Fault Hd2 Ov HW error	ov hardware error (Hd2)	ov hardware protection error when power is ON	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	Hd2 acts immediately when the drive detects the fault		
Fau	It Treatment Parameter	N/A		
	Reset Method	Power-off		
	Reset Condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Hardwa	re failure	Cycle the power.  If Hd2 still exists, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
39	Fault Hd3 occ HW error		Protection error of occ IGBT short-circuit detection when power is ON	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	Hd3 acts immediately when the drive detects the fault		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Power-off		
	Reset Condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Hardware failure		Cycle the power. If Hd3 still exists, return	to the factory for repair.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
40	Аито Fault AUE Auto tuning error	Auto-tuning error (AUE)	Motor auto-tuning error	
		Action and	l Reset	
	Action Condition	Hardware detection		
	Action Time	Immediately act		
Faul	t Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
Press "S tuning	TOP" key during auto-	Re-execute auto-tuning.		
Incorrect	t motor capacity (too large	Check motor capacity and related parameters.		
or too sn	nall) and parameter	Set the correct parameters, that is Pr.01-01–Pr.01-02.		
setting		Set Pr.01-00 larger than motor rated frequency.		
Incorrect	t motor wiring	Check the wiring.		
Motor sh	naft lock	Remove the cause of motor shaft lock.		
The elec	tromagnetic contactor is			
ON at ou	utput side (U/V/W) of the	Make sure the electromagnetic valve is OFF.		
drive				
The loss	l is too large.	Reduce the load.		
THE IDAC	i is too large.	Replace the motor with	a larger capacity model.	
Accel./D	Accel./Decel. time is too short Increase the setting values for Pr.01-12–Pr.01-19 (Accel./Decel. time).			

No.	Display on LCD Keypad	Fau	ult Name	Fault Descriptions
41	Fault  AFE PID Fbk error		loss ACI (AFE)	PID feedback loss (analog feedback signal is only valid when the PID function is enabled)
			Action and	Reset
	Action Condition	When the	e analog input ·	< 4 mA (only detects 4–20 mA analog input)
	Action Time	Pr.08-08		
		Pr.08-09 0: Warn a	and keep opera	ation
Faul	It Treatment Parameter	1: Fault and ramp to stop		
		2: Fault and coast to stop		
		3: Warn and operate at last frequency		
		When Pr.08-09 = 3 or 4, AFE is a "Warning". When the feedback		
	Reset Method	Auto	signal is > 4m	A, the "Warning" is automatically cleared.
		Manual When Pr.08-09 = 1 or 2, AFE is a "Fault". You must reset manually.		
	Reset Condition	Immediat	tely reset	
	Doord	When Pr.08-09 = 1 or 2, AFE is a "Fault", and the fault is recorded; when Pr.08-		
	Record	09=3 or 4, AFE is a "Warning", and the warning is not recorded.		
	Cause	Corrective Actions		
PID feed	dback cable is loose or cut	Tighten the terminal.		
off		Replace the cable with a new one.		
Feedbad	ck device failure	Replace the device with a new one.		
Hardwai	re failure	Check all	the wiring. If A	FE fault still exists, return to the factory for repair.

No.	Display on LCD Keypad	Fai	ult Name	Fault Descriptions	
48	Fault ACE ACI loss		.CI loss (ACE)	Analog input loss (including all the 4–20 mA analog signal)	
		T	Action and	d Reset	
	Action Condition	When the	e analog input i	s < 4 mA (only detects 4–20 mA analog input)	
	Action Time	Immedia	tely act		
Fau	It Treatment Parameter  Reset Method	Pr.03-19 0: Disable 1: Continue operation at the last frequency (warning, ANL is displayed on the keypad) 2: Decelerate to stop (warning, ANL is displayed on the keypad) 3: Stop immediately and display ACE  Auto When Pr.03-19 = 1 or 2, ACE is a "Warning". When analog input signal is > 4 mA, the warning is automatically cleared.			
	Reset Condition	Immedia	tely reset		
	Record	When Pr	.03-19 = 3, ACI	E is a "Fault", and the fault is recorded.	
	Cause	Corrective Actions			
ACI cable is loose or cut off			hten the terminal. place the cable with a new one.		
Externa	l device failure	Replace the device with a new one.			
Hardwa	re failure	Check al	I the wiring. If A	ACE still exists, return to the factory for repair.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
49	Fault  EF  External fault	External fault (EF)	External fault. When the drive decelerates based on the setting of Pr.07-20, the EF fault displays on the keypad.	
		Action and	d Reset	
	Action Condition	MIx = EF and the MI ter	minal is ON	
	Action Time	Immediately act		
Fault Treatment Parameter		Pr.07-20 0: Coast to stop 1: Stop by the first deceleration time 2: Stop by the second deceleration time 3: Stop by the third deceleration time 4: Stop by the fourth deceleration time 5: System deceleration 6: Automatic deceleration (Pr.01-46)		
	Reset Method	Manual reset		
	Reset Condition	Manual reset only after the external fault is cleared (terminal status is recovered)		
Record Yes				
	Cause	Corrective Actions		
Externa	l fault	Press RESET key after the fault is cleared.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
50	Fault EF1 Emergency stop	Emergency stop (EF1)	When the contact of MIx = EF1 is ON, the output stops immediately and displays EF1 on the keypad.  The motor is in free running.	
		Action and	d Reset	
	Action Condition	MIx = EF1 and the MI terminal is ON		
	Action Time	Immediately act		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Manual reset only after the external fault is cleared (terminal status is recovered)		
	Record	Yes		
	Cause	Corrective Actions		
When MIx=EF1 activates		Verify if the system is back to normal condition, and then press "RESET" key to go back to the default.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
51	Fault bb Base block	l (bb)	When the contact of MIx = bb is ON, the output stops immediately and displays bb on the keypad. The motor is in free running.	
		Action and	d Reset	
	Action Condition	MIx = bb and the MI terminal is ON		
	Action Time	Immediately act		
Fau	lt Treatment Parameter	N/A		
	Reset Method	The display "bb" is automatically cleared after the fault is cleared.		
	Reset Condition	N/A		
	Record	No		
	Cause	Corrective Actions		
When MIx=bb activates		Verify if the system is back to normal condition, and then press "RESET" key to go back to the default.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
52	Fault Pcod Password error	Password is locked (Pcod)	Entering the wrong password three consecutive times		
		Action and	d Reset		
	Action Condition	Entering the wrong pas	sword three consecutive times		
	Action Time	Immediately act			
Fau	ılt Treatment Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Power-off			
	Record	Yes			
	Cause		Corrective Actions		
		1. Input the correct pa	ssword after rebooting the motor drive.		
		2. If you forget the password, do the following steps:			
		Step 1: Input 9999 and press ENTER.			
Incorrec	ct password input through	Step 2: Repeat step 1. Input 9999 and press ENTER.			
Pr.00-0	7	(You need to finish step 1 and step 2 within 10 seconds. If you don't finish			
		the two steps in 10 seconds, try again.)			
		3. The parameter setti	ngs return to the default when the "Input 9999" process		
		is finished.			

No	Display on LCD Keypad	Fault Name	Fault Descriptions	
53	Fault ccod SW Code error	SW Code Error (ccod)	Firmware version is different with the control board hardware ID number	
		Action and	d Reset	
	Action Condition	N/A		
	Action Time	N/A		
Fau	lt Treatment Parameter	N/A		
	Reset Method	N/A		
	Reset Condition	N/A		
	Record	No		
	Cause		Corrective Actions	
Wrong firmware version (example:				
C2000 s	series firmware is burned	Return to the factory for repair.		
into CFF	2000 control board			
hardwar	re)			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
54	Fault CE1 PC err command	Illegal command (CE1)	Communication command is illegal		
		Action and	Reset		
	Action Condition	When the function code	is not 03, 06, 10, or 63.		
	Action Time	Immediately act			
Fau	It Treatment Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Immediately reset			
	Record	No			
	Cause	Corrective Actions			
Incorrect communication command from the upper unit		Check if the communication command is correct.			
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.			
	t communication setting upper unit	Check if the setting for Pr.09-04 is the same as the setting for the upper unit.			
Disconn of the ca	ection or bad connection able	Check the cable and re	place it if necessary.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
55	Fault CE2 PC err address	Illegal data address (CE2)	Data address is illegal		
		Action and	d Reset		
	Action Condition	When the data address	is correct.		
	Action Time	Immediately act			
Fau	lt Treatment Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Immediately reset			
	Record	No			
	Cause		Corrective Actions		
Incorrect communication command from the upper unit		Check if the communication command is correct.			
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.			
	t communication setting upper unit	Check if the setting for Pr.09-04 is the same as the setting for the upper unit.			
Disconn	ection or bad connection	Check the cable and replace it if necessary.			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
56	Fault CE3 PC err data	Illegal data value (CE3)	Data value is illegal	
		Action and	d Reset	
	Action Condition	When the data length is	too long	
	Action Time	Immediately act		
Faul	It Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	No		
	Cause	Corrective Actions		
	t communication nd from the upper unit	Check if the communication command is correct.		
Malfunct interfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	t communication setting upper unit	Check if the setting for Pr.09-04 is the same as the setting for the upper unit.		
Disconnection or bad connection of the cable  Check the cable and replace it if necessary.			place it if necessary.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
57	Fault CE4 PC slave fault	Data is written to read- only address (CE4)	Data is written to read-only address		
		Action and	d Reset		
	Action Condition	When the data is writter	n to read-only address.		
	Action Time	Immediately act			
Fau	It Treatment Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Immediately reset			
	Record	No			
	Cause	Corrective Actions			
Incorrect communication command from the upper unit		Check if the communication command is correct.			
Malfunc interfere	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.			
	t communication setting upper unit	Check if the setting for Pr.09-04 is the same as the setting for the upper unit.			
Disconnection or bad connection of the cable  Check the cable and replace it if necessary.			place it if necessary.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
58	Fault CE10 PC time out	Modbus transmission time-out (CE10)	Modbus transmission time-out occurs		
		Action and	Action and Reset		
	Action Condition	When the communication	on time exceeds the detection time for Pr.09-03 time-out.		
	Action Time	Pr.09-03			
		Pr.09-02			
		0: Warn and continue o	peration		
Fau	It Treatment Parameter	1: Fault and ramp to sto	q		
		2: Fault and coast to stop			
		3: No warning, no fault and continue operation			
	Reset Method	Manual reset			
	Reset Condition	Immediately reset			
	Record	Yes			
	Cause		Corrective Actions		
The upper unit does not transmit the communication command within Pr.09-03 setting time.  Check if the upper unit transmits the communication command within setting time for Pr.09-03.					
Malfunc	tion caused by ence	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.			
	t communication setting upper unit	Check if the setting for Pr.09-04 is the same as the setting for the upper unit.			
Disconn	ection or bad connection able	Check the cable and replace it if necessary.			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
60	Fault bF Braking fault		The brake transistor of the motor drive is abnormal. (for the models with built-in brake transistor)	
		Action and	l Reset	
	Action Condition	Hardware detection		
	Action Time	Immediately act		
Faul	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
Cause			Corrective Actions	
Hardware error		<ol> <li>Press "RESET" key to go back to the default. If bF still exists, return to the factory for repair.</li> <li>Power off the motor drive since the internal circuit is abnormal. Use a meter to check if it is short-circuit between B2 to DC If short-circuit exists, return to the factory for repair.</li> </ol>		
Malfunctinterfere	tion caused by ence	Verify wiring/grounding of the main circuit to prevent interference.		
Using th	e incorrect brake resistor	Check if the resistance value of the brake resistor matches to the drive.		
Incorrect wiring of the brake		Refer to the optional accessories instruction in chapter 7, and verify the wiring.		
resistor		Refer to the optional ac	cessories instruction in chapter 7, and verify the wiring.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
61	Fault ydc Y-delta connect	Y-connection / Δ- connection switch error (ydc)	An error occurs when Y-∆ switches	
		Action and	l Reset	
	Action Condition	<ol> <li>ydc occurs when the confirmation signals of Y-connection and Δ-connection are conducted at the same time.</li> <li>If any of confirmation signals is not conducted within Pr.05-25, ydc occurs.</li> </ol>		
	Action Time	Pr.05-25		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
Reset Condition		Can be reset only when the confirmation signal of Y-connection is conducted if it is Y-connection, or when the confirmation signal of $\Delta$ -connection is conducted if it is $\Delta$ -connection.		
	Record	Yes		
	Cause		Corrective Actions	
	ctromagnetic valve s incorrectly during Y-∆	Check if the electromagnetic valve works normally.  If not, replace it.		
Incorrect parameter setting Check if related parameters are all set up and set correctly.		eters are all set up and set correctly.		
The wiring of Y-∆ switch function is incorrect		Check the wiring.		

No.	Display on LCD Keypad	Fa	ult Name	Fault Descriptions
63	Fault oSL Over slip error		r slip error (oSL)	The speed deviation is abnormal. When the motor drive outputs at constant speed, F > H or F < H exceeds the level set via Pr.07-29, and it exceeds the time set via Pr.07-30, oSL shows. oSL occurs in induction motors only.
			Action and	d Reset
	Action Condition	Pr.07-29 100% of		maximum limit of the slip frequency (Pr.10-29)
	Action Time	Pr.07-30		
Fault Treatment Parameter		Pr.07-31  0: Warn and continue operation  1: Fault and ramp to stop  2: Fault and coast to stop  3: No warning		
	Reset Method	Pr.07-31 = 0 is  When the mot does not exce be cleared aut		or drive outputs at constant speed, and F > H or F < H ed the level set via Pr.07-29 anymore, oSL warning will
	Reset Condition	Immedia	tely reset	
	Record	Pr.07-31	= 1 or 2, oSL is	s "Fault", and will be recorded.
	Cause			Corrective Actions
	he motor parameters in ter group 5 may be t	Check the motor parameters.		
Overloa	d	Decrease the load.		
	he setting value of Pr.07- 30, and 10-29 is improper			L protection function related parameters.

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
64	Fault ryF MC Fault	Electric valve switch error (ryF)	Electric valve switch error when executing Soft Start	
		Action and	d Reset	
	Action Condition	Hardware detection (Fra	ame D)	
	Action Time	Immediately act		
Faul	It Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Reset when the electric valve switch is correctly closed		
	Record	Yes		
	Cause	Corrective Actions		
The innu	it nower is abnormal	Check if the power is shut down during the drive operation.		
The inpu	ut power is abnormal	Check if the three-phase input power is normal.		
Malfunction caused by		Verify the wiring/grounding of the main circuit to prevent interference.		
interference				
Hardwa	re failure	Cycle the power after checking the power. If ryF error still exists, return to the		
iaiuwai	ie ialiule	factory for repair.		

No. Display	on LCD Keypad	Fault Name	Fault Descriptions		
68 SpdF	SdRv bk Dir Rev	Reverse direction of the speed feedback (SdRv)	Rotating direction is different from the commanding direction detected by the sensorless		
		Action and	d Reset		
Action C	ondition	Software detection			
Action	Time	Pr.10-09			
		Pr.10-08			
Fault Treatme	nt Parameter	0: Warn and keep opera	ation		
T ddit Trodino	in r drameter	1: Fault and ramp to stop			
		2: Fault and coast to stop			
Reset Method		Manual reset			
Reset C	ondition	Immediately reset			
Rec	ord	When Pr.10-08 = 1 or 2, SdRv is a "Fault", and the fault is recorded.			
Cau	ıse		Corrective Actions		
The setting of mo	tor parameter is	Reset the motor parameter and execute parameter tuning			
incorrect		Reset the motor parameter and execute parameter tuning.			
The motor cable is	s abnormal or				
broken		Check if the cable is well functioned or replace the cable.			
A reverse force is exerted, or the					
motor runs in a reverse direction at		Start speed tracking fun	oction (Pr.07-12).		
start					
Malfunction cause	ed by	Verify the wiring of the control circuit and wiring/grounding of the main circuit to			
interference		prevent interference.			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
69	Fault SdOr SpdFbk over SPD	Over speed rotation feedback (SdOr)	Over speed rotation detected by sensorless	
		Action and	l Reset	
	Action Condition	Pr.10-10		
	Action Time	Pr.10-11		
Fault Treatment Parameter		Pr.10-12  0: Warn and keep operation  1: Fault and ramp to stop  2: Fault and coast to stop		
Reset Method		Manual reset		
	Reset Condition	Immediately reset		
	Record	When Pr.10-12 = 1 or 2, SdOr is a "Fault", and the fault is recorded.		
	Cause	Corrective Actions		
The setting of ASR bandwidth of speed controller is improper		Increase the bandwidth of ASR speed controller.		
The setting of motor parameter is incorrect Reset motor parameter and execute parameter tuning.			and execute parameter tuning.	
Malfunc	tion caused by	Verify the wiring of the control circuit and wiring/grounding of the main circuit to		
interfere	ence	prevent interference.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
70	Fault SdDe SpdFbk deviate	Large deviation of speed feedback (SdDe)	A large deviation between the rotating speed and the command detected by the sensorless	
		Action and	d Reset	
	Action Condition	Pr.10-13		
	Action Time	Pr.10-14		
		Pr.10-15 0: Warn and keep opera 1: Fault and ramp to sto	pp	
	Reset Method	2: Fault and coast to sto  Manual reset	op	
	Reset Condition	Immediately reset		
	Record	When Pr.10-15 = 1 or 2, SdDe is a "Fault", and the fault is recorded.		
Cause		Corrective Actions		
Improper parameter setting for abnormal rotating slip function		Reset proper setting for Pr.10-13 and Pr.10-14.		
Imprope	r parameter setting for	Reset ASR parameters.		
ASR and	d acceleration/deceleration	Set proper acceleration/deceleration time.		
The acc	eleration/deceleration time ort	Reset proper acceleration/deceleration time.		
Motor sh	naft lock	Remove the cause of motor shaft lock.		
The mechanical brake is not released		Verify the system action timeline.		
Incorrect parameter setting for torque limit (Pr.06-12, Pr.11-17 – 20)		Adjust the setting to proper value.		
Malfunctinterfere	tion caused by nce	Verify the wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
71	Fault WDTT Watchdog	Watchdog (WDTT)	Watchdog error	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	N/A		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Hardware failure and cannot reset. Cycle the power.		
	Reset Condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardwa	re interference	Verify the wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.		
		If the WDTT fault still exists, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
72	Fault STL1 STO Loss 1	STO Loss 1 (STL1)	STO1–SCM1 internal loop detection error	
		Action and	Reset	
	Action Condition	Hardware detection		
	Action Time	Immediately act		
Fau	It Treatment Parameter	N/A		
	Reset Method	Hardware failure, and cannot reset. Cycle the power.		
	Reset Condition	N/A		
Record		Yes		
Cause			Corrective Actions	
STO1 and SCM1 short circuit lines are not connected		Connect the short circui	t line.	
Hardware failure		After you make sure all the wiring is correct, if STOL fault still exists after cycling the power, return to the factory for repair.		
Bad cor	Check if the PIN of IO card is broken.  Bad connection of the IO card  Check if the PIN of IO card is broken.  Check if the PIN of IO card is broken.  Check if the PIN of IO card is broken.			
The IO card does not match the version of the control board		Contact local agent or Delta.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
73	Fault S1 S1-emergy stop	Emergency stop for external safety (S1)	Emergency stop for external safety	
		Action and	d Reset	
	Action Condition	Hardware detection		
	Action Time	Immediately act		
Faul	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Reset only after S1 error is cleared.		
	Record	Yes		
	Cause	Corrective Actions		
The switch action of S1 and SCM (OPEN)		Reset the switch and cycle the power.		
S1 and SCM short circuit lines are not connected		Re-connect the short circuit lines.		
Malfunc	tion caused by	Verify the wiring/grounding of the main circuit, control circuit and encoder to		
interfere	ence	prevent interference.		
Hardwai	re failure	If S1 fault still exists after cycling the power, return to the factory for repair.		
		Check if the PIN of IO card is broken.		
Poor co	nnection of the IO card	Check if the IO card connects to the control board correctly, and if the screws are tightened well.		
	card does not match the of the control board	Contact local agent or Delta.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
74	Fault Fire	Fire mode output (Fire)	This fault occurs when the Fire mode is triggered.	
		Action and	l Reset	
	Action Condition	MIx=58 or 59 and the MI terminal is ON		
	Action Time	Act immediately		
Fau	lt Treatment Parameter	Refer to settings of Pr.06-80–06-87		
	Reset Method	Manual reset		
	Reset Condition	Reset after the fault is cleared		
	Record	Yes		
	Cause	Corrective Actions		
The MI terminal = 58 or 59 is ON		Press RESET key after status.	checking the system status and returns to normal	

No.	Display on LCD Keypad	Fai	ult Name	Fault Descriptions	
76	Fault STO		STO (STO)	Safety Torque Off function active	
			Action and	Reset	
	Action Condition	Hardware	e detection		
	Action Time	Immedia	tely act		
Fau	lt Treatment Parameter	N/A			
	Reset Method		Auto When Pr.06-44 = 1 and after STO error is cleared, it automatically resets.		
		Manual	When Pr.06-4	4 = 0 and after STO error is cleared, reset it manually.	
	Reset Condition		Reset only after STO error is cleared.		
	Record	Yes			
	Cause	Corrective Actions			
	tch action of STO1/SCM1 D2/SCM2 (OPEN)	Reset the switch (ON) and cycle the power.		and cycle the power.	
Check if the PIN of IO card is broken.  Poor connection of the IO card  Check if the IO card connects to the control board correctly, and if are tightened well.					
	card does not match the of the control board	Contact local agent or Delta.			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
77	Fault STL2 STO Loss 2	STO Loss 2 (STL2)	STO2–SCM2 internal loop detection error	
		Action and	d Reset	
,	Action Condition	Hardware detection		
	Action Time	Immediately act		
Fault	Treatment Parameter	N/A		
	Reset Method	Hardware failure, and cannot reset. Cycle the power.		
	Reset Condition	N/A		
Record		Yes		
Cause			Corrective Actions	
STO2 and SCM2 short circuit lines are not connected		Connect the short circui	t lines.	
Hardware failure		After you make sure all the wiring is correct, if STL2 fault still exists after cycling the power, return to the factory for repair.		
		Check if the PIN of IO card is broken.  Check if the IO card connects to the control board correctly, and if the screws		
		are tightened well.		
	he IO card does not match the Contact local agent or Delta.			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
78	Fault STL3 STO Loss 3	STO Loss 3 (STL3)	STO1–SCM1 and STO2–SCM2 internal loop detection error		
		Action and	d Reset		
	Action Condition	Hardware detection			
	Action Time	Immediately act			
Fau	It Treatment Parameter	N/A			
	Reset Method	Hardware failure, and c	annot reset. Cycle the power.		
	Reset Condition	N/A			
	Record	Yes			
Cause		Corrective Actions			
STO1 and SCM1, or STO2 and					
SCM2 s	short circuit lines are not	Re-connect the short circuit lines.			
connect	red				
Hardwa	re failure	After you make sure all the wiring is correct, if STL3 fault still exists after cycling			
ilaiuwa	re fallule	the power, return to the factory for repair.			
		Check if the PIN of IO card is broken.			
Poor connection of the IO card		Check if the IO card connects to the control board correctly, and if the screws			
are tightened well.					
The IO	card does not match the	Contact local agent or Delta.			
version	of the control board	Contact local agent of L	· ond.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
82	Fault OPHL U phase lacked	Output phase loss U phase (OPHL)	U phase output phase loss	
		Action and	l Reset	
	Action Condition	Pr.06-47		
	Action Time	Pr.06-46 Pr.06-48: Use the setting value of Pr.06-48 first if there is DC braking function, and then use that of Pr.06-46.		
Fault Treatment Parameter		Pr.06-45  0: Warn and keep operation  1: Fault and ramp to stop  2: Fault and coast to stop  3: No warning		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Pr.06-45 = 1 or 2 is "Fau	ult", and will be recorded.	
	Cause	Corrective Actions		
	e-phase impedance of unbalanced	Replace the motor.		
The motor is wired incorrectly  Check the cable condition.  Replace the cable.		on.		
Using a single-phase motor Choose a three-phase motor.		notor.		
Check the flat cable of the control board. Re-do the wiring and test again flat cable is loose. If the fault still exists, return the unit to the factory.  Verify that the three-phase current is balanced via a current clamp meter balanced and the OPHL fault still exists, return the unit to the factory		fault still exists, return the unit to the factory. ase current is balanced via a current clamp meter. If it is		
	e capacity is much larger motor capacity	Make sure the capacity	of the drive and motor match to each other.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
83	Fault OPHL V phase lacked	Output phase loss V phase (OPHL)	V phase output phase loss	
		Action and	d Reset	
	Action Condition	Pr.06-47		
			g value of Pr.06-48 first. If DC braking function that of Pr.06-46.	
Fault Treatment Parameter		Pr.06-45  0: Warn and keep operation  1: Fault and ramp to stop  2: Fault and coast to stop  3: No warning		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
Record		When Pr.06-45 = 1 or 2	, OPHL is a "Fault", and the fault is recorded.	
	Cause		Corrective Actions	
	nced three-phase	Replace the motor.		
Check if	the wiring is incorrect	Check the cable and re	place it if necessary.	
Check if phase m	the motor is a single- notor	Choose a three-phase r	motor.	
Check if broken	the current sensor is	Check if the control board cable is loose. If yes, reconnect the cable and run the drive to test. If the fault still exists, return to the factory for repair.  Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the OPHL fault still exists, return to the factory for repair.		
larger	the drive capacity is motor capacity	Choose the drive that matches the motor capacity.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
84	Fault OPHL W phase lacked	Output phase loss W phase (OPHL)	W phase output phase loss	
		Action and	Reset	
	Action Condition	Pr.06-47		
	Action Time		g value of Pr.06-48 first. If DC braking function that of Pr.06-46.	
Fault Treatment Parameter		Pr.06-45  0: Warn and continue operation  1: Fault and ramp to stop  2: Fault and coast to stop  3: No warning		
	Reset Method	Manual reset		
Reset Condition Immediately reset				
	Record	When Pr.06-45 = 1 or 2	, OPHL is a "Fault", and the fault is recorded.	
Cause			Corrective Actions	
	ced three-phase ace of the motor	Replace the motor.		
Check if	the wiring is incorrect	Check the cable and replace it if necessary.		
Check if phase m	the motor is a single- notor	Choose a three-phase motor.		
Check if broken	the current sensor is	the drive to test. If the fault Check if the three-phas	rd cable is loose. If yes, reconnect the cable and run still exists, return to the factory for repair. e current is balanced with a current clamp meter. If the the OPHL fault still exists, return to the factory for	
larger	the drive capacity is motor capacity	Choose the drive that matches the motor capacity.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
87	Fault oL3 Derating Error	Overload protection at low frequency (oL3)	The load is approaching the power module limit		
		Action and	d Reset		
	Action Condition	Software detection			
	Action Time	Immediately act			
Fau	lt Treatment Parameter	N/A			
	Reset Method	Manual reset			
	Reset Condition	Immediately reset			
	Record	Yes			
	Cause		Corrective Actions		
		1. Reduce the motor of	lrive's load.		
		2. Decrease the carrier frequency (Pr.00-17).			
		3. Decrease the ambient temperature of the drive's operation.			
D		4. Decrease the current limit.			
Powerr	module overload	5. Choose motor drives with larger power.			
		6. Increase acceleration time.			
		7. If the drive is in V/F mode, decrease the output voltage for low-frequency			
		operation.			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
89	Fault RoPd Rotor Pos. Error	Rotor position detection error (RoPd)	Rotor position detection error protection	
		Action and	Reset	
	Action Condition	Software detection		
	Action Time	Immediately act		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Check if	the motor cable is	Check or replace the cable		
abnormal or broken		Check or replace the cable.		
Motor coil error		Replace the motor.		
Hardware failure		IGBT broken. Return to the factory for repair.		
Drive's	current feedback line error	Cycle the power. If RoPd still occurs during operation, return to the factory for		
וואפ א	bulletit leeuback lille ellül	repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
90	Fault Fstp Force Stop	Force to stop (FStp)	Keypad forces PLC to Stop	
		Action and	I Reset	
	Action Condition	When Pr.00-32 = 1, ST	OP button on the keypad is valid. When giving the	
	Action Condition	STOP command during the PLC operation, FStp fault will active.		
	Action Time	Immediately act		
Fau	It Treatment Parameter	N/A		
Reset Method		Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Pr.00-32 = 1: keypad STOP button		Check if it is necessary to set Pr.00-32 = 0, so the keypad STOP button is		
is valid		invalid.		
Press STOP button during PLC operation		Verify the timing of STOP function.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
93	Fault TRAP CPU Trap 0 error	CPU error 0 (TRAP)	CPU crash	
		Action and	l Reset	
	Action Condition	Hardware detection		
	Action Time	Immediately act		
Fau	It Treatment Parameter	N/A		
Reset Method		Cannot reset, power off.		
Reset Condition		N/A		
	Record	Yes		
	Cause		Corrective Actions	
		Verify the wiring of control circuit, and the wiring/grounding of the main circuit to		
Hardware interference		prevent interference.		
		If TRAP fault still exists, return to the factory for repair.		
Hardware failure		Return to the factory for repair.		
CPU is i	n an infinite loop	Cycle the power. If the TRAP fault still exists, return to the factory for repair.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
101	Fault CGdE Guarding T-out	CANopen guarding error (CGdE)	CANopen guarding error	
		Action and	l Reset	
		When CANopen Node (	Guarding detects that one of the slaves does not	
	Action Condition	response, the CGdE fau	ult will activate.	
		The upper unit sets fact	or and time during configuration.	
	Action Time	The time that upper unit	t sets during configuration	
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	The upper unit sends a reset package to clear this fault		
Record		Yes		
	Cause	Corrective Actions		
_	arding time is too short, or ection times	Increase the guarding time (Index 100C) and detection times.		
	1. Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the mair or wire in 90 degree for effective anti-interference performance.  2. Make sure the communication circuit is wired in series.  3. Use CANopen cable or add terminating resistance.		eparate the communication circuit from the main circuit, e for effective anti-interference performance.  munication circuit is wired in series.	
Commu bad con	nication cable is broken or nected			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
102	Fault CHbE Heartbeat T-out	CANopen heartbeat error (CHbE)	CANopen heartbeat error	
		Action and	l Reset	
Action Condition		When CANopen Heartbeat detects that one of the slaves does not response, the CHbE fault will activate.  The upper unit sets the confirming time of producer and consumer during configuration.		
	Action Time	The confirming time that upper unit sets for producer and consumer during configuration.		
Fau	It Treatment Parameter	N/A		
Reset Method		Manual reset		
	Reset Condition	The upper unit sends a reset package to clear this fault		
	Record	Yes		
	Cause	Corrective Actions		
The hea	artbeat time is too short	Increase heartbeat time	(Index 100C).	
Malfunc interfere	tion caused by ence	recommended to se or wire in 90 degree 2. Make sure the com	d grounding of the communication circuit. It is eparate the communication circuit from the main circuit, e for effective anti-interference performance. munication circuit is wired in series. e or add terminating resistance.	
Communication cable is broken or bad connected  Check or replace the communication cable.			ommunication cable.	

No.	Display on LCD Keypad	Fault	Name	Fault Descriptions
104	Fault CbFE Can bus off	_	bus off error bFE)	CANopen bus off error
		Action and Reset		
		Hardware	When CANo	pen card is not installed, CbFE fault will occur.
	Action Condition	Software	fault will occ	aster received wrong communication package, CbFE ur. terference on BUS
			When the Ca	AN_H and CAN_L communication cable is short, the
			master will r	eceive wrong package, and CbFE fault will occur.
	Action Time	Immediate	ly act	
Faul	t Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Cycle the power		
	Record	Yes		
Cause		Corrective Actions		
	Check if the CANopen card is installed		the CANope	n card is installed.
Check if	f the CANopen speed Reset CANopen speed (Pr.09-37).		(Pr.09-37).	
Malfunct interfere	tion caused by nce	<ol> <li>Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.</li> <li>Make sure the communication circuit is wired in series.</li> <li>Use CANopen cable or add terminating resistance.</li> </ol>		
Commun	nication cable is broken or nected	Check or re	eplace the co	ommunication cable.

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
105	Fault CldE Can bus Index Err	CANopen index error (CidE)	CANopen index error	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately act		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Upper unit sends a reset package to clear this fault		
	Record	Yes		
Cause		Corrective Actions		
Incorrectindex	ct setting of CANopen	Reset CANopen Index	(Pr.00-02 = 7).	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
106	Fault  CAdE  Can bus Add. Err	CANopen station address error (CAdE)	CANopen station address error (only supports 1–127)	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately act		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset (Pr.00-02 = 7)		
	Reset Condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Incorrect station a	et setting of CANopen	<ol> <li>Disable CANopen (Pr.09-36 = 0).</li> <li>Reset CANopen (Pr.00-02 = 7).</li> <li>Reset CANopen station address (Pr.09-36).</li> </ol>		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions		
107	Fault  CFrE  Can bus off	CANopen memory error (CFrE)	CANopen memory error		
		Action and	Reset		
	Action Condition	When the user update f	irmware version of the control board, the FRAM internal		
	Action Condition	data will not be changed, and then CFrE fault will occur.			
Action Time		Immediately act			
Fault Treatment Parameter		N/A			
	Reset Method	Manual reset			
	Reset Condition	Pr.00-02 = 7			
	Record	Pr.00-21 = 3, the fault is recorded			
Cause		Corrective Actions			
		1. Disable CANopen (Pr.09-36 = 0).			
CANope	en internal memory error	2. Reset CANopen (Pr.00-02 = 7).			
		3. Reset CANopen station address (Pr.09-36).			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
111	Fault ictE InrCom Time Out	InrCOM time-out error (ictE)	Internal communication time-out	
		Action and	d Reset	
	Action Condition	,	re is no -9), when the internal communication between normal, lctE fault occurs.	
	Action Time	Immediately act		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Automatically reset after the internal communication is normal		
	Reset Condition	N/A		
	Record	Yes		
	Cause	Corrective Actions		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
The communication condition is different with the upper unit		Verify the setting of Pr.0	9-04 is the same as the setting of upper unit.	
Commu bad con	nication cable is broken or nected	Check or replace the co	ommunication cable.	

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
112	Fault SfLK PMLess Shaft Lock	PMLess shaft lock (SfLK)	The drive has RUN command with output frequency, but the permanent magnetic motor does not turn.	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	3 sec.		
Fau	It Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Improper setting of the speed observer bandwidth		Increase the setting value.		
Motor shaft lock		Remove causes of the motor shaft lock.		
Motor e	rror (e.g. demagnetization)	Replace the motor with a new one.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
113	Fault SWOC SW over current	Software over-current (SWOC)	When the output current exceeds the set value, the drive immediately stops the output, the motor runs freely and the keypad displays SWOC error.	
Action and Reset			d Reset	
	Action Condition	When the output current exceeds the set level in Pr.06-88		
	Action Time	Immediately act		
Faul	t Treatment Parameter	N/A		
	Reset Method	Manaul reset		
	Reset Condition	Reset in 5 sec. after the	e fault is cleared	
	Record	Yes		
	Cause		Corrective Actions	
Acceleration time is set too short		<ol> <li>Increase the acceleration time.</li> <li>Increase the acceleration time of S-curve.</li> <li>Set auto-acceleration and auto-deceleration parameter (Pr.01-44).</li> <li>Set over-current stall prevention function (Pr.06-03).</li> <li>Replace the drive with a larger capacity model.</li> </ol>		
Short cir	cuit at motor output due to	Check the motor cable and remove causes of the short circuits, or replace the		
	ulation wiring	cable before turning on the power.		
Check fo	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
aging ins	sulation of the motor	insulation is poor.		
The load	l is too large	Check if the output current during the whole working process exceeds the AC motor drive's rated current. If yes, replace the AC motor drive with a larger capacity model.		
Impulsiv	e change of the load	Reduce the load or increase the capacity of AC motor drive.		
Use spe	cial motor or motor with	Check the motor capac	ity (the rated current on the motor's nameplate should	
larger ca	apacity than the drive	be ≤ the rated current o	f the drive).	
Use ON	/ OFF controller of an	Check the action timing	of the contactor and make sure it is not turned ON /	
electrom	agnetic contactor at the	OFF when the drive out		
output (l	output (U/V/W) of the drive			
V/F curv	e setting error		quency and votlage. When the fault occurs and the bigh, reduce the votlage.	
Torque compensation is too large  Adjust the torque compensation (refer to Pr.07-26 Torque compensation until the output current reduces and the motor does not stall.		ensation (refer to Pr.07-26 Torque compensation gain)		
Malfunct interfere	tion caused by	Verify the wiring of the operation of th	control circuit and wiring/ grounding of the main circuit to	
	notor starts when in free run Enable Pr.07-12 speed tracking during start up.		tracking during start up.	
The motor date when it had fall believe that 12 appear tracking daming start up.				

Cause	Corrective Actions		
Improper parameter settings for the speed tracking function (including restart after momentary power loss and restart after fault)	Correct the parameter settings for speed tracking.  1. Start the speed tracking function.  2. Adjust the maximum current for Pr.07-09 speed tracking.		
Incorrect combination of control mode and used motor	Check the settings for Pr.00-11 control mode:  1. For IM, Pr.00-11 = 0, 2.  2. For PM, Pr.00-11 = 6.		
The length of motor cable is too long	Increase AC motor drive's capacity.  Install AC reactor(s) on the output side (U/ V/ W).		
Hardware failure	The ocA occurs due to short circuit or ground fault at the output side of the drive.  Check for possible short circuits between terminals with the electric meter:  B1 correspond to U, V and W; DC- corresponds to U, V and W; corresponds to U, V and W.  If short circuit occurs, return to the factory for repair.		
If the setting for stall prevention is correct	Set the stall prevention to the proper value.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
142	АUTO Fault AUE1 Auto tuning Err	Auto-tune error 1 (AUE1)	No feedback current error when motor parameter automatically detects	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately act		
Fau	It Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Motor is	not wired	Wire the motor correctly.		
The electromagnetic contactor is				
used as	an open state on the	Verify that the electromagnetic valve is closed.		
output s	ide of the drive (U/V/W).			

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
143	Fault AUE2 Auto tuning Err	Auto-tune error 2 (AUE2)	Motor phase loss error when motor parameter automatically detects	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately act		
Faul	It Treatment Parameter	N/A		
Reset Method		Manual reset		
Reset Condition		Immediately reset		
Record		Yes		
	Cause	Corrective Actions		
Incorrec	t motor wiring	Wire the motor correctly.		
Motor er	rror	Check if the motor works normally.		
The electromagnetic contactor is				
used as	an open state on the	Verify that the three-phases of the electromagnetic valve are all closed.		
output side of the drive (U/V/W).				
Motor U	/V/W wire error	Check if the wires are broken.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
144	Fault AUE3 Auto tuning Err	Auto-tune error 3 (AUE3)	No load current I <sub>0</sub> measurement error when motor parameter automatically detects.	
		Action and	d Reset	
	Action Condition	Software detection		
	Action Time	Immediately act		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Incorrect settings for the motor		Charly the pattings for Dr. 05, 04 / Dr. 05, 42 / Dr. 05, 24		
parame	ter (rated current)	Check the settings for Pr.05-01 / Pr.05-13 / Pr.05-34.		
Motor e	rror	Check if the motor works normally.		

No.	Display on LCD Keypad	Fault Name	Fault Descriptions	
148	Fault AUE4 Auto tuning Err	Auto-tune error 4 (AUE4)	Leakage inductance Lsigma measurement error when motor parameter automatically detects.	
		Action and	I Reset	
	Action Condition	Software detection		
	Action Time	Immediately act		
Fau	lt Treatment Parameter	N/A		
	Reset Method	Manual reset		
	Reset Condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Motor e	rror	Check if the motor works normally.		
Incorrect setting of motor parameters (base frequency)		Check the setting of Pr.01-01.		

[This page is intentionally left blank]

# Chapter 15 CANopen Overview

- 15-1 CANopen Overview
- 15-2 Wiring for CANopen
- 15-3 CANopen Communication Interface Description
- 15-5 CANopen Fault Codes
- 15-6 CANopen LED Function

#### Chapter 15 CANopen Overview | CFP2000

The built-in CANopen function is a kind of remote control. You can control the AC motor drive by using the CANopen protocol. CANopen is a CAN-based higher layer protocol that provides standardized communication objects, including real-time data (Process Data Objects, PDO), configuration data (Service Data Objects, SDO) and special functions (Time Stamp, Sync message, and Emergency message). It also has network management data, including Boot-up message, NMT message, and Error Control message. Refer to CiA website <a href="http://www.can-cia.org/">http://www.can-cia.org/</a> for details. The content of this instruction sheet may be revised without prior notice. Consult our distributors or download the most updated version at <a href="http://www.delta.com.tw/industrialautomation">http://www.delta.com.tw/industrialautomation</a>

#### **Delta CANopen supporting functions:**

- Support CAN2.0A Protocol
- Support CANopen DS301 V4.02
- Support DSP-402 V2.0

#### **Delta CANopen supporting services:**

- PDO (Process Data Objects): PDO1-PDO4
- SDO (Service Data Object):

Initiate SDO Download;

Initiate SDO Upload;

Abort SDO

You can use the SDO message to configure the slave node and access the Object Dictionary in every node.

SOP (Special Object Protocol)

Support default COB-ID in Predefined Master / Slave Connection Set in DS301 V4.02

Support SYNC service

Support Emergency service

NMT (Network Management)

Support NMT module control

Support NMT Error control

Support Boot-up


#### **Delta CANopen not supporting service:**

Time Stamp service

## 15-1 CANopen Overview

#### **CANopen Protocol**

CANopen is a CAN-based higher layer protocol, and was designed for motion-oriented machine control networks such as handling systems. Version 4.02 of CANopen (CiA DS301) is standardized as EN50325-4. The CANopen specifications cover the application layer and communication profile (CiA DS301), as well as a framework for programmable devices (CiA DS302), recommendations for cables and connectors (CiA DS303-1) and SI units and prefix representations (CiA DS303-2).



#### **RJ45 Pin Definition**



PIN	Signal	Description						
1	CAN_H	CAN_H bus line (dominant high)						
2	CAN_L	CAN_L bus line (dominant low)						
3	CAN_GND	Ground / 0V / V-						
6	CAN_GND	Ground / 0V / V-						


## **CANopen Communication Protocol**

CANopen communication protocol contains the following services:

- NMT (Network Management Object)
- SDO (Service Data Objects)
- PDO (Process Data Object)
- EMCY (Emergency Object)

## **NMT (Network Management Object)**

The Network Management (NMT) follows a Master / Slave structure for executing NMT service. A network has only one NMT master, and the other nodes are slaves. All CANopen nodes have a present NMT state, and the NMT master can control the state of the slave nodes. The following shows the state diagram of a node:



(1) After power is applied, start in the auto-initialization state A: NMT

(2) Automatically enter the pre-operational state B: Node Guard

(3) (6) Start remote node C: SDO

(4) (7) Enter pre-operational state D: Emergency

(5) (8) Stop remote node E: PDO

(9) (10) (11) Reset node F: Boot-up

(12) (13) (14) Reset communication

(15) Automatically enter the reset application state

(16) Automatically enter the reset communication state

	Initializing	Pre-Operational	Operational	Stopped
PDO			0	
SDO		0	0	
SYNC		0	0	
Time Stamp		0	0	
EMCY		0	0	
Boot-up	0			
NMT		0	0	0

#### SDO (Service Data Objects)

Use SDO to access the Object Dictionary in every CANopen node using the Client / Server model. One SDO has two COB-ID (request SDO and response SDO) to upload or download data between two nodes. There is no data limit for SDOs to transfer data, but it must transfer data by segment when the data exceeds four bytes with an end signal in the last segment.

The Object Dictionary (OD) is a group of objects in a CANopen node. Every node has an OD in the system, and OD contains all parameters describing the device and its network behavior. The access path in the OD is the index and sub-index; each object has a unique index in the OD, and has a sub-index if necessary.

## PDO (Process Data Object)

PDO communication can be described by the producer / consumer model. Each node of the network listens to the messages of the transmission node and distinguishes whether the message has to be processed or not after receiving the message. A PDO can be transmitted from one device to one another device or to many other devices. Every PDO has two PDO services: a TxPDO and an RxPDO. PDOs are transmitted in a non-confirmed mode. All transmission types are listed in the following table:

Type Number		PDO											
	Cyclic	Acyclic	Synchronous	Asynchronous	RTR only								
0		0	0										
1–240	0		0										
241–251			Reserved										
252			0		0								
253				0	0								
254				0									
255				0									


- Type number 0 indicates the synchronous aperiodic message between two PDO transmissions.
- Type number 1–240 indicates the number of SYNC message between two PDO transmissions.
- Type number 252 indicates the data is updated (but not sent) immediately after receiving SYNC.
- Type number 253 indicates the data is updated immediately after receiving RTR.
- Type number 254 indicates that Delta CANopen does not support this transmission format.
- Type number 255 indicates the data is an asynchronous aperiodic transmission.
- All PDO transmission data must be mapped to index via Object Dictionary.

#### **EMCY (Emergency Object)**

When errors occur inside the hardware, an emergency object is triggered. An emergency object is only sent when an error occurs. As long as there is none of hardware error, there is no emergency object warning of an error message.

# 15-2 Wiring for CANopen

Use an external CANopen communication card EMC-COP01 for CANopen wiring to connect the CANopen to the CFP2000. The link uses an RJ45 cable. You must write the two farthest ends with 120  $\Omega$  terminating resistors as shown in the picture below.



# 15-3 CANopen Communication Interface Description

#### 15-3-1 CANopen Control Mode Selection

There are two control modes for CANopen: the DS402 standard (Pr.09-40 = 1) is the default, and the Delta's standard setting (Pr.09-40 = 0). There are two control modes according to Delta's standard. One is the old control mode (Pr.09-30 = 0); this control mode can only control the motor drive under frequency control. The other mode is a new standard (Pr.09-30 = 1); this new control mode allows the motor drive to be controlled under all kinds of modes. The CFP2000 currently only supports speed mode. The following table shows the control mode definitions:

CANlanan Cantral	Control Mode					
CANopen Control	Speed					
Mode Selection	Index	Description				
DS402 standard	6042-00	Target rotating speed (rpm)				
Pr.09-40 = 1						
Delta Standard (Old definition) Pr.09-40 = 0 Pr.09-30 = 0	2020-02	Target rotating speed (Hz)				
Delta Standard (New definition)	2060-03	Target rotating speed (Hz)				
Pr.09-40 = 0, Pr.09-30 = 1	2060-04	Torque Limit (%)				

CANopen Control Mode	Operatio	n Control
Selection	Index	Description
DS402 standard	6040-00	Operation Command
Pr.09-40 = 1		
Delta Standard (Old definition)	2020-01	Operation Command
Pr.09-40 = 0, Pr.09-30 = 0	2020-01	Operation Command
Delta Standard (New definition)	2060-01	Operation Command
Pr.09-40 = 0, Pr.09-30 = 1		

CANopen Control Mode	Otl	her	
Selection	Index	Description	
DC400 standard	605A-00	Quick stop processing method	
DS402 standard Pr.09-40 = 1	605C-00	Disable operation processing	
F1.09-40 = 1	803C-00	method	
Delta Standard (Old definition)			
Pr.09-40 = 1, Pr.09-30 = 0			
Delta Standard (New definition)			
Pr.09-40 = 0, Pr.09-30 = 1			

You can use some indices in either DS402 or Delta's standard.

#### For example:

1. Index that are defined as RO attributes.

2. The corresponding index of available parameter groups: 2000-00-200B-XX)

3. Acceleration / Deceleration Index: 604F 6050

4. Control mode: Index: 6060

#### 15-3-2 DS402 Standard Control Mode

15-3-2-1 Related Setting for an AC Motor Drive (Following the DS402 Standard)

If you want to use the DS402 standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 15-2 Wiring for CANopen)
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. (Run/stop, forward/reverse run...etc.)
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.)
- 4. Set DS402 for the control mode: Pr.09-40 = 1
- 5. Set the CANopen station: set Pr.09-36, the range is between 1–127. When Pr.09-36 = 0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02 = 7 to reset.
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS Baud Rate: 1 Mbps(0), 500 Kbps(1), 250 Kbps (2), 125 Kbps (3), 100 Kbps (4) and 50 Kbps (5))
- 7. Set the multiple input functions to Quick Stop. You can also choose to enable or disable; the default setting is disabled. If it is necessary to enable the function, set MI terminal to 53 in one of the following parameter: Pr.02-01–Pr.02-08 or Pr.02-26–Pr.02-31. Note that this function is available in DS402 only.

## 15-3-2-2 The Status of the Motor Drive (by Following DS402 Standard)

According to the DS402 definition, the motor drive is divided into 3 blocks and 9 statuses as described below.

#### 3 blocks

- Power Disable: Without PWM output
- Power Enable: With PWM output
- Fault: One or more errors have occurred.

#### 9 status

- Start: Power On
- Not ready to switch on: The motor drive is initiating.
- Switch On Disable: occurs when the motor drive finishes initiating.
- Ready to switch on: warming up before running.
- Switch On: the motor drive has the PWM output now, but the reference command is not effective.
- Operation Enable: able to control normally.
- Quick Stop Active: when there is a Quick Stop request, stop running the motor drive.
- Fault Reaction Active: the motor drive detects conditions which might trigger error(s).
- Fault: One or more errors have occurred in the motor drive.


When the motor drive turns on and finishes the initiation, it remains in Ready to Switch On status. To control the operation of the motor drive, change to Operation Enable status. To do this, set the control word's bit0–bit3 and bit7 of the Index 6040H and pair with Index Status Word (Status Word 0X6041). The control steps and index definition are described as below:

#### Index 6040

15–9	8	7	6–4	3	2	1	0
Reserved	Halt	Fault Reset	Operation	Enable operation	Quick Stop	Enable Voltage	Switch On

#### Index 6041

15–1	4 13–12	11	10	9	8	7	6	5	4	3	2	1	0
Reserv	edOperation	Internal limit active	Target reached	Remote	Reserved		Switch on disabled	Quick stop	Voltage enabled	Fault	Operation enable		Ready to switch on



Set command 6040 = 0xE, then set another command 6040 = 0xF. Then you can switch the motor drive to Operation Enable. The Index 605A determines the direction of the lines from Operation Enable when the control mode changes from Quick Stop Active. When the setting value is 1–3, both direction lines are active, but when the setting value of 605A is not 1–3, once the motor drive is switched to Quick Stop Active, it is not be able to switch back to Operation Enable.

#### Chapter 15 CANopen Overview | CFP2000

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	note
605Ah	0	Quick stop option code	2	RW	S16		No		O: disable drive function 1: slow down on slow down ramp 2: slow down on quick stop ramp 3: slow down on the current limit 5: slow down on slow down ramp and stay in QUICK STOP 6: slow down on quick stop ramp and stay in QUICK STOP 7: slow down on the current limit and stay in Quick stop

When the control block switches from Power Enable to Power Disable, use 605C to define the stop method.

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	note
605Ch		Disable operation option code	1	RW	S16		No		Disable drive function     Slow down with slow down ramp; disable of the drive function

15-3-2-3 Various Mode Control Method (by Following DS402 Standard)

CFP2000 currently only supports speed control which is described as below:

## Speed mode

- 1. Set CFP2000 to speed control mode: set Index6060 to 2.
- 2. Switch to Operation Enable mode: Set 6040 = 0xE, then set 6040 = 0xF.
- 3. Set the target frequency: Set target frequency for 6042, since the operation unit of 6042 is rpm, a conversion is required:

n: rotation speed (rpm) (rounds/minute)

 $n = f \times \frac{120}{p}$ P: motor's pole number (Pole)


f: rotation frequency (Hz)

For example:

Set 6042H = 1500 (rpm), if the number of poles for the drive is 4 (Pr.05-04 or Pr.05-16), then the motor drive's operation frequency is  $1500 \div (120 \div 4) = 50$  Hz. The 6042 is defined as a signed operation. The plus or minus sign means to rotate clockwise or counter-clockwise

- 4. To set acceleration and deceleration: Use 604F (Acceleration) and 6050 (Deceleration).
- 5. Trigger an ACK signal: in the speed control mode, control the bit6-4 of Index 6040. It is defined below:

		Index 6040		SUM
Chood mode	bit6	bit5	bit4	SUM
Speed mode (Index 6060 = 2)	1	0	1	Locked at the current signal.
(Index 0000 - 2)	1	1	1	Run to reach targeting signal.
		Other	Decelerate to 0 Hz.	



## NOTE:

- 1. Read 6043 to get the current rotation speed. (Unit: rpm)
- 2. Read bit10 of 6041 to check if the rotation speed has reached the targeting value. (0: Not reached; 1: Reached)

15-3-3 Using the Delta Standard (Old Definition, only Supports Speed Mode)


15-3-3-1 Various Mode Control Method (Following the Delta Old Standard)

If you want to use the Delta old standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 15-2 Wiring for CANopen)
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. (Run / stop, forward / reverse run..., etc.)
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set Delta Standard (Old definition, only supports speed mode) as the control mode: Pr.09-40 = 0 and Pr.09-30 = 0.
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36 = 0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02 = 7 to reset.
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS Baud Rate: 1 Mbps(0), 500 Kbps(1), 250 Kbps(2), 125 Kbps(3), 100 Kbps(4) and 50 Kbps(5))

#### 15-3-3-2 The control method under speed mode

- 1. Set the target frequency: Set 2020-02, the unit is Hz, with 2 decimal places. For example, 1000 is 10.00 Hz.
- 2. Operation control: set 2020-01 = 0002H for running, and set 2020-01 = 0001H for stopping.



## 15-3-4 By Using Delta Standard (New Definition)


15-3-4-1 Related Settings for an AC Motor Drive (Following the Delta New Standard) If you want to use the Delta new standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 15-2 Wiring for CANopen)
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. (Run / stop, forward / reverse run..., etc.)
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set Delta Standard (New definition) as the control mode: Pr.09-40 = 0 and Pr.09-30 = 1.
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36 = 0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02 = 7 to reset.)
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS Baud Rate: 1 Mbps (0), 500 Kbps (1), 250 Kbps (2), 125 Kbps (3), 100 Kbps (4) and 50 Kbps(5)).

# 15-3-4-2 Various Mode Control Method (Delta New Standard)

#### **Speed Mode**

- 1. Set CFP2000 to speed control mode: set Index6060 = 2.
- 2. Set the target frequency: set 2060-03, unit is Hz, with 2 decimal places. For example, 1000 is 10.00Hz.
- 3. Operation control: set 2060-01 = 008H for Server on, and set 2060-01 = 0081H for running.



#### NOTE:

- 1. Read 2061-05 to get the current position.
- 2. Read bit0 of 2061 to check if the position has reached to the target position. (0: Not reached, 1: Reached).

# 15-3-5 DI/ DO/ AI/ AO are controlled via CANopen

To control the DO and AO of the motor drive through CANopen, follow these steps:

- 1. Define the DO to be controlled by CANopen. For example, set Pr.02-14 = 50 to control RY2.
- 2. Define the AO to be controlled by CANopen. For example, set Pr.03-23 = 20 to control AFM2.
- 3. Control the Index mapped by CANopen. To control DO, use control Index2026-41. To control AO, use control 2026-AX. To set RY2 as ON, set bit1 of Index 2026-41 = 1, then RY2 outputs 1. To control AFM2 output = 50.00%, set Index 2026-A2 = 5000, then AFM2 outputs 50%.

The following table shows the mapping of CANopen DI/ DO/ AI/ AO:

DI:

Terminal	Related Parameters	R/W	Mapping Index
FWD	==	RO	2026-01 bit0
REV	==	RO	2026-01 bit1
MI 1	==	RO	2026-01 bit2
MI 2	==	RO	2026-01 bit3
MI 3	==	RO	2026-01 bit4
MI 4	==	RO	2026-01 bit5
MI 5	==	RO	2026-01 bit6
MI 6	==	RO	2026-01 bit7
MI 7	==	RO	2026-01 bit8
MI 8	==	RO	2026-01 bit9
MI 10	==	RO	2026-01 bit10
MI 11	==	RO	2026-01 bit11
MI 12	==	RO	2026-01 bit12
MI 13	==	RO	2026-01 bit13
MI 14	==	RO	2026-01 bit14
MI 15	==	RO	2026-01 bit15

DO:

Terminal	Related Parameters	R/W	Mapping Index
RY1	Pr.02-13 = 51	RW	2026-41 bit0
RY2	Pr.02-14 = 51	RW	2026-41 bit1
RY3	Pr.02-15 = 51	RW	2026-41 bit2
MO10/RY10	Pr.02-36 = 51	RW	2026-41 bit5
MO11/RY11	Pr.02-37 = 51	RW	2026-41 bit6
RY12	Pr.02-38 = 51	RW	2026-41 bit7
RY13	Pr.02-39 = 51	RW	2026-41 bit8
RY14	Pr.02-40 = 51	RW	2026-41 bit9
RY15	Pr.02-41 = 51	RW	2026-41 bit10

# AI:

Terminal	Related Parameters	R/W	Mapping Index
AVI1	==	RO	Value of 2026-61
ACI	==	RO	Value of 2026-62
AVI2	==	RO	Value of 2026-63

# AO:

Terminal	Related Parameters	R/W	Mapping Index
AFM1	Pr.03-20 = 21	RW	Value of 26A0h
AFM2	Pr.03-23 = 21	RW	Value of 26A1h
AFM10	Pr.14-12 = 21	RW	Value of 26AAh
AFM11	Pr.14-13 = 21	RW	Value of 26ABh

# 15-4 CANopen Supporting Index

CFP2000 Index:

The parameter index corresponds as following in this example:

Index sub-Index

2000H + Group Pr. Number+1

For example: Pr.00-20 (Master frequency command source)

Group member 00(00H) - 20(14H)

Index = 2000H + 00H = 2000Sub Index = 14H + 1H = 15H

# CFP2000 Control Index:

Delta Standard Mode (Old definition)

Index	Sub	Definition	Default	R/W	Size		Note
	0	Number	3	R	U8		
							00B: disable
						bit1–0	01B: stop
						טונו–ט	10B: disable
							11B: JOG Enable
						bit3-2	Reserved
							00B: disable
						bit5–4	01B: Direction forward
						มแจ–4	10B: Reverse
							11B: Switch Direction
							00B: 1st step Accel. /Decel.
						h:47 C	01B: 2 <sup>nd</sup> step Accel. /Decel.
						bit7–6	10B: 3 <sup>rd</sup> step Accel. /Decel.
							11B: 4 <sup>th</sup> step Accel. /Decel.
							0000B: Master speed
							0001B: 1st step speed
	1	Control word	0	RW	U16		0010B: 2 <sup>nd</sup> step speed
							0011B: 3 <sup>rd</sup> step speed
202011						bit11–8	0100B: 4 <sup>th</sup> step speed
2020H							0101B: 5 <sup>th</sup> step speed
							0110B: 6 <sup>th</sup> step speed
							0111B: 7 <sup>th</sup> step speed
							1000B: 8 <sup>th</sup> step speed
							1001B: 9 <sup>th</sup> step speed
							1010B: 10 <sup>th</sup> step speed
							1011B: 11 <sup>th</sup> step speed
							1100B: 12 <sup>th</sup> step speed
							1101B: 13 <sup>th</sup> step speed
							1110B: 14 <sup>th</sup> step speed
							1111B: 15 <sup>th</sup> step speed
						bit12	1: Enable the function of bit6–11
						bit15	Reserved
	2	Freq. command (XXX.XX Hz)	0	RW	U16		
		(				bit0	1: E.F. ON
						bit1	1: Reset
	3	Other trigger	0	RW	U16	bit2	1: Base Block (B.B) ON
						bit15–3	Reserved
		<u> </u>				51110 0	1.10001700

Index	Sub	Definition	Default	R/W	Size		Note
		Number	10	R	U8		1.1.1.
						High byte:	Warn code
	1	Error code	0	R	U16		Error code
							00B: stop
							01B: decelerate to stop
						bit1–0	10B: waiting for operation
							command
							11B: in operation
						bit2	1: JOG command
							00B: run forward
							01B: switch from run in reverse to
							run forward
						bit4–3	10B: switch from run forward to run
							in reverse
	0	AC motor drive status	0		1140		11B: run in reverse
	2	AC motor drive status	0	R	U16	bit7-5	Reserved
							1: master frequency command
						bit8	controlled by communication
							interface
						bit0	1: master frequency command
						bit9	controlled by analog signal input
						bit10	1: operation command controlled
						DILTO	by communication interface
2021H						bit11	1: Parameter lock
						bit12	1: Enable the digital keypad copy
						DILIZ	parameter function
						bit15-13	Reserved
	3	Freq. command	0	R	U16		
		(XXX.XX Hz)					
	4	Output freq. (XXX.XX Hz)	0	R	U16		
	5	Output current (XX.X A)	0	R	U16		
	6	DC bus voltage (XXX.X V)	0	R	U16		
	7	Output voltage (XXX.X V)	0	R	U16		
	•	The current segment run by	•	_	1140		
	8	the multi-segment speed	0	R	U16		
	0	command	0	П	1146		
	9 A	Reserved Display counter value (c)	0	R R	U16		
	Α	Display counter value (c)  Display output power angle	U	Г	010		
	В	(XX.X°)	0	R	U16		
		Display output torque					
	С	(XXX.X%)	0	R	U16		
		Display actual motor speed					
	D	(rpm)	0	R	U16		
	10	Power output (X.XXX kWh)	0	R	U16		
		Multi-function display					
	17	(Pr.00-04)	0	R	U16		
	0	Reserved	0	R	U16		
	1	Display output current	0	R	U16		
	2	Display counter value	0	R	U16		
2022H		Display actual output					
	3	frequency (XXX.XX Hz)	0	R	U16		
		Display DC bus voltage					
	4	(XXX.X V)	0	R	U16		
<u> </u>		11 5 /		<u> </u>	<u> </u>	1	1

Index	Sub	Definition	Default	R/W	Size	Note
	5	Display output voltage	0	R	U16	
	Ü	(XXX.X V)	<u> </u>	Γ.	010	
	6	Display output power angle (XX.X°)	0	R	U16	
	7	Display output power in kW	0	R	U16	
	8	Display actual motor speed (rpm)	0	R	U16	
	9	Display estimate output torque (XXX.X%)	0	R	U16	
	В	Display PID feedback value after enabling PID function in % (To 2 decimal places)	0	R	U16	
	С	Display signal of AVI 1 analog input terminal, 0–10 V corresponds to 0–100% (To 2 decimal places)	0	R	U16	
	D	Display signal of ACI analog input terminal, 4–20 mA /0–10 V corresponds to 0–100% (To 2 decimal places)	0	R	U16	
	Е	Display signal of AVI 2 analog input terminal, -10– 10 V corresponds to -100– 100% (To 2 decimal places)	0	R	U16	
	F	Display the IGBT temperature of drive power module in °C	0	R	U16	
	10	Display the temperature of capacitance in °C	0	R	U16	
	11	The status of digital input (ON/OFF), refer to Pr.02-12	0	R	U16	
	12	The status of digital output (ON/OFF), refer to Pr.02-18	0	R	U16	
	13	Display the multi-step speed that is executing	0	R	U16	
	14	The corresponding CPU pin status of digital input	0	R	U16	
	15	The corresponding CPU pin status of digital output	0	R	U16	
	1A	Display times of counter overload (0.00–100.00%)	0	R	U16	
	1B	Display GFF in %	0	R	U16	
	1C	Display DC bus voltage ripples (Unit: V <sub>DC</sub> )	0	R	U16	
	1D	Display PLC register D1043 data	0	R	U16	
	1E	Display Pole of Permanent Magnet Motor	0	R	U16	
	1F	User page displays the value in physical measure	0	R	U16	
	20	Output Value of Pr.00-05	0	R	U16	
	21	Number of motor turns when drive operates	0	R	U16	
		Operation position of motor	0	R	U16	
	23	Fan speed of the drive	0	R	U16	

Index	Sub	Definition	Default	R/W	Size	Note
	24	Control mode of the drive 0: speed mode	0	R	U16	
	25	Carrier frequency of the drive	0	R	U16	
	26	Reserved				
	27	Motor status				
	2A	kWh display				
	2D	Motor actual position low- word				
	2E	Motor actual position highword				
	2F	PID reference target				
	30	PID bias value				
	31	PID output frequency				

# CANopen Remote IO mapping

Index	Sub	R/W	Definition
	01h	R	Each bit corresponds to different terminal input contact
	03h-40h	R	Reserved
	41h	RW	Each bit corresponds to different terminal output contact
	42h-60h	R	Reserved
	61h	R	AVI1 proportional value
	62h	R	ACI proportional value
	63h	R	AVI2 proportional value
2026H	64h–6Ah	R	Reserved
202011	6Bh	R	Extension card Al10, 0.0–100.0% (EMC-A22A)
	6Ch	R	Extension card Al11, 0.0–100.0% (EMC-A22A)
	6Dh-A0h	R	Reserved
	A1h	RW	AFM1 output proportional value
	A2h	RW	AFM2 output proportional value
	A3h–AAh	RW	Reserved
	ABh	RW	Extension card AO10, 0.0–100.0% (EMC-A22A)
	ACh	RW	Extension card AO11, 0.0–100.0% (EMC-A22A)

Index 2026-01	bit0	bit1	bit2	bit3	bit4	bit5	bit6	bit7	bit8	bit9	bit10	bit11	bit12	bit13	bit14	bit15
1	FWD	REV	MI1	MI2	MI3	MI4	MI5	MI6	MI7	MI8						
2											MI10	MI11	MI12	MI13	MI14	MI15
3											MI10	MI11	MI12	MI13		

- 1: Control broad I/O (Standard)
- 2: Add external card, EMC-D611A
- 3: Add external card, EMC-D42A

Index 2026-41	bit0	bit1	bit2	bit3	bit4	bit5	bit6	bit7	bit8	bit9	bit10	bit11	bit12	bit13	bit14	bit15
1	RY1	RY2	RY3													
2						MO10	MO11									
3						RY10	RY11	RY12	RY13	RY14	RY15					

- 1: Control broad I/O (Standard)
- 2: Add external card, EMC-D42A
- 3: Add external card, EMC-R6AA

Delta Standard Mode (New definition)

Index	sub	R/W	Size		Descriptions		Speed Mede
index	Sub	FV/VV	Size	bit	Definition	Priority	Speed Mode
	00h	R	U8				
				0	Ack	4	0: fcmd = 0 1: fcmd = Fset (Fpid)
				1	Dir	4	0: FWD run command 1: REV run command
				2			1. NEV Tan command
				3	Halt		0: drive run till target speed is attained 1: drive stop by deceleration setting
				4	Hold		0: drive run till target speed is attained 1: frequency stop at current frequency
	01h	RW	U16	5	JOG		0: JOG OFF Pulse 1: JOG RUN
				6	QStop		Quick Stop
2060h				7	Power		0:Power OFF 1:Power ON
				8	Reserved		
				9	Ext Cmd2	4	0->1: Absolute position cleared
				10–14	Reserved		
				15	RST	4	Pulse 1: Fault code cleared
	02h	RW	U16		Mode Cmd		0: Speed mode
	03h	RW	U16				Speed command (unsigned decimal)
	04h	RW	U16				
	05h	RW	S32				
	06h	RW					
	07h	RW	U16				
	08h	RW	U16				
				0	Arrive		Frequency attained
				1	Dir		0: Motor FWD run 1: Motor REV run
				2	Warn		Warning
	01h	R	U16	3	Error		Error detected
				4			
				5	JOG		JOG
				6	QStop		Quick stop
2061h				7	Power On		Switch ON
				15–8			
	02h	R					
	03h	R	U16				Actual output frequency
	04h	R					
	05h	R	S32				Actual position (absolute)
	06h	R					
	07h	R	S16				Actual torque


# Mapping for CANopen built-in PLC register D (mapping from D900–D999 to 3000H–3063H)

Index	Sub	R/W	Definition
3000	0	RW	PLC D900
3001	0	RW	PLC D901
3002	0	RW	PLC D902
3063	0	RW	PLC D999

# DS402 Standard

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	Note
6007h	0	Abort connection option code	2	RW	S16		Yes		0: No action 2: Disable Voltage 3: quick stop
603Fh	0	Error code	0	RO	U16		Yes		
6040h	0	Control word	0	RW	U16		Yes		
6041h	0	Status word	0	RO	U16		Yes		
6042h	0	vl target velocity	0	RW	S16	rpm	Yes	٧l	
6043h	0	vl velocity demand	0	RO	S16	rpm	Yes	٧l	
6044h	0	vl velocity actual value	0	RO	132	rpm	Yes	vl	
604Fh	0	vl ramp function time	10000	RW	U32	1ms	Yes	٧l	Limit reveat have 100 mag. and about
6050h	0	vl slow down time	10000	RW	U32	1ms	Yes	vl	Unit must be: 100 ms, and check if the setting is 0.
6051h	0	vl quick stop time	1000	RW	U32	1ms	Yes	νl	ii the setting is 0.
605Ah	0	Quick stop option code	2	RW	S16		No		disable drive function     slow down on slow down ramp     slow down on quick stop ramp     slow down on slow down ramp and stay in QUICK STOP     slow down on quick stop ramp and stay in QUICK STOP     slow down on quick STOP     slow down on quick STOP
605Ch	0	Disable operation option code	1	RW	S16		No		Slow down with slow down ramp; disable of the drive function
6060h	0	Mode of operation	2	RW	S8		Yes		2: Velocity Mode
6061h	0	Mode of operation display	2	RO	S8		Yes		Same as above
6064h	0	Position actual value	0	RO	S32	pulse	Yes		
6071h	0	Target torque	0	RW	S16	0.1%	Yes		
6072h	0	Max torque	1500	RW	U16	0.1%	Yes	tq	Valid value unit is 1%
6075h	0	Motor rated current	0	RO	U32	mA	No	tq	-
6077h	0	Torque actual value	0	RO	S16	0.1%	Yes	tq	
6078h	0	Current actual value	0	RO	S16	0.1%	Yes	tq	
6079h	0	DC link circuit voltage	0	RO	U32	mV	No	tq	
607Ah	0	Target position	0	RW	S32	pulse	Yes		

# 15-5 CANopen Fault Codes



- ① Display error signal
- Abbreviate error code
- 3 Display error description
- Refer to setting value of Pr.06-17–Pr.06-22.
- Refer to Chapter 14 Fault Codes for detailed descriptions.

ID No.	Display	Fault Code	Description	CANopen Fault Register (bit0–7)	CANopen Fault Code
1	Fault ocA Oc at accel	0001H	Over-current during acceleration (ocA)	1	2213 H
2	Fault ocd Oc at decel	0002H	Over-current during deceleration (ocd)	1	2213 H
3	Fault ocn Oc at normal SPD	0003H	Over-current during steady operation (ocn)	1	2214H
4	Fault GFF Ground fault	0004H	Ground fault (GFF)	1	2240H
5	Fault occ Short Circuit	0005H	IGBT short circuit between upper bridge and lower bridge (occ)	1	2250H
6	Fault ocS Oc at stop	0006H	Over-current at stop (ocS)	1	2314H
7	Fault ovA	0007H	Over-voltage during acceleration (ovA)	2	3210H
8	Fault ovd Ov at decel	0008H	Over-voltage during deceleration (ovd)	2	3210H
9	Fault  OVN  Ov at normal SPD	0009Н	DC bus over-voltage at constant speed (ovn)	2	3210H

ID No.	Display	Fault Code	Description	CANopen Fault Register (bit0–7)	CANopen Fault Code
10	Fault ovS Ov at stop	000AH	Over-voltage at stop (ovS)	2	3210H
11	Fault LvA Lv at accel	000BH	Low-voltage during acceleration (LvA)	2	3220H
12	Fault Lvd Lv at decel	000CH	Low-voltage during deceleration (Lvd)	2	3220H
13	Раиlt Lvn Lv at normal SPD	000DH	Low-voltage at constant speed (Lvn)	2	3220H
14	Fault LvS Lv at stop	000EH	Low-voltage at stop (LvS)	2	3220H
15	Fault OrP Phase lacked	000FH	Phase loss protection (OrP)	2	3130H
16	Fault oH1	0010H	IGBT overheating (oH1)	3	4310H
17	Fault оН2 Heat Sink оН	0011H	Heatsink overheating (oH2)	3	4310H
18	Раши НПО Thermo 1 open	0012H	IGBT temperature detection failure (tH1o)	3	FF00H
19	аито Fault tH2o Thermo 2 open	0013H	Capacitor hardware error (tH2o)	3	FF01H
21	Рашіто Башіто OL Over load	0015H	Over load (oL)	1	2310H

ID No.	Display	Fault Code	Description	CANopen Fault Register (bit0–7)	CANopen Fault Code
22	Fault EoL1 Thermal relay 1	0016H	Electronic thermal relay 1 protection (EoL1)	1	2310H
23	Fault EoL2 Thermal relay 2	0017H	Electronic thermal relay 2 protection (EoL2)	1	2310H
24	Fault oH3 Motor over heat	0018H	Motor overheating (oH3)	3	FF20H
26	Fault ot1 Over torque 1	001AH	Over torque 1 (ot1)	3	8311H
27	Fault ot2 Over torque 2	001BH	Over torque 2 (ot2)	3	8311H
28	Fault uC Under current	001CH	Under current (uC)	1	8321H
30	Fault cF1 EEPROM write err	001EH	EEPROM write error (cF1)	5	5530H
31	Fault cF2 EEPROM read err	001FH	EEPROM read error (cF2)	5	5530H
33	Fault cd1 las sensor err	0021H	U-phase error (cd1)	1	FF04H
34	Fault cd2 Ibs sensor err	0022H	V-phase error (cd2)	1	FF05H
35	Fault cd3	0023H	W-phase error (cd3)	1	FF06H

ID No.	Display	Fault Code	Description	CANopen Fault Register (bit0–7)	CANopen Fault Code
36	Fault Hd0 cc HW error	0024H	cc (current clamp) hardware error (Hd0)	5	FF07H
37	Fault Hd1 Oc HW error	0025H	oc hardware error (Hd1)	5	FF08H
38	Fault Hd2 Ov HW error	0026H	ov hardware error (Hd2)	5	FF09H
39	Fault Hd3 occ HW error	0027H	occ hardware error (Hd3)	5	FF0AH
40	Fault AUE Auto tuning error	0028H	Auto-tuning error (AUE)	1	FF21H
41	Fault AFE PID Fbk error	0029H	PID loss ACI (AFE)	7	FF22H
48	Fault ACE ACI loss	0030H	ACI loss (ACE)	1	FF25H
49	Fault  EF  External fault	0031H	External fault (EF)	5	9000Н
50	Башіт Fault EF1 Emergency stop	0032H	Emergency stop (EF1)	5	9000Н
51	Fault bb Ваѕе block	0033H	External base block (bb)	5	9000Н
52	Разучения Разучения Рособ Разучения Рособ Разучения Россий Разучения Разучения Разучения Разучения Разучения Россий Россий Разучения Россий России Россий России Россий Россий России Росси	0034H	Password is locked (Pcod)	5	FF26H

ID No.	Display	Fault Code	Description	CANopen Fault Register (bit0-7)	CANopen Fault Code
53	Fault ccod SW code error	0035H	SW code error (ccod)	5	6100H
54	Fault CE1 PC err command	0036H	Illegal command (CE1)	4	7500H
55	Fault CE2 PC err address	0037H	Illegal data address (CE2)	4	7500H
56	Fault CE3 PC err data	0038H	Illegal data value (CE3)	4	7500H
57	РС slave fault	0039H	Data is written to read-only address (CE4)	4	7500H
58	Fault CE10 PC time out	003AH	Modbus transmission time-out (CE10)	5	7500H
60	Fault bF Braking fault	003CH	Brake transistor error (bF)	4	7110H
61	лито Fault ydc Y-delta connect	003DH	Y-connection / Δ-connection switch error (ydc)	2	3330H
63	Fault oSL Over slip error	003FH	Over slip error (oSL)	7	FF28H
64	Fault ryF MC Fault	0040H	Electric valve switch error (ryF)	5	7110H
68	Fault SdRv SpdFbk Dir Rev	0044H	Reverse direction of the speed feedback (SdRv)	0	8400H

ID No.	Display	Fault Code	Description	CANopen Fault Register (bit0–7)	CANopen Fault Code
69	Башіt SdOr SpdFbk over SPD	0045H	Over speed rotation feedback (SdOr)	0	8400H
70	Fault SdDe SpdFbk deviate	0046H	Large deviation of speed feedback (SdDe)	0	8400H
71	Fault WDTT Watchdog	0047H	Watchdog (WDTT)	1	6010H
72	Fault STL1 STO Loss 1	0048H	STO loss 1 (STL1)	5	FF30H
73	Fault S1 S1-emergy stop	0049H	Emergency stop for external safety (S1)	5	FF2AH
74	Fault Fire On Fire	004AH	Fire mode (Fire)	7	FF2FH
76	Fault STO	004CH	Safe torque off (STO)	5	FF31H
77	Fault STL2 STO Loss 2	004DH	STO loss 2 (STL2)	5	FF32H
78	Fault STL3 STO Loss 3	004EH	STO loss 3 (STL3)	5	FF33H
82	АИТО Fault OPHL U phase lacked	0052H	Output phase loss U phase (OPHL)	2	2331H
83	Баиlt OPHL V phase lacked	0053H	Output phase loss V phase (OPHL)	2	2332H

ID No.	Display	Fault Code	Description	CANopen Fault Register (bit0–7)	CANopen Fault Code
84	Fault OPHL W phase lacked	0054H	Output phase loss 3 W phase (OPHL)	2	2333H
87	Fault  oL3  Derating Error	0057H	Overload protection at low frequency (oL3)	0	8A00H
89	лито Fault RoPd Rotor Pos. Error	0059H	Rotor position detection error (RoPd)	7	8A00H
90	Fault Fstр Force Stop	005AH	Force to stop (FStp)	7	FF2EH
93	АИТО Fault TRAP CPU Trap 0 error	005CH	CPU error 0 (TRAP) (applied to 230V / 460V models)	7	6000H
101	Fault  CGdE  Guarding T-out	0065H	CANopen guarding error (CGdE)	4	8130H
102	Раиlt CHbE Heartbeat T-out	0066Н	CANopen heartbeat error (CHbE)	4	8130H
104	Fault CbFE Can bus off	0068H	CANopen bus off error (CbFE)	4	8140H
105	Fault CldE Can bus Index Err	0069Н	CANopen index error (CldE)	4	8100H
106	Fault  CAdE  Can bus Add. Err	006AH	CANopen station address error (CAdE)	4	8100H
107	Баult CFrE Can bus off	006BH	CANopen memory error (CFrE)	4	8100H

ID No.	Display	Fault Code	Description	CANopen Fault Register (bit0–7)	CANopen Fault Code
111	Баиlt ictE	006FH	InrCOM time-out error (ictE)	4	7500H
112	Fault SfLK PMLess Shaft Lock	0070H	PMLess shaft lock (SfLK)	0	8A00H
113	AUTO Fault SWOC SW over current	0071H	Software over-current (SWOC)	1	2213H
142	АUTO Fault AUE1 Auto tuning Err	008EH	Auto-tune error 1 (AUE1)	1	FF3DH
143	AUTO Fault AUE2 Auto tuning Err	008FH	Auto-tune error 2 (AUE2)	1	FF3EH
144	AUTO Fault AUE3 Auto tuning Err	0090Н	Auto-tune error 3 (AUE3)	1	FF3FH
148	AUTO Fault AUE4 Auto tuning Err	0094H	Auto-tune error 4 (AUE4)	1	FF43H


# 15-6 CANopen LED Function

There are two CANopen flash signs: RUN and ERR.

# **RUN LED:**

LED Status	Condition	CANopen State
OFF		Initial
Blinking	ON 200 ms ms	Pre-Operation
Single flash	ON 200 1000 ms ms ms	Stopped
ON	err — <u>Can</u> — run	Operation

#### ERR LED:



# Chapter 16 PLC Function Applications

- 16-1 PLC Summary
- 16-2 Notes before PLC Use
- 16-3 Turn On
- 16-4 Basic Principles of PLC Ladder Diagrams
- 16-5 Various PLC Device Functions
- 16-6 Introduction to the Command Window
- 16-7 Error Display and Handling
- 16-8 CANopen Master Control Applications
- 16-9 Explanation of Various PLC Speed Mode Controls
- 16-10 Internal Communications Main Node Control
- 16-11 Modbus Remote IO Control Applications (use MODRW)
- 16-12 Calendar Functions

# **16-1 PLC Summary**

#### 16-1-1 Introduction

The commands provided by the CFP2000's built-in PLC functions, including the ladder diagram editing tool WPLSoft, as well as the usage of basic commands and applications commands, chiefly retain the operating methods of Delta's PLC DVP series.

# 16-1-2 WPLSoft Ladder Diagram Editing Tool


WPLSoft is Delta's program editing software for the DVP and CFP2000 programmable controllers in the Windows operating system environment. Apart from general PLC program design general Windows editing functions (such as cut, paste, copy, multiple windows, etc.), WPLSoft also provides many Chinese / English annotation editing and other convenience functions (such as registry editing, settings, file reading, saving, and contact graphic monitoring and settings, etc.).

The following basic requirements that need to install WPLSoft editing software:

Item	System Requirements
Operating system	Windows 95 / 98 / 2000 / NT / ME / XP / 7 / 10
CPU	At least Pentium 90
Memory	At least 16MB (we recommend at least 32 MB)
Hard drive	Hard drive capacity: at least 100MB free space
Hard drive	One optical drive (for use in installing this software)
Dioploy	Resolution: 640×480, at least 16 colors; it is recommended that the screen
Display	area be set at 800×600 pixels
Mouse	Ordinary mouse or Windows-compatible device
Printer	Printer with a Windows driver program
RS-485 port	Must have at least an RS-485 port to link to the PLC

#### 16-2 Notes before PLC Use


- 1. The PLC has a preset communications format of 7, N, 2, 9600, with node 2; the PLC node can be changed in Pr.09-35, but this address may not be the same as the drive's address setting of Pr.09-00.
- The CFP2000 provides two communications serial ports that can be used to download PLC programs (see figure below). Channel 1 has a fixed communications format of 19200, 8, N, 2 RTU.



- 3. You can simultaneously access data from the converter and internal PLC, which is performed through identification of the node. For instance, if the converter node is 1 and the internal PLC node is 2, then the client command will be
  - 01 (node) 03 (read) 0400 (address) 0001 (1 data item), indicating that it must read the data in converter Pr.04-00.
  - 02 (node) 03 (read) 0400 (address) 0001 (1 data item), indicating that it must read the data in internal PLC X0
- 4. The PLC program is disabled when uploading / downloading programs.
- 5. When using WPR commands to write in parameters, values may be modified up to a maximum of 10<sup>9</sup> times, otherwise a memory write error will occur. The calculation of modifications is based on whether the entered value has been changed. If the entered value is left unchanged, the modifications does not increase afterwards. However, if the entered value is different from before, the number of modifications increases by one. Those parameters listed below are exceptions, refer to the next page for details:
  - Pr.00-11 Speed control mode
  - Pr.01-12-Pr.01-19 Acceleration / Deceleration time 1-4
  - Pr.02-12 Multi-function input mode selection
  - Pr.02-18 Multi-function output direction
  - Pr.04-50-Pr.04-59 PLC buffer 0-9
  - Pr.08-04 Upper limit of integral control
  - Pr.08-05 PID output command limit

#### Chapter 16 PLC Function Applications | CFP2000

6. When Pr.00-04 is set as 28, the displayed value is the value of PLC register D1043 (see figure below):



Keypad KPC-CC01 Can display 0–65535


- 7. In the PLC Run and PLC Stop mode, the content 9 and 10 of Pr.00-02 cannot be set nor be reset to the default value.
- 8. The PLC can be reset to the default value when Pr.00-02 is set as 6.
- 9. The corresponding MI function is disabled when the PLC writes to input contact X.
- 10. When the PLC controls converter operation, the control command is entirely controlled by the PLC and will not be affected by the setting of parameter 00-21.
- 11. When the PLC controls converter frequency commands (FREQ commands), frequency commands is entirely controlled by the PLC, and will not be affected by the setting of Pr.00-20 or the Hand ON / OFF configuration.
- 12. When the PLC controls the drive's operation, if the keypad Stop setting is valid, this will trigger an FStP error and cause stoppage.

# 16-3 Turn On


#### 16-3-1 Connect to PC

Start operation of PLC functions in accordance with the following four steps

1. After pressing the Menu key and selecting 4: PLC on the KPC-CC01 digital keypad, press the Enter key (see figure below).



2. Wiring: Connect the drive's RJ45 communications interface to a PC via the RS-485



3. PLC function usage



PLC functions are as shown in the figure on the left; select item 2 and implement PLC functions.

- 1: No function (Disable)
- 2: Enable PLC (PLC Run)
- 3: Stop PLC functions (PLC Stop)

When the external multifunctional input terminals (MI1–MI8) are in PLC Mode select bit0 (51) or PLC Mode select bit1 (52), and the terminal contact is closed or open, it will compulsorily switch to the PLC mode, and keypad switching will be ineffective. Corresponding actions are as follows:

PLC mode	DLC Made select bit1 (52)	DLC Made select bit0 (51)		
Using KPC-CC01	PLC Mode select bit1 (52)	PLC Mode select bit0 (51)		
Disable	OFF	OFF		
PLC Run	OFF	ON		
PLC Stop	ON	OFF		
Maintain previous state	ON	ON		

#### NOTE:

- 1. When input / output terminals (FWD REV MI1–MI8, MI10–15, Relay1–3, RY10–RY15, MO10–MO11,) are included in the PLC program, these input / output terminals will only be used by the PLC. As an example, when the PLC program controls Y0 during PLC operation (PLC1 or PLC2), the corresponding output terminal relay (RA / RB / RC) will operate in accordance with the program. At this time, the multifunctional input/output terminal setting will be ineffective. Because these terminal functions are already being used by the PLC, the DI / DO / AO in use by the PLC can be determined by looking at Pr.02-52, Pr.02-53, and Pr.03-30.
- 2. When the PLC's procedures use special register D1040, the corresponding AO contact AFM1 will be occupied, and AFM2 corresponding to special register D1045 will have the same situation.
- 3. Pr.03-30 monitors the state of action of the PLC function analog output terminal; bit0 corresponds to the AFM1 action state, and bit1 corresponds to the AFM2 action state.

## 16-3-2 I/O Device Explanation

# Input devices:

Serial No.	X0	X1	X2	Х3	X4	X5	X6	X7	X10	X11	X12	X13	X14	X15	X16	X17
1	FWD	REV	MI1	MI2	MI3	MI4	MI5	MI6	MI7	MI8						
2											MI10	MI11	MI12	MI13	MI14	MI15
3											MI10	MI11	MI12	MI13		

1: Control I/O

2: Extension card: EMC-D611A (D1022=4)

3: Extension card: EMC-D42A (D1022=5)

#### Output devices:

Serial No.	Y0	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y10	Y11	Y12	Y13	Y14	Y15	Y16	Y17
1	RY1	RY2	RY3													
2						MO10	MO11									
3						RY10	RY11	RY12	RY13	RY14	RY15					

1: Control I/O

2: Extension card: EMC-D42A (D1022=5) 3: Extension card: EMC-R6AA (D1022=6)

#### RY1 / RY2 / RY3

#### RY10 / RY11 / RY12 / RY13 / RY14 / RY15





#### 16-3-3 Installation WPLSoft

Download and install WPLSoft editing software in Delta's website:



After completing installation, the WPLSoft program will be installed in the designated subfolder "C: \Program Files\Delta Industrial Automation\WPLSoft x.xx".

# 16-3-4 Program Writing

Step 1: Click on the WPLSoft icon to start the editing software. (See Figure 16-1)




Figure 16-1 (Left: WPLSoft icon; Right: Start WPLSoft)

Step 2: The WPLSoft editing window appears (see Figure 16-2 below). When running WPLSoft for the first time, before "New file" has been used, only the "File (F)," "Communications (C)," View (V)," "Options (O)," and "Help (H)" columns will appear on the function toolbar.




Figure 16-2

**NOTE:** After running WPLSoft for the second time, the last file edited will open and be displayed in the editing window. The following Figure 16-3 provides an explanation of the WPLSoft editing software window:




Figure 16-3

Step 3: Click on the icon on the toolbar: opens new file (Ctrl+N), see Figure 16-4 below.



Figure 16-4

**NOTE:** You can also find "New file (N) (Ctrl+N)" in the "File (F)", as shown in Figure 16-5 below.




Figure 16-5

Step 4: The "Device settings" window will appear after clicking, see Figure 16-6 below. You can now enter the project title and filename, and select the device and communication settings to be used.




Figure 16-6

Communications settings: Perform settings in accordance with the desired communications method. See Figure 16-7 below.




Figure 16-7

Step 5: Press Confirm after completing settings and begin program editing. There are two program editing methods; you can choose whether to perform editing in the command mode or the ladder diagram mode (see Figure 16-8 below).




Figure 16-8

**NOTE:** In ladder diagram mode, you can perform program editing using the buttons on the function icon row (see Figure 16-9 below).




Figure 16-9

#### Basic Operation-Example

Input the ladder diagram as the figure below. The following steps can be operated through the mouse or function key (F1–F12) on the keyboard.

```
M10 ( Y0 )
```

Figure 16-10

Step 1: The following screen will appear after a new file is established:




Figure 16-11

Step 2: Click on the always-open switch icon or press the function key F1. After the name of the input device and the comment dialog box have appeared, the device name (such as "M"), device number (such as "10"), and input comments (such as "auxiliary contact") can be selected; press the OK button when finished (see Figure 16-12 and 16-13 below).




Figure 16-12




Figure 16-13

Step 3: Click on the output coil icon or press function key F7. After the name of the input device and the comment dialog box have appeared, the device name (such as "Y"), device number (such as "0"), and input comments (such as "output coil") can be selected; press the OK button when finished (see Figure 16-14 and 16-15 below).




Figure 16-14





Figure 16-15

Step 4: Press "ENTER" button, when the "Input Instructions" window appears, key in "END" in the field and press the OK button (see Figure 16-16 and 16-17 below).



**Figure 16-16** 




Figure 16-17

Step 5: Click on the "Ladder diagram => Code" icon, which will compile the edited ladder diagram as a command program. After compiling, the number of steps will appear on the left side of the busbar (see Figure 16-18 below).




Figure 16-18

# Chapter 16 PLC Function Applications | CFP2000

# 16-3-5 Program Download

After inputting a program using WPLSoft, select compile . After completing compilation, select the to download a program. WPLSoft will perform program download with the online PLC in the communications format specified in communications settings.

# 16-3-6 Program Monitoring


While confirming that the PLC is in the Run mode, after downloading a program, click on the communications menu and select start ladder diagram control (see figure below)



# 16-4 Basic Principles of PLC Ladder Diagrams

16-4-1 Schematic Diagram of PLC Ladder Diagram Program Scanning

Output results are calculated on the basis of the ladder diagram configuration (internal devices will have real-time output before results are sent to an external output point)



Repeated implementation

# 16-4-2 Introduction to Ladder Diagrams

Ladder diagrams comprise a graphic language widely applied in automatic control, and employs common electrical control circuit symbols. After a ladder diagram editor has been used to create a ladder pattern, PLC program designed is completed. The use of a graphic format to control processes is very intuitive, and is readily accepted by personnel who are familiar with electrical control circuit technology. Many of the basic symbols and actions in a ladder diagram comprise commonly seen electrical devices in conventional automatic control power distribution panels, such as buttons, switches, relays, timers, and counters.

Internal PLC devices: The types and quantities of internal PLC devices vary in different brands of products. Although these internal devices use the same names as conventional electrical control circuit elements such as relays, coils, and contacts, a PLC does not actually contain these physical devices, and they instead correspond to basic elements in the PLC's internal memory (bits). For instance, if a bit is 1, this may indicate that a coil is electrified, and if that bit is 0, it will indicate that the coil is not electrified. An N.O. contact (Normal Open, or contact a) can be used to directly read the value of the corresponding bit, and an N.C. contact (Normal Close, or contact b) can be used to obtain the inverse of the bit's value. Multiple relays occupy multiple bits, and 8 bits comprise one byte; two bytes comprise one word, and two words comprise a double word. When multiple relays are processing at the same time (such as addition/ subtraction or displacement, etc.), a byte, word, or double word can be used. Furthermore, a PLC contains two types of internal devices: a timer and a counter. It not only has a coil, but can count time and numerical values. Because of this, when it is necessary to process some numerical values, these values are usually in the form of bytes, words, or double words.

The various internal devices in a PLC all account for a certain quantity of storage units in the PLC's storage area. When these devices are used, the content of the corresponding storage area is red in the form of bits, bytes, or words.

Introduction to the basic internal devices in a PLC

Device Type	Description of Function
Input Relay	An input relay constitutes the basic unit of storage in a PLC's internal memory corresponding to an external input point (which serves as a terminal connecting with an external input switch and receiving external input signals). It is driven by external input signals, to which it assigns values of 0 or 1. A program design method cannot change the input relay status, and therefore cannot rewrite the corresponding basic units of an input relay, and WPLSoft cannot be used to perform compulsory ON / OFF actions. A relay's contacts (contacts a and b) can be used an unlimited number of times. An input relay with no input signal must be left idle and cannot be used for some other purpose.  • Device indicated as: X0, X1, X7, X10, X11, etc. This device is expressed with the symbol "X," and a device's order is indicated with an octal number. Input point numbers are indicated in Section 16-8 I/O devices explanation.
Output Relay	An output relay constitutes the basic unit of storage in a PLC's internal memory corresponding to an external output point (which connects with an external load). It may be driven by an input relay contact, a contact on another internal device, or its own contacts. It uses one N.O. contact to connect with external loads or other contacts, and, like input contacts, can use the contact an unlimited number of times. An output relay with no input signal will be idle, but may be used an internal relay if needed.  Device indicated as: Y0, Y1, Y7, Y10, Y11, etc. This device is expressed with the symbol "Y," and a device's order is indicated with an octal number. Output point numbers are indicated in Section 16-8 I/O devices explanation.
Internal Relay	Internal relays have no direct connection with the outside. These relays are auxiliary relays inside a PLC. Their function is the same as that of an auxiliary (central) relay in an electrical control circuit: Each auxiliary relay corresponding to a basic unit of internal storage; they can be driven by input relay contacts, output relay contacts, and the contacts of other internal devices. An internal auxiliary relay's contact can also be used an unlimited number of times.  Internal relays have no outputs to outside, and must output via an output point.  Device indicated as: M0, M1 to M799, etc. This device is expressed as the symbol "M," expressed, and its order is expressed as a decimal number.
Counter	A counter is used to perform counting operations. A count setting value (such as the number of pulses to be counted) must be assigned when a counter is used. A counter contains a coil, contact, and a counting storage device. When the coil goes from OFF to ON, this indicates that the counter has an input pulse, and one is added to its count. There are 16 bits that can be employed by the user.  • Device indicated as: C0, C1 to C79, etc. This device is expressed as the symbol "C," expressed, and its order is expressed as a decimal number.

Device Type	Description of Function					
	A timer is used to complete control of timing. The timer contains a coil, contact,					
	and a time value register. When the coil is electrified, if the preset time is					
	reached, the contact will be actuated (contact a will close, contact b will open),					
	and the timer's fixed value be given by the set value. Timer has a regulated					
Timer	clock cycle (timing units: 100 ms). As soon as power to the coil is cut off, the					
	contact will no longer be actuated (contact a will open, contact b will close),					
	and the original timing value will return to zero.					
	Device indicated as: T0, T1 to T159, etc. The device is expressed as the					
	symbol "T," and its order is expressed as a decimal number.					
	When a PLC is used to perform various types of sequence control and set time					
	value and count value control, it most commonly perform data processing and					
	numerical operations, and data registers are used exclusively for storage of					
Data register	data and various parameters. Each data register contains 16 bits of binary					
Data register	data, which means that it can store one word. Two data registers with adjacent					
	numbers can be used to process double words.					
	Device indicated as: D0, D1 to D399, etc. The device is expressed as the					
	symbol "D," and its order is expressed as a decimal number.					

# Ladder diagram images and their explanation


Ladder Diagram Structures	Explanation of Commands	Command	Using Device			
	N.O. switch, contact a	LD	X, Y, M, T, C			
V	N.C. switch, contact b	LDI	X, Y, M, T, C			
<u> </u>	Series N.O.	AND	X, Y, M, T, C			
	Series N.C.	ANI	X, Y, M, T, C			
	Parallel N.O.	OR	X, Y, M, T, C			
	Parallel N.C.	ORI	X, Y, M, T, C			
-  ↑	Positive edge-triggered switch	LDP	X, Y, M, T, C			
	Negative edge-triggered switch	LDF	X, Y, M, T, C			
	Positive edge-triggered series	ANDP	X, Y, M, T, C			
	Negative edge-triggered series	ANDF	X, Y, M, T, C			
	Positive edge-triggered parallel	ORP	X, Y, M, T, C			

Chapter 16 PLC Function Applications | CFP2000

Ladder Diagram Structures	Explanation of Commands	Command	Using Device
	Negative edge-triggered parallel	ORF	X, Y, M, T, C
	Block series	ANB	N/A
	Block parallel	ORB	N/A
	Multiple outputs	MPS MRD MPP	N/A
—	Coil driven output commands	OUT	Y, M
	Some basic commands, applications commands	Some basic commands Applications commands	
	Inverted logic	INV	N/A


# 16-4-3 Overview of PLC Ladder Diagram Editing

The program editing method begins from the left busbar and proceeds to the right busbar (the right busbar is omitted when editing using WPLSoft). Continue to the next row after completing each row; there is a maximum of 11 contacts on each row. If this is not sufficient, a continuous line will be will be generated to indicate the continued connection and more devices can be added. A continuous series of numbers will be generated automatically and identical input points can be used repeatedly. See figure below:




The ladder diagram programming method involves scanning from the upper left corner to the lower right corner. The coils and applications command computing box are handled in the output, and the ladder diagram is placed on the farthest right. Taking the figure below as an example, we can gradually analyze the procedural sequence of the ladder diagram. The number in the upper right corner gives the sequential order.

Explanation of command sequence




Explanation of basic structure of ladder diagrams

1. **LD (LDI) command:** An LD or LDI command is given at the start of a block.



LDP and LDF have this command structure, but there are differences in their action state. LDP, LDF only act at the rising or falling edge of a conducting contact. (see figure below):




2. **AND (ANI) command:** A series configuration in which a single device is connected with one device or a block.




ANDP, ANDF also have structures like this, but their action occurs at the rising and falling edge.

3. OR (ORI) command: A single device is connected with one device or a block.




ORP, ORF also have identical structures, but their action occurs at the rising and falling edge.

4. **ANB command:** A configuration in which one block is in series with one device or block.




5. **ORB command:** A configuration in which one block is in parallel with one device or block.



In the case of ANB and ORB operations, if a number of blocks are connected, they should be combined to form a block or network from the top down or from left to right.

- 6. MPS, MRD, MPP commands: Branching point memory for multiple outputs, enabling multiple, different outputs. The MPS command begins at a branching point, where the so-called branching point refers to the intersection of horizontal and vertical lines. We have to rely on the contact status along a single vertical line to determine whether the next contact can give a memory command. While each contact is basically able to give memory commands, in view of convenience and the PLC's capacity restrictions, this can be omitted from some places when converting a ladder diagram. The structure of the ladder diagram can be used to judge what kinds of contact memory commands are used.
  - MPS can be distinguished by use of the "T" symbol; this command can be used
    consecutively for up to 8 times. The MRD command is read from branching point memory;
    because logic states along any one vertical line must be the same, in order to continue
    analysis of other ladder diagrams, the original contact status must be read.
  - MRD can be distinguished by use of the " |-" symbol. The MPP command is read from the starting state of the uppermost branching point, and it is read from the stack (pop); because it is the final command along a vertical line, it indicates that the state of the vertical line can be concluded.
  - MPP can be distinguished by use of the "L" symbol. Although there should basically be no
    errors when using the foregoing analytical approach, the compiling program may
    sometimes omit identical state output, as shown in the following figure:




# 16-4-4 Commonly-Used Basic Program Design Examples

### Start, stop, and protection

Some applications may require a brief close or brief break using the buttons to start and stop equipment. A protective circuit, therefore, must be designed to maintain continued operation in these situations; this protective circuit may employ one of the following methods:


## Example 1: Priority stop protective circuit

When the start N.O. contact X1=ON, and the stop N.C. contact X2 = OFF, Y1 = ON; if X2 = ON at this time, coil Y1 will no longer be electrified, and this is therefore referred to as priority stop.



### Example 2: Priority start protective circuit

When start N.O. contact X1 = ON, and the stop N.C. contact X2 = OFF, Y1 = ON, and coil Y1 will be electrified and protected. At this time, if X2 = ON, coil Y1 will still protect the contact and continue to be electrified, and this is therefore priority start.



Example 3: Setting (SET) and reset (RST) command protective circuit

The following figure shows a protective circuit composed of RST and SET commands.

Priority stop occurs when the RST command is placed after the SET command.

Because the PLC executes programs from the top down, at the end of the program, the state of Y1 will indicate whether coil Y1 is electrified. When X1 and X2 are both actuated, Y1 will lose power, and this is therefore priority stop.

Priority start occurs when the SET command is placed after the RST command. When X1 and X2 are both actuated, Y1 will be electrified, and this is therefore priority start.


Top priority of stop

X1

SET Y1

X2


RST Y1



# **Commonly-used control circuits**


### Example 4: Conditional control

X1 and X3 respectively starts and stops Y1; X2 and X4 respectively starts and stops Y2. All of these have protective circuits. Because Y1's N.O. contact is series connected with Y2's circuit, it becomes an AND condition for the actuation of Y2. The action of Y1 is therefore a condition for the action of Y2, and Y1 must be actuated before Y2 can be actuated.




Example 5: Interlocking control

The figure below shows an interlocking control circuit. Depending on which of the start contacts X1, X2 is valid first, the corresponding output Y1 or Y2 will be actuated, and when one is actuated, the other will not be actuated. This implies that Y1 and Y2 cannot be actuated at the same time (interlocking effect). Even if both X1 and X2 are valid at the same time, because the ladder diagram program is scanned from the top down, it is impossible for Y1 and Y2 to be actuated at same time. This ladder diagram assigns priority only to Y1.



#### Example 6: Sequence control


If the N.C. contact of Y2 in the interlocking control configuration of example 5 is put in series with the Y1 circuit, so that it is an AND condition for actuation of Y1 (see figure below), not only is Y1 a condition for the actuation of Y2 in this circuit, the actuation of Y2 will also stop the actuation of Y1. This configuration confirms the actuation order of Y1 and Y2.



Example 7: Oscillating circuit


### Oscillating circuit with a period of $\Delta T + \Delta T$

The figure below shows a very simple ladder diagram. When starting to scan the Y1 N.C. contact, because the Y1 coil has lost power, the Y1 N.C. contact will be closed. When the Y1 coil is then scanned, it will be electrified, and the output will be 1. When the Y1 N.C. contact is scanned in the scanning cycle, because Y1 coil is electrified, the Y1 N.C. contact will be open, the Y1 coil will then lose power, and the output will be 0. Following repeated scanning, the output of Y1 coil will have an oscillating waveform with a period of  $\Delta T$  (ON) + $\Delta T$  (OFF).




## Oscillating circuit with a period of nT+ΔT

The program of the ladder diagram shown below uses timer T0 to control coil Y1's electrified time. After Y1 is electrified, it causes timer T0 to close during the next scanning cycle, which will cause the output from Y1 to have the oscillating waveform shown in the figure below. Here n is the timer's decimal setting value, and T is the clock cycle of the timer.




#### Example 8: Flashing circuit

The following figure shows an oscillating circuit of a type commonly used to cause an indicator light to flash or buzzers to buzz. It uses two timers to control the ON and OFF time of Y1 coil. Here n1, n2 are the timing set values of T1 and T2, and T is the clock cycle of the timer.




Example 9: Triggering circuit

In the figure below, a command consisting of the differential of the rising edge of X0 causes coil M0 to generate a single pulse for  $\Delta T$  (length of one scanning cycle), and coil Y1 is electrified during this scanning cycle. Coil M0 loses power during the next scanning cycle, N.C. contact M0 and N.C. contact Y1 are both closed. This causes coil Y1 to stay in an electrified state until there is another rising edge in input X0, which again causes the electrification of coil M0 and the start of another scanning cycle, while also causing coil Y1 to lose power, etc. The sequence of these actions can be seen in the figure below. This type of circuit is commonly used to enable one input to perform two actions in alternation. It can be seen from the time sequence in the figure below that when input X0 is a square wave signal with a period of T, the output of coil Y1 will be a square wave signal with a period of 2T.




# Example 10: Delay circuit

When input X0 is On, the timer T10 is in no power status because the corresponding N.C. contacts OFF, and the output coil Y1 is electrified. T10 receives power and begins timing only after input X0 is OFF, and the output coil Y1 is delayed for 100 sec. (K1000 × 0.1 sec. =100 sec.) before losing power; refer to the sequence of actions in the figure below.




Example 11: The open / close delay circuit is composed of two timers; output Y4 has a delay whether the input X0 is ON or OFF.



# Example 12: Extended timing circuit

In the circuit in the figure on the left, the total delay time from the moment input X0 closes to the time output Y1 is electrified is  $(n1+n2) \times T$ , where T is the clock cycle. Timers: T11, T12; clock cycle: T.



# **16-5 Various PLC Device Functions**

Item	Specifications	Notes
Algorithmic control	Program stored internally, alternating back-and-	
method	forth scanning method	
Input / output control	When it starts again after ending (after execution	
method	to the END command), the input/output has an	
metriou	immediate refresh command	
Algorithmic	Basic commands (several µs);	Applications command (1-several tens
processing speed	Dasic commands (several μs),	of μs)
Programming	Command + ladder diagram	
language	Command Fladder diagram	
Program capacity	10000 steps	
		This number of contacts constitutes
Input / output terminal	Input (X): 10, output (Y): 3	CFP2000 input/output contacts; other
		devices have different correspondences

Туре	Device	ľ	tem	Range		Function		
			relav	X0-X17, 16 points, octal	Total	Corresponds to external		
	^	External input relay		number	32	input point		
	Υ	Evternal outnu	t relav	Y0–Y17, 16 points, octal	points	Corresponds to external		
	•	External output relay		number		output point		
		Auxiliary	General Use	M0–M799, 800 points	Total	Contact can switch ON /		
	М	Relay	Special purpose	M1000–M1079, 80 points	880 points	OFF within the program		
Relay bit						Timers referred to by the		
form					Total	TMR command; contact of		
101111	Т	Timer	100ms timer	T0-T159, 160 points	160	the T with the same number		
					points	will go On when the time is reached		
						Counter referred to by the		
			16-bit counter,	C0–C79, 80 points	Total	CNT command; contact of		
	С	Counter	general use		80	the C with the same		
		96	general use		points	number will go On when the		
						count is reached		
	Т	Current timer value		T0–T159, 160 points		The contact will be On		
	•					when the time is reached		
	_			00 070 401%		The counter contact will		
Register word	С	Current counte	er value	C0–C79, 16-bit counter 80 points		come On when the count is reached		
data		Data	Used to maintain power OFF	D0–D399, 400 points	Total	Used as data storage		
	D	Register	0	D1000-D1199, 200 points	1400	memory area		
		_	Special purpose	D2000-D2799, 800 points	points			
	K	Docimal	Single-byte	Setting Range: K-32,768–K32,767				
Constant	r۱	Decimal	Double-byte	Setting Range: K-2,147,48	3,648–K	(2,147,483,647		
Constant	Н	Hexadecimal Single-byte		Setting Range:H0000–HFFFF				
	11	TICACUCUITIAI	· · · · · · · · · · · · · · · · · · ·	Setting Range: H00000000-HFFFFFFF		FFFFF		
Serial con	Serial communications port (program write / read)		RS-485/keypad port					
	Input / output		Built-in three analog inputs and two analog outputs					
Function expansion module Optional Accessories		EMC-D42A; EMC-R6AA; EMC-D611A						
Comm	Communication Expansion Optional			EMC-COP01 (CANopen)				
	Module		Accessories	Livio-ooi oi (ozivopeii)				


#### 16-5-1 Introduction to Device Functions

# **Input / Output Contact Functions**

Input contact X functions: Input contact X is connected with an input device, and reads input signals entering the PLC. The number of times that contact a or b of input contact X used in the program is not subject to restrictions. The ON / OFF state of input contact X will change as the input device switches ON and OFF; a peripheral device (WPLSoft) cannot be used to force contact X ON or OFF.

# **Output Contact Y Functions**

The job of output contact Y is to send an ON / OFF signal to drive the load connected with output contact Y. Output contacts consist of two types: relays and transistors. While number of times that contact a or b of each output contact Y used in the program is not subject to restrictions, it is recommended that the number of output coil Y be used only once in a program, otherwise the right to determine the output state when the PLC performs program scanning will be assigned to the program's final output Y circuit.



i.e. decided by On/Off of X10.

### Numerical value, constant [K] / [H]

Constant	Single-byte	ν.	Decimal	K-32,768–K32,767
	Double-byte	, r		K-2,147,483,648–K2,147,483,647
	Single-byte	Н		H0000-HFFFF
	Double-byte	П		H00000000-HFFFFFFF


The PLC can use five types of numerical values to implement calculations based on its control tasks; the following is an explanation of the missions and functions of different numerical values.

#### Binary Number, BIN

The PLC's numerical operations and memory employ binary numbers. Binary nibbles and relevant terms are explained as follows:

bit	bits are the fundamental units of binary values, and have a state of either 1 or 0
Nibble	Comprised of a series of 4 bits (such as b3–b0); can be used to express a one-nibble decimal number 0–9 or hexadecimal number: 0–F.
Byte	Comprised of a series of two nibbles (i.e. 8 bits, b7–b0); can express a hexadecimal number: 00–FF.
Word	Comprised of a series of two bytes (i.e. 16 bits, b15–b0); can express a hexadecimal number with four nibbles: 0000–FFFF.
Double Word	Comprised of a series of two words (i.e. 32 bits, b31–b0); can express a hexadecimal number with eight nibbles: 00000000–FFFFFFF

Relationship between bits, digits, nibbles, words, and double words in a binary system (see figure below):



#### Octal Number, OCT

The external input and output terminals of a DVP-PLC are numbered using octal numbers Example: External input: X0–X7, X10–X17... (Device number table);

External output: Y0–Y7, Y10–Y17... (Device number table)

#### Decimal Number, DEC

Decimal numbers are used for the following purposes in a PLC system:

- The setting values of timer T or counter C, such as TMR C0 K50. (K constant)
- The numbers of devices including M, T, C, or D, such as M10 or T30. (device number)
- Used as an operand in an application command, such as MOV K123 D0. (K constant)

### Binary Code Decimal, BCD

Uses one nibble or 4 bits to express the data in a decimal number; a series of 16 bits can therefore express a decimal number with 4 nibbles. Chiefly used to read the input value of a fingerwheel numerical switch input or output a numerical value to a seven-segment display driver.

### Hexadecimal Number, HEX

Applications of hexadecimal numbers in a PLC system: Used as operands in application commands, such as MOV H1A2B D0. (H constant)

#### Constant K

Decimal numbers are usually prefixed with a "K" in a PLC system, such as K100. This indicates that it is a decimal number with a numerical value of 100.

Exceptions: K can be combined with bit device X, Y, M, or S to produce data in the form of a nibble, byte, word, or double word, such as in the case of K2Y10 or K4M100. Here K1 represents a 4-bit combination, and K2-K4 variously represent 8-, 12-, and 16-bit combinations.

#### Constant H

Hexadecimal numbers are usually prefixed with the letter "H" in a PLC system, such as in the case of H100, which indicates a hexadecimal number with a numerical value of 100.

# **Functions of Auxiliary Relays**

Like an output relay Y, an auxiliary relay M has an output coil and contacts a and b, and the number of times they can be used in a program is unrestricted. Users can use an auxiliary relay M to configure the control circuit, but cannot use it to directly drive an external load. Auxiliary relays have the following two types of characteristics:

- Ordinary auxiliary relays: Ordinary auxiliary relays will all revert to the OFF state if a power outage occurs while the PLC is running, and will remain in the OFF state if power is again turned down.
- Special purpose auxiliary relays: Each special purpose auxiliary relay has its own specific use.
   Do not use any undefined special purpose auxiliary relays.

### **Timer Functions**

Timers take 100 ms as their timing units. When the timing method is an upper time limit, when the current timer value = set value, power will be sent to the output coil. Timer setting values consist of decimal K values, and the data register D can also serve as a setting value.

Actual timer setting time = timing units × set value

#### Counter features

Item	16-bit counter
Туре	General Type
CT Direction:	Score:
Setting	0–32,767
Designation of set value	Constant K or data register D
Change in current value	When the count reaches the set value, there is no longer a count
Output contact	When the count reaches the set value, the contact comes ON and stays ON
Reset	The current value reverts to 0 when an RST command is executed, and the contact reverts to OFF
Contact actuation	All are actuated after the end of scanning

#### Counter functions


When a counter's counting pulse input signal goes OFF→ON, if the counter's current value is equal to the set value, the output coil will become ON. The setting value will be a decimal K values, and the data register D can also serve as a setting value.

#### 16-bit counter C0-C79:


- 16-bit counter setting range: K0–K32,767. (when K0 and K1 are identical, the output contact will immediately be ON during the first count.)
- The current counter value will be cleared from an ordinary counter when power is shut off to the PLC.
- If the MOV command or WPLSoft is used to transmit a value greater than the set value to the C0 current value register, when the next X1 goes from OFF→ON, the C0 counter contact will change to On, and the current value will change to the set value.
- A counter's setting value may be directly set using a constant K or indirectly set using the value in register D (not including special data registers D1000–D1199 or D2000–D2799).

• If the set value employs a constant K, it may only be a positive number; the set value may be either a positive or a negative number if the value in data register D is used. The current counter value will change from 32,767 to -32,768 as the count continues to accumulate.

## Example



- When X0 = ON and the RST command is executed, the current value of C0 will revert to 0, and the output contact will revert to OFF.
- When X1 changes from OFF → ON, the current value of the counter will execute an increase (add one).
- When the count of counter C0 reaches the set value K5, the contact C0 becomes ON, and the current value of C0 = set value = K5.
   Afterwards, signal C0 triggered by X1 cannot be received, and the current value of C0 will remain K5.



# 16-5-2 Introduction to Special Relay Functions (Special M)

RO: read only; RW: read and write

Special M	Description of Function	R/W *
M1000	Operates monitor N.O. contact (contact a). N.O. while RUN, contact a. This contact is ON while in the RUN state.	RO
M1001	Operates monitor N.C. contact (contact b). N.C. while RUN, contact b. This contact is OFF while in the RUN state.	RO
M1002	Initiates a forward (the instant RUN is ON) pulse. Initial pulse, contact a. Produces a forward pulse the moment RUN begins; its width = scan cycle	RO
M1003	Initiates a reverse (the instant RUN is OFF) pulse. Initial pulse, contact a. Produces a reverse pulse the moment RUN ends; the pulse width = scan cycle	RO
M1004	Reserved	RO
M1005	Driver malfunction instructions	RO
M1006	Converter has no output	RO
M1007	Driver direction FWD (0) / REV (1)	RO
M1007	Driver direction ( vvb (0) / NEV (1)	110
IVI 1000		
и М1010		
M1010	10 ms clock pulse, 5 ms ON / 5 ms OFF	RO
M1011	100 ms clock pulse, 50 ms ON / 50 ms OFF	RO
M1012	1 sec. clock pulse, 0.5s ON / 0.5s OFF	RO
	•	
M1014	1 min. clock pulse, 30s ON / 30s OFF	RO
M1015	Frequency attained (when used together with M1025)	RO
M1016	Parameter read / write error	RO
M1017	Parameter write successful	RO
M1018	<del></del>	
M1019	Motor drive warning indicator	RO
M1020	Zero flag	RO
M1021	Borrow flag	RO
M1022	Carry flag	RO
M1023	Divisor is 0	RO
M1024		
M1025	Drive frequency = set frequency (ON)  Drive frequency = 0 (OFF)	RW
M1026	Drive operating direction FWD (OFF) / REV (ON)	RW
M1027	Drive Reset	RW
M1028		
M1030		
M1031	Compulsory setting of the current PID integral value equal to D1019 (0 change, 1 valid)	RW
M1032	Compulsory definition of FREQ command after PID control	RW
M1033		
M1034	Initiates CANopen real-time control	RW
M1035	Initiates internal communications control	RW
1111000	Intracted internal continuations control	

Special M	Description of Function	R/W *
M1037	·	
M1039		
M1040	Excitation (Servo ON)	RW
M1041		
M1042	Quick stop	RW
M1043		
M1044	Pause (Halt)	RW
M1045		
M1051		
M1052	Lock frequency (lock, frequency locked at the current operating frequency)	RW
M1053		
M1055		
M1056	Excitation ready (Servo ON Ready)	RO
M1057		
M1058	On Quick Stopping	RO
M1059	CANopen Master setting complete	RO
M1060	CANopen Currently initializing slave station	RO
M1061	CANopen Slave station initialization failure	RO
M1062		
	<b></b>	
M1064		
M1065	Read / write CANopen data time out	RO
M1066	Read / write CANopen data complete	RO
M1067	Read / write CANopen data successful	RO
M1068	Calendar calculation error	RO
M1069		
M1075		
M1076	Calendar time error or refresh time out	RO
M1077	485 Read / write complete	RO
M1078	485 Read-write error	RO
M1079	485 Communications time out	RO
M1168	SMOV BCD and BIN mode switch	RW
M1260	PLC PID1 Enable	RW
M1262	PLC PID1 Positive integral value limit	RW
M1270	PLC PID2 Enable	RW
M1272	PLC PID2 Positive integral value limit	RW

# 16-5-3 Introduction to Special Register Functions (Special D)

Special D	Description of Function	R/W *
D1000		
D1000	Device system program version	RO
D1001	Program capacity	RO
D1002		RO
	Total program memory content	, KO
D1004		
D4000	<del></del>	
D1009	Ourself and the country of the count	
D1010	Current scan time (units: 0.1 ms)	RO
D1011	Minimum scan time (units: 0.1 ms)	RO
D1012	Maximum scan time (units: 0.1 ms)	RO
D1013		
D1017		
D1018	Current integral value	RO
D1019	Compulsory setting of PID I integral	RW
D1020	Output frequency (0.00–600.00 Hz)	RO
D1021	Output current (####.# A)	RO
	Al AO DI DO extension card number	
	0: No extension card	
D1022	4: AC input card (6 in) (EMC-D611A)	RO
D 1022	5: Digital I/O Card (4 in 2 out) (EMC-D42A)	
	6: Relay card (6 out) (EMC-R6AA)	
	11: Analog I/O card (2 in 2 out) (EMC-A22A)	
	Communication extension card number	
	0: No extension card	
	1: DeviceNet Slave (CMC-DN01)	
D1023	2: Profibus-DP Slave (CMC-PD01)	RO
	3: CANopen Slave (EMC-COP01)	
	5: EtherNet/IP Slave (CMC-EIP01)	
	12: PROFINET Slave (CMC-PN01)	
D1024		
D1027		
D4007	PID calculation frequency command	DO.
D1027	(frequency command after PID calculation)	RO
D1028	AVI1value (0.00–100.00%)	RO
D1029	ACI value (0.0–100.00%)	RO
D1030	AVI2 value (0.00–100.00%)	RO
D1031	C series: extension card Al10 (0.0–100.0%)	RO
D1032	C series: extension card Al11 (0.0–100.0%)	RO
D1033		
D1035		
D1036	Servo fault bit	RO
D1037	Drive output frequency	RO
D1037	DC bus voltage	RO
D1030	Output voltage	RO
פטום	Catpat voltage	110

Special D	Description of Function	R/W *
D1040	Analog output value AFM1 (-100.00–100.00%)	RW
D1041	C series: extension card AO10 (0.0–100.0%)	RW
D1042	C series: extension card AO11 (0.0–100.0%)	RW
	Can be user-defined (will be displayed on panel when Pr.00-04 is set as 28; display	
D1043	method is C xxx)	RW
D1044		_
D1045	Analog output value AFM2 (-100.00–100.00%)	RW
D1046	,	
I		
D1049		
D4050	Actual Operation Mode	DO
D1050	0: Speed	RO
D1051		
D1059		
D1060	Operation Mode setting	RW
D 1000	0: Speed	1700
D1061	485 COM1 communications time out time (ms)	RW
D1062	Torque command (torque limit in speed mode)	RW
D1063	Year (Western calendar) (display range 2000-2099) (must use KPC-CC01)	RO
D1064	Week (display range 1-7) (must use KPC-CC01)	RO
D1065	Month (display range 1-12) (must use KPC-CC01)	RO
D1066	Day (display range 1-31) (must use KPC-CC01)	RO
D1067	Hour (display range 0-23) (must use KPC-CC01)	RO
D1068	Minute (display range 0-59) (must use KPC-CC01)	RO
D1069	Second (display range 0-59) (must use KPC-CC01)	RO
D1100	Target frequency	RO
D1101	Target frequency (must be operating)	RO
D1102	Reference frequency	RO
D1103		
D1106		
D1107	π(Pi) Low word	RO
D1108	π(Pi) High word	RO
D1109	Random number	RO
D1110	Internal node communications number (set number of slave stations to be controlled)	RW
D1111		
D1113		
	Numbering of the operating motors:	
D1114	1: Motor 1	RO
	2: Motor 2	
D1115	Internal node synchronizing cycle (ms)	RO
D1116	Internal node error (bit0 = Node 0, bit1 = Node 1,bit7 = Node 7)	RO
D1117	Internal node online correspondence (bit0 = Node 0, bit1 = Node 1,bit7 = Node 7)	RO
D1118		
D1119		
D1120	Internal node 0 control command	RW


Special D	Description of Function	R/W *
D1121	Internal node 0 mode	RW
D1122	Internal node 0 reference command L	RW
D1123	Internal node 0 reference command H	RW
D1124		
D1125		
D1126	Internal node 0 status	RO
D1127	Internal node 0 reference status L	RO
D1128	Internal node 0 reference status H	RO
D1129		
D1130	Internal node 1 control command	RW
D1131	Internal node 1 mode	RW
D1132	Internal node 1 reference command L	RW
D1133	Internal node 1 reference command H	RW
D1134		
D1135		
D1136	Internal node 1 status	RO
D1137	Internal node 1 reference status L	RO
D1138	Internal node 1 reference status H	RO
D1139		
D1140	Internal node 2 control command	RW
D1141	Internal node 2 mode	RW
D1142	Internal node 2 reference command L	RW
D1143	Internal node 2 reference command H	RW
D1144		
D1145		
D1146	Internal node 2 status	RO
D1147	Internal node 2 reference status L	RO
D1148	Internal node 2 reference status H	RO
D1149		
D1150	Internal node 3 control command	RW
D1151	Internal node 3 mode	RW
D1152	Internal node 3 reference command L	RW
D1153	Internal node 3 reference command H	RW
D1154		
D1155		
D1156	Internal node 3 status	RO
D1157	Internal node 3 reference status L	RO
D1158	Internal node 3 reference status H	RO
D1159		
D1160	Internal node 4 control command	RW
D1161	Internal node 4 mode	RW
D1162	Internal node 4 reference command L	RW
D1163	Internal node 4 reference command H	RW
D1164		
D1165		
D1166	Internal node 4 status	RO
D1167	Internal node 4 reference status L	RO
= • .		

Special D	Description of Function	R/W *
D1168	Internal node 4 reference status H	RO
D1169		
D1170	Internal node 5 control command	RW
D1171	Internal node 5 mode	RW
D1172	Internal node 5 reference command L	RW
D1173	Internal node 5 reference command H	RW
D1174		RW
D1175		
D1176	Internal node 5 status	
D1177	Internal node 5 reference status L	RO
D1178	Internal node 5 reference status H	RO
D1179		
D1180	Internal node 6 control command	RW
D1181	Internal node 6 mode	RW
D1182	Internal node 6 reference command L	RW
D1183	Internal node 6 reference command H	RW
D1184		
D1185		
D1186	Internal node 6 status	RO
D1187	Internal node 6 reference status L	RO
D1188	Internal node 6 reference status H	RO
D1189		
D1190	Internal node 7 control command	RW
D1191	Internal node 7 mode	RW
D1192	Internal node 7 reference command L	RW
D1193	Internal node 7 reference command H	RW
D1194		
D1195		
D1196	Internal node 7 status	RO
D1197	Internal node 7 reference status L	RO
D1198	Internal node 7 reference status H	RO
D1199		
D1560	Motor drive warning code	RO

Special D	Description of Function	Default	R / W*
D1200	PID1 mode:	0	RW
D1200	0: Basic mode	U	IZVV
	PID1 target selection:		
	0: Refer to D1202		
D1201	1: AVI1	0	RW
	2: ACI		
	3: AVI2		
D1202	PID1 target value (0.00–100.00%)	5000	RW
	PID1 feedback selection		
	0: Refer to D1204		
D1203	1: AVI1	1	RW
	2: ACI		
	3: AVI2		

Chapter 16 PLC Function Applications | CFP2000

Special D	Description of Function	Default	R/W*
D1204	PID1 feedback value (0.00–100.00%)	0	RW
D1205	PID1 P value (decimal point 2)	10	RW
D1206	PID1 I value (decimal point 2)	1000	RW
D1207	PID1 D value (decimal point 2)	0	RW
D1209	Max. limit of PID1	10000	RW
D1215	Counting value of PID1 (decimal point 2)	0	RO
D1220	PID2 mode:	0	RW
D1220	0: Basic mode	U	KVV
	PID2 target selection:		
	0: Refer to D1202		
D1221	1: AVI1	0	RW
	2: ACI		
	3: AVI2		
D1222	PID2 target value (0.00–100.00%)	5000	RW
	PID2 feedback selection		
	0: Refer to D1204		
D1223	1: AVI1	1	RW
	2: ACI		
	3: AVI2		
D1224	PID2 feedback value (0.00–100.00%)	0	RW
D1225	PID1 P value (decimal point 2)	10	RW
D1226	PID2 I value (decimal point 2)	1000	RW
D1227	PID2 D value (decimal point 2)	0	RW
D1229	Max. limit of PID2	10000	RW
D1235	Counting value of PID2 (decimal point 2)	0	RO



The following is CANopen Master's special D (can be written in only with PLC in Stop state)

X CFP2000 does not have torque and position mode. As CANopen master, however, CFP2000 can issue torque and position commands to CANopen slaves.

n = 0-7

Special D	Description of Function	PDO Mapping	Power OFF Memory	Default	R/W
D1070	Channel opened by CANopen initialization (bit0=Machine code0)	NO	NO	0	R
D1071	Error channel occurring in CANopen initialization process (bit0=Machine code0)	NO	NO	0	R
D1072	Reserved	-	-		-
D1073	CANopen break channel (bit0=Machine code0)	NO	NO		R
D1074	Error code of master error  0: No error  1: Slave station setting error  2: Synchronizing cycle setting error (too small)	NO	NO	0	R
D1075	Reserved	-	-		-
D1076	SDO error message (main index value)	NO	NO		R
D1077	SDO error message (secondary index value)	NO	NO		R
D1078	SDO error message (error code)	NO	NO		R
D1079	SDO error message (error code)	NO	NO		R
D1080   D1089	Reserved	-	-		-
D1090	Synchronizing cycle setting	NO	YES	4	RW
D1091	Sets slave station On or Off (bit0-bit7 correspond to slave stations number 0-7)	NO	YES	FFFFH	RW
D1092	Delay before start of initialization	NO	YES	0	RW
D1093	Break time detection	NO	YES	1000ms	RW
D1094	Break number detection	NO	YES	3	RW
D1095	Reserved	-	-		-
D1096	Reserved	-	-		-
D1097	Corresponding real-time transmission type (PDO) Setting range: 1–240	NO	YES	1	RW
D1098	Corresponding real-time receiving type (PDO) Setting range: 1–240	NO	YES	1	RW
D1099	Initialization completion delay time Setting range: 1 to 60000 sec	NO	YES	15 sec.	RW
D2000+100× n	Station number n of slave station Setting range: 0–127 0: No CANopen function	NO	YES	0	RW

The CFP2000 supports 8 slave stations under the CANopen protocol; each slave station occupies 100 special D locations; stations are numbered 1–8, total of 8 stations.

Explanation of slave	Slave station no. 1	D2000	Node ID
station number		D2001	Slave station no. 1 torque restrictions
		D2099	Address 4(H) corresponding to receiving channel 4
	Slave station no. 2	D2100	Node ID
		D2101	Slave station no. 2 torque restrictions
		D2199	Address 4(H) corresponding to receiving channel 4
	Slave station no. 3	D2200	Node ID
		D2201	Slave station no. 3 torque restrictions
		D2299	Address 4(H) corresponding to receiving channel 4
		Û	
	Slave station no. 8	D2700	Node ID
		D2701	Slave station no. 8 torque restrictions
		D2799	Address 4(H) corresponding to receiving channel 4

- 1. The range of n is 0–7
- 2. indicates PDOTX, ▲ indicates PDORX; unmarked special D can be refreshed using the CANFLS command

Special D	Description of Function		R/W
	Station number n of slave station		
D2000+100×n	Setting range: 0–127	0	RW
	0: No CANopen function		
D2002+100×n	Manufacturer code of slave station number n (L)	0	R
D2003+100×n	Manufacturer code of slave station number n (H)	0	R
D2004+100×n	Manufacturer's product code of slave station number n (L)	0	R
D2005+100×n	Manufacturer's product code of slave station number n (H)	0	R

### **Basic definitions**

Special D	Description of Function		PDO	PDO Default				R/W	
Орсска В	Description of Function	Default	Mapping	1	2	3	4	17/77	
D2006+100×n	Communications break handling method of	0	0 00071	6007H-0010H					RW
D2000+100×11	slave station number n		6007H-0010H					IZVV	
D2007+100×n	Error code of slave station number n error	0	603FH-0010H					R	
D2008+100×n	Control word of slave station number n	0	6040H-0010H	•		•	•	RW	
D2009+100×n	Status word of slave station number n	0	6041H-0010H	•		<b>A</b>	<b>A</b>	R	
D2010+100×n	Control mode of slave station number n	2	6060H-0008H					RW	
D2011+100×n	Actual mode of slave station number n	2	6061H-0008H					R	

# Velocity Control

# Slave station number n = 0-7

Cassial D	Description of Function	Default	PDO	PDO Default				D/M
Special D	Description of Function		Mapping	1	2	3	4	R/W
D2001+100×n	Torque restriction on slave station number n	0	6072H-0010H					RW
D2012+100×n	Target speed of slave station number n	0	6042H-0010H	•				RW
D2013+100×n	Actual speed of slave station number n	0	6043H-0010H	•				R
D2014+100×n	Error speed of slave station number n	0	6044H-0010H					R
D2015+100×n	Acceleration time of slave station number n	1000	604FH-0020H					R
D2016+100×n	Deceleration time of slave station number n	1000	6050H-0020H					RW

20XXH correspondences: MI / MO / AI / AO

Slave station number n = 0-7

Special D	Description of Function	Default	PDO	PDO Default		ult	DAM		
Special D	Description of Function	Delault	Mapping	1	2	3	4	R/W	
D2026+100×n	MI status of slave station number n	0	2026H-0110H		<b>A</b>			RW	
D2027+100×n	MO setting of slave station number n	0	2026H-4110H		•			RW	
D2028+100×n	Al1 status of slave station number n	0	2026H-6110H		•			RW	
D2029+100×n	Al2 status of slave station number n	0	2026H-6210H		•			RW	
D2030+100×n	Al3 status of slave station number n	0	2026H-6310H		•			RW	
D2031+100×n	AO1 status of slave station number n	0	2026H-A110H		•			RW	
D2032+100×n	AO2 status of slave station number n	0	2026H-A210H		•			RW	
D2033+100×n	AO3 status of slave station number n	0	2026H-A310H		•			RW	

# PDO reflection length setting

Special D	Description of Function	Default	R/W
D2034+100×n	Real-time transmission setting of slave station number n	000AH	RW
D2067+100×n Real-time reception setting of slave station number n		0000H	RW

16-5-4 PLC Communication Address

Device	Range	Туре	Address (Hex)
X	00–37 (Octal)	bit	0400-041F
Υ	00-37 (Octal)	bit	0500-051F
Т	00–159	bit / word	0600-069F
M	000–799	bit	0800-0B1F
М	1000–1079	bit	0BE8-0C37
С	0–79	bit / word	0E00-0E47
D	00–399	word	1000–118F
D	1000–1198	word	13E8-144B
D	2000–2799	word	17D0-1AEF

### Command code that can be used

Function Code	Description of Function	Function target
01	Coil status read	Y, M, T, C
02	Input status read	X, Y, M, T, C
03	Read single unit of data	T, C, D
05	Compulsory single coil status change	Y, M, T, C
06	Write single unit of data	T, C, D
0F	Compulsory multiple coil status change	Y, M, T, C
10	Write multiple units of data	T, C, D

**NOTE:** When PLC functions have been activated, the CFP2000 can match PLC and driver parameters; this method employs different addresses and driver (default station number is 1, PLC sets station number as 2).

# **16-6 Introduction to the Command Window**

# 16-6-1 Overview of Basic Commands

# Ordinary commands

Command Code	Function	OPERAND	Execution Speed (us)
LD	Load contact a	X, Y, M, T, C	0.8
LDI	Load contact b	X, Y, M, T, C	0.8
AND	Connect contact a in series	X, Y, M, T, C	0.8
ANI	Connect contact b in series	X, Y, M, T, C	0.8
OR	Connect contact a in parallel	X, Y, M, T, C	0.8
ORI	Connect contact b in parallel	X, Y, M, T, C	0.8
ANB	Series circuit block	N/A	0.3
ORB	Parallel circuit block	N/A	0.3
MPS	Save to stack	N/A	0.3
MRD	Stack read (pointer does not change)	N/A	0.3
MPP	Read stack	N/A	0.3

# Output command

Command Code	Function	OPERAND	Execution Speed (us)
OUT	Drive coil	Y, M	1
SET	Action continues (ON)	Y, M	1
RST	Clear contact or register	Y, M, T, C, D	1.2

# Timer, counter

Command Code	Function	OPERAND	Execution Speed (us)
TMR	16-bit timer	T-K or T-D commands	1.1
CNT	16-bit counter	C-K or C-D (16-bit)	0.5

# Main control command

Command Code	Function	OPERAND	Execution Speed (us)
MC	Common series contact connection	N0–N7	0.4
MCR	Common series contact release	N0-N7	0.4

# Contact rising edge / falling edge detection command

Command Code	Function	OPERAND	Execution Speed (us)
LDP	Start of forward edge detection action	X, Y, M, T, C	1.1
LDF	Start of reverse edge detection action	X, Y, M, T, C	1.1
ANDP	Forward edge detection series connection	X, Y, M, T, C	1.1
ANDF	Reverse edge detection series connection	X, Y, M, T, C	1.1
ORP	Forward edge detection parallel connection	X, Y, M, T, C	1.1
ORF	Reverse edge detection parallel connection	X, Y, M, T, C	1.1

# Upper / lower differential output commands

Command Code	Function	OPERAND	Execution Speed (us)
PLS	Upper differential output	Y, M	1.2
PLF	Lower differential output	Y, M	1.2

#### Stop command

Command Code	Function	OPERAND	Execution Speed (us)
END	Program conclusion	N/A	0.2

#### Other commands

Command Code	Function	OPERAND	Execution Speed (us)
NOP	No action	N/A	0.2
INV	Inverse of operation results	N/A	0.2
Р	Index	Р	0.3


# 16-6-2 Detailed explanation of basic commands

Command	Function					
LD	Load contact a	oad contact a				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The LD command is used for contact a starting at the left busbar or contact a starting at a contact circuit block; its function is to save current content and save the acquired contact status in the cumulative register.








Command code:		Description:
LD	X0	Load Contact a of X0
AND	) X1	Create series connection
AND	<b>^</b> 1	to contact a of X1
OUT	Y1	Drive Y1 coil

Command	Function Load contact b					
LDI						
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The LDI command is used for contact b starting at the left busbar or contact b starting at a contact circuit block; its function is to save current content and save the acquired contact status in the cumulative register.




	Command code:		Description:	
LDI X0		X0	Load Contact b of X0	
AND	AND	X1	Create series connection	
	AND		to contact a of X1	
	OUT	Y1	Drive Y1 coil	

Command	Function					
AND	Connect conta	Connect contact a in series				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The AND command is used to create a series connection to contact a; first reads current status of the designated series contact and logical operation results before contact in order to perform "AND" operation; saves results in cumulative register.

Example



Ladder diagram:

Command code: Description:

LDI X1 Load Contact b of X1


AND X0 Create series connection to contact a of X0

OUT Y1 Drive Y1 coil

Command		Function				
ANI	Connect conta	act b in series				
Onerend	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The ANI command is used to create a series connection to contact b; its function is to first read current status of the designated series contact and logical operation results before contact in order to perform "AND" operation; saves results in cumulative register.



Command code: Description:

LD X1 Load Contact a of X1


ANI X0 Create series connection to contact b of X0

OUT Y1 Drive Y1 coil

Command	Function					
OR	Connect conta	act a in parallel				
On an and	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The OR command is used to establish a parallel connection to contact a; its function is to first read current status of the designated series contact and logical operation results before contact in order to perform "OR" operation; saves results in cumulative register.




Comr	mand code:	Description:
LD	X0	Load Contact a of X0
OR	<b>X</b> 1	Create series connection
OK	ΛI	to contact a of X1
OUT	Y1	Drive Y1 coil

Command		Function				
ORI	Connect conta	act b in parallel				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
	✓	✓	✓	✓	✓	-

Explanation

The ORI command is used to establish a parallel connection to contact b; its function is to first read current status of the designated series contact and logical operation results before contact in order to perform "OR" operation; saves results in cumulative register.



Comman	d code:	Description:
LD	X0	Load Contact a of X0
ORI	<b>X</b> 1	Create series connection
OKI	Λı	to contact b of X1
OUT	Y1	Drive Y1 coil


Command	Function
ANB	Series circuit block
Operand	N/A

Explanation

ANB performs an "AND" operation on the previous saved logic results and the current cumulative register content.

Example

# Ladder diagram:



Commar	nd code:	Description:
LD	X0	Load Contact a of X0
		Establish parallel
ORI	X2	connection to contact b of
		X2
LDI	X1	Load Contact b of X1
		Establish parallel
OR	X3	connection to contact a of
		X3
ANB		Series circuit block
OUT	Y1	Drive Y1 coil


Command	Function
ORB	Parallel circuit block
Operand	N/A

Explanation

ORB performs an "OR" operation on the previous saved logic results and the current cumulative register content.

Example

Ladder diagram:



Comman	d code:	Description:
LD	X0	Load Contact a of X0
		Establish parallel
ANI	X1	connection to contact b of
		X1
LDI	X2	Load Contact b of X2
		Establish parallel
AND	Х3	connection to contact a of
		X3
ORB		Parallel circuit block
OUT	Y1	Drive Y1 coil

Command	Function
MPS	Save to stack
Operand	N/A

Explanation

Save current content of cumulative register to the stack. (Add one to stack pointer)

Command	Function
MRD	Read stack (pointer does not change)
Operand	N/A

Explanation


Reads stack content and saves to cumulative register. (Stack pointer does not change)

Command	Function
MPP	Read stack
Operand	N/A

Explanation

Retrieves result of previously-save logical operation from the stack, and saves to cumulative register. (Subtract one from stack pointer)

Example



Comman	d code:	Description:
LD	X0	Load Contact a of X0
MPS		Save to stack
AND	X1	Create series connection
AND	ΛI	to contact a of X1
OUT	Y1	Drive Y1 coil
MRD		Read stack (pointer does
WIKD		not change)
AND	X2	Create series connection
AND	ΛZ	to contact a of X2
OUT	M0	Drive M0 coil
MPP		Read stack
OUT	Y2	Drive Y2 coil
END		Program conclusion

Command		Function				
OUT	Orive coil					
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	-	✓	✓	-	-	-

Explanation

Outputs result of logical operation before OUT command to the designated element. Coil contact action:

		Out commar	nd
Result:	Cail	Access Point:	
	Coil	Contact a (N.O.)	Contact b (N.C.)
FALSE	Off	Not conducting	Conducting
TRUE	On	Conducting	Not conducting

Example

Ladder diagram:



Command code: Description:

LD X0 Load Contact b of X0

AND X1 Establish parallel connection to contact a of X1


OUT Y1 Drive Y1 coil

Command		Function				
SET	Action continu	action continues (ON)				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	-	✓	✓	-	-	-

Explanation

When the SET command is driven, the designated element will be set as On, and will be maintained in an On state, regardless of whether the SET command is still driven. The RST command can be used to set the element as Off.





Command code:

Description:

LD X0 Load Contact a of X0

Establish parallel

ANI Y0 connection to contact b of Y0

SET	Y1	Action continues (ON)

Command		Function				
RST	Clear contact	or register				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	-	✓	✓	✓	✓	✓

Explanation

When the RST command is driven, the action of the designated element will be as follows:

Element	Mode	
Y, M Both coil and contact will be set as Off.		
т.о	The current timing or count value will be set as 0, and both the coil and	
T, C	contact will be set as Off.	
D	The content value will be set as 0.	

If the RST command has not been executed, the status of the designated element will remain unchanged.

Example

Ladder diagram:



Command code: Description:

LD X0 Load Contact a of X0

RST Y5 Clear contact or register


Command	Function			
TMR	16-bit timer			
Operand	T-K	T0-T159, K0-K32,767		
Operand	T-D	T0-T159, D0-D399		

Explanation

When the TMR command is executed, the designated timer coil will be electrified, and the timer will begin timing. The contact's action will be as follows when the timing value reaches the designated set value (timing value ≥ set value):

N.O. (Normally Open) contact	Closed
N.C. (Normally Close) contact	Open

If the RST command has not been executed, the status of the designated element will remain unchanged.




Command	Function		
CNT	6-bit counter		
Operand	C-K	C0-C79, K0-K32,767	
Operand	C-D	C0-C79, D0-D399	

Explanation

When the CNT command is executed from OFF to ON, this indicates that the designated counter coil goes from no power to electrified, and 1 will be added to the counter's count value; when the count reaches the designated value (count value = set value), the contact will have the following action:

N.O. (Normally Open) contact	Closed
N.C. (Normally Close) contact	Open

After the count value has been reached, the contact and count value will both remain unchanged even if there is continued count pulse input. Please use the RST command if you wish to restart or clear the count.



	Command	Function
	MC/MCR	Connect/release a common series contact
-	Operand	N0–N7

Explanation


MC is the main control initiation command, and any commands between MC and MCR will be executed normally. When the MC command is OFF, any commands between MC and MCR will act as follows:

Determination of commands	Description
Ordinary timer	The timing value will revert to 0, the coil will lose power,
Ordinary timer	and the contact will not operate
Country	The coil will lose power, and the count value and contact
Counter	will stay in their current state
Coil driven by OUT command	None receive power
Elements driven by SET, RST	Will remain in their current state
commands	Will remain in their current state
Applications commands	None are actuated

MCR is the main control stop command, and is placed at the end of the main control program. There may not be any contact commands before the MCR command. The MC-MCR main control program commands support a nested program structure with a maximum only 8 levels; use in the order N0-N7, please refer to the following program:

Example

# Ladder diagram:



Command code:		Description:	
LD	X0	Load Contact a of X0	
MC	N0	Connection of N0 common series contact	
LD	X1	Load Contact a of X1	
OUT	Y0	Drive Y0 coil	
:			
LD	X2	Load Contact a of X2	
MC	N1	Connection of N1 common series contact	
LD	X3	Load Contact a of X3	
OUT	Y1	Drive Y1 coil	
:			
MCR	N1	Release N1 common series contact	
:			
MCR	N0	Release N0 common series contact	
:			
LD	X10	Load Contact a of X10	
MC	N0	Connection of N0 common series contact	
LD	X11	Load Contact a of X11	
OUT	Y10	Drive Y10 coil	
:			
MCR	N0	Release N0 common series contact	


Command	Function					
LDP	Start of forwar	Start of forward edge detection action				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The LDP command has the same usage as LD, but its action is different; its function is to save current content, while also saving the detected state of the rising edge of the contact to the cumulative register.

Example

Ladder diagram:



Command code: Description:

LDP	ΧO	Start of X0 forward edge detection
	ΛU	action
AND	X1	Create series connection to contact a
AND	<b>^</b> 1	of X1
OUT	Y1	Drive Y1 coil

Remark

Refer to the function specifications table for each device in series for the scope of usage of each operand.


A rising edge contact will be TRUE after power is turned on if the rising edge contact is On before power is turned on to the PLC.

Command	Function					
LDF	Start of revers	Start of reverse edge detection action				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The LDF command has the same usage as LD, but its action is different; its function is to save current content while also saving the detected state of the falling edge of the contact to the cumulative register.





	Command code:		Description:		
	LDF	X0	Start of X0 reverse edge		
		ΛU	detection action		
	AND	X1	Create series connection to		
		<b>^</b> 1	contact a of X1		
	OUT	Y1	Drive Y1 coil		


Command	Function					
ANDP	Forward edge	orward edge detection series connection				
Onerend	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The ANDP command used for a contact rising edge detection series connection.

Example

Ladder diagram:



Command code: Description:

LD X0 Load Contact a of X0

X1 Forward edge

ANDP X1 detection series

connection

OUT Y1 Drive Y1 coil


Command	Function					
ANDF	Reverse edge	Reverse edge detection series connection				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation

The ANDF command is used for a contact falling edge detection series connection.

Example

Ladder diagram:



Command code:

Description:

LD X0 Load Contact a of X0

X1 Reverse edge


ANDF X1 detection series

connection

OUT Y1 Drive Y1 coil

Command	Function					
ORP	Forward edge	orward edge detection parallel connection				
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation The ORP command is used for a contact rising edge detection parallel connection.



Command code:

Description:

LD X0 Load Contact a of X0

X1 Forward edge


ORP X1 detection parallel

connection

OUT Y1 Drive Y1 coil

Command	Function					
ORF	Reverse edge detection parallel connection					
0	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	-

Explanation The ORF command is used for contact falling edge detection parallel connection.




Command code:		Description:	
LD	X0	Load Contact a of X0	
		X1 Reverse edge	
ORF	<b>X</b> 1	detection parallel	
		connection	
OUT	Y1	Drive Y1 coil	

Command	Function					
PLS	Upper differential output					
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
	-	✓	✓	-	-	-


Upper differential output commands. When X0 = OFF→ON (positive edge-triggered), the PLS command will be executed, and M0 will send one pulse, with a pulse length consisting of one scanning period.

Example

Ladder diagram:



Time sequence diagram:



Command code:		Description:		
LD	X0	Load Contact a of X0		
PLS	MO	M0 Upper differential		
PLO	IVIU	output		
LD	MO	Load Contact a of M0		
SET	Y0	Y0 Action continues (ON)		


Command	Function					
PLF	Lower differential output					
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
	-	✓	✓	-	-	-

Lower differential output command. When X0 = ON→OFF (negative edge-triggered), the PLF command will be executed, and M0 will send one pulse, with pulse length consisting of one scanning period.

\_\_\_ Ladder diagram:

X0
PLF M0
M0
SET Y0

Time sequence diagram:



X0	One scan cycle One scan o	cycle
M0		
Y0		

Command	Function
END	Program conclusion
Operand	N/A

Explanation

An END command must be added to the end of a ladder diagram program or command program. The PLC will scan from address 0 to the END command and will return to address 0 and begins scanning again after execution.

Command	Function
NOP	No action
Operand	N/A

Explanation

The command NOP does not perform any operation in the program. Because execution of this command will retain the original logical operation results, it can be used in the following situation: the NOP command can be used to replace a command that is deleted without changing the program length.

Command anda:

Example

Ladder diagram:

NOP command will be simplified and not displayed when the ladder diagram is displayed.

X0

Command code.		Description.
LD	X0	Load Contact b of X0
NOP		No action
OUT	Y1	Drive Y1 coil

Description:


Command	Function					
INV	Inverse of operation results					
Operand	N/A					
Explanation	Saves the result of the logic inversion ope cumulative register.					
Example	Ladder diagram:	Command code:		Description:		
	X0 Y1	LD	X0	Load Contact a of X0		
		INV		Inverse of operation results		
		OUT	Y1	Drive Y1 coil		

Command	Function
P	Index
Operand	P0-P255

Explanation

Pointer P is used to subprogram call command API 01 CALL. Use does not require starting from zero, but the number cannot be used repeatedly, otherwise an unpredictable error will occur.





Commar	nd code:	Description:
LD	X0	Load Contact a of X0
CALL	P10	Call command CALL to
		P10

P10 Pointer P10

LD X1 Load Contact a of X1

OUT Y1 Drive Y1 coil

16-6-3 Overview of Application Commands

Classification	ΛDI	Comma	nd code	D commond	Eunotion	STE	PS
Classification	API	16 bit	32 bit	P command	Function	16 bit	32 bit
	01	CALL	=	✓	Call subprogram	3	-
Circuit control	02	SRET	_	_	Conclusion of subprogram	1	-
	06	FEND	_	_	Conclusion of main program	1	_
	10	CMP	DCMP	✓	Compares set output	7	13
Send	11	ZCP	DZCP	✓	Range comparison	9	17
comparison	12	MOV	DMOV	✓	Data movement	5	9
companson	13	SMOV	DSMOV	✓	Nibble movement	11	21
	15	BMOV	_	✓	Send all	7	_
	18	BCD	DBCD	✓	BIN to BCD transformation	5	9
	19	BIN	DBIN	✓	BCD to BIN transformation	5	9
	20	ADD	DADD	✓	BIN addition	7	13
Four logical	21	SUB	DSUB	✓	BIN subtraction	7	13
operations	22	MUL	DMUL	✓	BIN multiplication	7	13
	23	DIV	DDIV	✓	BIN division	7	13
	24	INC	DINC	✓	BIN add one	3	5
	25	DEC	DDEC	✓	BIN subtract one	3	5
Rotational	30	ROR	DROR	✓	Right rotation	5	-
displacement	31	ROL	DROL	✓	Left rotation	5	_
	40	ZRST	_	✓	Clear range	5	-
	41	DECO	DDECO	✓	Decoder	7	13
	42	ENCO	DENCO	✓	Encoder	7	13
Data Process	43	SUM	DSUM	✓	ON bit number	5	9
	44	BON	DBON	✓	ON bit judgement	7	13
					BIN whole number → binary		
	49	_	DFLT	✓	floating point number	_	9
					transformation		
	110	1	DECMP	<b>✓</b>	Comparison of binary floating		13
	110		DECIVIP	•	point numbers	ı	13
	111	_	DEZCP	<b>√</b>	Comparison of binary floating		17
	111		DEZUP	<b>,</b>	point number range	_	17
	116	_	DRAD	✓	Angle → Radian	_	9
	117	_	DDEG	✓	Radian → Angle	_	9
	120	_	DEADD	✓	Binary floating point number addition	_	13
Floating point	124		DEGLIB	<b>✓</b>	Binary floating point number		10
operation	121	_	DESUB	•	subtraction		13
	122	_	DEMUL	<b>✓</b>	Binary floating point number multiplication	_	13
	123	-	DEDIV	<b>✓</b>	Binary floating point number division	-	13
	124	_	DEXP	<b>✓</b>	Binary floating point number obtain exponent	_	9
	125	_	DLN	<b>✓</b>	Binary floating point number obtain logarithm	_	9

Chapter 16 PLC Function Applications | CFP2000

		Comma	nd code	_		STE	EPS
Classification	API	16 bit	32 bit	P command	Function	16 bit	32 bit
	127	_	DESQR	✓	Binary floating point number find square root	-	9
	129	INT	DINT	<b>√</b>	Binary floating point number  → BIN whole number transformation	_	9
	130	_	DSIN	✓	Binary floating point number SIN operation	_	9
	131	-	DCOS	✓	Binary floating point number COS operation	_	9
	132	-	DTAN	✓	Binary floating point number TAN operation	_	9
	133	-	DASIN	✓	Binary floating point number ASIN operation	_	9
	134	-	DACOS	✓	Binary floating point number ACOS operation	_	9
	135	-	DATAN	<b>✓</b>	Binary floating point number ATAN operation	_	9
	136	-	DSINH	✓	Binary floating point number SINH operation	_	9
Floating point operation	137	-	DCOSH	✓	Binary floating point number COSH operation	_	9
	138	_	DTANH	✓	Binary floating point number TANH operation	_	9
Other	147	SWAP	DSWAP	✓	Exchange the up / down 8 bits	3	5
Communication	150	MODRW	=	✓	Modbus read/write	7	_
	160	TCMP	_	✓	Compare calendar data	11	_
Calandar	161	TZCP	-	✓	Compare calendar data range	9	_
Calendar	162	TADD	-	✓	Calendar data addition	7	_
	163	TSUB	-	✓	Calendar data subtraction	7	_
	166	TRD	-	✓	Calendar data read	3	_
05.07	170	GRY	DGRY	✓	BIN→GRY code transformation	5	9
GRAY code	171	GBIN	DGBIN	✓	GRY code →BIN transformation	5	9
	215	LD&	DLD&	_	Contact form logical operation LD#	5	9
	216	LD	DLD	_	Contact form logical operation LD#	5	9
Contact form logical operation	217	LD^	DLD^	_	Contact form logical operation LD#	5	9
	218	AND&	DAND&	_	Contact form logical operation AND#	5	9
	219 ANDI		DANDI	_	Contact form logical operation AND#	5	9

	ADI	Comma	nd code	D	F	STE	EPS
Classification	API	16 bit	32 bit	P command	Function	16 bit	32 bit
	220	AND^	DAND^	_	Contact form logical operation AND#	5	9
	221	OR&	DOR&	_	Contact form logical operation OR#	5	9
	222	ORI	DOR	_	Contact form logical operation OR#	5	9
	223	OR^	DOR^	_	Contact form logical operation OR#	5	9
	224	LD =	DLD =	_	Contact form compare LD ※	5	9
	225	LD>	DLD >	_	Contact form compare LD ※	5	9
	226	LD <	DLD <	_	Contact form compare LD ※	5	9
	228	LD < >	DLD < >	_	Contact form compare LD ※	5	9
	229	LD < =	DLD < =	_	Contact form compare LD ※	5	9
	230	LD > =	DLD > =	_	Contact form compare LD ※	5	9
	232	AND =	DAND =	_	Contact form compare AND※	5	9
	233	AND >	DAND >	_	Contact form compare AND※	5	9
Contact form	234	AND <	DAND <	_	Contact form compare AND※	5	9
compare command	236	AND < >	DAND < >	_	Contact form compare AND※	5	9
	237	AND < =	DAND < =	_	Contact form compare AND※	5	9
	238	AND > =	DAND > =	_	Contact form compare AND※	5	9
	240	OR =	DOR=	_	Contact form compare OR ※	5	9
	241	OR>	DOR>	_	Contact form compare OR ※	5	9
	242	OR <	DOR <	_	Contact form compare OR **	5	9
	244	OR < >	DOR < >	_	Contact form compare OR ※	5	9
	245	OR < =	DOR < =	_	Contact form compare OR ※	5	9
	246	OR > =	DOR > =	-	Contact form compare OR ※	5	9

Classification	API	Comma	nd code	P command	Function	STE	PS
Classification	API	16 bit	32 bit	P command	Function	16 bit	32 bit
	275	ı	FLD =	_	Floating point number contact form compare LD※	1	9
Floating point contact form	276	ı	FLD >	_	Floating point number contact form compare LD※	1	9
	277	Ι	FLD <	_	Floating point number contact form compare LD※	1	9
	278	ı	FLD < >	_	Floating point number contact form compare LD※	ı	9
Compare command	279	1	FLD < =	_	Floating point number contact form compare LD※	1	9
	280	-	FLD > =	_	Floating point number contact form compare LD※	_	9

Chapter 16 PLC Function Applications | CFP2000

01 15 11	4.51	Comma	nd code			STE	EPS
Classification	API	16 bit	32 bit	P command	Function	16 bit	32 bit
	281	_	FAND =	_	Floating point number contact form compare AND %	_	9
	282	_	FAND >	_	Floating point number contact form compare AND %	_	9
	283	_	FAND <	_	Floating point number contact form compare AND ※	_	9
	284	_	FAND < >	_	Floating point number contact form compare AND ※	_	9
	285	_	FAND < =	-	Floating point number contact form compare AND※	_	9
	286	_	FAND > =	_	Floating point number contact form compare AND※	_	9
	287	_	FOR =	_	Floating point number contact form compare OR※	_	9
	288	-	FOR>	_	Floating point number contact form compare OR ※	ı	9
	289	-	FOR <	_	Floating point number contact form compare OR※	Ι	9
	290	-	FOR < >	_	Floating point number contact form compare OR **	-	9
	291	-	FOR < =	_	Floating point number contact form compare OR **	ı	9
	292	-	FOR > =	_	Floating point number contact form compare OR **	1	9
	139	RPR	_	✓	Read servo parameter	5	_
	140	WPR	_	✓	Write servo parameter	5	_
	141	FPID	_	✓	Driver PID control mode	9	_
	142	FREQ	_	✓	Driver torque control mode	7	_
	261	CANRX	_	✓	Read CANopen slave station data	9	_
Driver special command	264	CANTX	_	<b>√</b>	Write CANopen slave station data	9	_
	265	CANFLS	_	<b>✓</b>	Refresh special D corresponding to CANopen	3	_
	320	ICOMR	DICOMR	✓	Internal communications read	9	17
	321	ICOMW	DICOMW	✓	Internal communications write	9	17
	323	WPRA	_	_	RAM write in drive parameters	5	_

## 16-6-4 Detailed Explanation of Applications Commands

0′			CALL	P		<u>S</u>			C	all su	ıbprogra	m		
	Bit X	t dev Y	ice M	K	Н		devic KnM	е	С	D	16-bit cor CALL	nmand (3 STE Continuous execution type	CALLP	Pulse execution type
Note	The S	oper	d usag and ca eries d	n desi	•	and c	an des	signa	te P0-	P63	32-bit cor - Flag signa	mmand _	-	-


Explanation

- S: Call subprogram pointer.
- Write the subprogram after the FEND command.
- The subprogram must end after the SRET command.
- Refer to the FEND command explanation and sample content for detailed command functions.

API O2 SRET P	Conclusion of subprogram
Bit device Word device	
X Y M K H KnX KnY KnM	T C D FEND Continuous
Notes on operand usage:	32-bit command_
No operand	
A contact-driven command is not needed	Flag signal: none


Explanation


- A contact-driven command is not needed. Automatically returns next command after CALL command
- Indicates end of subprogram. After end of subprogram, SRET returns to main program, and executes next command after the original call subprogram CALL command.
- Refer to the FEND command explanation and sample content for detailed command functions.



- This command indicates the end of the main program. It is the same as the END command when the PLC executes this command.
- The CALL command program must be written after the FEND command, and the SRET command added to the end of the subprogram.
- When using the FEND command, an END command is also needed.
   However, the END command must be placed at the end, after the main program and subprogram.

CALL command process





- S1: Compare value 1.
- S2: Compare value 2.
- D: Results of comparison.
- Compares the size of the content of operand S1 and S2; the results of comparison are expressed in D.
- Size comparison is performed algebraically. All data is compared in the form of numerical binary values. Because this is a 16-bit command, when b15 is 1, this indicates a negative number.

Example

- ▶ When the designated device is Y0, it automatically occupies Y0, Y1 and Y2.
- When X10 = ON, the CMP command executes, and Y0, Y1 or Y2 will be ON.
   When X10 = OFF, the CMP command will not execute, and the state of Y0, Y1 and Y2 will remain in the state prior to X10 = OFF.
- If ≥, ≤, or ≠ results are needed, they can be obtained via series / parallel connections of Y0-Y2.

```
X10

CMP K10 D10 Y0

Y0

If K10 > D10, Y0 = ON

Y1

If K10 = D10, Y1 = ON

Y2

If K10 < D10, Y2 = ON
```

• To clear results of comparison, use the RST or ZRST command.

AF 1'		2	ZCP	P	<u>S1</u>	) (S	2 (	S	D	R	ange	e comparison
	Bit	dev	ice			V	Vord	devic	е			16-bit command (9 STEP)
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S1				*	*	*	*	*	*	*	*	execution type execution type
S2				*	*	*	*	*	*	*	*	22 hit command (17 STED)
S				*	*	*	*	*	*	*	*	32-bit command (17 STEP)  DZCP Continuous DZCPP Pulse
D		*	*									execution type execution type
The S2	contopera	ent va nd	alue o	•	and S			an the		nt valu	ue of	f Flag signal: none

API

**S1**: Lower limit of range comparison.

- **S2**: Upper limit of range comparison.
- **S**: Comparative value.
- **D**: Results of comparison.
- When the comparative value **S** is compared with the lower limit **S1** and upper limit **S2**, the results of comparison are expressed in **D**.
- When lower limit **S1** > upper limit **S2**, the command will use the lower limit **S1** to perform comparison with the upper and lower limit.
- Size comparison is performed algebraically. All data is compared in the form of numerical binary values. Because this is a 16-bit command, when b15 is 1, this indicates a negative number.


Example

- When the designated device is M0, it automatically occupies M0, M1 and M2.
- When X0 = ON, the ZCP command executes, and M0, M1 or M2 will be ON. When X0 = OFF, the ZCP command will not execute, and the state of M0, M1 or M2 will remain in the state prior to X0 = OFF.
- If ≥, ≤, or ≠ results are needed, they can be obtained via series / parallel connections of M0-M2.

```
ZCP
        K10 K100
                    C10
                           M0
M0
        - If K10 > C10, M0 = ON
Μ1
         If K10 \le C10 \le K100, M1 = ON
М2
        - If C10 > K100, M2 = ON
```

To clear results of comparison, use the RST or ZRST command.


```
RST
      M0
                          ZRST
                                 M0
                                       M2
RST
     M1
RST
      M2
```



- S: Data source.
- D: Destination of data movement.
- When this command is executed, the content of S content will be directly moved to D. When the command is not executed, the content of D will not change.

- When X0 = OFF, the content of D10 will not change; if X0 = ON, the value K10 will be sent to data register D10.
- When X1 = OFF, the content of D10 will not change; if X1 = ON, the current value of T0 will be sent to data register D10.

```
X0 | MOV | K10 | D0 | X1 | MOV | T0 | D10
```




- S: Data source.
- m1: The data source transfers starting bit number.
- m2: The data source transfers individual bit number.
- D: Transfer destination.
- n: Transferring starting bit number of the destination.
- BCD mode (M1168 = OFF):

SMOV enables and operates BCD under this mode, the operation is similar to the way SMOV operates decimal numbers. The command copies specific bit number of arithmetic element **S** (S is a 4-figure decimal number), and sends the bit number to arithmetic element **D** (**D** is also a 4-figure decimal number). The current data on the target register will be covered.

- m1 range: 1–4
- **m2** range: 1–m1 (m2 cannot be larger than m1)
- n range: m2–4 (n cannot be smaller than m2)


Example 1

• When M1168 = OFF (BCD mode), X0 is ON, the instruction transfers two digits of the decimal number starting from the fourth digit of the decimal number (the digit in the thousands place of the decimal number) in D10 to the two digits of the decimal number starting from the third digit of the decimal number (the digit in the hundreds place of the decimal number) in D20. After the instruction is executed, the digits in the thousands place of the decimal number (10³) and the ones place of the decimal number (10¹) in D20 are unchanged.



Example 2

 When M1168 is ON (BIN mode), and the SMOV command is executed, D10 and D20 do not change in BCD mode, but send 4 digits as a unit in BIN mode.



AF		В	MΟ\	/ <u>P</u>	(	S	D		n	S	end a	ill			
	Bit	dev	ice			٧	Vord	devic	е			16-bit cor	nmand (7 STE	<u>:P)</u>	
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	BMOV	Continuous	BMOVP	
S						*	*	*	*	*	*		execution type		execution type
D							*	*	*	*	*				
n				*	*				*	*		32-bit cor	<u>nmand</u>		

Notes on operand usage:

n operand scope n =

- S: Initiate source device.
- **D**: Initiate destination device.
- n: Send block length.

1 to 512

• The content of n registers starting from the initial number of the device designated by S will be sent to the n registers starting from the initial number of the device designated by n; if the number of points referred to n exceeds the range used by that device, only points within the valid range will be sent.


Flag signal: none

Example 1

When X10 = ON, the content of registers D0–D3 will be sent to the four registers D20 to D23.

Example 2

• If the designated bit devices KnX, KnY, and KnM are sent, S and D must have the same number of nibbles, which implies that n must be identical.





Example 3

In order to prevent overlap between the transmission addresses of two operands, which would cause confusion, make sure that the addresses designated by the two operands have different sizes, as shown below:

When S > D, send in the order  $\bigcirc \rightarrow \bigcirc \rightarrow \bigcirc$ .

When S < D, send in the order  $3 \rightarrow 2 \rightarrow 1$ 





Explanation

- S: Data source.
- D: Destination of data movement.
- The content of data source S (BIN value, 0–9999) executes BCD transformation and saves in D.
- Arithmetic elements **S** and **D** use the F device, it can only use 16-bit command.

Example

 When X0 is ON, and the BIN value of D10 is transformed to BCD value, the digit is saved in 4-bit element of K1Y0 (Y0–Y3).

```
BCD D10 K1Y0
```

If D10 = 001E (Hex) = 0030 (Decimal), the executed result will be Y0–Y3=0000 (BIN).

S	AP 19		o l	BIN	P			s) (	D		В	CD to	BIN transformation
S		Bit	dev	ice			V	Vord	devic	е			16-bit command (5 STEP)
D		Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
DBIN Continuous DBINP P	S						*	*	*	*	*	*	execution type execution type
DBIN Continuous DBINP P	D							*	*	*	*	*	
Flag signal: none		es on	oper	and u	sage:	none							execution type execution type

Explanation

- S: Data source.
- D: Transformation result.
- The content of data source S (BCD: 0–9,999) executes BIN transformation and saves in D.
- Valid number range of the data source S: BCD (0–9,999), DBCD (0–99,999,999).

Example

 When X0 is ON, and the BCD value of K1X20 is transformed to BIN value, the result saves in D10.

```
BIN K1X20 D10
```

Remark

 When PLC reads a BCD type switch-off from the outside, it has to use the BIN command to transform the read data to BIN value, then saves the value into PLC.

20	) [	ו		Р												
	Bit	dev	ice			V	Vord	devic	е			16-bit cor	mmand	(7 STEI	P)	
	Х	Υ	М	K	Н	KnX		KnM	Т	С	D	ADD	Contin		ADDP	Pulse
S1				*	*	*	*	*	*	*	*	<u> </u>	executio	n type		execution type
S2				*	*	*	*	*	*	*	*	32-bit cor	mmand	(13 STE	=D\	
D							*	*	*	*	*	DADD	Contin	\ <u> </u>	DADDP	Pulse
Not	es on	oper	and u	sage:	none								executio			execution type
												Flag signa	M1021 I M1022 ( Please r	Borrow Carry fla efer to	flag	

BIN addition

Explanation

- S1: Augend.
- S2: Addend.
- **D**: Sum.
- Using two data sources: The result of adding S1 and S2 using the BIN method will be stored in D.
- The highest bit of any data is symbolized as bit 0 indicating (positive) 1 indicating (negative), enabling the use of algebraic addition operations. (e.g.: 3 + (-9) = -6)
- Flag changes connected with the addition.

(S1) (S2) (D)

- 1. When calculation results are 0, the zero flag M1020 will be ON.
- 2. When calculation results are less than –32,768, the borrow flag M1021 will be ON.
- 3. When calculation results are greater than 32,767, the carry flag M1022 will be ON.


Example

 16-bit BIN addition: When X0 = ON, the result of the content of addend D0 plus the content of augend D10 will exist in the content of D20.




Remark

Relationship between flag actions and negative/positive numbers: 16-bit:



32-bit:



2´		5	SUB	P	(	<u>S1</u> )	(S2		<u>D</u>	ВІ	N su	btraction
		dev						devic	e_			16-bit command (7 STEP) SUB Continuous SUBP Pulse
	Χ	Υ	М	K	<u>H</u>	KnX		KnM	ı	С	D	
S1				*	*	*	*	*	*	*	*	execution type execution type
S2				*	*	*	*	*	*	*	*	32-bit command (13 STEP)
D							*	*	*	*	*	Continuous Dules
Note	es on	oper	and u	sage:	none							DSUB execution type DSUBP execution type  Flag signal: M1020 Zero flag  M1021 Borrow flag  M1022 Carry flag
												Please refer to the following supplementary explanation

Explanation

API


- S1: Minuend.
- S2: Subtrahend.
- **D**: Difference.
- Using two data sources: The result of subtraction of S1 and S2 using the BIN method is stored in **D**.
- The highest bit of any data is symbolized as bit 0 indicating (positive) 1 indicating (negative), enabling the use of algebraic subtraction operations.
- Flag changes connected with subtraction.

- 1. When calculation results are 0, the zero flag M1020 will be ON.
- 2. When calculation results are less than -32,768, the borrow flag M1021 will be ON.
- 3. When calculation results are greater than 32,767, the carry flag M1022 will be ON.

Example


16-bit BIN subtraction: When X0 = ON, the content of D10 is subtracted from the content of D0, and the difference is stored in D20.

```
SUB
      D0
           D10
                 D20
```



- \$1: Multiplicand.
- S2: Multiplier.
- D: Product.
- Using two data sources: When S1 and S2 are multiplied using the BIN method, the product is stored in D.

16-bit BIN multiplication operation:




b15 is a symbol bit b15 is a symbol bit b31 is a symbol bit (b15 of D+1)


Symbol bit = 0 refers to a positive value Symbol bit = 1 refers to a negative value

 When D is a bit device, K1–K4 can be designated as a hexadecimal number, which will occupy 2 consecutive units.


Example

 When 16-bit DO is multiplied by 16-bit D10, the result will be a 32-bit product; the upper 16 bits will be stored in D21, and the lower 16 bits will be stored in D20.
 Whether the bit at the farthest left is OFF or ON will indicate the sign of the result.





- S1: Dividend.
- S2: Divisor.
- D: Quotient and remainder.
- Using two data sources: The quotient and remainder will be stored in **D** when **S1** and **S2** are subjected to division using the BIN method. The sign bit for **S1**, **S2** and **D** must be kept in mind when performing a 16-bit operation.
   16-bit BIN division:




 If D is a bit device, K1–K4 can be designated 16 bits, which will occupy 2 consecutive units and yield the quotient and remainder.

Example

When X0 = ON, the quotient resulting from division of dividend D0 by divisor D10 will be placed in D20, and the remainder will be placed in D21. Whether the highest bit is OFF or ON will indicate the sign of the result.

```
DIV D0 D10 D20
```



- D: Destination device.
- If a command is not the pulse execution type, when the command is executed, the program will add 1 to the content of device **D** for each scanning cycle.
- This command is ordinarily used as a pulse execution type command (INCP).
- During 16-bit operation, 32,767 +1 will change the value to -32,768. During 32 bit operation, 2,147,483,647 +1 will change the value to -2,147,483,648.

Example

When  $X0 = OFF \rightarrow ON$ , 1 is automatically added to the content of D0.

```
X0 INCP D0
```

AF		) [	DEC	P			D			N su	ubtract one						
	Bit	devi	ice			٧	Vord	16-bit cor	nmand (3 STE	P)							
	X Y M K H KnX KnY KnM T C D												Continuous	DECP	Pulse		
D													execution type execution type				
Not	es on	oper	and u	sage:	none							32-bit command (5 STEP)					
												DDEC	Continuous	DDECP	Pulse		
													execution type		execution type		
	Flag signal: none																


Explanation

- D: Destination device.
- If a command is not the pulse execution type, when the command is executed, the program will add 1 to the content of device **D** for each scanning cycle.
- This command is ordinarily used as a pulse execution type command (DECP).
- During 16-bit operation, -32,768 -1 will change the value to 32,767. During 32 bit operation, -2,147,483,648 -1 will change the value to 2,147,483,647.

Example

• When X0 = OFF→ON, 1 is automatically subtracted from the content of D0.


```
X0 DECP D0
```



- D: Device to be rotated.
- n: Number of bits for one rotation.
- Rotate the device designated by D to the right n bits.
- This command is ordinarily used as a pulse execution type command (RORP).

Example

When X0 = OFF→ON, 4 of the 16 bits in D10 specify a right rotation; the content of the bit indicated with \* (see figure below) will be sent to the carry flag signal M1022.




Notes on operand usage: Only K4 (16-bit) will be valid if the operand D is designated as KnY or KnM.  n operand n=1 to 16 (16 bit)	3 <sup>2</sup>		F	ROL	P			) (	n		Le	eft rot	tation					
D		Bit	dev	ice														
Notes on operand usage: Only K4 (16-bit) will be valid if the operand D is designated as KnY or KnM.  n operand n=1 to 16 (16 bit)		Χ	Υ	М	K	Н	KnX	KnY	KnM	D								
Notes on operand usage:  Only K4 (16-bit) will be valid if the operand D is designated as KnY or KnM.  Property of the continuous of the c	D							*	*	*	*	*	execution type execution type					
Only K4 (16-bit) will be valid if the operand D is designated as KnY execution type or KnM.		n * * * 32-bit command (9 STEP)																
Flag signal: M1022 Carry flag	Only or K																	

- D: Device to be rotated.
- **n**: Number of bits for one rotation.
- Rotates the device designated by **D** to the left n bits.
- This command is ordinarily used as a pulse execution type command (ROLP).

Example

• When X0 = OFF→ON, 4 of the 16 bits in D10 specify a left rotation; the content of the bit indicated with \* (see figure below) will be sent to the carry flag signal M1022.



40	)			Р								
	Bit	dev	ice			V	Vord	devic	16-bit command (5 STEP)			
	Χ	Υ	М	K	Н	KnX	KnY	KnM	D	ZRST Continuous ZRSTP Pulse		
D1		*	*						execution type execution type			
D2		*	*									
Not	es on	oper	and u	sage:								32-bit command
				_	erand	d ≤ nur	mber d					
						ite the		<u> </u>				
Plea	ase re	efer to	the	function	on sp	ecifica	in Flag signal: none					

Clear range

Explanation

ZRST

series for the scope of device usage

D1: Clear range's initial device.

(D1) (D2)

- **D2**: Clear range's final device.
- When the number of operand D1 > number of operand D2, only the operand designated by D2 will be cleared.

Example

- When X0 is ON, auxiliary relays M300–M399 will be cleared and changed to OFF.
- When X1 is ON, 16-bit counters C0–C127 will all be cleared. (Writes 0, and clears and changes contact and coil to OFF).
- When X10 is ON, timer T0–T127 will all be cleared. (Writes 0, and clears and changes contact and coil to OFF).
- When X3 is ON, the data in data registers D0–D100 will be cleared and set as 0.

```
X0
┨┠
                ZRST
                         M300
                                  M399
X1
┨┠
                ZRST
                          C0
                                  C127
X10
                ZRST
                          T0
                                  T127
┨┠
X3
┨┞
                ZRST
                          D0
                                  D100
```

Remark

Devices can independently use the clear command (RST), such as bit device Y,
 M and word device T, C, D.

```
RST M0

RST T0

RST Y0
```


API

4		D	ECC	P	(	<u>s</u> )	D	) (	ecod	er	
	Bit	devi	ice			V	Vord	16-bit command (7 STEP)			
	Χ	Υ	М	K	Н	KnX	KnY	KnM	D	DECO Continuous DECOP Pulse	
S	*	*	*	*	*			execution type execution type			
D		*	*				*	*	*	32-bit command (13 STEP)	
n				*	*					DDECO Continuous DDECOP Pulse execution type	
Note	es on	opera	and u	sage:	none			Flag signal: none			


Explanation

- S: Decoding source device.
- D: Device that saves the decoding result.
- n: Length of decoding bit.
- Decodes with the lower "n" bit, and saves the length of "2" bit in D.
- This command usually uses pulse execution type command (DECOP).
- When **D** is the bit device,  $\mathbf{n} = 1-8$ , when **D** is the word device,  $\mathbf{n} = 1-4$ .

- When Dis the bit device, the valid range of n is 0< n ≤ 8. If n = 0 or n > 8, a fault will occur.
- When  $\mathbf{n} = 8$ , the maximum decoding will be  $2^8 = 256$  points.
- When M200 switches from Off to On, the content of X0–X2 is decoded to M100– M107.
- If S = 3, M103 (the third digit starting from M100) = ON.
- When the command is executed, M200 turns to OFF. The ones that are decoded and outputted act as usual.




- When **D** is word device, the valid range of **n** is  $0 < n \le 4$ . If **n** = 0 or **n** > 4, the fault occurs.
- When  $\mathbf{n} = 4$ , the maximum decoding will be  $2^4 = 16$  points.
- When M200 switches from OFF to ON, the content of D10 (b2-b0) is decoded to D20 (b7-b0). The unused digits (b15-b8) of D20 become 0.
- The lower 3 digits of D10 are decoded and saved in the lower 8 digits of D20, the upper 8 digits are 0.
- When the command is executed, M200 turns to OFF. The ones that are decoded and outputted act as usual.




42		E	NC	P	(	S	D		n	Er	ncod	er		
	16-bit command (7 STEP)													
	Χ	Υ	М	K	Н	KnX	KnY	KnM	D	ENCO Continuous ENCOP Pulse				
S	*	*	*						*	*	*	execution type execution type		
D							*	*	*	*	*	32-bit command (13 STEP)  DENCO Continuous DENCOP Pulse		
n				*	*							execution type execution type		
Note	Notes on operand usage: none Flag signal: none													

- S: Encoding source device.
- D: Device that saves the encoding result.
- n: Length of encoding bit.
- Encodes the data of lower "2" bit length from encoding source device S, and saves the encoding result in D.
- If multiple digits of encoding source device are 1, the command will process the first digit starting from high digit.
- This command usually uses pulse execution type command (ENCOP).
- When **S** is the bit device,  $\mathbf{n} = 1-8$ , when **S** is the word device,  $\mathbf{n} = 1-4$ .

- When S is the bit device, the valid range of n is 0 < n ≤ 8. If n = 0 or n > 8, a fault will occur.
- When  $\mathbf{n} = 8$ , the maximum decoding will be  $2^8 = 256$  points.
- When X0 switches from OFF to ON, the content of 2<sup>3</sup> digit (M0–M7) is encoded and saved in the lower 3 digits (b2–b0). The unused digits (b15–b3) in D0 become 0.
- When the command is executed, X0 turns to OFF. The data in D is unchanged.



- When **S** is word device, the valid range of **n** is  $0 < n \le 4$ . If **n** = 0 or **n** > 4, the fault occurs.
- When  $\mathbf{n} = 4$ , the maximum decoding will be  $2^4 = 16$  points.
- When X0 switches from OFF to ON, 2<sup>3</sup> digit data of D10 (b0-b7) is encoded and saved in the lower 3 digits (b2-b0) of D20. The unused digits (b15-b3) of D20 become 0. (b8-b15 in D10 are invalid data)
- When the command is executed, X0 turns to OFF. The data in **D** is unchanged.



All values become 0


4:		5	SUM	P			3)(	D		O	N bit	it number		
	Bit	dev	ice			V	Vord	devic	16-bit command (5 STEP)					
	Χ	Υ	М	K	Н	KnX	KnY	KnM	D	SUM Continuous SUMP Pulse				
s				*	*	*	*	*	*	*	*	execution type execution type		
D									*	*	*	32-bit command (9 STEP)		
	es on	oper	and u	sage:	none					DSUM Continuous DSUMP Pulse execution type execution type				
								Flag signal: M1020						

Explanation

- S: Source device.
- D: Destination of saving counter values.
- The total amount of all digits that is "1" in S will be saved in D.
- **D** will use 2 registers when use the 32-bit command.
- Arithmetic elements S and D use F device, and can only use 16-bit command.
- If there is no bit is ON, the flag signal M1020 will be ON.

Example

When M200 = ON, the total amount of content "1" digit in D0's 16-bit command will be saved in D2.




_	API D BON P S D n ON bit judgement														
	Bit device Word device 16-bit command (7 STEP)  X Y M K H KnX KnY KnM T C D BON Continuous BONP Pulse														
	Χ	Υ	М	K	Н	KnX	KnY	KnM	D	BON Continuous BONP Pulse					
S				*	*	* * * * * *					execution type execution				
D		*	*						*	*	*	32-bit command (9 STEP)			
Ľ												DBON Continuous DBONP Pulse			
n	n * * * execution type execution type														
Not	Notes on operand usage: none Flag signal: none														

Explanation

- **S**: Source device.
- D: Destination of saving judging result.
- **n**: assign judged digit (numbering from 0)
- The status of specific digit from source device is shown on target position.
- Arithmetic element S uses F device, and can only use the 16-bit command.
- The valid range of arithmetic element  $\mathbf{n}$ :  $\mathbf{n} = 0-15$  (16-bit),  $\mathbf{n} = 0-31$  (32-bit).

- When X0 = ON, if the 15<sup>th</sup> digit of D0 is "1", M0 is ON. If it is "0", M0 is OFF.
- When X0 turns to OFF, M0 remains previous status.



AF		)	FLT	P		C.	3)(	D				ole num	ber → binary	decimal	
	Bit device Word device 16-bit command														
	X Y M K H KnX KnY KnM T C D FLT Continuous FLTP Pulse														
S	X I W K II KIK KIII KIW I O D														
D		*	*						*	*	*	32-bit con	nmand (9stens)		
spe dev	Notes on operand usage: Please refer to the function specifications table for each device in series for the scope of device usage  The operand D will occupy 2 consecutive points    32-bit command (9steps)   DFLT   Continuous execution type   DFLTP   Pulse execution type   Execu														

Explanation

- S: Transformation source device.
- **D**: Device storing transformation results.
- Transforms BIN whole number into a binary decimal value.

Example

When X11 is ON, converts the whole number of values corresponding to D0 and D1 into floating point numbers, which are placed in D20 and D21.

```
M200
           DFLT
                     D0
                             D20
```

11	110 D ECIVIP P 31 32 D Comparison of binary floating point numbers														
	Bit	dev	ice			V	Vord	16-bit command							
	X Y M K H KnX KnY KnM T C														
S1				*	*				*						
S2				*	*				*	32-bit command (13 STEP)					
D											*				
Note	Notes on operand usage:											execution type P execution type			
	The operand D occupies three consecutive points														
Plea	Please refer to the function specifications table for each device in Flag signal: none														
seri	eries for the scope of device usage														

API

S1: Comparison of binary floating point numbers value 1.

(S1) (S2) (D)

- S2: Comparison of binary floating point numbers value 2.
- D: Results of comparison, occupies 3 consecutive points.
- When binary floating point number 1 is compared with comparative binary floating point number 2, the result of comparison (>, =, <) will be expressed in D.</li>
- If the source operand S1 or S2 designates a constant K or H, the command will transform the constant to a binary floating-point number for the purpose of comparison.

- ▶ When the designated device is M10, it will automatically occupy M10–M12.
- When X0 = ON, the DECMP command executes, and one of M10–M12 will be
   ON. When X0 = OFF, the DECMP command will not execute, and M10–M12 will remain in the X0 = OFF state.
- If results in the form of ≥, ≤, or ≠ are needed, they can be obtained by series and parallel connection of M10-M12.
- Please use the RST or ZRST command to clear the result.

```
M10

M10

M11

ON when (D1, D0) > (D101, D100)

M11

ON when (D1, D0) = (D101, D100)

M12

ON when (D1, D0) < (D101, D100)
```

 $\left( \begin{array}{c} 92 \\ \end{array} \right) \left( \begin{array}{c} 9 \\ \end{array} \right)$ 

111 D EZCP P 31 32 3 D Companson of binary loating point number														umber range	
	Bit	dev	ice			V	Vord	[40]							
	X Y M K H KnX KnY KnM T C D												mand_		
S1				*	*				-	-	-	-			
S2				*	*										
S				*	*						*	-	mand (17 STEF	/	
D		*	*									DEZCP	Continuous	DEZCP	Pulse
Not	00.00	<u> </u>		0000:								<u> </u>	execution type	Р	execution type
	Notes on operand usage:														
	he operand D occupies three consecutive points											Flag signal	: none		
	Please refer to the function specifications table for each device in										0 0				
lseri	eries for the scope of device usage														


Explanation

API

- **S1**: Lower limit of binary floating point number in range comparison.
- **S2**: Upper limit of binary floating point number in range comparison.
- **S**: Comparison of binary floating point numerical values.
- D: Results of comparison, occupies 3 consecutive points.
- Comparison of binary floating point numerical value S with binary floating point number lower limit value S1 and binary floating point number upper limit value S2; the results of comparison are expressed in D.
- If the source operand S1 or S2 designates a constant K or H, the command will transform the constant to a binary floating-point number for the purpose of comparison.
- When the lower limit binary floating point number S1 is greater than the upper limit binary floating point number S2, a command will be issued to perform comparison with the upper and lower limits using the binary floating point number lower limit value S1.

- When the designated device is M0, it will automatically occupy M0–M2.
- When X0 = ON, the DEZCP command will be executed, and one of M0–M2 will be ON. When X0 = OFF, the EZCP command will not execute, and M0–M2 will continue in the X0 = OFF state.
- Please use the RST or ZRST command to clear the result.


```
M0
M1
ON \text{ when } (D1, D0) > (D21, D20)
M1
M2
ON \text{ when } (D21, D20) > (D11, D10)
```



- S: data source (angle).
- D: result of transformation (radian).
- Uses the following formula to convert angles to radians.
- Radian = Angle × (π/180)

Example

When X0 = ON, the angle of the designated binary floating point number (D1, D0) will be converted to radians and stored in (D11, D10), with the content consisting of a binary floating point number.




11		ם כ	DEG	P			<u>S</u> ) (	<u>D</u> )		Ra	adian	→ Angle	)		
	Bit	dev	ice			V	Vord	devic	е			16-bit com	nmand_		
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	-	-	_	-
S				*	*						*	L		<u>i</u>	<u> </u>
D											*	32-bit con	nmand (9 STE	P)	
				sage:								DDEG	Continuous	DDEGP	Pulse
							tions t	able f	or eac	ch dev	ice in		execution type		execution type
seri	es foi	the s	scope	of dev	vice u	sage						Flag signa	l: none		

Explanation

- S: data source (radian).
- D: results of transformation (angle).
- Uses the following formula to convert radians to an angle.
- Angle = Radian × (180/π)

Example

 When X0 = ON, angle of the designated binary floating point number (D1, D0) in radians will be converted to an angle and stored in (D11, D10), with the content consisting of a binary floating point number.



12		E	ADE	P	(	<u>S1</u>	S2		)	A	dding	g binary floating point numbers
	Bit	dev	ice			٧	Vord	devic	е			16-bit command
	Χ	Υ	М	K	Н	KnX	KnY	KnM	T	С	D	] -   -   -   -
S1				*	*						*	<u> </u>
S2				*	*						*	32-bit command (9 STEP)
D											*	DEADD Continuous DEADDP Pulse
Note	es on	oper	and u	sage:								execution type execution type
				function of dev			tions t	able f	or ead	ch dev	ice in	n Flag signal: none

(S1) (S2) (D)

Explanation

- **S1**: augend.
- S2: addend.
- **D**: sum.
- When the content of the register designated by S2 is added to the content of the register designated by **S1**, and the result is stored in the register designated by **D**. Addition is performed entirely using binary floating-point numbers.
- If the source operand S<sub>1</sub> or S<sub>2</sub> designates a constant K or H, the command will transform that constant into a binary floating point number for use in addition.
- In the situation when S1 and S2 designate identical register numbers, if a "continuous execution" command is employed, when conditional contact is ON, the register will perform addition once during each scan. Pulse execution type commands (DEADDP) are generally used under ordinary circumstances.

Example

When X0 = ON, a binary floating point number (D1, D0) will be added to a binary floating point number (D3, D2), and the results stored in (D11, D10).

```
X0
       DEADD
                 D0
                         D2
                                 D10
```

When X2 = ON, a binary floating point number (D11, D10) will be added to K1234 (which has been automatically converted to a binary floating-point number), and the results stored in (D21, D20).

```
X2
       DEADD
                 D10
                        K1234
                                  D20
```

12		) E	SUE	P	(	<u>S1</u> )	(S2	(1	<u>D</u> )	Sı	ıbtra	ction of b	inary floating	point nu	mbers
	Bit	dev	ice			٧	Vord	devic	е			16-bit cor	nmand_		
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	-	-	-	-
S1				*	*						*	i	<u>i</u>	<u> </u>	i
S2				*	*						*	32-bit cor	nmand (13 ST	EP)	
D											*	DESUB	Continuous	DESUBP	Pulse
Not	es on	oper	and u	sage:									execution type		execution type
				function of dev			tions t	table f	or ead	ch dev		Flag signa	al: none		

Explanation

API

- S1: minuend.
- **S2**: subtrahend.
- **D**: difference.
- When the content of the register designated by S2 is subtracted from the content
  of the register designated by S1, the difference will be stored in the register
  designated by D; subtraction is performed entirely using binary floating-point
  numbers.
- If the source operand **S1** or **S2** designates a constant K or H, the command will transform that constant into a binary floating point number for use in subtraction.
- In the situation when S1 and S2 designate identical register numbers, if a
  "continuous execution" command is employed, when conditional contact is ON,
  the register will perform addition once during each scan. Pulse execution type
  commands (DESUBP) are generally used under ordinary circumstances.

Example

• When X0 = ON, a binary floating point number (D1, D0) will be subtracted to a binary floating point number (D3, D2), and the results stored in (D11, D10).

```
DESUB D0 D2 D10
```

 When X2 = ON, the binary floating point number (D1, D0) will be subtracted from K1234 (which has been automatically converted to a binary floating-point number), and the results stored in (D11, D10).

```
X2
DESUB K1234 D0 D10
```

12		E	MUI	P	(	<u>S1</u>	S2		)	М	ultipli	lication of binary floating point numbers
	Bit	dev	ice			٧	Vord	devic	е			16-bit command
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	] -   -   -   -
S1				*	*						*	7
S2				*	*						*	32-bit command (13 STEP)
D											*	DEMUL Continuous DEMULP Pulse
Note	es on	oper	and u	sage:								execution type execution type
				function of dev		ecifica sage	tions t	able fo	or ead	ch dev	ice in	Flag signal: none

API

\$1: multiplicand.

- S2: multiplier.
- **D**: product.
- When the content of the register designated by **S1** is multiplied by the content of the register designated by **S2**, the product will be stored in the register designated by **D**; multiplication is performed entirely using binary floating-point numbers.
- If the source operand **S1** or **S2** designates a constant K or H, the command will transform that constant into a binary floating point number for use in multiplication.
- In the situation when **S1** and **S2** designate identical register numbers, if a "continuous execution" command is employed, when conditional contact is ON, the register will perform multiplication once during each scan. Pulse execution type commands (DEMULP) are generally used under ordinary circumstances.

Example

When X1 = ON, the binary floating point number (D1, D0) will be multiplied by the binary floating point number (D11, D10), and the product will be stored in the register designated by (D21, D20).

```
DEMUL
          D0
                 D10
                          D20
```

When X2 = ON, the binary floating point number (D1, D0) will be multiplied from K1234 (which has been automatically converted to a binary floating-point number), and the results stored in (D11, D10).

```
X2
                          D0
       DEMUL
                K1234
                                  D10
```

12		<b>E</b>	DIV	P	(	<u>S1</u>	(S2		)	D	ivisio	n of binar	y floating poi	nt numb	ers
	Bit	dev	ice			V	Vord	devic	е			16-bit com	nmand_		
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	_	-	-	-
S1				*	*						*	LL			Li
S2				*	*						*	32-bit com	nmand (13 STE	P)	
D											*	DEDIV	Continuous	DEDIVP	Pulse
Not	es on	oper	and u	sage:									execution type		execution type
				function of dev			tions t	able fo	or ead	ch de	vice in	Flag signa	l: none		

Explanation

API

- **S1**: dividend.
- S2: divisor.
- **D**: quotient and remainder.
- When the content of the register designated by **S1** is divided by the content of the register designated by **S2**, the quotient will be stored in the register designated by **D**; division is performed entirely using binary floating-point numbers.
- If the source operand **S1** or **S2** designates a constant K or H, the command will transform that constant into a binary floating point number for use in division.

Example

When X1 = ON, the binary floating point number (D1, D0) will be divided by the binary floating point number (D11, D10), and the quotient stored in the register designated by (D21, D20).

```
X1
                  D0
        DEDIV
                          D10
                                  D20
```

• When X2 = ON, the binary floating point number (D1, D0) will be divided by K1,234 (which has been automatically converted to a binary floating-point number), and the results stored in (D11, D10).

```
X2
        DEDIV
                  D0
                        K1234
                                  D10
```

12			EXP	P			S) (	D		В	inary	floating p	point number	obtain e	xponent
	Bit	dev	ice			V	Vord (	devic	е			16-bit cor	nmand_		
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	-	_	-	_
S				*	*						*	L	<u>i</u>	i	<u></u>
D											*	32-bit cor	nmand (9 STEP)	)	
				sage:								DEXP	Continuous	DEXPP	Pulse
							tions t	able f	or ea	ch de	vice in		execution type		execution type
seri	es for	the s	scope	of de	vice u	sage						Flag signa	al: none		

API

**S**: operation source device.

- **D**: operation results device.
- Taking e =2.71828 as a base, S is the exponent in the EXP operation.
- $[D + 1, D] = EXP^{[S+1,S]}$
- Valid regardless of whether the content of **S** has a positive or negative value. The designated register **D** must have a 32-bit data format. This operation is performed using floating-point numbers, and S must therefore be converted to a floating point number.
- Content of operand  $\mathbf{D} = e^{S}$ ; e = 2.71828, **S** is the designated source data

- When M0 is ON, the value of (D1, D0) will be converted to a binary floating point number, which will be stored in register (D11, D10).
- When M1 is ON, the EXP operation is performed on the exponent of (D11, D10); its value is a binary floating point number stored in register (D21, D20).

```
M0
∃⊦
                        DFLT
                                D0
                                     D10
M1
                        DEXP
                                D10
                                      D20
┨┠
                                     END
```

AF 12		)	LN	P			s) (	D		Bi	nary	floating <sub>l</sub>	point number	obtain l	ogarithm
	Bit	dev	ice			٧	Vord	devic	е			16-bit cor	nmand_		
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	-	-	-	-
S				*	*						*	i	<u>i</u>		<u>.li</u>
D											*	32-bit cor	nmand (9 STEP)	)	
			and u									DLN	Continuous	DLNP	Pulse
							tions t	able fo	or eac	ch dev	rice in		execution type		execution type
seri	es for	the s	scope	of dev	vice u	sage						Flag signa	al: none		

Explanation

- **S**: operation source device.
- **D**: operation results device.
- Taking e =2.71828 as a base, S is the exponent in the EXP operation.
- [D+1, D] = EXP[S+1,S]
- Valid regardless of whether the content of **S** has a positive or negative value. The
- designated register D must have a 32-bit data format. This operation is performed using floating-point numbers, and S must therefore be converted to a floating point number.
- Content of operand **D** =e <sup>S</sup>; e=2.71828, **S** is the designated source data

- When M0 is ON, the value of (D1, D0) will be converted to a binary floating point
- number, which will be stored in register (D11, D10).
- When M1 is ON, the EXP operation is performed on the exponent of (D11, D10);its value is a binary floating point number stored in register (D21, D20).

AF 12		ES	QR	P			3)(	D		Bi	nary	floating point number find square root
	Bit	devi	се			٧	/ord	devic	е			16-bit command
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S				*	*						*	<u>L</u>
D											*	32-bit command (9 STEP)
		opera										DESQR Continuous DESQR Pulse
							ions t	able fo	r eac	h dev	ice in	execution type P execution type
serie	es for	the so	cope (	of dev	ice us	age						Flag signal: none

- S: source device for which square root is desired
- D: result of finding square root.
- When the square root is taken of the content of the register designated by S, the result is temporarily stored in the register designated by D. Taking square roots is performed entirely using binary floating-point numbers.
- If the source operand **S** refers to a constant K or H, the command will transform that constant into a binary floating point number for use in the operation.

Example

When X0 = ON, the square root is taken of the binary floating point number (D1, D0), and the result is stored in the register designated by (D11, D10).

```
DESQR D0 D10
\sqrt{(D1 \cdot D0)} \longrightarrow (D11 \cdot D10)
Binary floating point Binary floating point
```

 When X2 = ON, the square root is taken of K1,234 (which has been automatically converted to a binary floating-point number), and the results stored in (D11, D10).

AF 12		)	INT	P			3) (	D				/ floating point number → BIN whole er transformation
	Bit	dev	ice			V	/ord	devic	е			16-bit command_
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	INT Continuous INTP Pulse
S											*	execution type execution type
D											*	32-bit command (9 STEP)
Plea	se ref	er to	nd usag the fu ope of	nction			ons ta	ible fo	r eac	h dev	ice in	DINT Continuous DINTP Pulse execution type execution type
												Flag signal: none

Explanation

- **S**: the source device to be transformed.
- **D**: results of transformation.
- The content of the register designated by S is transformed from a binary floating point number format into a BIN whole number, and is temporarily stored in D.
   The BIN whole number floating point number will be discarded.
- The action of this command is the opposite of that of command API 49 (FLT).


Example

 When X0 = ON, the binary floating point number (D1, D0) is transformed into a BIN whole number, and the result is stored in (D10); the BIN whole number floating point number will be discarded.

```
X0
DINT D0 D10
END
```


API 130	D	SI	N	P		(5	3) (	D		Bi	nary	y floating point number SIN operation
	Bit	devic	е			W	ord o	devic	е			16-bit command
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	] -   -   -   -
S				*	*						*	<u> </u>
D											*	32-bit command (9 STEP)
Please	on oper e refer to e scope	the fu	nctior		ificati	ions ta	ble fo	r each	devid	ce in s		S DSIN Continuous DSINP Pulse execution type  Flag signal: none

- **S**: the designated source value.
- **D**: the SIN value result.
- **S** is the designated source in radians.
- The value in radians (RAD) is equal to (angle  $\times \pi/180$ ).
- The SIN obtained from the source value designated by **S** is stored in **D**.
- The following figure displays the relationship between the arc and SIN results:




Example

When X0 = ON, the SIN value of the designated binary floating point number (D1, D0) in radians (RAD) will be stored in (D11, D10), with the content consisting of a binary floating point number.




AF 13		0	cos	P		(	3)(	D		Bi	nary	y floating point number COS operation	
	Bit	devi	се			V	/ord	devic	е			16-bit command	
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Τ	С	D	] -   -   -   -	
S				*	*						*	<u> </u>	i
D											*	32-bit command (9 STEP)	
Plea		er to	the f				ions to	able fo	eac	h dev	ice in	DCOS Continuous DCOSP Pulse execution type  Flag signal: none	9

- **S**: the designated source value.
- D: the COS value result.
- The source designated by S can be given as radians or an angle; this is decided by flag M1018.
- When M1018 = OFF, the operation is in radians mode, where the radians (RAD) value is equal to (angle  $\times \pi/180$ ).
- When M1018 = ON, the operation is in the angle mode, where the angular range is 0° ≤ angle < 360°.</li>
- When calculation results yield 0, M1020 = ON.
- The COS obtained from the source value designated by **S** is stored in **D**.
- The following figure displays the relationship between the arc and SIN results:




Example

 When X0 = ON, the COS value of the designated binary floating point number (D1, D0) in radians will be stored in (D11, D10), with the content consisting of a binary floating point number.




AF 13		<sup>1</sup>	ΓΑΝ	P			3)(	D		Bi	nary	floating point number TAN operation
	Bit	dev	ice			٧	Vord	devic	е			16-bit command_
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	] -   -   -
S				*	*						*	<u> </u>
D											*	32-bit command (9 STEP)
Plea	ase re	efer to	the	sage: function of dev			tions t	able f	or eac	h dev	ice in	DTAN Continuous DTANP Pulse execution type  Flag signal: none


- **S**: the designated source value.
- **D**: the TAN value result.
- The source designated by S can be given as radians or an angle; this is decided by flag M1018.
- When M1018 = OFF, the operation is in radians mode, where the radians (RAD) value is equal to (angle  $\times$   $\pi/180$ ).
- When M1018 = ON, the operation is in the angle mode, where the angular range is 0° ≤ angle < 360°.</li>
- When calculation results yield 0, M1020 = ON.
- The TAN obtained from the source value designated by **S** is stored in **D**.
- The following figure displays the relationship between the arc and SIN results:



Example


When X0 = ON, the TAN value of the designated binary floating point number (D1, D0) in radians (RAD) will be stored in (D11, D10), with the content consisting of a binary floating point number.






Explanation

- **S**: the designated source (binary floating point number).
- D: the ASIN value result.
- ASIN value =sin<sup>-1</sup>
- The figure below shows the relationship between input data and result:




Example

 When X0 = ON, the ASIN value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.



AF		A	cos	P			S) (	D		Bi	nary	floating point number ACOS operation
	Bit	devi	ce			V	Vord (	devic	е			16-bit command
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S				*	*						*	<u>L</u>
D											*	32-bit command (9 STEP)
Plea	se re		the f			ecificat sage	ions t	able fo	or eac	h dev		DACOS Continuous DACOS Pulse execution type P execution type  Flag signal: none


- S: the designated source (binary floating point number).
- D: the ACOS value result.
- ACOS value = cos<sup>-1</sup>
- The figure below shows the relationship between input data and result:



Example


 When X0 = ON, the ACOS value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.

```
D D 11 D 10 Binary floating point ACOS value Binary floating point
```




Explanation


- **S**: the designated source (binary floating point number).
- **D**: the ATAN value result.
- ATAN value = tan<sup>-1</sup>
- The figure below shows the relationship between input data and result:



Example

 When X0 = ON, the TAN value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.






Explanation

- S: the designated source (binary floating point number).
- D: the SINH value result.
- SINH value = (e<sup>s</sup>-e<sup>-s</sup>) / 2

Example

 When X0 = ON, the SINH value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.




AF 13		C	OSF	l P			3)(	D		Bi	nary	floating point number COSH operation
	Bit	dev	ice			٧	/ord	devic	е			16-bit command
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S				*	*						*	L
D											*	32-bit command (9 STEP)
				sage:								DCOSH Continuous DCOSH Pulse
						ecifica	tions t	able fo	or eac	h dev	ice in	execution type P execution type
seri	es for	the s	cope	of de	vice u	sage						Flag signal: none


Explanation

- **S**: the designated source (binary floating point number).
- D: the COSH value result.
- COSH value = (e<sup>s</sup>+e<sup>-s</sup>) / 2

Example

 When X0 = ON, the COSH value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.






- **S**: the designated source (binary floating point number).
- D: the TANH value result.
- TANH value = (e<sup>s</sup>-e<sup>-s</sup>) / (e<sup>s</sup>+e<sup>-s</sup>)

Example

 When X0 = ON, the TANH value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.



AF	7 7	S	WAF	P			S			E	cha	nge the up/down 8 bits
	Bit	devi	ce			V	Vord	devic	е			16-bit command (3 STEP)
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	SWAP Continuous SWAPP Pulse execution
S						*	*	*	*	*	*	execution type type
Not	es on	opera	and u	sage:	none							32-bit command (5 STEP)  DSWAP Continuous DSWAPP Pulse execution execution type type
												Flag signal: none

Explanation

- S: The device that going to exchange its up / down 8 bits.
- When using 16-bit command, the upper 8-bit and lower 8-bit exchange.
- When using 32-bit command, the contents of upper 8-bit and lower 8-bit of the 2 registers exchange.
- This command usually uses pulse execution type (SWAPP, DSWAPP)

15		MC	DDR	WP	<u>S1</u>	) (S2	2) (3	S3) (	<u>s</u>	n	Mo	odbus data read / write
	Bit	dev	ice			V	/ord	devic	е			16-bit command (5 STEP)
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	MODRW Continuous MODRW Pulse
S1				*	*						*	execution type P execution type
S2				*	*						*	32-bit command
S3				*	*						*	32-bit command
S											*	<u> </u>
n				*	*						*	Flag signal: M1077 M1078 M1079
												Triag signal. W1077 W1076 W1079

API

- **S1**: online device address.
- **\$2**: communications function code.
- \$3: address of data to read / write.
- **S**: register for data to be read / written is stored.
- **n**: length of data to be read / written.
- COM1 must be defined as controlled by the PLC (set Pr.09-31 = -12) before using this command, and the corresponding communications speed and format must also be set (set Pr.09-01 and Pr.09-04). **\$2**: communications function code. Currently only supports the following function code; the remaining function code cannot be executed.

Function	Description
H 02	Input read
H 03	Read word
H 06	Write single word
H 0F	Write multiple coils
H10	Write single word

- After executing this command, M1077, M1078 and M1079 will be immediately changed to 0.
- As an example, when CFP2000 must control another converter and PLC, if the converter has a station number of 10 and the PLC has a station number of 20, see the following example:


#### Control slave device converter

			MOD	RW com	mand	
Serial No.	Example	S1	S2	S3	S4	n
NO.		Node ID	Function code	Address	Register	Length
1	Reads 4 sets of data comprising the converter slave device Pr.01-00 to Pr.01-03, and saves the read data in D0 to D3	K10	НЗ	H100	D0	K4
2	Reads 3 sets of data comprising the converter slave device addresses H2100 to H2102, and saves the read data in D5 to D7	K10	НЗ	H2100	D5	K3
3	Reads 3 sets of data comprising the converter slave device Pr.05-00 to Pr.05-03, and writes the values as D10 to D12	K10	H10	H500	D10	К3
4	Writes 2 sets of data comprising the converter slave device addresses H2000 to H2001, and writes the values as D15 to D16	K10	H10	H2000	D15	K2

# PLC controlling slave device

			MOD	RW com	mand	
Serial	Example	S1	S2	S3	S4	n
No.	2	Node ID	Function code	Address	Register	Length
1	Reads 4 sets of data comprising the PLC slave device's X0 to X3 state, and saves the read data in bits 0 to 3 of D0	K20	H2	H400	D0	K4
2	Reads 4 sets of data comprising the PLC slave device's Y0 to Y3 state, and saves the read data in bits 0 to 3 of D1	K20	H2	H500	D1	K4
3	Reads 4 sets of data comprising the PLC slave device's M0 to M3 state, and saves the read data in bits 0 to 3 of D2	K20	H2	H800	D2	K4
4	Reads 4 sets of data comprising the PLC slave device's T0 to T3 state, and saves the read data in bits 0 to 3 of D3	K20	H2	H600	D3	K4
5	Reads 4 sets of data comprising the PLC slave device's C0 to C3 state, and saves the read data in bits 0 to 3 of D4	K20	H2	HE00	D4	K4
6	Reads 4 sets of data comprising the PLC slave device's T0 to T3 count value, and saves the read data of D10 to D13	K20	НЗ	H600	D10	K4
7	Reads 4 sets of data comprising the PLC slave device's C0 to C3 count value, and saves the read data of D20 to D23	K20	НЗ	HE00	D20	K4
8	Reads 4 sets of data comprising the PLC slave device's D0 to D3 count value, and saves the read data of D30 to D33	K20	НЗ	H1000	D30	K4
	Writes 4 sets of the PLC slave device's Y0 to Y3 state, and writes the values as bits 0 to 3 of D1	K20	HF	H500	D1	K4
10	Writes 4 sets of the PLC slave device's M0 to M3 state, and writes the values as bits 0 to 3 of D2	K20	HF	H800	D2	K4
	Writes 4 sets of the PLC slave device's T0 to T3 state, and writes the values as bits 0 to 3 of D3	K20	HF	H600	D3	K4
	Writes 4 sets of the PLC slave device's C0 to C3 state, and writes the values as bits 0 to 3 of D4	K20	HF	HE00	D4	K4
13	Writes 4 sets of the PLC slave device's T0 to T3 state, and writes the values of D10 to D13	K20	H10	H600	D10	K4
14	Writes 4 sets of the PLC slave device's C0 to C3 state, and writes the values of D20 to D23	K20	H10	HE00	D20	K4
15	Writes 4 sets of the PLC slave device's D0 to D3 state, and writes the values of D30 to D33	K20	H10	H1000	D30	K4

- Will trigger M0 ON when the PLC begins to operate, and sends instruction to execute one MODRW command.
- After receiving the slave device's response, if the command is correct, it will execute one ROL command, which will cause M1 to be ON.
- After receiving the slave device's response, will trigger M50 = 1 after a delay of 10
   PLC scanning cycles, and then execute one MODRW command.
- After again receiving the slave device's response, if the command is correct, it will execute one ROL command, and M2 will change to ON at this time (and M2 can be defined as a repeat of M); K4M0 will change to K1, and only M0 will remain 1.
   Transmission can proceed in a continuous cycle. If you wish to add a command, merely add the desired command in the empty frame, and change repeat M to Mn+1.



	Bit	dev	ice			٧	Vord	devic	е			[40.1::
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	16-bit command (11 STEP)
S1				*	*	*	*	*	*	*	*	TCMP Continuous TCMPP Pulse execution type execution type
S2				*	*	*	*	*	*	*	*	CXCCUIIOT Type   CXCCUIIOT Type
S3				*	*	*	*	*	*	*	*	32-bit command
S									*	*	*	
D		*	*									L
Vote	es on	oper	and u	sage:								Flag signal: none

API

- **\$1**: Sets the hours of the comparison time, setting range is "K0–K23."
- S2: Sets the minutes of the comparison time, setting range is "K0–K59."
- **\$3**: Sets the seconds of the comparison time, setting range is "K0–K59."
- S: current calendar time.
- D: Results of comparison.
- Compares the time in hours, minutes, and seconds set in S1–S3 with the current calendar time in hours, minutes, and seconds, with the results of comparison expressed in D.
- **S** The hour content of the current calendar time is "K0–K23." **S** +1 comprises the minutes of the current calendar time, and consists of "K0–K59." **S** +2 comprises the seconds of the current calendar time, and consists of "K0–K59."
- The current calendar time designated by S is usually compared using the TCMP command after using the TRD command to read the current calendar time. If the content value of S exceeds the range, this is considered an operating error, the command will not execute, and M1068 = ON.

- When X10 = ON, the command will execute, and the current calendar time in D20–D22 will be compared with the preset value of 12:20:45; the results will be displayed in M10–M12. When X10 ON→OFF, the command will not be executed, but the ON/OFF status prior to M10–M12 will be maintained.
- If results in the form of ≥, ≤, or ≠ are needed, they can be obtained by series and parallel connection of M10–M12.

```
X10
            TCMP
                        K12
                                  K20
                                                      D20
                                            K45
                                                                 M<sub>10</sub>
                                            D20 (hr)
                                            D21 (min)
               - ON when 12 : 20 : 45 >
                                            D22 (sec)
       M11
                                            D20 (hr)
                - ON when 12 : 20 : 45 =
                                            D21 (min)
                                            D22 (sec)
       M12
                                            D20 (hr)
               ON when 12 : 20 : 45 <
                                            D21 (min)
                                            D22 (sec)
```

16	— ⊢	Т	ZCF	P		<u>S1</u> )	(S2)	<u>S</u>		D	С	omparisc	n of calendar	data	
	Bit	devi	ice			٧	Vord (	devic	е			16-bit con	nmand (9 STEI	P)	
	Χ	Υ	М	Κ	Τ	KnX	KnY	KnM	T	С	D	TZCP	Continuous	TZCPP	Pulse
S1									*	*	*		execution type		execution type
S2									*	*	*				
S									*	*	*	32-bit con	nmand_		
D		*	*									-	-	-	-
Note	es on	opera	and u	sage:			•						<u></u>		
Plea	ase re	efer to	the	functio	on spe	ecifica	tions t	able fo	or eac	ice in	Flag signa	al: none			
seri	es for	the s	cope	of dev	vice u	sage									

API

- **\$1**: Sets the lower limit of the comparison time.
- **S2**: Sets the upper limit of the comparison time.
- **S**: current calendar time.
- **D**: Results of comparison.
- Performs range comparison by comparing the hours, minutes, and seconds of the current calendar time designated by S with the lower limit of the comparison time set as S1 and the upper limit of the comparison time set as S2, and expresses the results of comparison in **D**.
- S1, S1 +1, S1 +2: Sets the hours, minutes, and seconds of the lower limit of the comparison time.
- S2, S2 +1, S2 +2: Sets the hours, minutes, and seconds of the upper limit of the comparison time.
- S, S +1, S +2: The hours, minutes, and seconds of the current calendar time
- The D0 designated by the S listed in this program is usually obtained by comparison using the TZCP command after using the TRD command in advance to read the current calendar time. If the value of **S1**, **S2**, or S exceeds the range, this is considered an operating error, the command will not execute, and M1068 = ON.
- When the current time **S** is less than the lower limit value **S1** and **S** is less than the upper limit value **S2**, **D** will be ON. When the current time **S** is greater than the lower limit value **S1** and **S** is greater than the upper limit value **S2**, **D** +2 will be On; **D** +1 will be ON under other conditions.

Example

When X10 = ON, the TZCP command executes, and one of M10-M12 will be ON. When X10 = OFF, the TZCP command will not execute, and M10-M12 will remain in the X10 = OFF state.

```
X10
            TZCP
                       D0
                                D20
                                          D10
                                                    M10
       M10
                     D0 (hr)
                                      D10 (hr)
                         (min)
                                      D11
                                          (min)
                     D2
                                     D12
                         (sec)
                                          (sec
        ON when
       M11
                     D0 (hr)
                                     D10 (hr)
                                                      D20 (hr)
        ┨┠
                     D1 (min)
                                     D11 (min)
                                     D12 (sec)
                     D2 (sec)
                                                      D22 (sec)
        ON when
       M12
                                     D10 (hr)
                                                      D20 (hr)
        4 F
                                                      D21 (min)
                                      D11 (min)
                                     D12 (sec)
                                                      D22 (sec
        ON when
```

AF 16		Т.	ADD	P		S	1) (	S2)	D	)	С	alendar data addition
	Bit	dev	ice			٧	Vord	devic	е			16-bit command_ (7 STEP)
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	TADD Continuous TADDP Pulse
S1									*	*	*	execution type execution type
S2									*	*	*	32-bit command
D									*	*	*	SZ-BIL COMMINATIO
Note	es on	oper	and u	sage:						ı		-   -   -
				function of dev			tions t	able fo	or ead	ch dev	rice in	<ul> <li>Flag signal: M1020 Zero flag         M1022 Carry flag         M1068 Calendar error</li> </ul>

- S1: time addend.
- **\$2**: time augend.
- D: time sum.
- The calendar data in hours, minutes, and seconds designated by S2 is added to
  the calendar data in hours, minutes, and seconds designated by S1, and the result
  is stored as hours, minutes, and seconds in the register designated by D.
- If the value of S1 or S2 exceeds the range, this is considered an operating error, the command will not execute, M1067, M1068 = ON, and D1067 will record the error code 0E1A (HEX).
- If the results of addition are greater than or equal to 24 hours, carry flag M1022 = ON, and D will display the results of addition minus 24 hours.
- If the results of addition are equal to 0 (0 hours, 0 minutes, 0 seconds), zero flag M1020 = ON.

Example

 When X10 = ON, the TADD command will be executed, and the calendar data in hours, minutes, and seconds designated by D0 to D2 will be added to the calendar data in hours, minutes, and seconds designated by D10 to D12, and the results are stored as a total number of hours, minutes, and seconds in the registers designated by D20 to D22.




16		† T	SUE	P		( <u>S</u>	1) (	S2)	(D	)	С	alendar data subtraction
	Bit	dev	ice			٧	Vord	devic	е			16-bit command (7 STEP)
	Χ	Υ	М	K	Н	KnX	KnY	KnM	T	С	D	TSUB Continuous TSUBP Pulse
S1									*	*	*	execution type execution type
S2									*	*	*	32-bit command
D									*	*	*	32-bit command
Not	es on	oper	and u	sage:								1 -   -   -
				function of dev			tions t	able fo	or ead	ch dev	rice in	<ul> <li>Flag signal: M1020 Zero flag</li> <li>M1022 Carry flag</li> <li>M1068 Calendar error</li> </ul>

API \_\_\_\_

- S1: time minuend.
- **\$2**: time augend.
- D: time sum.
- Subtracts the calendar data in hours, minutes, and seconds designated by S2 from
  the calendar data in hours, minutes, and seconds designated by S1, and the result
  is temporarily stored as hours, minutes, and seconds in the register designated by
  D.
- If the value of S1 or S2 exceeds the range, this is considered an operating error, the command will not execute, M1067, M1068 = ON, and D1067 will record the error code 0E1A (HEX).
- If subtraction results in a negative number, borrow flag M1021 = ON, and the result
  of that negative number plus 24 hours will be displayed in the register designated
  by D.
- If the results of subtraction are equal to 0 (0 hours, 0 minutes, 0 seconds), zero flag M1020 = ON.

Example

• When X10 = ON, the TADD command will be executed, and the calendar data in hours, minutes, and seconds designated by D10 to D12 will be subtracted from the calendar data in hours, minutes, and seconds designated by D0 to D2, and the results are stored as a total number of hours, minutes, and seconds in the registers designated by D20 to D22.




AF 16		1	ΓRD	P				D			С	Calendar data read
	Bit	devi	ice			V	Vord	devic	е			16-bit command (3 STEP)
	Χ	Υ	М	K	Н	KnX	KnY	KnM	T	С	D	TRD Continuous TRDP Pulse
D									*	*	*	execution type execution type
Not Plea	es on	opera	and u	sage: function	on spe	ecifica	tions t	able fo	or eac	ch dev	ice in	in 32-bit command
seri	es for	the s	cope	of dev	vice u	sage						
												Flag signal: none

Explanation

- **\$1**: time minuend.
- **\$2**: time augend.
- **D**: time sum.
- D: device used to store the current calendar time after reading.
- The EH / EH2 / SV / EH3 / SV2 / SA / SX / SC main units have a built-in calendar clock, and the clock provides seven sets of data comprising year, week, month, day, hour, minute, and second stored in D1063 to D1069. The TRD command function allows program designers to directly read the current calendar time into the designated seven registers.
- D1063 only reads the two right digits of the Western calendar year.

- When X0 = ON, the current calendar time is read into the designated registers D0 to D6.
- In D1064, 1 indicates Monday, 2 indicates Tuesday, and so on, with and 7 indicating Sunday.


Special D	Item	Content		General D	Item
D1063	Year (Western)	00–99	<b>→</b>	D0	Year (Western)
D1064	Weeks	1–7	<b>†</b>	D1	Weeks
D1065	Month	1–12	$\rightarrow$	D2	Month
D1066	Day	1–31	$\rightarrow$	D3	Day
D1067	Hour	0–23	<b>→</b>	D4	Hour
D1068	Minute	0–59	<b>→</b>	D5	Minute
D1069	Second	0–59	<b>→</b>	D6	Second




- **S**: source device.
- D: device storing GRAY code.
- Transforms the content value (BIN value) of the device designated by S to GRAY code, which is stored in the device designated by D.
- The valid range of S is as shown below; if this range is exceeded, it will be considered an error, and the command will not execute.
- 16-bit command: 0–32,767
- 32-bit command: 0–2,147,483,647

Example

 When X0 = ON, the constant K6513 will be transformed to GRAY code and stored in D0.





Explanation

- **S**: source device used to store GRAY code.
- D: device used to store BIN value after transformation.
- The GRAY code corresponding to the value of the device designated by S is transformed into a BIN value, which is stored in the device designated by D.
- This command will transform the value of the absolute position encoder connected with the PLC's input and (this encoder usually has an output value in the form of GRAY code) into a BIN value, which is stored in the designated register.
- The valid range of **S** is as shown below; if this range is exceeded, it will be considered an error, and the command will not execute.

16-bit command: 0-32,767


32-bit command: 0-2,147,483,647

Example

 When X20 = ON, the GRAY code of the absolute position encoder connected with input points X0 to X17 will be transformed into BIN value and stored in D10.

```
GRAY CODE 6513 000110010101110001

H1971=K6513 000110010111100011
```




- S1: data source device 1.
- S2: data source device 2.
- This command performs comparison of the content of S1 and S2; when the result
  of comparison is not 0, this command will be activated, but this command will not
  be activated when the result of comparison is 0.
- The LD#This command can be used while directly connected with the busbar

Api No.	16-bit	32-bit	С	ondit	ions fo	or	C	Condit	ions for	
Api No.	Commands	Commands	Activation				Inactivation			
215	LD&	DLD&	S1	&	S2	<b>≠</b> 0	S1	&	S2	= 0
216	LD	DLD	S1		S2	<b>≠</b> 0	S1		S2	= 0
217	LD^	DLD^	S1	٨	S2	<b>≠</b> 0	S1	٨	S2	= 0

- &: logical AND operation.
- |: logical OR operation.
- ^: logical XOR operation.

- When the content of C0 and C10 is subjected to the logical AND operation, and the result is not equal to 0, Y10 = ON.
- When the content of D200 and D300 is subjected to the logical OR operation, and the result is not equal to 0, and X1 = ON, Y11=On and remains in that state.




API 218- 220 D AND# S1 S2 Contact						<u>s1</u> ) (	t form logical operation AND#					
Bit device Word device						16-bit command (5 STEP)						
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	AND# Continuous
S1				*	*	*	*	*	*	*	*	execution type
S2				*	*	*	*	*	*	*	*	32-bit command (9 STEP)
Note	es on	opera	and u	sage:	#	<sup>‡</sup> : &,  ,	٨					DAND# Continuous
							tions t	able fo	or eac	h dev	vice in	execution type
seri	es for	the s	cope	of dev	vice u	sage						Flag signal: none


- **\$1**: data source device 1.
- **\$2**: data source device 2.
- This command performs comparison of the content of S1 and S2; when the result
  of comparison is not 0, this command will be activated, but this command will not
  be activated when the result of comparison is 0.
- The AND# command is an operation command in series with the contact.

	Api No.	16-bit	32-bit	-bit Conditions for				Conditions for				
	Аргио.	Commands	Commands		Activation				Inactivation			
Ī	218	AND&	DAND&	S1	&	S2	<b>≠</b> 0	S1	&	S2	= 0	
Ī	219	AND	DAND	S1		S2	<b>≠</b> 0	S1		S2	= 0	
	220	AND^	DAND^	S1	٨	S2	<b>≠</b> 0	S1	٨	S2	= 0	

- &: logical AND operation.
- |: logical OR operation.
- ^: logical XOR operation.

- When X0 = ON and the content of C0 and C10 is subjected to the logical AND operation, and the result is not equal to 0, Y10 = ON.
- When X1 = OFF and D10 and D0 is subjected to the logical OR operation, and the result is not equal to 0, Y11 = ON and remains in that state.
- When X2 = ON and the content of the 32-bit register D200 (D201) and 32-bit register D100 (D101) is subjected to the logical XOR operation, and the result is not equal to 0 or M3 = ON, M50 = ON.







- S1: data source device 1.
- **\$2**: data source device 2.
- This command performs comparison of the content of S1 and S2; when the result
  of comparison is not 0, this command will be activated, but this command will not
  be activated when the result of comparison is 0.
- The OR# command is an operation command in series with the contact.

Ī	Api No. 16-bit Commands		32-bit	С	onditi	ions for	Conditions for			
			Commands	Activation			Inactivation			
	221	OR&	DOR&	S1	&	S2 ≠0	S1	&	S2	= 0
ſ	222	OR	DOR	S1		S2 ≠0	S1		S2	= 0
ſ	223	OR^	DOR^	S1	٨	S2 ≠ 0	S1	٨	S2	= 0

- &: logical AND operation.
- |: logical OR operation.
- ^: logical XOR operation.

- When X1 = ON or the content of C0 and C10 is subjected to the logical AND operation, and the result is not equal to 0, Y0 = ON.
- When X2 and M30 are both equal to ON, or the content of 32-bit register D10 (D11) and 32-bit register D20 (D21) is subjected to the logical OR operation, and the result is not equal to 0, or the content of the 32-bit counter C235 and the 32-bit register D200 (D201) is subjected to the logical XOR operation, and the result is not equal to 0, M60 = ON.







Explanation

- \$1: data source device 1.
- **\$2**: data source device 2.
- This command compares the content of S1 and S2. Taking API 224 (LD=) as an example, this command will be activated when the result of comparison is "equal," and will not be activated when the result is "unequal."
- The LD\* can be used while directly connected with the busbar

Api No.	16-bit Commands	32-bit Commands	Conditions for Activation	Conditions for Inactivation
224	LD =	DLD =	S1 = S2	S1 ≠ S2
225	LD >	DLD >	S1 > S2	S1 ≤ S2
226	LD <	DLD <	S1 < S2	S1 ≥ S2
228	LD < >	DLD <>	S1 ≠ S2	S1 = S2
229	LD < =	DLD < =	S1≤ S2	S1 > S2
230	LD > =	DLD > =	S1≥ S2	S1 < S2

- When the content of C10 is equal to K200, Y10 = ON.
- When the content of D200 is greater than K-30, and X1 = ON, Y11 = ON and remains in that state.







- S1: data source device 1.
- **\$2**: data source device 2.
- This command compares the content of S1 and S2. Taking API 232 (AND=) as an example, when the result of comparison is equal, this command will be activated; when the result of comparison is unequal, this command will not be activated.
- The AND\* command is a comparison command in series with a contact.

Api No.	16-bit Commands	32-bit Commands	Conditions for Activation	Conditions for Inactivation
232	AND =	DAND =	S1 = S2	S1 ≠ S2
233	AND >	DAND >	S1 > S2	S1≤S2
234	AND <	DAND <	S1 < S2	S1≥S2
236	AND <>	DAND <>	S1 ≠ S2	S1 = S2
237	AND < =	DAND <=	S1≤S2	S1 > S2
238	AND > =	DAND > =	S1≥S2	S1 < S2

- When X0 = ON and the current value of C10 is also equal to K200, Y10 = ON.
- When X1 = OFF and the content of register D0 is not equal to K-10, Y11 = ON and remains in that state.
- When X2 = ON and the content of the 32-bit register D0 (D11) is less than 678,493, or M3 = ON, M50 = ON.







Explanation

- **\$1**: data source device 1.
- **\$2**: data source device 2.
- This command compares the content of S1 and S2. Taking API 240 (OR=) as an
  example, when the result of comparison is equal, this command will be activated;
  when the result of comparison is unequal, this command will not be activated.
- The OR\* command is a compare command in parallel with a contact.

Api No.	16-bit Commands	32-bit Commands	Conditions for Activation	Conditions for Inactivation
240	OR =	DOR =	S1 = S2	S1 ≠ S2
241	OR >	DOR >	S1 > S2	S1 ≤ S2
242	OR <	DOR <	S1 < S2	S1≥ S2
244	OR < >	DOR <>	S1 ≠ S2	S1 = S2
245	OR < =	DOR <=	S1 ≤ S2	S1 > S2
246	OR > =	DOR > =	S1≥ S2	S1 < S2

- When X0 = ON and the current value of C10 is also equal to K200, Y10 = ON.
- When X1 = OFF and the content of register D0 is not equal to K-10, Y11 = ON and remains in that state.
- When X2 = ON and the content of the 32-bit register D0 (D11) is less than 678,493, or M3 = ON, M50 = ON.






- S1: data source device 1.
- S2: data source device 2.
- This command compares the content of S1 and S2. Taking "FLD=" as an example, if the result of comparison is "equal," this command will be activated; but it will not be activated when the result is "unequal."
- The FLD\* command can directly input floating point numerical values (for instance: F1.2) to the S1, S2 operands, or store floating-point numbers in register D for use in operations.
- This command can be used while directly connected with the busbar

Api No.	32-bit Commands	Conditions for Activation	Conditions for Inactivation
275	FLD =	S1 = S2	S1≠S2
276	FLD >	S1 > S2	S1 ≤ S2
277	FLD <	S1 < S2	S1≥S2
278	FLD <>	S1 ≠ S2	S1 = S2
279	FLD < =	S1≤S2	S1 > S2
280	FLD > =	S1≥S2	S1 < S <sub>2</sub>

Example

When the floating point number of register D200 (D201) is less than or equal to F1.2, and X1 activated, contact Y21 will be activated and remain in that state.

```
FLD<= D200 F1.2 | SET Y21
```



Explanation


- \$1: data source device 1.
- \$2: data source device 2.
- This command compares the content of S1 and S2. Taking "FAND=" as an example, if the result of comparison is "equal," this command will be activated; but it will not be activated when the result is "unequal."
- The FAND\* command can directly input floating point numerical values (for instance: F1.2) to the S1, S2 operands, or store floating-point numbers in register D for use in operations.
- This command can be used while directly connected with the busbar

Api No.	32-bit	Conditions for	Conditions for
, ib	Commands	Activation	Inactivation
281	FAND =	S1 = S2	S1 ≠ S2
282	FAND >	S1 > S2	S1 ≤ S2
283	FAND <	S1 < S2	S1≥ S2
284	FAND <>	S1 ≠ S2	S1 = S2
285	FAND < =	S1 ≤ S2	S1 > S2
286	FAND > =	S1≥ S2	S1 < S2

Example

 When X1 = OFF, and the floating point number in register D100 (D101) is not equal to F1.2, Y21 = ON and remains in that state.

```
X1 FAND<> F1.2 D0 SET Y21
```



- \$1: data source device 1.
- **S2**: data source device 2.
- This command compares the content of S1 and S2. Taking "FOR=" as an example, if the result of comparison is "equal," this command will be activated; but it will not be activated when the result is "unequal."
- The FOR\* command can directly input floating point numerical values (for instance: F1.2) to the S1, S2 operands, or store floating-point numbers in register D for use in operations.
- This command can be used while directly connected with the busbar

Api No.	32-bit Commands	Conditions for Activation	Conditions for Inactivation
287	FOR =	S1 = S2	S1≠S2
288	FOR >	S1 > S2	S1 ≤ S2
289	FOR <	S1 < S2	S1≥ S2
290	FOR <>	S1 ≠ S2	S1 = S2
291	FOR <=	S1 ≤ S2	S1 > S2
292	FOR > =	S1≥ S2	S1 < S2

Example

 When X2 and M30 are both equal to "ON," or the floating point number in register D100 (D101) is greater than or equal to F1.234, M60 = ON.

### 16-6-5 Detailed Explanation of Driver Special Applications Commands

	RPR     S1   S2									Re	ead s	ervo par	rameter		
	Bit	dev	ice			٧	Vord	devic		16-bit command (5 STEP)					
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Τ	С	D	RPR	Continuous	RPRP	Pulse
S1				*	*						*		execution type		execution type
S2											*	32-bit cor	 mmond		
Note	es on	oper	and u	sage:	none							- 52-DIL COI	nmanu -	_	-
												i Flag signa	al: none		<u> </u>

Explanation

- **\$1**: Parameter address of data to be read.
- \$2: Register where data to be read is stored.

API 140		V	VPR	P		S	31) (	<u>S2</u> )		W	rite s	e servo parameter
	В	it devi	ice			V	ord o	devic	е			16-bit command (5 STEP)
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	WPR Continuous WPRP Pulse
S1				*	*						*	execution type execution type
S2				*	*						*	
Notes	on c	perano	d usag	e: noi	ne							32-bit command
		•	Ū									
												Flag signal: none

Explanation

- **\$1**: Data to write to specified page.
- **\$2**: Parameter address of data to be written.

Example

- When the data in the CFP2000 driver's parameter H01.00 is read and written to D0, data from H01.01 will be read and written to D1.
- When M0 = ON, the content of D10 will be written to the CFP2000 driver parameter 04-00 (first speed of multiple speed levels).
- When the parameter has been written successfully, M1017 = ON.
- The CFP2000's WPR command does not support writing to the 20XX address, but the RPR command supports reading of 21XX, 22XX.

Recommendation Take care when using the WPR command. When writing parameters, because most parameters are recorded as they are written, these parameters may only be revised 109 times; a memory write error may occur if parameters are written more than 109 times.

> Because the following commonly-used parameters have special processing, there are **no** restrictions on the number of times they may be written.

Pr.00-11: Speed mode selection

Pr.00-27: User-defined value

Pr.01-12: Acceleration time 1

Pr.01-13: Deceleration time 1

Pr.01-14: Acceleration time 2

Pr.01-15: Deceleration time 2

Pr.01-16: Acceleration time 3

Pr.01-17: Deceleration time 3

Pr.01-18: Acceleration time 4

Pr.01-19: Deceleration time 4

Pr.02-12: Select MI Conversion Time mode:

Pr.02-18: Select MO Conversion Time mode:

Pr.04-50-Pr.04-69: PLC register parameter 0-19

Pr.08-04: Upper limit of integral

Pr.08-05: PID output upper limit

Calculation of the number of times written is based on whether the written value is modified. For instance, writing the same value 100 times at the same time counts as writing only once.

When writing a PLC program, if unsure of usage of the WPR command, we recommend that you use the WPRP command.

(S1)

Bit device Word device											16-bit command (9 STEP)	
İ	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	FPID Continuous FPIDP Pulse
S1				*	*						*	execution type execution type
S2				*	*						*	32-bit command
S3				*	*						*	<u>32-bit command</u>
S4				*	*						*	
Notes on operand usage: none											Flag signal: none	


(S2) (S3) (S4) Driver PID control mode

Explanation

- **\$1**: PID reference target value input terminal selection.
- S2: PID function proportional gain P.
- **\$3**: PID function integral time I.
- **\$4**: PID function differential time D.
- The FPID command can directly control the driver's feedback control of PID parameter, terminal selection of PID feedback (Pr.08-00), proposal gain P (Pr.08-01), integral time I (Pr.08-02), and differential time D (Pr.08-03).

Example

- When M0 = ON, the set Terminal selection of PID feedback is 0 (no PID function), the PID function proportional gain P is 0, the PID function integral time I is 1 (units: 0.01 sec.), and the PID function differential time D is 1 (units: 0.01 sec.).
- When M1 = ON, the set Terminal selection of PID feedback is 0 (no PID function), the PID function proportional gain P is 1 (units: 0.01), the PID function integral time I is 0, and the PID function differential time D is 0.
- When M2 = ON, the set Terminal selection of PID feedback is 1 (target frequency input is controlled from the digital keypad), the PID function proportional gain P is 1 (units: 0.01), the PID function integral time I is 0, and the PID function differential time D is 0.
- D1027: Frequency command after PID operation.



				•											
	Bit device Word device											16-bit con	nmand (7 STE	P)	
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	FREQ	Continuous	FREQP	Pulse
S1				*	*						*	]L	execution type		execution type
S2				*	*						*	32-bit con	 nmand		
S3				*	*						*	32-bit coi	ililialiu_		<del>                                     </del>
Note	es on	oper	and u	sage:	none							<u> </u>	<u>-</u>		
												Flag signa	al: M1015		

FREQ D

- \$1: Frequency command.
- \$2: Acceleration time.
- \$3: Deceleration time
- \$2, \$3: In acceleration / deceleration time settings, the number of decimal places is determined by the definitions of Pr.01-45.

Driver speed control mode

#### Example

When Pr.01-45 = 0: units of 0.01 sec.

(S1) (S2) (S3)

The setting of 50 for **S2** (acceleration time) in the ladder diagram below implies 0.5 sec., and the **S3** (deceleration time) setting of 60 implies 0.6 sec

 The FREQ command can control driver frequency commands, and acceleration and deceleration time; it also uses special register control actions, such as:

M1025: Control driver RUN (ON) / STOP (OFF) [RUN requires Servo On (M1040 ON) to be effective)

M1026: Control driver operating direction FWD (OFF) / REV (ON)

M1040: Control Servo ON / Servo OFF.


M1042: Trigger quick stop (ON) / does not trigger quick stop (OFF).

M1044: Pause (ON) / release pause (OFF)

M1052: Lock frequency (ON) / release lock frequency (OFF)

Example

- M1025: Driver RUN (ON) / STOP (OFF), M1026: driver operating direction FWD (OFF) / REV (ON). M1015: frequency reached.
- When M10 = ON, sets the driver frequency command K300 (3.00 Hz), with an acceleration / deceleration time of 0.
- When M11 = ON, sets the driver frequency command K3000 (30.00 Hz), with an acceleration time of 50 (0.5 sec.) and deceleration time of 60 (0.6 sec.). (When Pr.01-45 = 0)
- When M11 = OFF, the drive frequency command will now change to 0



 Pr.09-33 are defined based on whether the reference commands have been cleared before PLC operation.

bit0: Prior to PLC scanning procedures, whether the target frequency has been cleared is 0. (This will be written to the FREQ command when the PLC is ON). Example: When using r to write a program

If we force M0 to be 1, the frequency command will be 20.00 Hz; but when M0 is set as 0, there will be a different situation.

Case 1: When the bit0 of Pr.09-33 is 0, and M0 is set as 0, the frequency command remains at 20.00 Hz.

Case 2: When the bit0 of Pr.09-33 is 1, and M0 is set as 0, the frequency command changes to 0.00 Hz.

The reason is that when the Pr.09-33 bit0 is 1 prior to the PLC scanning procedures, the frequency will firstly revert to 0.

When the Pr.09-33 bit0 is 0, the frequency will not revert to 0.

	Dit	dev	ico			١٨	lord i	devic	^			16-bit command (9 STEP)
	Х	Y	M	K	Н	KnX		KnM	T	С	D	CANRX Continuous CANRX Pulse
S1				*	*							execution type P execution type
S2				*	*							32-bit command
S3				*	*							<u>GE BICCOMMINION</u>
D									*	*	*	

- **\$1**: Slave station number.
- S2: Main index.
- **\$3**: Subindex + bit length.
- D: Preset address.
- The CANRX command can read the index of the corresponding slave station. When it is executed, it will send the SDO message format to the slave station. M1066 and M1067 will both be 0 at that time, and M1066 will be set as 1 after reading. If the slave station gives the correct response, it will write the value to the preset register, and set M1067 as 1. If the slave station has a response error, M1067 will be set as 0, and an error message will be recorded to D1076 to D1079.

Example

M1002: When the PLC runs, the command will be triggered once and will set
 K4M400 = K1

Afterwards, each time M1066 is 1, it will switch to a different message.


```
M1002
0
                                                        MOV
                                                                       K4M400
                                                                K1
        Start running forward
        (Instantaneously)
        M1066
6
                                                        TMR
                                                                           K5
          ┨┠
                                                                T10
        Read & write to
                           T10
        CANopen
                            -1 |-
                                                        ROLP
                                                                            K1
                                                               K4M400
        completed
        M400
                                      CANRXP
17
         \dashv \vdash
                                                  K1
                                                        H6041
                                                                  H10
                                                                          D120
        M401
27
                                      CANRXP
                                                  K2
                                                        H6041
         \dashv \vdash
                                                                  H10
                                                                          D121
        M402
37
         \dashv \vdash
                                      CANTXP
                                                  K1
                                                        D120
                                                                H6040
                                                                          H10
        M403
47
                                      CANTXP
                                                  K2
         ┨┠
                                                        D120
                                                                H6040
                                                                          H10
        M404
57
         ┨┠
                                                           CANFLS
                                                                        D2025
                                                           Speed diagram of
                                                           sub-station 1 (H)
        M405
61
         ⊣⊢
                                                           CANFLS
                                                                        D2125
                                                           Speed diagram of
                                                           sub-station 1 (H)
65
                                                                         END
```

20	4											
	Bit device Word device											16-bit command (9 STEP)
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	CANTX Continuous CANTX Pulse
S1				*	*							execution type P execution type
S2				*	*				*	*	*	
S3				*	*							32-bit command
S4				*	*							
Note	Notes on operand usage: none											Flag signal

CANTX S1 S2 S3 S4 Write CANopen slave station data

Explanation

- **\$1**: Slave station number.
- **S2**: Address to be written.
- S3: Main index.
- \$4: Subindex + bit length.
- The CANTX command can write a value to the index of the corresponding slave station. When it is executed, it will send the SDO message format to the slave station. M1066 and M1067 will both be 0 at that time, and M1066 will be set as 1 after reading. If the slave station gives the correct response, it will write the value to the preset register, and set M1067 as 1. If the slave station has a response error, M1067 will be set as 0, and an error message will be recorded to D1076 to D1079.




- D: Special D to be refreshed.
- The CANFLS command can refresh special D commands. When is a read only attribute, executing this command will send a message equivalent to that of CANRX to the slave station, and the number of the slave station will be transmitted back and refreshed to this special D. When there is a read / write attribute, executing this command will send a message equivalent to that of CANTX to the slave station, and the value of this special D will be written to the corresponding slave station.
- When M1066 and M1067 are both 0, and M1066 is set as 1 after reading, if the slave station gives a correct response, the value will be written to the designated register, and M1067 will be set as 1. If the slave station's response contains an error, then M1067 will be set as 0, and an error message will be recorded to D1076-D1079.

AF 32		) IC	ОМЕ	₹ P	<u>S1</u>	) (S	2) (	S3)	D	) In	terna	al communications read
	Bit	dev	ice			W	ord (	16-bit command (9 STEP)				
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ICOMR Continuous ICOMRP Pulse
S1				*	*						*	execution type execution type
S2				*	*						*	32-bit command (17 STEP)
S3				*	*						*	DICOMR Continuous DICOMRP Pulse
D				*	*						*	execution execution
Note	es on	opera	and us	age: r	none							type type
												Flag signal: M1077 M1078 M1079

Explanation


- \$1: Selection of slave device.
- **\$2**: Device selection (0: converter, 1: internal PLC).
- \$3: Read address.
- D: Saving target.
- The ICOMR command can obtain the slave station's converter and the internal PLC's register value.



- **\$1**: Selection of slave device.
- **\$2**: Device selection (0: converter, 1: internal PLC).
- \$3: Read address.
- D: Saving target.
- The ICOMW command write a value to the slave station's converter and the internal PLC's register.

Example

#### Please refer to the following example:



	API   WPRA										parameters write-in			
	Bit	dev	ice			V	/ord	devic	е			16-bit command (5 STEP)		
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	WORA Continuous WORAP Pulse		
S1				*	*						*	execution type execution type		
S2				*	*						*	32-bit command		
Note	es on	opera	and us	age: r	none									
												Flag signal: none		

- **\$1**: Data that is going to write in
- S2: Parameter address of the write-in data

Example

- Read the data of CFP2000 drive's parameter H01.00 and write into D0, read data of H01.01 and write into D1.
- When M0 is ON, write the content of D10 into CFP2000 drive's Pr.04-00 (1st step speed frequency).
- When parameter writes-in successfully, M1017 is ON.
- The WPR command does not support the write-in of 20XX address, but the RPR command supports the read-out of 21XX and 22XX.

```
M1000
                      RPR
  H100
                                           D0
Normally open contact of
operation monitoring (a)
                      RPR
                                H101
                                           D1
 M0
 ┨┠
                      WPRA
                                 D10
                                           H400
                                           END
```

Recommendation

 When WPRA executes, the data is only written into the RAM area, and will get back to previous record when the power is off.

# 16-7 Error Display and Handling

Code	ID	Description	Recommended handling approach
PLrA	47	RTC time check	Turn power on and off when resetting the
PLIA	47	RTC time check	keypad time
PLrt	49	incorrect RTC mode	Turn power on and off after making sure that the
FLIT	43	incorrect NTC mode	keypad is securely connected
PLod	50	Data writing memory error	Check whether the program has an error and
FLOG	30	Data writing memory error	download the program again
PLSv	51	Data write memory error during	Restart power and download the program again
FLOV	J1	program execution	
PLdA	52	Program transmission error	Try uploading again; if the error persists, sent to
PLUA	JZ	Program transmission error	the manufacturer for service
PLFn	53	Command error while downloading	Check whether the program has an error and
FLFII	55	program	download the program again
PLor	54	Program exceeds memory capacity	Restart power and download the program again
FLOI	J <del>4</del>	or no program	
PLFF	55	Command error during program	Check whether the program has an error and
FLII	33	execution	download the program again
PLSn	56	Check code error	Check whether the program has an error and
PLOII	30	Check code enoi	download the program again
PLEd	57	Program has no END stop	Check whether the program has an error and
FLLU	31	command	download the program again
PLCr	58	MC command has been used	Check whether the program has an error and
FLOI	30	continuously more than nine times	download the program again
PLdF	59	Download program error	Check whether the program has an error and
FLUI	39	Download program error	download again
PLSF	60	PLC scan time excessively long	Check whether the program code has a writing
FLOF	00	r LO scan time excessively long	error and download again

## 16-8 CANopen Master Control Applications


Control of a simple multi-axis application is required in certain situations. If the device supports the CANopen protocol, a CFP2000 can serve as the master in implementing simple control (speed control). The setting method comprises the following seven steps:

#### Step 1: Activating CANopen Master functions


- 1. Pr.09-45 = 1 (initiates Master functions); restart power after completing setting, the status bar on the KPC-CC01 digital keypad will display "CAN Master".
- 2. Pr.00-02 = 6 reset PLC (please note that this action will reset the program and PLC registers to the default values)
- 3. Turn power off and on again.
- 4. Use the KPC-CC01 digital keypad to set the PLC control mode as "PLC Stop" (if a newly-introduced driver is used, the blank internal PLC program will cause a PLFF warning code to be issued).

## Step 2: Master memory settings


- After connecting the 485 communications cable, use WPL Soft to set the PLC status as Stop (if the PLC mode has been switched to the "PLC Stop" mode, the PLC status should already be Stop)
- 2. Set the address and corresponding station number of the slave station to be controlled. For instance, if it is wished to control two slave stations (a maximum of 8 stations can be controlled simultaneously), and the station numbers are 21 and 22, it is only necessary to set D2000 and D2100 as 20 and 21, and then set D2200, D2300, D2400, D2500, D2600, and D2700 as 0. The setting method involves use of the PLC's WPL editing software WPL as follows:
  - Open WPL and implement communications > register edit (T C D) function



• After leaving the PLC register window, the register setting screen will appear, as shown below:



If there is a new PLC program and no settings have yet been made, you can read default data from the converter, and merely edit it to suit the current application. If settings have already been made, however, the special D in the CANopen area will display the saved status (the CANopen D area is located at D1090 to D1099 and D2000 to D2799). Assuming it is a new program, we will first read the default data from the converter; check the communications format if there is no communications link (the default PLC station number is 2, 9600, 7N2, ASCII). Perform the following steps: 1. Switch the PLC to Stop status; 2. Press the transmit button; 3. click on read memory after exiting the window; 4. Ignore D0-D399; and 5. click on the confirm button.)



After reading the data, it is necessary to perform some special D settings. Before proceeding, we will first introduce the special D implications and setting range. The CANopen Master's special D range is currently D1070 to D1099 and D2000 to D2799; this range is divided into 3 blocks:

- The first block is used to display CANopen's current status, and has a range of D1070 to D1089
- The second block is used for CANopen's basic settings, and has a range of D1090 to D1099
- The third block is the slave station mapping and control area, and has a range of D2000 to D2799

These areas are therefore introduced as follows:

The first area displays the current CANopen status

When the master initializes a slave station, we can find out from D1070 whether configuration of the slave device has been completed; we can find out whether an error occurred in the configuration process from D1071 and whether the configuration is inappropriate from D1074.

After entering normal control, we can find out whether the slave device is offline from D1073. In addition, we can check the slave device's read/write information using the CANRX, CANTX, and CANFLS commands; error information can be obtained from D1076 to D1079 if there has been a read / write failure.

Special D	Description of Function	R/W
D1070	Channel opened by CANopen initialization (bit0 = Machine code0)	R
D1071	Error channel occurring in CANopen initialization process (bit0=Machine code0)	R
D1072	Reserved	-
D1073	CANopen break channel (bit0=Machine code0)	R
	Error code of master error  0: No error	
D1074	1: Slave station setting error 2: Synchronizing cycle setting error (too small)	R
D1075	Reserved	-
D1076	SDO error message (main index value)	R
D1077	SDO error message (secondary index value)	R
D1078	SDO error message (error code L)	R
D1079	SDO error message (error code H)	R

The second area is for basic CANopen settings: (the PLC must have stopped when this area is used to make settings)

We must set the information exchange time for the master and slave station,

Special D	Description of Function	Default	R/W
D1090	Synchronizing cycle setting	4	RW

Use D1090 to perform settings; setting time relationships include:

Sync time 
$$\geqslant \frac{1M}{Rate} * \frac{N}{4}$$


#### N: TXPDO + RXPDO

For instance, when communications speed is 500 Kbps, TXPDO + RXPDO have 8 sets, and synchronizing time will require more than 4 ms.

We must also define how many slave stations will be open. D1091 is the channel for defining station opening, and D2000 + 100×n is the station number defining this channel. See the detailed explanation below.

Slave station number **n**=0-7

Special D	Description of Function	R/W
D1091	Sets slave station ON or OFF (bit0-bit 7 correspond to slave stations number 0-7)	RW
D2000+100* <b>n</b>	Slave station number	RW



If slave devices have a slow start-up, the master can delay for a short time before performing slave station configuration; this time delay can be set via D1092.

Special D	Description of Function	Default	R/W
D1092	Delay before start of initialization		RW

With regard to slave device initialization, a delay time can be set to judge whether failure has occurred. If the communications speed is relatively slow, the delay time can be adjusted to judge whether initialization has been completed, which will ensure that there is time to perform slave device initialization.

Special D	Description of Function		R/W
D1099	Initialization completion delay time	15 000	RW
	Setting range: 1 to 60000 sec.	Default 15 sec.	KVV

After communication is successful, the system must detect whether there is a break in communications with the slave station. D1093 is used to set detection time, and D1094 sets the number of consecutive errors that will trigger a break error.

Special D	Description of Function	Default	R/W
D1093	Break time detection	1000 ms	RW
D1094	Break number detection	3	RW

The packet type transmitted by PDO is set before establishing normal communications and generally does not require adjustment.

Special D	Special D Description of Function		R/W
D1097	D1097 Corresponding real-time transmission type (PDO) Setting range: 1–240		RW
D1098	D1098 Corresponding real-time receiving type (PDO) Setting range: 1–240		RW

The third area is the slave station mapping and control area.

CANopen provides a PDO method to perform mapping of the master and slave station memory, and enables the master to directly access read/write data in a certain memory area. The master will automatically perform data exchange with the corresponding slave device, and the read/write values can be seen directly from the special D area after real-time exchange (M1034 = 1 time) has been established. The CFP2000 currently supports real-time mapping of four PDOs, and there are two types of PDO RXPDO (reads slave device information) and TXPDO (writes to slave device). In addition, in order to facilitate control, the CFP2000 cannot perform mapping of commonly used registers; the following is an overview of the current PDO mapping situation:

TX PDO					
PDO2 (Re	emote I/O)	PDO1	(Speed)		
Description	Special D	Description	Special D		
Slave device DO	D2027+100×n	Controller word	D2008+100×n		
Slave device AO1	D2031+100×n	Target speed	D2012+100×n		
Slave device AO2	D2032+100×n				
Slave device AO3	D2033+100×n				

RXPDO					
PDO2 (Re	emote I/O)	PDO1 (	(Speed)		
Description	Special D	Description	Special D		
Slave device DI	D2026+100×n	Mode word	D2009+100×n		
Slave device Al1	D2028+100×n	Actual frequency	D2013+100×n		
Slave device Al2	D2029+100×n				
Slave device Al3	D2030+100×n				

Because usage requires only simple to open the corresponding PDO, where TXPDO employs D2034+100\*n settings and RXPDO employs D2067+100×n settings.

These two special D areas are defined as follows:

	PD	O2	PDO1		
Default definition	Remote I/O		Speed		
bit	7	6–4	3	2–0	
Definition	En	Length	En	Length	

#### NOTE:

En: indicates whether PDO is used

Length: indicates mapping of several variables

In a simple example, if we wish to control a CFP2000 slave device and cause it to operate in speed mode, we only have to make the following settings:

D2034+100×n =000Ah

		TXT	PDO			
Length	PD	PDO2 PDO1		PDO2		01
	Description	Special D	Description	Special D		
1	Slave device DO	D2027+100×n	Controller word	D2008+100×n		
2	Slave device AO1	D2031+100×n	Target speed	D2012+100×n		
3	Slave device AO2	D2032+100×n				
4	Slave device AO3	D2033+100×n				

	PDO2		PDO1	
Definition	Remote I/O		Speed	
bit	7	6–4	3	2–0
Definition	0	0	1	2

#### D2067+100\*n =000Ah

		TX F	PDO	
Length	PD	O2	PD	01
	Description	Special D	Description	Special D
1	Slave device DI	D2026+100×n	Controller word	D2009+100*n
2	Slave device Al1	D2028+100×n	Actual frequency	D2013+100*n
3	Slave device Al2	D2029+100×n		
4	Slave device Al3	D2030+100×n		

	PD	O2	PDO1		
Definition	Remo	te I/O	Speed		
bit	7	6–4	3	2–0	
Definition	0	0	1	2	

Switch the PLC to Run after completing settings. Now wait for successful initialization of CANopen (M1059 = 1 and M1061 = 0), and then initiate CANopen memory mapping (M1034 = 1). The control word and frequency command will now automatically refresh to the corresponding slave device (D2008+n×100 and D2012+n×100), and the slave device's status word and currently frequency will also be automatically sent back to the master station (D2009+n×100 and D2013+n\*100). This also illustrates how the master can handle these tasks through read/write operations in the special D area.

Furthermore, it should be noted that the remote I/O of PDO2 can obtain the slave device's current DI and AI status, and can also control the slave device's DO and AO status. Nevertheless, after introducing a fully automatic mapping special D, the CFP2000 CANopen master also provides additional information refreshes. For instance, while in speed mode, acceleration/deceleration settings may have been refreshed. The special D therefore also stores some seldom-used real-time information, and these commands can be refreshed using the CANFLS command. The following is the CFP2000's current CANopen master data conversion area, which has a range of D2001+100\*n - D2033+100\*n, as shown below:

- 1. The range of n is 0-7
- 2. ●Indicates PDOTX, ▲Indicates PDORX; unmarked special D can be refreshed using the

## **CANFLS** command

Special D	Description of Eupation		PDO [	R/W	
Special D	Description of Function	Default	1	2	Γζ/ V V
	Station number n of slave station				
D2000+100*n	Setting range: 0–127	0			RW
	0: No CANopen function				
D2002+100*n	Manufacturer code of slave station number n (L)	0			R
D2003+100*n	Manufacturer code of slave station number n (H)	0			R
D2004+100*n	Manufacturer's product code of slave station number n (L)	0			R
D2005+100*n	Manufacturer's product code of slave station number n (H)	0			R

## Basic definitions

Conside D	Description of Function	Defect	PDO Default		D/\/
Special D	Description of Function	Default	1	2	R/W
D2006+100*n	Communications break handling method of slave station	0			RW
D2000+100*N	number n	U			IXVV
D2007+100*n	Error code of slave station number n error	0			R
D2008+100*n	Control word of slave station number n	0	•		RW
D2009+100*n	Status word of slave station number n	0	•		R
D2010+100*n	Control mode of slave station number n	2			RW
D2011+100*n	Actual mode of slave station number n	2			R


## Velocity Control

Special D	Description of Function  Default PDO Defa		Default	R/W	
Special D			1	2	TC/ V V
D2001+100*n	Torque restriction on slave station number n	0			RW
D2012+100*n	Target speed of slave station number n (rpm)	0	•		RW
D2013+100*n	Actual speed of slave station number n (rpm)	0	<b>A</b>		R
D2014+100*n	Error speed of slave station number n (rpm)	0			R
D2015+100*n	Acceleration time of slave station number n (ms)	1000			RW
D2016+100*n	Deceleration time of slave station number n (ms)	1000			RW

## Remote I/O

Chariel D	Description of Function	Defect	PDO Default		D / \\/
Special D	Description of Function	Default	1	2	R/W
D2026+100*n	MI status of slave station number n	0		<b>A</b>	R
D2027+100*n	MO setting of slave station number n	0		•	RW
D2028+100*n	Al1 status of slave station number n	0		<b>A</b>	R
D2029+100*n	Al2 status of slave station number n	0		<b>A</b>	R
D2030+100*n	Al3 status of slave station number n	0		<b>A</b>	R
D2031+100*n	AO1 setting of slave station number n	0		•	RW
D2032+100*n	AO2 setting of slave station number n	0		•	RW
D2033+100*n	AO3 setting of slave station number n	0		•	RW

After gaining an understanding of special D definitions, we return to setting steps. After entering the values corresponding to D1090 to D1099, D2000+100×n, D2034+100×n and D2067+100\*n, we cannot begin to perform downloading, which is performed in accordance with the following steps: (1. D2000 and D2100 are set as 20 and 21, and D2200, D2300, D2400, D2500, D2600, and D2700 are set as 0; if a setting of 0 causes problems, D1091 can be set as 3, and slave stations 2 to 7 can be closed. 2. Switch PLC to Stop status. 3. Press the transmit button. 4. Click on write memory after exiting the window. 5. Ignore D0–D399. 6. Change the second range to D1090–D1099. 7. Click on Confirm.)



Another method can be used to set D1091: Determine which of slave stations 0 to 7 will not be needed, and set the corresponding bits to 0. For instance, if it is not necessary to control slave stations 2, 6 and 7, merely set D1091 = 003B, and the setting method is the same as described above: Use WPL to initiate communications > use register edit (T C D) function to perform settings.

Step 3: Set the master's communications station number and communications speed

- When setting the master's station number (Pr.09-46, default is set as 100), make sure not to use the same number as a slave station.
- Set the CANopen communications speed (Pr.09-37); regardless of whether the driver is defined as a master or slave station, the communications speed is set via this parameter.

### Step 4: Write program code

Real-time access: Can directly read / write to or from the corresponding D area.

Non real-time access:

#### Read command:

Use the CANRX command for reading. M1066 will be 1 when reading is complete; M1067 will be 1 if reading is successful, and M1067 will be 0 if an error has occurred.

#### Write command:

Use the CANTX command for writing. M1066 will be 1 when writing is complete; M1067 will be 1 if writing is successful, and M1067 will be 0 if an error has occurred.

#### Refresh command:

Use CANFLS command to refresh (if there are RW attributes, the master will write to the slave station; if there are RO attributes, the slave station will return the read values to the master); M1066 will be 1 if refresh has been completed; M1067 will be 1 if refresh is successful, and M1067 will be 0 if an error has occurred.

**NOTE:** When using CANRX, CANTX or CANFLS, internal implementation commands will wait until M1066 is completed before executing the next CANRX, CANTX or CANFLS.

Afterwards, download program to the driver (Please note that the PLC's default communications format is ASCII 7N2 9600, and the station number is 2. The WPL must therefore be modified, and the WPL setting pathway is settings > communications settings)

Step 5: Set the slave stations' station numbers, communications speed, control source, and command source

Delta's CFP2000 and EC series devices currently support the CANopen communications interface driver, and the corresponding slave station numbers and communications speed parameters are as follows:


	Corresponding de	Corresponding device parameters		Definition
	CFP2000	E-C	Value	Delimition
Slave station	Pr.09-36	Pr.09-20	0	Disable CANopen hardware interface
address	P1.09-30	P1.09-20	1–127	CANopen Communication address
			0	1 Mbps
			1	500 Kbps
Communication	Dr 00 27	Dr 00 24	2	250 Kbps
speed	Pr.09-37	Pr.09-21	3	125 Kbps
			4	100 Kbps
			5	50 Kbps

Delta's A2 Servo currently supports the CANopen communications interface, and the corresponding slave station numbers and communications speed parameters are as follows:

	Corresponding device parameters A2	Value	Definition
Slave station address	Pr.03-00	1–127	CANopen Communication address
		R = 0	125 Kbps
Communication		R = 1	250 Kbps
	Pr.03-01 bit8-11 XRXX	R = 2	500 Kbps
speed		R = 3	750 Kbps
		R = 4	1 Mbps
Control / command source	Pr.01-01	В	

Step 6: Connect hardware wiring

When performing wiring, note the head and tail terminal resistance; connection methods are as follows:



Step 7: Initiate control

After a program has been written and downloaded, switch the PLC mode to Run. Merely turn power to master and slave stations off and then on again.

Refer to CANMasterTest 1 vs. 2 driver.dvp

Example: CFP2000 driver one-to-two control

#### Step 1: Activating CANopen Master functions

- 1. Pr.09-45 = 1 (initiates Master functions); restart power after completing setting, the status bar on the KPC-CC01 digital keypad will display "CAN Master".
- 2. Pr.00-02 = 6 reset PLC (please note that this action will reset the program and PLC registers to the default values)
- 3. Turn power off and on again.
- 4. Use the KPC-CC01 digital keypad to set the PLC control mode as "PLC Stop" (if a newly-introduced driver is used, the blank internal PLC program will cause a PLFF warning code to be issued).

#### Step 2: Master memory correspondences

- 1. Enable WPL
- 2. Use keypad set PLC mode as Stop (PLC 2)
- 3. WPL read D1070 to D1099, D2000 to D2799
- 4. Set D2000=10 D2100 = 11
- 5. Set D2100 2200 2300 2400 2500 2600 2700 = 0
- 6. Download D2000 to D2799 settings

#### Step 3: Set the master's communications station number and communications speed

- 1. When setting the master's station number (Pr.09-46, default is set as 100), make sure not to use the same number as a slave station.
- 2. Set the CANopen communications speed as 1M (Pr.09-37 = 0); regardless of whether the driver is defined as a master or slave station, the communications speed is set via this parameter.

#### Step 4: Write program code

Real-time access: Can directly read / write to or from the corresponding D area.

Non real-time access:

#### Read command:

Use the CANRX command for reading. M1066 will be 1 when reading is complete; M1067 will be 1 if reading is successful, and M1067 will be 0 if an error has occurred.

#### Write command:

Use the CANTX command for writing. M1066 will be 1 when writing is complete; M1067 will be 1 if writing is successful, and M1067 will be 0 if an error has occurred.

#### Refresh command:

Use CANFLS command to refresh (if there are RW attributes, the master will write to the slave station; if there are RO attributes, the slave station will return the read values to the master); M1066 will be 1 if refresh has been completed; M1067 will be 1 if refresh is successful, and M1067 will be 0 if an error has occurred.

**NOTE:** When using CANRX, CANTX or CANFLS, internal implementation commands will wait until M1066 is completed before executing the next CANRX, CANTX or CANFLS.

Afterwards, download program to the driver (Please note that the PLC's default communications format is ASCII 7N2 9600, and the station number is 2. The WPL must therefore be modified, and the WPL setting pathway is settings > communications settings)


## Step 5: Set the slave stations' station numbers and communications speed

Slave station no. 1: Pr.09-37 = 0 (Speed 1M) Pr.09-36=10 (Node ID 10)

Slave station no. 2: Pr.09-37 = 0 (Speed 1M) Pr.09-36=10 (Node ID 11)

## Step 6: Connect hardware wiring

When performing wiring, note the head and tail terminal resistance; connection methods are as follows:



Step 7: Initiate control

After a program has been written and downloaded, switch the PLC mode to Run. Merely turn power to master and slave stations off and then on again.

Refer to CANMasterTest 1 vs. 2 driver.dvp

## 16-9 Explanation of Various PLC Speed Mode Controls

Speed mode supports SVC control. Under the speed mode of SVC control, it cannot be performed successfully unless finish motor parameter auto tuning ahead of time.

Control methods and settings are explained as follows:

#### Speed control

Register table for speed mode:

#### Control special M

Special M	Description of Function	Attributes
M1025	Driver frequency = set frequency (ON) / driver frequency =0 (OFF)	RW
M1026	Driver operating direction FWD (OFF) / REV (ON)	RW
M1040	Hardware power (Servo On)	RW
M1042	Quick stop	RW
M1044	Pause (Halt)	RW
M1052	Lock frequency (lock, frequency locked at the current operating frequency)	RW

#### Status special M

Special M	Description of Function	Attributes
M1015	Frequency attained (when used together with M1025)	RO
M1056	Servo On Ready	RO
M1058	On Quick Stopping	RO

#### Control special D

Special D	Description of Function	Attributes
D1060	Mode setting (speed mode is 0)	RW

## Status special D

Special D	Description of Function	Attributes
D1037	Converter output frequency (0.00–600.00)	RO
D1050	Actual operating mode (speed mode is 0)	RO

Speed mode control commands:

**FREQ (P)** S1 S2 S3

Target speed The first acceleration time setting The first deceleration time setting

## Example:

Before performing speed control, if the SVC control method is used, setting of electromechanical parameters must first be completed.

- 1. Setting D1060 = 0 will shift the converter to the speed mode (default).
- 2. Use the FREQ command to control frequency, acceleration time, and deceleration time.
- 3. Set M1040 = 1, the driver will now be excited, but the frequency will be 0.
- 4. Set M1025 = 1, the driver frequency command will now jump to the frequency designated by FREQ, and acceleration/deceleration will be controlled based on the acceleration time and deceleration time specified by FREQ.
- 5. M1052 can be used to lock the current operating frequency.

- 6. M1044 can be used to temporarily pause operation, and the deceleration method will comply with deceleration settings.
- 7. M1042 can be used to perform quick stop, and deceleration will be as quick as possible without giving rise to an error. (There may still be a jump error if the load is too large.)
- 8. Control user rights: M1040 (Servo ON) > M1042 (Quick Stop) > M1044(Halt) > M1052 (LOCK)

```
0
      M1002
                                               MOV
         11
                                                        K0
                                                               D1060
       start running forward (instantaneously)
                                                     control mode setup (0: speed)
6
                                        FREQ
         11
                                                 K3500
                                                          K100
                                                                 K200
        X<sub>0</sub>
14
                                        FREQ
         11
                                                 K4500
                                                          K40
                                                                 K50
                                                                (M1026)
                                                          running direction
        X1
H
                                                          of the motor drive FWD(OFF)
23
                                                                M1040)
                                                                Servo On
        X2
25
                                                                (M1025)
                                                        running direction of the
        X3
27
                                                        motor drive RUN(ON)STOP(OFF)
                                                                M1044)
29
        X4
         11
                                                                (M1052)
                                                                frequency locked
        X5
31
                                                                (M1042)
                                                                quick stop
33
                                                                 END
9999
```

#### 16-10 Internal Communications Main Node Control

The protocol has been developed in order to facilitate the use of 485 instead of CANopen in certain application situations. The 485 protocol offers similar real-time characteristics as CANopen. The maximum number of slave devices is 8.

Internal communications have a master-slave structure. The initiation method is very simple:

#### Slave device:


Set Pr.09-31 = -1 to -8 in order to access 8 nodes, and set Pr.00-20 = 1 to define the control source as 485 and access the reference sources that must be controlled, namely speed command (Pr.00-21 = 2). This will complete slave device settings. (PLC functions do not need to be activated)

#### System:

Setting the master is even simpler; it is only necessary to set Pr.09-31 = -10, and enable the PLC.

#### • Hardware wiring:

The master and slave stations are connected via the 485 serial port. The CFP2000 provide two types of 485 serial port interfaces, see the figure below: (please refer to Section 06 Control terminals concerning detailed terminal connections)



Master programming: In a program, D1110 can be used to define a slave station to be controlled (1–8, if set as 0, can jump between 8 stations). Afterwards, M1035 is set as 1, and the memory positions of the master and slave stations will correspond. At this time, it is only necessary to send commands to the correlation slave station address to control that station. The following is a register table connected with internal communications:

## Control special M

Special M	Description of Function	Attributes
M1035	Initiates internal communications control	RW

## Control special D

Special D	Description of Function			
	Internal node communications number 1-8 (set the station number of the slave station to			
D1110	be controlled)	RW		

	Description of	f Functio	n		Attributes
Special D	Definition	bit	User rights	Speed mode	
		0	4	Command functions	
		1	4	Reverse rotation requirements	
		2	4	-	
		3	3	Temporary pause	
	Internal node N control command	4	4	Frequency locking	╡
D1120+10×N		5	4	JOG	
		6	2	Quick Stop	
		7	1	Servo ON	
		11–8	4	Speed interval switching	
		13–12	4	Deceleration time change	
		14	4	Enable bit13–8	
		15	4	Clear error code	
D1121+10×N	Internal node N control mode			0	RW
D1122+10×N	Internal node N reference command L		_	Speed command (no number)	RW
D1123+10×N	Internal node N reference command H			-	RW

N = 0-7


## Status special D

Special D	Description of Function				
D1115	Internal node synchronizing cycle (ms)	RO			
D1116	Internal node error (bit0 = slave device 1, bit1 = slave device 2,bit7 = slave device 8)	RO			
D1117	Internal node online correspondence (bit0 = slave device 1, bit1 = slave device 2,bit7 = slave device 8)	RO			


Special D	Description of Function					
Special D	bit	Speed Mode				
	0	Frequency command arrival				
	1	Clockwise	]			
	ı	Counterclockwise:				
D1126+10×N	2	Warning	BO			
D1120+10*N	3	Error	RO			
	5	JOG				
	6	Quick Stop				
	7	Servo ON				
D1127+10×N		Actual frequency	RO			
D1128+10×N		-	KO			

**※** N = 0−7


Example: Assume it is desired to control slave station 1 operation at frequencies of 30.00 Hz and 60.00 Hz, status, and online node correspondences:



When it is judged that slave station 1 is online, delay 3 sec. and begin control



It is required slave station 1 maintain forward rotation at 30.00 Hz for 1 sec., and maintain reverse rotation at 60.00 Hz for 1 sec., and repeat this cycle continuously.



## 16-11 Modbus Remote IO Control Applications (use MODRW)

The CFP2000's internal PLC supports 485 read/write functions, which can be realized using the MODRW command. However, the 485 serial port must be defined as available for the PLC's 485 use before writing a program, and the Pr.09-31 must be set as -12. After completing settings, the standard functions defined by 485 can be used to implement read / write commands at other stations. Communications speed is defined by Pr.09-01, the communications format is defined by Pr.09-04, and the PLC's current station number is defined by Pr.09-35. The CFP2000 currently supports the functions read coil (0x01), read input (0x02), read register (0x03), write to single register (0x06), write to several coils (0x0F), and write to several registers (0x10). Explanations and the usage of these functions are provided as follows:


MODRW command							
S1	S2	S3	S4	S5	General	   Slave device is Delta's PLC meaning	Slave device is Delta's
Node ID	Command	Address	Return: D area	Length:	meaning Glave device is Bella 3 i 20 meaning		converter meaning
КЗ	H01	H500	D0	K18	Read coil (Bit)	Read 18 bits of data corresponding to slave station 3 PLC Y0 to Y21. This data is stored by bit 0 to 15 of this station's D0 and bit 0 to bit 3 of D1.	Does not support this function
КЗ	H02	H400	D10	K10	Read input (Bit)	Read 10 bits of data corresponding to slave station 3 PLC X0 to X11. This data is stored by bit 0 to 9 of this station's D10.	Does not support this function
К3	H03	H600	D20		(word)	Read 3 words of data corresponding to slave station 3 PLC T0 to T2. This data is stored by D20 to D22.	Read 3 words of data corresponding to slave station 3 converter parameters 06-00 to 06-02. This data is stored by D20 to D22
К3	H06	H610	D30	XX	Write to single register (word)	vvrite slave station 3 PLC's 116 to this	Write slave station 3 converter 06 to 16 parameter to this station's D30 value
КЗ	H0F	H509	D40		lmultinla coile	Write slave station 3 PLC's Y11 to Y22 to bit 0 to 9 of D40.	Does not support this function
КЗ	H10	H602	D50	KΔ			Write slave station 3 converter 06-02 to 06-05 parameters to this station's D50 to D53

NOTE: XX indicates doesn't matter

After implementing MODRW, the status will be displayed in M1077 (485 read / write complete), M1078 (485 read/write error), and M1079 (485 read / write time out). M1077 is defined so as to immediately revert to 0 after the MODRW command has been implemented. However, any of three situations—a report of no error, a data error report, or time out with no report—will cause the status of M1077 to change to ON.


Example program: Testing of various functions

At the start, will cause the transmitted time sequence to switch to the first data unit.



When the reported message indicates no error, it will switch to the next transmitted command

If time out occurs or an error is reported, the M1077 will change to ON. At this time, after a delay of 30 scanning cycles, it will re-issue the original command once



It will repeat after sending all commands

```
102 M5 MOV K1 K4M0
INC D1

121 END
```

## Practical applications:

Actual use to control the RTU-485 module.

Step 1: Set the communications format. Assume that the communications format is 115200, 8, N, 2, RTU CFP2000: The default PLC station number is set as 2 (Pr.09-35)


Pr.09-31 = -12 (COM1 is controlled by the PLC), Pr.09-01 = 115.2 (The communications speed is 115200)

Pr.09-04 = 13 (The format is 8, N, 2, RTU)

RTU485: The station number = 8 (give example)

ID7	ID6	ID5	ID4	ID3	ID2	ID1	ID0
0	0	0	0	1	0	0	0

PA3	PA2	PA1	PA0	DR2	DR1	DR0	A/R
1	0	0	0	1	1	1	0



Communication station #: ID0~ ID7 are defined as 2°, 2¹, 2²...26, 2<sup>7</sup>

## Communication protocol

PA3	PA2	PA1	PAO	A/R	Communication Protocol
OFF	OFF	OFF	OFF	ON	7,E,1 · ASCII
OFF	OFF	OFF	ON	ON	7,0,1 · ASCII
OFF	OFF	ON	OFF	ON	7,E,2 · ASCII
OFF	OFF	ON	ON	ON	7,0,2 · ASCII
OFF	ON	OFF	OFF	ON	7,N,2 · ASCII
OFF	ON	OFF	ON	ON	8,E,1 · ASCII
OFF	ON	ON	OFF	ON	8,O,1 · ASCII
OFF	ON	ON	ON	ON	8,N,1 · ASCII
ON	OFF	OFF	OFF	ON	8,N,2 · ASCII
OFF	ON	OFF	ON	OFF	8,E,1 - RTU
OFF	ON	ON	OFF	OFF	8,0,1 · RTU
OFF	ON	ON	ON	OFF	8,N,1 · RTU
ON	OFF	OFF	OFF	OFF	8,N,2 · RTU

DR2	DR1	DR0	Communication Speed
OFF	OFF	OFF	1,200 bps
OFF	OFF	ON	2,400 bps
OFF	ON	OFF	4,800 bps
OFF	ON	ON	9,600 bps
ON	OFF	OFF	19,200 bps
ON	OFF	ON	38,400 bps
ON	ON	OFF	57,600 bps
ON	ON	ON	115,200 bps

Step 2: Install control equipment. We sequentially connect a DVP16-SP (8 IN 8 OUT), DVP-04AD (4 channels AD), DVP02DA (2 channels DA), and DVP-08ST (8 switches) to the RTU485.


The following corresponding locations can be obtained from the RTU485's configuration definitions:


Module	Terminals	485 Address
DVP16-SP	X0-X7	0400H-0407H
DVF 10-3F	Y0-Y7	0500H-0507H
DVP-04AD	AD0-AD3	1600H-1603H
DVP02DA	DA0-DA1	1640H–1641H
DVP-08ST	Switch 0-7	0408H-040FH

Step 3: Physical configuration




Step 4: Write to PLC program






#### Step 5: Actual testing situation:

I/O testing: When the switch is activated, it can be discovered that the display corresponds to M115 - M108. Furthermore, it can be seen that one output point light is added every 1 sec. (the display uses a binary format)



## Chapter 16 PLC Function Applications | CFP2000

AD DA testing: It can be discovered that D200 and D201 are roughly twice of the D300, and continue to increase progressively. For their part, the D202 and D203 are roughly twice of the D301, and continue to decrease progressively.



### 16-12 Calendar Functions

Keypad (KPC-CC01) should be connected, or the CFP2000 cannot be used. Currently-support commands include TCMP (comparison of calendar data), TZCP (calendar data range comparison), TADD (calendar data addition), TSUB (calendar data subtraction), and TRD (calendar reading). Refer to the explanation of relevant commands and functions for the usage of these commands.

In real applications, the internal PLC can judge whether calendar function have been activated; if they have been activated, calendar warning codes may be displayed in some situations. The basis for whether a calendar function has been activated is whether the program has written the calendar time (D1063 to D1069) in connection with the foregoing calendar commands or programs.

The calendar's time display is currently assigned to D1063 to D1069, and is defined as follows:

Special D	Item	Content	Attributes
D1063	Year (Western)	20xx (2000–2099)	RO
D1064	Weeks	1–7	RO
D1065	Month	1–12	RO
D1066	Day	1–31	RO
D1067	Hour	0–23	RO
D1068	Minute	0–59	RO
D1069	Second	0–59	RO

Calendar-related special M items are defined as follows:

Special D	Item	Attributes
M1068	Calendar time error	RO
M1076	Calendar time error or refresh time out	RO
M1036	Ignore calendar warning	RW

#### NOTE:

- When a program writes to the commands TCMP, TZCP, TADD, or TSUB, if it is discovered that a value exceeds the reasonable range, M1026 will be 1.
- 2. When the keypad display is PLra (RTC correction warning) or PLrt (RTC time out warning), M1076 will be ON.
- 3. When M1036 is 1, the PLC will ignore the calendar warning.

Calendar trigger warning code is defined as follows:

Warning	Description	Reset approach	Affects PLC operation
PLra	Calendar time correction	Restart power	No
PLrt	Calendar time refresh time out	Restart power	No

#### NOTE:


- 1. When the PLC's calendar functions are operating, if the keypad is replaced with another keypad, it will jump to PLra.
- 2. When it is discovered at startup that the keypad has not been powered for more than 7 days, or the time is wrong, PLra will be triggered.
- 3. When it is discovered that the CFP2000 has no keypad in 10 sec. after start up, PLrt will be triggered.
- 4. If the keypad is suddenly pulled out while the calendar is operating normally, and is not reconnected in 1 minute, PLrt will be triggered.

#### Chapter 16 PLC Function Applications | CFP2000


Practical applications:

We will perform a demo of simple applications.

We first correct the keypad time. After pressing Menu on the keypad, select the 9th time setting option. After selection, set the current time.



We set converter on during the period of 8:00–17:20, which allows us to write the following example



# Chapter 17 Introduction to BACnet

- 17-1 About BACnet
- 17-2 CFP2000 BACnet-Object and Property
- 17-3 Steps to setup the Parameters about BACnet in CFP2000
- 17-4 BACnet Protocol Implementation Conformance Statement

## 17-1 About BACnet

**BACnet** is an ASHRAE communication protocol for **b**uilding **a**utomation and **c**ontrol **net**works.

(ASHRAE: **A**merican **S**ociety of **H**eating, **R**efrigerating and Air-Conditioning **E**ngineers, Inc.). CFP2000's BACnet is based on version 2004.

BACnet's regulations are related to several kinds of physical layers' interfaces. The physical layer built inside CFP2000 is achieved via MS/TP interface.

The BACnet of CFP2000 supports a device type called B-ASC. B-ASC supports six types of services such as DS-RP-B, DS-RPM-B, DS-WP-B, DM-DDB-B, DM-DOB-B and DM-DCC-B.

# 17-2 CFP2000 BACnet-Object and Property

In CFP2000, BACnet supports 3 object types: Device, AnalogValue (AV) and BinaryValue (BV). In each object type, we have the following table to show the Properties list:

Droporty ID			Object Type			
	Property ID	Device	Analog Value	Binary Value		
#4	ACTIVE TEXT			V		
#11	APDU_TIMEOUT	V				
#12	APPLICATION_SOFTWARE_VERSION	V				
#28	DESCRIPTION	V	V	V		
#30	DEVICE ADDRESS BINDING	V	V			
#36	EVENT STATE		V	V		
#44	FIRMWARE_REVISION	V				
#46	INACTIVE TEXT			V		
#62	MAX_APDU_LENGTH_ACCEPTED	V				
#63	MAX_INFO_FRAMES	V				
#64	MAX_MASTER	V				
#70	MODEL_NAME	V				
#73	NUMBER_OF_APDU_RETRIES	V				
#75	OBJECT_IDENTIFIER	V *1	V	V		
#76	OBJECT_LIST	V				
#77	OBJECT_NAME	V *1	V	V		
#79	OBJECT_TYPE	V	V	V		
#81	OUT OF SERVICE		V	V		
#85	PRESENT VALUE		V *2	V *2		
#87	PRIORITY ARRAY		V *3	V *3		
#96	PROTOCOL_OBJECT_TYPES_SUPPORTED	V				
#97	PROTOCOL_SERVICES_SUPPORTED	V				
#98	PROTOCOL_VERSION	V				
#104	RELINQUISH DEFAULT		V *3	V *3		
#107	SEGMENTATION_SUPPORTED	V				
#111	STATUS FLAGS		V	V		
#112	SYSTEM_STATUS	V				

	Proporty ID	Object Type			
	Property ID	Device	Analog Value	Binary Value	
#117	UNITS		V		
#120	VENDOR_IDENTIFIER	V			
#121	VENDOR_NAME	V			
#139	PROTOCOL_REVISION	V			
#155	DATABASE_REVISION	V			

<sup>\*1.</sup> The Object ID and Object Name Properties of Device are writeable.

## The AV objects, we have commandable and readonly cases.

- Commendable case: We can use Write\_Service to access the Present\_Value property of commandable AV objects. Thus, the commandable AV objects are linking to the Control\_Word and Pr Word in CFP2000.
- Readonly case: We can use Read\_Service to access the Present\_Value property of readonly AV objects. Thus, these readonly AV objects are linking to the Status\_Word in CFP2000.

#### The BV objects, we also have commandable and readonly cases.

- Commandable case: We can use Write\_Service to access the Present\_Value property of commendable BV objects. Thus, the commandable BV objects are linking to the Control\_Bit in CFP2000.
- Readonly case: We can use Read\_Service to access the Present\_Value property of readonly BV objects. Thus, these readonly BV objects are linking to the Status Bit in CFP2000.

# 17-2-1 Commandable Analog Value Object

In CFP2000, we have AV\_000–AV\_026 supporting commandable Present\_Value property. For these AV\_Objects, we also can use (Multi) Read\_Service to access Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description	Unit
AV 000	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 001	RW	FreqRefValue	Frequency Reference Value	UNITS_HERTZ
AV 002	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 003	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 004	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 005	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 006	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 007	RW	Reserved	Reserved	UNITS_NO_UNITS
800 VA	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 009	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 010	RW	Reserved	Reserved	UNITS_NO_UNITS

<sup>\*2.</sup> The Present\_Value Property of some AV and BV objects is commandable.

<sup>\*3.</sup> Only Commandable objects support Priority Array and Relinquish Default.

Object Number	R/W	Object Name	Object Description	Unit
AV 011	RW	(P9-11 map set)	AV11 will modify data which is P9-11 mapping to	Depends
AV 012	RW	(P9-12 map set)	AV12 will modify data which is P9-12 mapping to	Depends
AV 013	RW	(P9-13 map set)	AV13 will modify data which is P9-13 mapping to	Depends
AV 014	RW	(P9-14 map set)	AV14 will modify data which is P9-14 mapping to	Depends
AV 015	RW	(P9-15 map set)	AV15 will modify data which is P9-15 mapping to	Depends
AV 016	RW	(P9-16 map set)	AV16 will modify data which is P9-16 mapping to	Depends
AV 017	RW	(P9-17 map set)	AV17 will modify data which is P9-17 mapping to	Depends
AV 018	RW	(P9-18 map set)	AV18 will modify data which is P9-18 mapping to	Depends
AV 019	RW	(P9-19 map set)	AV19 will modify data which is P9-19 mapping to	Depends
AV 020	RW	(P9-20 map set)	AV20 will modify data which is P9-20 mapping to	Depends
AV 021	RW	(P9-21 map set)	AV21 will modify data which is P9-21 mapping to	Depends
AV 022	RW	(P9-22 map set)	AV22 will modify data which is P9-22 mapping to	Depends
AV 023	RW	(P9-23 map set)	AV23 will modify data which is P9-23 mapping to	Depends
AV 024	RW	(P9-24 map set)	AV24 will modify data which is P9-24 mapping to	Depends
AV 025	RW	(P9-25 map set)	AV25 will modify data which is P9-25 mapping to	Depends
AV 026	RW	(P9-26 map set)	AV26 will modify data which is P9-26 mapping to	Depends

# 17-2-2 Status (Readonly) Analog Value Object

In CFP2000, we have AV\_027–AV\_068 with readonly Present\_Value property. For these AV\_Objects, we do NOT have Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description	Unit
AV 027	R	Reserved	Reserved	UNITS_NO_UNITS
AV 028	R	Reserved	Reserved	UNITS_NO_UNITS
AV 029	R	Reserved	Reserved	UNITS_NO_UNITS
AV 030	R	Reserved	Reserved	UNITS_NO_UNITS
AV 031	R	Output frequency	Display output frequency (Hz)	UNITS_HERTZ
AV 032	R	Reserved	Reserved	UNITS_NO_UNITS
AV 033	R	Reserved	Reserved	UNITS_NO_UNITS
AV 034	R	Reserved	Reserved	UNITS_NO_UNITS
AV 035	R	Output torque (%)	Display output torque (%)	UNITS_PERCENT
AV 036	R	Reserved	Reserved	UNITS_NO_UNITS
AV 037	R	Reserved	Reserved	UNITS_NO_UNITS
AV 038	R	Reserved	Reserved	UNITS_NO_UNITS
AV 039	R	Status word	Display status word,made from BV16–BV31	UNITS_NO_UNITS
AV 040	R	Reserved	Reserved	UNITS_NO_UNITS
AV 041	R	Driver type code	Driver type code	UNITS_NO_UNITS
AV 042	R	Warn code	Warn code	UNITS_NO_UNITS
AV 043	R	Error code	Error code	UNITS_NO_UNITS

Object Number	R/W	Object Name	Object Description	Unit
AV 044	R	Output current	Display output current (Amp)	UNITS_AMPERES
AV 045	R	DC-bus voltage	Display DC bus voltage (Volt)	UNITS_VOLTS
AV 046	R	Output Voltage	Display output voltage of U, V, W (Volt)	UNITS_VOLTS
AV 047	R	Count Value	Display counter value of TRG terminal	UNITS_NO_UNITS
AV 048	R	Power Angle	Display output power angle of U, V, W	UNITS_POWER_FA CTOR
AV 049	R	Output Power	Display actual output power of U, V, W (kW)	UNITS_KILOWATTS
AV 050	R	IGBT temperature	Display the IGBT temperature	UNITS_DEGREES_ CELSIUS
AV 051	R	Temperature of driver	Display the temperature of capacitance	UNITS_DEGREES_ CELSIUS
AV 052	R	Real carry frequency	Display real carrier frequency of the drive (kHz)	UNITS_KILOHERTZ
AV 053	R	PID feedback value (%) value		UNITS_PERCENT
AV 054	R	Overload rate	Display overload condition (%)	UNITS_PERCENT
AV 055	R	Ground fail detect	Display GND fail detect level (%)	UNITS_PERCENT
AV 056	R	DC bus ripple	Display DC bus voltage ripples (Volt)	UNITS_VOLTS
AV 057	R	Fan Speed	Fan speed of the drive (%)	UNITS_PERCENT
AV 058	R	Output speed(rpm)	Output speed(rpm)	UNITS_REVOLUTIO  NS_PER_MINUTE
AV 059	R	KW per Hour	kW per Hour	UNITS_KILOWATTS
AV 060	R	Multi-speed switch	Real multi-speed switch	UNITS_NO_UNITS
AV 061	R	AVI1 input value	0–10 V corresponds to 0–100%	UNITS_PERCENT
AV 062	R	ACI input value	4–20 mA / 0–10 V corresponds to 0–100%	UNITS_PERCENT
AV 063	R	AVI2 input value	0 V-10 V corresponds to 0-100%	UNITS_PERCENT
AV 064	R	Digital input status	Refer to Pr.02-12	UNITS_NO_UNITS
AV 065	R	Digital output status	Refer to Pr.02-18	UNITS_NO_UNITS
AV 066	R	CPU pin status of DI	Corresponding CPU pin status of digital input	UNITS_NO_UNITS
AV 067	R	CPU pin status of DO	Corresponding CPU pin status of digital output	UNITS_NO_UNITS
AV 068	R	PLC D1043 value	PLC D1043 value	UNITS_NO_UNITS

## 17-2-3 Commandable Binary Value Object

In CFP2000, we have BV\_000–BV\_015 supporting commandable Present\_Value property. For these BV\_Objects, we also can use (Multi) Read\_Service to access Priority\_Array and Relinquish Default properties.

Object	R/W	Object Name	Object Description
Number		,	
BV 000	RW	ACTIVE CMD	(0)FreqCmd=0;(1)FreqCmd=FreqRefValue
BV 001	RW	FWD/REV CMD	(0)Forward; (1)Reverse
BV 002	RW	Reserved	Reserved
BV 003	RW	HALT CMD	(0)None;(1)RampDown to 0 Hz.
BV 004	RW	LOCK CMD	(0)None;(1)OutputFreq stays at current frequency
BV 005	RW	Reserved	Reserved
BV 006	RW	QSTOP CMD	(0)None;(1)Force driver quick stop
BV 007	RW	ServoPower CMD	(0)PowerOff(free run to stop);(1)PowerOn
BV 008	RW	Reserved	Reserved
BV 009	RW	Reserved	Reserved
BV 010	RW	Reserved	Reserved
BV 011	RW	Reserved	Reserved
BV 012	RW	Reserved	Reserved
BV 013	RW	Reserved	Reserved
BV 014	RW	Reserved	Reserved
BV 015	RW	RESET	RESET:(0)Do nothing;(1)Reset fault

## 17-2-4 Status (Readonly) Binary Value Object

In CFP2000, we have BV\_016–BV\_031 with readonly Present\_Value property. For these BV\_Objects, we do NOT have Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description
BV 016	R	ARRIVE STATE	(0)Not yet;(1)Arrive (OutputFreq=FreqCmd)
BV 017	R	FWD/REV STATE	(0)Forward;(1)Reverse
BV 018	R	WARN STATE	(0)No Warn;(1)Occur Warn
BV 019	R	ERROR STATE	(0)No Error;(1)Occur Error
BV 020	R	Reserved	Reserved
BV 021	R	Reserved	Reserved
BV 022	R	QSTOP STATE	(0)No QSTOP;(1)Occur QSTOP
BV 023	R	ServoPower STATE	(0)PowerOff(free run to stop);(1)PowerOn
BV 024	R	Reserved	Reserved
BV 025	R	Reserved	Reserved
BV 026	R	Reserved	Reserved
BV 027	R	Reserved	Reserved
BV 028	R	Reserved	Reserved

# Chapter 17 Introduction to BACnet $\mid$ CFP2000

Object Number	R/W	Object Name	Object Description
BV 029	R	Reserved	Reserved
BV 030	R	Reserved	Reserved
BV 031	R	Reserved	Reserved

## 17-3 Steps to setup the Parameters about BACnet in CFP2000

Related to BACnet function in CFP2000, We have to configure 2 parts of parameters

Part1. Setup parameters related to Communication at Pr Group9.

Part2. Setup parameters related to System Parameter at Pr Group0.

## Part1. Pr\_Group9, Communication.

1. Set Pr.09-31 = 1, BACnet is enabled, then the COM1\_Port will be accessed by BACnet. When this is set, the COM1\_Port communication format will be changed to RTU 8, N, 1.

(**NOTE:** The HW Pins of COM1\_Port are shared by RJ45 and RS-485. When BACnet is enabled, BACnet will access the COM1\_Port, that also means we can **NOT** have Modbus, PLC connections, VFDSoft and VFD Explorer by COM1\_Port).

- 2. Set Pr.09-50, Default = 10, BACnet's MS/TP station number 0–127
- 3. Set Pr.09-51, Default = 38400, BACnet communication baud rate, 9600, 19200, 38400 or 76800 bps.
- 4. Set Pr.09-52 and Pr.09-53, the default setting of Device Object\_Identifier is 0x000A (Pr.09-52 = 10, Pr.09-53 = 00). Device Object\_Identifier is the combination of Pr.09-52 and Pr.09-53, thus the setting range can be 0–4194303.
  - For example, Pr.09-53 = 12(0x0C) and Pr.09-52 = 3456(0x0D80), then the device Identifier's value =  $12 \times 65536 + 3456 = 789888 (0x0C0D80)$ .
- 5. Set Pr.09-55, Default =127, the highest allowable address for master nodes on the same MS/TP network. CFP2000 base on this setting to know the Max search range.
- 6. Set Pr.09-56, setup the BACnet password. If setup is successful, the keypad will display 8888.

#### Part2. Pr Group0, System Parameter.

- 1. Set Pr.00-20 = 1, that means the source of the Frequency command is from RS-485 Interface (accessed by BACnet).
- 2. Set Pr.00-21 = 2, that means the source of the Operation command is from RS-485 Interface (accessed by BACnet).

#### Here is a simple example:


After setting up the 2 parts of Pr, we can enable the BACnet function in CFP2000. Thus, we can access some BACnet objects to make the CFP2000 driving motor Run or Stop.

Step1. Write Service on AV 001, Present Value =60.0 → Setup Frequency Reference Value.

Step2. Write\_Service on BV\_007, Present\_Value =Active. → Setup Servo Power CMD.

Step3. Write Service on BV 000, Present Value =Active. → Setup Active CMD.

Step4. Read\_Service on AV\_031, Present\_Value → User can know the Output frequency.




**NOTE:** In CFP2000, based on different Pr setting or IO setting, we can make FreqCmd with different source of Reference Value. Please check the usage of Keypad, Pr and IO setting for more detail information.

• Connection of the communication cable as shown in the below diagram.

Please note that HW Pins of COM1\_Port are shared by RJ45 and RS-485. That means user can use RJ45 cable or RS-485 lines to access the COM1\_Port.

When BACnet is enabled, COM1\_Port will be dominated by BACnet function. Under this condition, user will not be able to have Modbus VFD Soft, VFD Explorer or PLC function on COM1\_Port.



**Date**: July 24, 2014

# 17-4 BACnet Protocol Implementation Conformance Statement

# **BACnet Protocol Implementation Conformance Statement**

Vendor Name: Delta Electronics, Inc.			
Product Name: CFP2000			
Product Model Number: CFP2000			
Applications Software Version: Ver 01.04- yyyymm	Firmware Revision:	Ver 01.04	<b>BACnet Protocol</b>
Revision: 7			
Product Description:			
Delta CFP2000 is a Variable Frequency AC motor Drive	with BACnet embedded		
In CFP2000, the BACnet connection is by MS/TP, RS-4	85-based. CFP2000 pr	ovides a BA0	Cnet communication
function that permits it as a server and supports BIBBs	defined by the BACnet	B-ASC.	
CFP2000 BACnet provides the capability to control and	monitor the CFP2000 r	machine.	
BACnet Standardized Device Profile (Annex L):			
☐ BACnet Operator Workstation (B-OWS)_			
☐ BACnet Building Controller (B-BC)			
☐ BACnet Advanced Application Controller (B-AAC	)_		
■ BACnet Application Specific Controller (B-ASC)			
□ BACnet Smart Sensor (B-SS)			
☐ BACnet Smart Actuator (B-SA)			
List all BACnet Interoperability Building Blocks Sup	pported (Annex K):		
Data Sharing BIBBs			
Data Sharing-ReadProperty-B (DS-RP-B)			
Data Sharing-WriteProperty-B (DS-WP-B)			
Data Sharing-ReadPropertyMultiple-B (DS-RPM-B)			
Device and Network Management BIBBs			
Device Management-Dynamic Device Binding-B (DM-D	DDB-B)		
Device Management-Dynamic Object Binding-B (DM-D	OB-B)		
Device Management-DeviceCommunicationControl-B (	DM-DCC-B)		
Segmentation Capability:			
☐ Segmented requests supported Window Size _			
☐ Segmented responses supported Window Size			
Standard Object Types Supported:			
Analog Value			
Binary Value			
Device			

Object instantiation is static. Refer to table at end of this document for object details.

Data Link Layer Options:			
☐ BACnet IP, (Annex J)			
☐ BACnet IP, (Annex J), Fo	reign Device		
☐ ISO 8802-3, Ethernet (Cl	ause 7)		
☐ ANSI/ATA 878.1, 2.5 Mb.	ARCNET (Clause 8)		
☐ ANSI/ATA 878.1, RS-485	ARCNET (Clause 8), baud rate(s)	3)	
■ MS/TP master (Clause 9)	), baud rate(s): <u>9600, 19200, 3840</u>	00, 76800	
☐ MS/TP slave (Clause 9),	baud rate(s):		
□ Point-To-Point, EIA 232 (	Clause 10), baud rate(s):		
□ Point-To-Point, modem, (	Clause 10), baud rate(s):		
□ LonTalk, (Clause 11), me	dium:		
☐ Other:			
Device Address Binding:			
Is static device binding supp	oorted? (This is currently necessar	ary for two-way communication with MS/TP slaves a	nd
certain other devices.) □Ye	s ■No		
Networking Options:			
☐ Router, Clause 6 - List al	I routing configurations, e.g., ARCI	NET-Ethernet, Ethernet-MS/TP, etc.	
☐ Annex H, BACnet Tunnel	ing Router over IP		
☐ BACnet/IP Broadcast Ma	nagement Device (BBMD)		
Does the BBMD support reg	gistrations by Foreign Devices?	∃Yes □ No	
Character Sets Supported	l:		
Indicating support for multip	le character sets does not imply th	that they can all be supported simultaneously.	
■ ANSI X3.4	☐ IBM <sup>™</sup> /Microsoft <sup>™</sup> DBCS	□ ISO 8859-1	
□ ISO 10646 (UCS-2)	☐ ISO 10646 (UCS-4)	□ JIS C 6226	
If this product is a commu	unication gateway, describe the	types of non-BACnet equipment/networks(s) th	at
the gateway supports:			

# The Properties of Objects

Dronesti ID			Object Type			
	Property ID		Analog Value	Binary Value		
#4	ACTIVE TEXT			V		
#11	APDU_TIMEOUT	V				
#12	APPLICATION_SOFTWARE_VERSION	V				
#28	DESCRIPTION	V	V	V		
#30	DEVICE ADDRESS BINDING	V	V			
#36	EVENT STATE		V	V		
#44	FIRMWARE_REVISION	V				
#46	INACTIVE TEXT			V		
#62	MAX_APDU_LENGTH_ACCEPTED	V				
#63	MAX_INFO_FRAMES	V				
#64	MAX_MASTER	V				
#70	MODEL_NAME	V				
#73	NUMBER_OF_APDU_RETRIES	V				
#75	OBJECT_IDENTIFIER	V *1	V	V		
#76	OBJECT_LIST	V				
#77	OBJECT_NAME	V *1	V	V		
#79	OBJECT_TYPE	V	V	V		
#81	OUT OF SERVICE		V	V		
#85	PRESENT VALUE		V *2	V *2		
#87	PRIORITY ARRAY		V *3	V *3		
#96	PROTOCOL_OBJECT_TYPES_SUPPORTED	V				
#97	PROTOCOL_SERVICES_SUPPORTED	V				
#98	PROTOCOL_VERSION	V				
#104	RELINQUISH DEFAULT		V *3	V *3		
#107	SEGMENTATION_SUPPORTED	V				
#111	STATUS FLAGS		V	V		
#112	SYSTEM_STATUS	V				
#117	UNITS		V			
#120	VENDOR_IDENTIFIER	V	V			
#121	VENDOR_NAME	E V				
#139	PROTOCOL_REVISION	V				
#155	DATABASE_REVISION	V				

<sup>\*1.</sup> The Object\_ID and Object\_Name Properties of Device are writeable.

<sup>\*2.</sup> The Present\_Value Property of some AV and BV objects are commandable.

<sup>\*3.</sup> Only Commandable objects support Priority\_Array and Relinquish\_Default.

# • Commandable Analog Value Object

In CFP2000, we have AV\_000–AV\_026 supporting commandable Present\_Value property. In these AV\_Objects, we also can use (Multi) Read\_Service to access Priority\_Array and Relinquish\_Default properties.

propertie	· · · · · · · · · · · · · · · · · · ·			
Object Number	R/W	Object Name	Object Description	Unit
AV 000	RW	AV_000_Reserved	Reserved	UNITS_NO_UNITS
AV 001	RW	AV_001_FreqRefValue	Frequency Reference Value	UNITS_HERTZ
AV 002	RW	AV_002_Reserved	Reserved	UNITS_NO_UNITS
AV 003	RW	AV_003_Reserved	Reserved	UNITS_NO_UNITS
AV 004	RW	AV_004_Reserved	Reserved	UNITS_NO_UNITS
AV 005	RW	AV_005_Reserved	Reserved	UNITS_NO_UNITS
AV 006	RW	AV_006_Reserved	Reserved	UNITS_NO_UNITS
AV 007	RW	AV_007_Reserved	Reserved	UNITS_NO_UNITS
AV 008	RW	AV_008_Reserved	Reserved	UNITS_NO_UNITS
AV 009	RW	AV_009_Reserved	Reserved	UNITS_NO_UNITS
AV 010	RW	AV_010_Reserved	Reserved	UNITS_NO_UNITS
AV 011	RW	AV_011_P9-11 map set=	AV11 will modify data which is P9-11 mapping to	Depends
AV 012	RW	AV_012_P9-12 map set=	AV12 will modify data which is P9-12 mapping to	Depends
AV 013	RW	AV_013_P9-13 map set=	AV13 will modify data which is P9-13 mapping to	Depends
AV 014	RW	AV_014_P9-14 map set=	AV14 will modify data which is P9-14 mapping to	Depends
AV 015	RW	AV_015_P9-15 map set=	AV15 will modify data which is P9-15 mapping to	Depends
AV 016	RW	AV_016_P9-16 map set=	AV16 will modify data which is P9-16 mapping to	Depends
AV 017	RW	AV_017_P9-17 map set=	AV17 will modify data which is P9-17 mapping to	Depends
AV 018	RW	AV_018_P9-18 map set=	AV18 will modify data which is P9-18 mapping to	Depends
AV 019	RW	AV_019_P9-19 map set=	AV19 will modify data which is P9-19 mapping to	Depends
AV 020	RW	AV_020_P9-20 map set=	AV20 will modify data which is P9-20 mapping to	Depends
AV 021	RW	AV_021_P9-21 map set=	AV21 will modify data which is P9-21 mapping to	Depends
AV 022	RW	AV_022_P9-22 map set=	AV22 will modify data which is P9-22 mapping to	Depends
AV 023	RW	AV_023_P9-23 map set=	AV23 will modify data which is P9-23 mapping to	Depends
AV 024	RW	AV_024_P9-24 map set=	AV24 will modify data which is P9-24 mapping to	Depends
AV 025	RW	AV_025_P9-25 map set=	AV25 will modify data which is P9-25 mapping to	Depends
AV 026	RW	AV_026_P9-26 map set=	AV26 will modify data which is P9-26 mapping to	Depends

Status (Readonly) Analog Value Object
In CFP2000, we have AV\_027–AV\_068 with readonly Present\_Value property. In these AV\_Objects,
we do NOT have Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description	Unit
AV 027	R	AV_027_Reserved	Reserved	UNITS_NO_UNITS
AV 028	R	AV_028_Reserved	Reserved	UNITS_NO_UNITS
AV 029	R	AV_029_Reserved	Reserved	UNITS_NO_UNITS
AV 030	R	AV_030_Reserved	Reserved	UNITS_NO_UNITS
AV 031	R	AV_031_Output frequency	Display output frequency (Hz)	UNITS_HERTZ
AV 032	R	AV_032_Reserved	Reserved	UNITS_NO_UNITS
AV 033	R	AV_033_Reserved	Reserved	UNITS_NO_UNITS
AV 034	R	AV_034_Reserved	Reserved	UNITS_NO_UNITS
AV 035	R	AV_035_Output torque (%)	Display output torque (%)	UNITS_PERCENT
AV 036	R	AV_036_Reserved	Reserved	UNITS_NO_UNITS
AV 037	R	AV_037_Reserved	Reserved	UNITS_NO_UNITS
AV 038	R	AV_038_Reserved	Reserved	UNITS_NO_UNITS
AV 039	R	AV_039_Status word	Display status word,made from BV16–BV31	UNITS_NO_UNITS
AV 040	R	AV_040_Reserved	Reserved	UNITS_NO_UNITS
AV 041	R	AV_041_Driver type code	Driver type code	UNITS_NO_UNITS
AV 042	R	AV_042_Warn code	Warn code	UNITS_NO_UNITS
AV 043	R	AV_043_Error code	Error code	UNITS_NO_UNITS
AV 044	R	AV_044_Output current	Display output current (Amp)	UNITS_AMPERES
AV 045	R	AV_045_DC bus voltage	Display DC bus voltage (Volt)	UNITS_VOLTS
AV 046	R	AV_046_Output Voltage	Display output voltage of U, V, W (Volt)	UNITS_VOLTS
AV 047	R	AV_047_Count Value	Display counter value of TRG terminal	UNITS_NO_UNITS
AV 048	R	AV_048_Power Angle	Display output power angle of U, V, W	UNITS_POWER_FACT OR
AV 049	R	AV_049_Output Power	Display actual output power of U, V, W (kW)	UNITS_KILOWATTS
AV 050	R	AV_050_IGBT temperature	Display the IGBT temperature	UNITS_DEGREES_CE LSIUS
AV 051	R	AV_051_Temperature of driver	Display the temperature of capacitance	UNITS_DEGREES_CE LSIUS
AV 052	R	AV_052_Real carry frequency	Display real carrier frequency of the drive (kHz)	UNITS_KILOHERTZ
AV 053	R	AV_053_PID feedback value	Display PID feedback value (%)	UNITS_PERCENT
AV 054	R	AV_054_Overload rate	Display overload condition (%)	UNITS_PERCENT
AV 055	R	AV_055_Ground fail detect level	Display GND fail detect level (%)	UNITS_PERCENT
AV 056	R	AV_056_DC bus ripple	Display DC bus voltage ripples (Volt)	UNITS_VOLTS
AV 057	R	AV_057_Fan Speed	Fan speed of the drive (%)	UNITS_PERCENT
AV 058	R	AV_058_Output speed (rpm)	Output speed (rpm)	UNITS_REVOLUTION S_PER_MINUTE

Object Number	R/W	Object Name	Object Description	Unit
AV 059	R	AV_059_kW per Hour	kW per Hour	UNITS_KILOWATTS
AV 060	R	AV_060_Multi-speed switch	Real multi-speed switch	UNITS_NO_UNITS
AV 061	R	AV_061_AVI1 input value	0–10 V corresponds to 0–100%	UNITS_PERCENT
AV 062	R	AV_062_ACI input value	4–20 mA / 0–10 V corresponds to 0–100%	UNITS_PERCENT
AV 063	R	AV_063_AVI2 input value	0 V-10 V corresponds to 0-100%	UNITS_PERCENT
AV 064	R	AV_064_Digital input status	Refer to Pr.02-12	UNITS_NO_UNITS
AV 065	R	AV_065_Digital output status	Refer to Pr.02-18	UNITS_NO_UNITS
AV 066	R	AV_066_CPU pin status of DI	Corresponding CPU pin status of digital input	UNITS_NO_UNITS
AV 067	R	AV_067_CPU pin status of DO	Corresponding CPU pin status of digital output	UNITS_NO_UNITS
AV 068	R	AV_068_PLC D1043 value	PLC D1043 value	UNITS_NO_UNITS

# Commandable Binary Value Object

In CFP2000, we have BV\_000–BV\_015 supporting commandable Present\_Value property. In these BV\_Objects, we also can use (Multi) Read\_Service to access Priority\_Array and Relinquish\_Default properties.

properties	•		
Object Number	R/W	Object Name	Object Description
BV 000	RW	BV_000_ACTIVE CMD	(0)FreqCmd=0;(1)FreqCmd=FreqRefValue
BV 001	RW	BV_001_FWD/REV CMD	(0)Forward; (1)Reverse
BV 002	RW	BV_002_Reserved	Reserved
BV 003	RW	BV_003_HALT CMD	(0)None;(1)RampDown to 0Hz.
BV 004	RW	BV_004_LOCK CMD	(0)None;(1)OutputFreq stays at current frequency
BV 005	RW	BV_005_Reserved	Reserved
BV 006	RW	BV_006_QSTOP CMD	(0)None;(1)Force driver quick stop
BV 007	RW	BV_007_ServoPower CMD	(0)PowerOff(free run to stop);(1)PowerOn
BV 008	RW	BV_008_Reserved	Reserved
BV 009	RW	BV_009_Reserved	Reserved
BV 010	RW	BV_010_Reserved	Reserved
BV 011	RW	BV_011_Reserved	Reserved
BV 012	RW	BV_012_Reserved	Reserved
BV 013	RW	BV_013_Reserved	Reserved
BV 014	RW	BV_014_Reserved	Reserved
BV 015	RW	BV_015_RESET	RESET:(0)Do nothing;(1)Reset fault

## Chapter 17 Introduction to BACnet | CFP2000

Status (Readonly) Binary Value Object
 In CFP2000, we have BV\_016-BV\_031 with readonly Present\_Value property. In these BV\_Objects, we do NOT have Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description
BV 016	R	BV_016_ARRIVE STATE	(0)Not yet;(1)Arrive (OutputFreq=FreqCmd)
BV 017	R	BV_017_FWD/REV STATE	(0)Forward;(1)Reverse
BV 018	R	BV_018_WARN STATE	(0)No Warn;(1)Occur Warn
BV 019	R	BV_019_ERROR STATE	(0)No Error;(1)Occur Error
BV 020	R	BV_020_Reserved	Reserved
BV 021	R	BV_021_Reserved	Reserved
BV 022	R	BV_022_QSTOP STATE	(0)No QSTOP;(1)Occur QSTOP
BV 023	R	BV_023_ServoPower STATE	(0)PowerOff(free run to stop);(1)PowerOn
BV 024	R	BV_024_Reserved	Reserved
BV 025	R	BV_025_Reserved	Reserved
BV 026	R	BV_026_Reserved	Reserved
BV 027	R	BV_027_Reserved	Reserved
BV 028	R	BV_028_Reserved	Reserved
BV 029	R	BV_029_Reserved	Reserved
BV 030	R	BV_030_Reserved	Reserved
BV 031	R	BV_031_Reserved	Reserved

# Chapter 18 Safe Torque Off Function

- 18-1 The Drive Safety Function Failure Rate
- 18-2 Safe Torque Off Terminal Function Description
- 18-3 Wiring Diagram
- 18-4 Parameter
- 18-5 Operating Sequence Description
- 18-6 New Error Code for STO Function

# **18-1 The Drive Safety Function Failure Rate**

Item	Definition	Standard	Performance	
STO	Safe Torque Off	EN 61508	Channel 1: 80.08%	
310	Sale lorque Oil	LIN 01300	Channel 2: 68.91%	
HFT	Hardware Fault Tolerance	EN 61508	1	
(Type A subsystem)	Traidware Fault Tolerance	EN 01308	I	
SIL	Sofoty Integrity Level	EN 61508	SIL 2	
SIL	Safety Integrity Level	EN IEC 62061	SILCL 2	
PFH	Average frequency of dangerous	EN 61508	9.56×10 <sup>-10</sup>	
PFN	failure [h-1]	EN 01306	9.50^10 **	
DED	Probability of Dangerous Failure	EN 61508	4.18×10 <sup>-6</sup>	
PFD <sub>av</sub>	on Demand	EN 01306	4.10^10 °	
Category	Category	EN ISO 13849-1	Category 3	
PL	Performance level	EN ISO 13849-1	d	
MTTF <sub>d</sub>	Mean time to dangerous failure	EN ISO 13849-1	High	
DC	Diagnostic coverage	EN ISO 13849-1	Low	

## 18-2 Safe Torque Off Terminal Function Description

The Safe Torque Off function is to cut off the power supply to motor through the hardware, thereby the motor could not produce torque.

The STO function controls the motor current driving signal through two hardware circuits respectively, and thus cut off the inverter power module output in order to achieve the status of safety stop.

Operation Principle Description as following table 1:


Table 1: Terminal operation description

Signal	Channel	Photo-coupler status			
CTO simulati	STO1-SCM1	ON (High)	ON (High)	OFF (Low)	OFF (Low)
STO signal	STO2-SCM2	ON (High)	OFF (Low)	ON (High)	OFF (Low)
Driver Output status		Ready	STL2 mode (Torque output off)	STL1 mode (Torque output off)	STO mode (Torque output off)

- STO means Safe Torque Off
- STL1–STL3 means Safe Torque Off hardware abnormal.
- STL3 means STO1–SCM1 and STO2–SCM2 internal circuit detected abnormal.
- STO1–SCM1 ON (High): means STO1–SCM1 has connected to a +24 V<sub>DC</sub> power supply.
- STO2–SCM2 ON (High): means STO2–SCM2 has connected to a +24 V<sub>DC</sub> power supply.
- STO1–SCM1 OFF (Low): means STO1–SCM1hasn't connected to a +24 V<sub>DC</sub> power supply.
- STO2–SCM2 OFF (Low): means STO2–SCM2hasn't connected to a +24 V<sub>DC</sub> power supply.


# 18-3 Wiring Diagram

18-3-1 Internal STO circuit as below:



## 18-3-2 STO Default Short-Circuit


In the figure below, the default setting for +24V-STO1-STO2 and SCM1-SCM2-DCM is short circuit:



## 18-3-3 The Control Loop Wiring Diagram


Use built-in +24V

- 1. Remove the short-circuit of +24V-STO1-STO2.
- 2. The wiring as below diagram. The ESTOP switch must be at Close status in normal situation and the drive will be able to Run.



#### Use external +24V


1. Remove short-circuit of \*1 (DCM-SCM1-SCM2) and \*2 (+24V-STO1-STO2).



#### NOTE:

- \*1. Default short-circuit of DCM-SCM1-SCM2. Remove the short-circuit to use the Safety function.
- \*2. Default short-circuit of +24V-STO1-STO2. Remove the short-circuit to use the Safety function.

- 2. The wiring as below diagram. The ESTOP switch must be at Close status in normal situation and the drive will be able to Run.
- 3. Use external +24  $V_{DC}$  power to replace the built-in +24V after removing the short-circuit.
- 4. When in STO mode and the switch ESTOP is opened, the drive stops outputting and the keypad displays STO.



### 18-4 Parameter

# M 06-44 STO Alarm Latch

Default: 0

Settings 0: STO Alarm Latch

1: STO Alarm no Latch

- Pr.06-44 = 0 STO Alarm Latch: after the reason of STO Alarm is cleared, you need a Reset command to clear STO Alarm.
- Pr.06-44 = 1 STO Alarm no Latch: after the reason of STO Alarm is cleared, the STO Alarm will be cleared automatically.
- The STL1-STL3 error are all "Alarm latch" mode (in STL1-STL3 mode, the Pr.06-44 function is no effective).

# Multi-Function Output 1 (Relay1)

Default: 11

Multi-Function Output 2 (Relay2)

Default: 1

Multi-Function Output 3 (Relay3)

Default: 66

Settings 66: SO N.O. logic A output

68: SO N.C. logic B output

Settings	Functions	Descriptions		
66	SO Logic A output	Safety Output Normal Open		
68	SO Logic B output	Safety Output Normal Close		

☐ CFP2000 default Pr.02-15 (Relay3) = 66 (N.O.) and Multi-function Output setting item adds two new functions: 66 and 68.

	Safety Output Status		
Drive Status	N.O.	N.C.	
	(MOx = 66)	(MOx = 68)	
Normal run	Open	Close	
STO	Close	Open	
STL1-STL3	Close	Open	

# Content of Multi-Function Display

Default: 3

Settings 45: Hardware version

## **18-5 Operating Sequence Description**

#### 18-5-1 Normal Operation Status

As shown in Figure 1: When the STO1–SCM1 and STO2–SCM2 = ON (no STO function is needed), the drive executes "Operating" or "Output Stop" according to the RUN/STOP command.




Figure 1

#### 18-5-2 STO

18-5-2-1 STO, Pr.06-44 = 0, Pr.02-35 = 0

As shown in Figure 4: When both of STO1–SCM1 and STO2–SCM2 channel have turned off during operating, the STO function enables, and the drive stops output regardless of Run command is ON or OFF status.




Figure 2

18-5-2-2 STO, Pr.06-44 = 0, Pr.02-35 = 1

As shown in Figure 3: the same as figure 2. However, due to the setting for Pr.02-35 is 1, if the operating command still exists after the Reset command, the drive will immediately execute the run command again.




Figure 3

## 18-5-3 STO, Pr.06-44 = 1 STO Alarm no latch




Figure 4

#### 18-5-4 STL1




Figure 5

## 18-5-5 STL2




Figure 6

# **18-6 New Error Code for STO Function**

06-17	Fault Record 1
06-18	Fault Record 2
06-19	Fault Record 3
06-20	Fault Record 4
06-21	Fault Record 5
06-22	Fault Record 6

Settings 72: Channel 1 (STO1–SCM1) safety loop error (STL1)

76: Safe torque off (STO)

77: Channel 2 (STO2-SCM2) safety loop error (STL2)

78: Internal loop error (STL3)

Error Code	Name	Description	
76	STO	Safe Torque Off function active	
72	STL1	STO1–SCM1 internal hardware detect error	
12	(STO1-SCM1)	STOT-SCMT Internal hardware detect error	
77	STL2	STO2–SCM2 internal hardware detect error	
77	(STO2-SCM2)		
78	STL3	STO1–SCM1 and STO2–SCM2 internal hardware detect error	


## The Old/New control board and Old/New I/O card:

CFP2000	v1.12 Firmware	v1.20 Firmware
v1.12 control board + old I/O card (no STO function)	OK	OK
v1.12 control board + new I/O card (with STO function)	Error	Error
v1.20 control board + old I/O card (no STO function)	Error	Error
v1.20 control board + new I/O card (with STO function)	Error	OK

# Appendix A. Modbus Protocol

- A-1 Code Description
- A-2 Data Format
- A-3 Communication Protocol
- A-4 Address List
- A-5 Exception Response

- This appendix helps users to control by computers and monitor drive parameters and status through Modbus by using RS-485 serial communication interface
- When using the communication interface, the diagram on the right shows the communication port pin definitions. It is recommended that you connect the AC motor drive to your PC by using Delta IFD6530 or IFD6500 as a communication converter.



- The default communication formats for communication port:
  - 1. Modbus ASCII mode
  - 2. 9600 bps bps serial communication baud rates
  - 3. 7-bit data character
  - 4. No calibration
  - 5. 2 stop bit
- Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex)

# **A-1 Code Description**


The communication protocol is in hexadecimal, ASCII: "0"..."9", "A"..."F", every hexadecimal value represents an ASCII code. The following table shows some examples.

Character	'0'	'1'	'2'	'3'	<b>'4'</b>	<b>'</b> 5'	<b>'6'</b>	<b>'7'</b>
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H


#### A-2 Data Format

10-bit character frame (For ASCII):







(7, E, 1)




(7, O, 1)




11-bit character frame (For RTU):









# **A-3 Communication Protocol**

## 1. Communication data frame

#### **ASCII** mode:

STX	Start character = ':' (3AH)
Address High	Communication address:
Address Low	one 8-bit address consists of 2 ASCII codes
Function High	Command code:
Function Low	one 8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
	n x 8-bit data consists of 2n ASCII codes
DATA 0	n ≤ 16, maximum of 32 ASCII codes (20 sets of data)
LRC Check High	LRC checksum:
LRC Check Low	one 8-bit checksum consists of 2 ASCII codes
END High	End characters:
END Low	END1= CR (0DH), END0= LF(0AH)

### RTU mode:

START	Defined by a silent interval of larger than / equal to 3.5 char
Address	Communication address: 8-bit binary address
Function	Command code: 8-bit binary command
DATA (n-1)	Contents of data:
	N × 8-bit data, n ≤ 16
DATA 0	N ^ 0-bit data, II ≥ 10
CRC Check Low	CRC checksum:
CRC Check High	one 16-bit CRC checksum consists of 2 8-bit binary
ONG Grieck High	characters
END	Defined by a silent interval of larger than / equal to 3.5 char

## 2. Communication address (Address)

00H: broadcast to all AC motor drives

01H: AC motor drive of address 01 0FH: AC motor drive of address 15 10H: AC motor drive of address 16

:

FEH: AC motor drive of address 254

Function (function code) and data (data characters)

03H: read data from a register

Example: Reading two continuous data from register address 2102H, AMD address is 01H.

## **ASCII** mode:

Command Message

STX	6.7 *
Address	'0'
Address	<b>'1'</b>
Function	<b>'</b> 0'
Function	<b>'</b> 3'
	'2'
Starting register	<b>'1'</b>
Starting register	<b>'</b> 0'
	'2'
	<b>'</b> 0'
Number of register	<b>'</b> 0'
(count by word)	<b>'</b> 0'
	'2'
LDC Chook	'D'
LRC Check	<b>'7'</b>
END	CR
EIND	LF

Response Message

STX	· . ·
Address	<b>'</b> 0'
Address	<b>'1'</b>
Function	<b>'</b> 0'
FullClion	<b>'3</b> '
Number of register	<b>'</b> 0'
(count by byte)	<b>'4'</b>
	<b>'1'</b>
Content of starting	<b>'7</b> '
register 2102H	<b>'7</b> '
	<b>'</b> 0'
	'0'
Content of register 2102	<b>'</b> 0'
Content of register 2103H	'0'
	'0'
LRC Check	<b>'</b> 7'
LKC Check	'1'
END	CR
END	LF

## RTU mode:

## **Command Message**

## Response Message

	•
Address	01H
Function	03H
Starting data register	21H
Starting data register	02H
Number of register	00H
(count by word)	02H
CRC Check Low	6FH
CRC Check High	F7H

Address	01H
Function	03H
Number of register (count by byte)	04H
Content of register	17H
address 2102H	70H
Content of register	00H
address 2103H	00H
CRC Check Low	FEH
CRC Check High	5CH

3. 06H: single write, write single data to a register.

Example: Writing data 6000 (1770H) to register 0100H. AMD address is 01H.

#### **ASCII** mode:

#### Command Message

## Response Message

Oommand Wessage		1 tosponso Message		
STX	.,,	STX	· ·	
Address	'0'	Address	'0'	
Addiess	'1'	Addiess	'1'	
Function	'0'	Function	'0'	
1 diletion	'6'	1 diletion	'6'	
	'0'		'0'	
Target register	'1'	Target register	'1'	
larger register	'0'		'0'	
	'0'		'0'	
	'1'	Register content	'1'	
Register content	'7'		'7'	
Register content	'7'		'7'	
	'0'		'0'	
LRC Check	'7'	LRC Check	'7'	
LRC Check	'1'	LIVO Offect	'1'	
END	CR	END	CR	
	LF	LIND	LF	

## RTU mode:

## **Command Message**

## Response Message

Address	01H	
Function	06H	
Target register	01H	T
Target register	00H	"
Degister content	17H	Re
Register content	70H	I KE
CRC Check Low	86H	CF
CRC Check High	22H	CF

Address	01H
Function	06H
Target register	01H
	00H
Register content	17H
	70H
CRC Check Low	86H
CRC Check High	22H

4. 10H: write multiple registers (can write at most 20 sets of data simultaneously).

Example: Set the multi-step speed of an AC motor drive (address is 01H),

Pr.04-00 = 50.00 (1388H), Pr.04-01 = 40.00 (0FA0H.)

## **ASCII** mode:

## **Command Message**

	3
STX	6.5 -
ADR 1	'0'
ADR 0	<b>'1'</b>
CMD 1	<b>'1'</b>
CMD 0	'0'
	'0'
Target register	<b>'4'</b>
Target register	'0'
	'0'
	'0'
Number of register	'0'
(count by word)	'0'
	'2'
Number of register	'0'
(count by byte)	<b>'4'</b>
	<b>'1'</b>
The first data content	<b>'3'</b>
The first data content	<b>'8'</b>
	'8'
	'0'
The second data content	'F'
The second data content	'A'
	<b>'</b> 0'
LRC Check	<b>'</b> 9'
LRC CHeck	'A'
END	CR
END	LF

## Response Message

STX	( , ) -
ADR 1	'0'
ADR 0	'1'
CMD 1	'1'
CMD 0	'0'
	'0'
Torget register	<b>'4'</b>
Target register	'0'
	'0'
	'0'
Number of register	'0'
(count by word)	'0'
	'2'
L DC Chaok	'E'
LRC Check	·8'
END	CR
END	LF

# RTU mode:

# **Command Message**

ADR	01H
CMD	10H
Target register	04H
raiget register	00H
Number of register	00H
(Count by word)	02H
Quantity of data (byte)	04
The first data content	13H
The first data content	88H
The second data content	0FH
The second data content	A0H
CRC Check Low	40H
CRC Check High	49H

## Response Message

ADR	01H
CMD	10H
Target register	04H
Target register	00H
Number of register	00H
(Count by word)	02H
CRC Check Low	41H
CRC Check High	04H

#### 5. Checksum

1. ASCII mode (LRC Check):

LRC (Longitudinal Redundancy Check) is calculated by summing up the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

Example:

01H + 03H + 21H + 02H + 00H + 02H = 29H, the 2's-complement negation of 29H is D7H.

2. RTU mode (CRC Check):

CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFh.

- Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.
- Step 3: Examine the LSB of CRC register.
- Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right, fill MSB with zero, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right, fill MSB with zero, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.
- Step 5: Repeat step 3 and 4 until you perform eight shifts. This processes a complete 8-bit byte.
- Step 6: Repeat step 2 through 5 for the next 8-bit byte of the command message. Continue doing this until all bytes are processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, that is, the lower order byte is transmitted first.
- 6. The following is an example of CRC generation using C language.

```
Unsigned char* data ← a pointer to the message buffer
```

```
Unsigned char length ← the quantity of bytes in the message buffer
unsigned int crc chk(unsigned char* data, unsigned char length)
      int j;
      unsigned int reg crc=0xffff;
      while(length--){
           reg crc ^= *data++;
           for(j=0;j<8;j++){
                if(reg crc \& 0x01){ /* LSB(b0)=1 */
                     reg crc=(reg crc>>1) ^ 0xa001;
                }else{
                     reg crc=reg crc >>1;
           }
      }
      return reg crc;
                                         // return register CRC
 }
```

# **A-4 Address List**

#### 1. ASCII

- (1) Reads one or more parameter values: 3Ah (start bit': ') + 30h 31h (station address 01) + 30h 33h (function code 03h) + 30h 30h xxh xxh–32h 36h xxh xxh (Modbus address 00xxh–26xxh) + xxh xxh xxh xxh (reading length 1) + LRC (checksum) + CR/LF
- (2) Writes one parameter value: 3Ah (start bit': ') + 30h 31h (station address 01) + 30h 36h (function code 06h) + 30h 30h xxh xxh–32h 36h xxh xxh(Modbus address 00xxh–26xxh) + xxh xxh xxh (writing value) + LRC (checksum) + CR/LF
- (3) Writes 20 parameter values: 3Ah (start bit': ') + 30h 31h (station address 01) + 31h 30h (function code 10h) + 30h 30h xxh xxh–32h 36h xxh xxh (Modbus address 00xxh–26xxh) + 30h 30h 31h 34h (word data length) + 32h 38h (byte data length) + xxh xxh xxh xxh (the first writing value) + ... + xxh xxh xxh xxh (the 20th writing value) + LRC (checksum) + CR/LF

#### 2. RTU

- (1) Reads one or more parameter values: 01h (station address 01) + 03h (function code 03h) + 00xxh–26xxh (Modbus address) + xxxxh (reading length) + CRC (checksum)
- (2) Writes one parameter value: 01h (station address 01) + 06h (function code 06h) + 00xxh–26xxh (Modbus address) + xxxxh (writing value) + CRC (checksum)
- (3) Writes 20 parameter values: 01h (station address 01) + 10h (function code 10h) + 00xxh–26xxh (Modbus address) + 0014h (data length, count by word) + 28h (data length, count by byte) + xxxxh (the first writing value) + ... + xxxxh (the 20th writing value) + CRC (checksum)
- 3. AC motor drive parameters (GGnnH): communication station address is Pr.09-00 setting value

Modbus Address	Attribute (Function Code)	Description
GGnnH	R(03H) / W(06H, 10H)	GG means parameter group, nn means parameter number. For example, the Modbus address of Pr.04-10 is 040AH when reading by Delta VFDsoft.

4. Control command (20xx): communication station address is Pr.09-00 setting value

Function Name	Modbus Address	Attribute (Function Code)	Size	Size Description		
Operation command	2000H	R (03H) / W (06H, 10H)	U16	bit1–0 bit3–2 bit5–4	00b: No function 01b: Stop 10b: Run 11b: JOG + Run Reserved 00b: No function 01b: FWD 10b: REV 11b: Change direction 00b: 1st accel. / decel.	Remains the status specified by a first command until a second command is received.  Valid only when operation command source is set to communication (Pr.00-03=2).
			bit7–6	01b: 2nd accel. / decel. 10b: 3rd accel. / decel.	bit12 is set to 1. Obtain the current running	
					11b: 4th accel. / decel.	speed by reading 2107h.

Function	Modbus	Attribute				
Name	Address	(Function	Size		Description	n
	- 1	Code)			T	
					0000b: zero step speed	
					0001b: 1st step speed	
					0010b: 2nd step speed	
					0011b: 3rd step speed	
					0100b: 4th step speed	
					0101b: 5th step speed	
					0110b: 6th step speed	
				bit11–8	0111b: 7th step speed	
				DILTI-0	1000b: 8th step speed	
					1001b: 9th step speed	
					1010b: 10th step speed	
					1011b: 11th step speed	
					1100b: 12th step speed	]
					1101b: 13th step speed	
					1110b: 14th step speed	
				bit12	1111b: 15th step speed	
					1: Enable bit06–11 functi	on
				bit15-13	Reserved	
_		R (03H)/	U16	_		
Frequency	2001H	W (06H,		1	command (XXX.XX Hz).	There are two decimal
command		10H)		places for	general-purpose drives.	
		·				To trigger an external fault
						to the drive to make it
				bit0	1: External Fault (E.F.)	stop running. Drive's stop
					ON	method can be set
						through drive parameters.
Fault / control		R (03H)/		bit1	1: Reset	To clear the fault status
command	2002H	W (06H,				To trigger an external
source		10H)				base block to the drive to
				F:10	4. Dana blank (D.D.) ON	suspend the operation.
			bit2	1: Base block (B.B) ON	When bit = 0 and clear BB	
						situation, the drive returns
				to the previous operation.		
				bit15-3	Reserved	
DID		R(03H)/			PID reference	
PID	2003H	W(06H,		bit15-0	-10000- +100000 corres	ponds to
reference		10H)			-100.0%– 100.00%.	

5. Status monitor read only (21xx): communication station address is Pr.09-00 setting value

Function Name	Modbus Address	Attribute (Function Code)	Size	Description		
Fault status	2100H	R(03H)	U16	bit7–0: Fault code bit15–8: Warning code		
Drive operation status	2101H	R(03H)	U16	bit1–0 bit2 bit4–3 bit7 bit8 bit9 bit10 bit11 bit12	Status of RUN / STOP  00b: Drive fully stops (RUN indicator is OFF / STOP indicator is ON)  01b: Drive is stopping (RUN indicator flashes / STOP indicator is ON)  10b: Drive is in standby status (RUN indicator is ON / STOP indicator flashes)  11b: Drive is running (RUN indicator is ON / STOP indicator is OFF)  1: JOG command  Operation direction  00b: FWD (REV indicator is OFF / FWD indicator is ON)  01b: from REV to FWD (REV indicator flashes / FWD indicator is ON)  10b: from FWD to REV (REV indicator is ON / FWD indicator flashes)  11b: REV (REV indicator is ON / FWD indicator is OFF)  Drive is controlled by external terminals  1: Master frequency controlled by communication interface  1: Master frequency controlled by analog / external terminal signal  1: Operation command controlled by communication interface  1: Parameter locked  Reserved  The status of HOA and LOC / REM  000b (0): HOA mode OFF  001b (1): HOA mode HAND-ON  010b (2): HOA mode AUTO-ON  011b (3): LOC/REM mode LOC-ON	
Frequency command	2102H	R(03H)			100b (4): LOC/REM mode REM-ON quency command (XXX.XX Hz) node→Speed command	
Output frequency	2103H	R(03H)		·	put frequency (XXX.XX Hz)	
Output current	2104H	R(03H)		Drive's output current (XX.XX A). Decimal places can be referred by the high byte of 211Fh		
DC bus voltage	2105H	R(03H)		Drive's DC	bus voltage (XXX.X V)	

Function Name	Modbus Address	Attribute (Function Code)	Size	Description
Output voltage	2106H	R(03H)		Drive's output voltage (XXX.X V)
Multi-step speed status	2107H	R(03H)		Drive's current running speed step given by multi-step speed command (0 is main speed)
Counter value	2109H	R(03H)		The present value of MI
Output power factor angle	210AH	R(03H)		Drive's output power factor angle (XXX.X°) (0.0–180.0°)
Reserve	210BH	R(03H)		Reserve
Motor actual speed	210CH	R(03H)		Actual motor speed (XXXXX rpm)
Reserve	210DH	R(03H)		Reserve
Reserve	210EH	R(03H)		Reserve
Power output	210FH	R(03H)	U16	Drive's output power (X.XXX kW)
Multi- function display	2116H	R(03H)		Display the low word value (Pr.00-04) of user-defined items, the value is low 16 bits data.
Maximum user- defined value	211BH	R(03H)		Maximum Operation Frequency (Pr.01-00) or Maximum User-defined Value (Pr.00-26) When Pr.00-26 is 0, this value is equal to Pr.01-00 setting When Pr.00-26 is not 0, and the command source is keypad, this value = Pr.00-24 × Pr.00-26 / Pr.01-00 When Pr.00-26 is not 0, and the command source is 485, this value = Pr.09-10 × Pr.00-26 / Pr.01-00
Keypad output current display (A page) attribute	211FH	R(03H)		bit7–0: Reserve bit9–8: Decimal point of A page bit15–10: Reserve

# 6. Status monitor read only (22xx): communication station address is Pr.09-00 setting value

		, ,		3
Function Name	Modbus Address	(Function	Size	Description
Output current	2200H	R(03H)		Display output current (A). When current is higher than 655.35, it shifts the decimal as (XXX.X A). The decimal can refer to High byte of 211F.
Counter value	2201H	R(03H)	U16	Display counter value (c)
Output frequency	2202H	R(03H)		Actual output frequency (XXXXX Hz)

Function Name	Modbus Address	Attribute (Function Code)	Size	Description
DC bus voltage	2203H	R(03H)		DC bus voltage (XXX.X V)
Output voltage	2204H	R(03H)		Output voltage (XXX.X V)
Power factor angle	2205H	R(03H)		Power angle (XXX.X)
Power output	2206H	R(03H)		Display actual motor speed kW of U, V, W (XXXX.X kW)
Motor actual speed	2207H	R(03H)		Display motor speed in rpm estimated by the drive or encoder feedback (XXXXX rpm)
Reserve	2208H	R(03H)		Reserve
Reserve	2209H	R(03H)		Reserve
PID feedback value	220AH	R(03H)		PID feedback value after enabling PID function (XXX.XX %)
AVI1 analog input	220BH	R(03H)		Display signal of AVI1 analog input terminal, 0–10 V corresponds to 0.00–100.00% (1.) (see NOTE 2 in Pr.00-04)
ACI analog input	220CH	R(03H)		Display signal of ACI analog input terminal, 4–20 mA / 0–10 V corresponds to 0.00–100.00% (2.) (see NOTE 2 in Pr.00-04)
AVI2 analog input	220DH	R(03H)		Display signal of AVI2 analog input terminal, -10 V-10 V corresponds to -100.00-100% (3.) (see NOTE 2 in Pr.00-04)
IGBT temperature	220EH	R(03H)	U16	IGBT temperature of drive power module (XXX.X°C)
Drive capacitance temperature	220FH	R(03H)		The temperature of capacitance (XXX.X°C)
Digital input status	2210H	R(03H)		The status of digital input (ON/OFF), refer to Pr.02-12 (see NOTE 3 in Pr.00-04)
Digital output status	2211H	R(03H)		The status of digital output (ON/OFF), refer to Pr.02-18 (see NOTE 4 in Pr.00-04)
Multi-step speed	2212H	R(03H)		The multi-step speed that is executing (S)
The cor- responding CPU pin status of digital input	2213H	R(03H)		The corresponding CPU pin status of digital input (d.) (see NOTE 3 in Pr.00-04)
The corresponding CPU pin status of digital output	2214H	R(03H)		The corresponding CPU pin status of digital output (O.) (see NOTE 4 in Pr.00-04)
Reserve	2215H	R(03H)		Reserve

Function Name	Modbus Address	Attribute (Function Code)	Size		Description		
Reserve	2216H	R(03H)		Reserve			
Reserve	2217H	R(03H)		Reserve			
Reserve	2218H	R(03H)		Reserve			
Overload		,					
counter	2219H	R(03H)		Display tin	nes of counter overload (XXX.XX %)		
GFF	221AH	R(03H)		GFF (XXX	XX%)		
DC bus							
voltage	221BH	R(03H)		DC bus voltage ripples (XXX.X V)			
ripples							
PLC	221CH	R(03H)		PLC regist	ter D1043 data (C)		
register		. ,			( )		
Reserve	221DH	R(03H)		Reserve			
Display of							
user-	221EH	R(03H)		User page	displays the value in physical measure		
defined		(/			,		
output							
Pr.00-05	221FH	R(03H)		Output fre	quency × Pr.00-05 (XXX.XX Hz)		
gain value		. ,			4		
Reserve	2220H	R(03H)		Reserve			
Reserve	2221H	R(03H)		Reserve			
Running							
speed of	2222H	R(03H)		Fan speed	d of the drive (XXX%)		
fan			U16				
Control	2223H	R(03H)		Control mo	ode of the drive 0: speed mode		
mode					·		
Frequency	000411	D (0011)					
of carrier	2224H	R(03H)		Carrier fre	quency of the drive (XX kHz)		
wave				Drive statu	In the second se		
				Drive Statt			
				h:44 O	00b: No direction		
				bit1~0	01b: Forward		
					10b: Reverse		
Drive status	2226H	R(03H)		bit3~2	01b: Drive ready		
		,		-	10b: Error		
				bit4	0b: Motor drive did not output		
				DIL4	1b: Motor drive did output		
				L:47	0b: No alarm		
				bit5	1b: Alarm		
Reserve	2227H	R(03H)		Reserve			
Torque	2228H	R(03H)		Reserve			
command				I/e2e1 Ae			
kWh	2229H	R(03H)		kWh display (XXXX.X)			
Reserve	222AH	R(03H)		Reserve			
Reserve	222BH	R(03H)		Reserve			
Reserve	222CH	R(03H)		Reserve			

# Appendix A. Modbus Protocol | CFP2000

Function Name	Modbus Address	Attribute (Function Code)	Size	Description
Reserve	222DH	R(03H)		Reserve
PID reference	222EH	R(03H)		PID reference (XXX.XX%)
PID offset	222FH	R(03H)		PID offset (XXX.XX%)
PID output frequency	2230H	R(03H)		PID output frequency (XXX.XX Hz)
Hardware ID of control board	2231H	R(03H)		Hardware ID
Reserve	2232H   2235H	R(03H)		Reserve
Extension card Al10	2238H	R(03H)		Al10%
Extension card Al11	2239H	R(03H)	U16	Al11%
Reserve	223FH	R(03H)		Reserve
d-axis current command	224AH	R(03H)		Id Reference (XXX.XX A)
q-axis current command	224BH	R(03H)		Iq Reference (XXX.XX A)
d-axis current feedback	224CH	R(03H)		Id feedback value (XXX.XX A)
q-axis current feedback	224DH	R(03H)		Iq feedback value (XXX.XX A)

# 7. Remote IO (26xx): communication station address is Pr.09-00 setting value

1 (0111010 10 (2				
Function Name	Modbus Address	Attribute (Function Code)	Size	Description
Digital input terminal MI16–MI1 status	2600H	R(03H)		Each bit corresponds to different input terminal contact
Digital output terminal MO16–MO1 status	2640H	R(03H) / W(06H, 10H)	U16	Each bit corresponds to different input terminal contact
AVI1 proportional value	2660H	R(03H)		Analog input signal Al0 proportion
ACI proportional value	2661H	R(03H)		Analog input signal Al1 proportion
AVI2 proportional value	2662H	R(03H)		Analog input signal Al2 proportion
Percentage of analog input signal AI10	266AH	R(03H)		Extension card Al10, 0.0–100.0% (EMC-A22A)
Percentage of analog input signal AI11	266BH	R(03H)		Extension card Al11, 0.0–100.0% (EMC-A22A)
AFM1 output proportional value	26A0H	R(03H) / W(06H, 10H)	U16	AFM1 output proportional value (%)
AFM2 output proportional value	26A1H	R(03H) / W(06H, 10H)		AFM2 output proportional value (%)
Percentage of analog output signal AO10	26AAH	R(03H) / W(06H, 10H)		Extension card AO10, 0.0–100.0% (EMC-A22A)
Percentage of analog output signal AO11	26ABH	R(03H) / W(06H, 10H)		Extension card AO11, 0.0–100.0% (EMC-A22A)

8. 60xxh Output message (Upper unit → Drive): Pr.09-30 = 1

Indov	Index Attr.	Cizo		Description		Speed Made										
index	Aur.	Size	bit	Definition	Access	Speed Mode										
			0	Cmd_Act	4	0: fcmd =0										
			O	Cilid_Act	4	1: fcmd = Fset (Fpid)										
			1	Dir_Cmd	4	0: FWD command										
			'	Dii_Cilid	~	1: REV command										
			2	Reserve												
			3	Halt	3	0: Continue operating to the target speed										
			3	Hait	0	1: Stops according to the deceleration setting										
			4	Lock	4	0: Continue operating to the target speed										
			7	LOOK	7	1: Stops at current frequency										
			5	JOG	4	0: JOG OFF										
6000h	RW					Edge 0 → 1: JOG RUN (Act OFF is valid)										
		U16	6	QStop	2	Quick Stop										
			16 7	Servo_ON	1 1	0: Servo OFF										
						1: Servo ON										
			8	Reserve												
			9	Ext Cmd2	4	Edge 0 → 1: Clear absolute position										
							10	InrDOS	4	0: Disable internal positioning						
							10 14–1		-	10	10	10	10	InrPOS	4	Edge 0 → 1: Execute internal positioning
											14–11	Reserve				
			15	RST	1	Edge 0 → 1: Clear fault codes										
6001h	RW			Mode		0: Speed mode										
6002h	RW			Speed		Speed command (unsigned)										
6003h	RW			Torque Limit		Torque limit (signed)										
6007h	RW			Speed Limit		Speed limit (unsigned)										

# 9. 61xxh Input message (Drive → Upper unit): Pr.09-30 = 1

Index Attr.		Cina	Description		Speed Mode										
index	Aur.	Size	bit	Definition	Speed Mode										
			0	Arrive	0: Frequency command not arrived										
			O		1: Frequency command arrived										
			1	Dir	0: FWD command										
	6100h R U16		'		1: REV command										
6100h		U16	2	Warn	0: No warning										
		3						2	2	2	2	2	2	vvaiii	1: Warning
			3											2	F
				3	Error	1: Error									
			4	Reserve											

la day	۸ 44	4 C:		Description	Chand Mada
Index	Attr.	Size	bit	Definition	Speed Mode
			E		0: JOG OFF
			5	JOG	1: On JOG
			6	QStop	Quick Stop
			7	Sonro ON	0: PWM OFF
			,	Servo_ON	1: PWM ON
			8	POS_Match	0: Mechanical origin not matched
			0	POS_Match	1: Mechanical origin matched
			10–9	Reserve	
				OMS	0: bit11 Internal limit no active
			11	(Operation mode	1: bit 11 Internal limit active
				specific)	1. Dit 11 mileman minit active
			13–12	Reserve	
				OMS	O. hit14 not reaching hardware limit
			14	(Operation mode	0: bit14 not reaching hardware limit 1: bit14 reaches hardware limit
				specific)	1. Dit 14 reaches hardware innit
			15	Synchronous	0: Not synchronizing
			13	detection	1: Synchronized
6101h	R			Mode	Actual mode
6102h	R			Actual Velocity	Actual output command
010211	17			Actual velocity	(unit: 0.01 Hz / high-speed model: 0.1Hz)
6103h	R			Error code	Defines the drive error codes with DS302 and DS402
310011				2.707 0000	(only valid with EtherCAT and CANopen)
6104h	R			Actual Pos	Actual position (absolute) (Unit: Pulse)
6105h	R			, (0.00.1 00	total position (abborato) (orna i albo)
6106h	R			Actual Torq	Actual torque (signed) (unit: 0.1%)

# **A-5 Exception Response**

When the drive is using the communication connection, if an error occurs, the drive responds to the error code and sets the highest bit (bit 7) of the command code to 1 (function code AND 80H) then responds to the control system to signal that an error occurred.

If the keypad displays "CE-XX" as a warning message, "XX" is the error code at that time. Refer to the table of error codes for communication error for reference.

#### **ASCII** mode

STX	·.,
Address	'0'
Address	'1'
Function	'8'
Function	'6'
Evention and	'0'
Exception code	'2'
LRC Check	'7'
LRC CHeck	'7'
END	CR
EIND	LF

## **RTU** mode

Address	01H
Function	86H
Exception code	02H
CRC Check Low	СЗН
CRC Check High	A1H

The explanation of exception codes:

Error Code	Explanation
1	Function code is not supported or unrecognized.
2	Address is not supported or unrecognized.
3	Data is not correct or unrecognized.
4	Failure to execute this function code

# Appendix B. Revision History

Version	Add Information					
version	Description	Related Chapter				
FW V1.07	Add 230V and 575V series models information	All manual				
Manual V01	Add consumption data to AC input / output reactors	Chapter 7				
	Add option card eZVFD-CC	Chapter 8				
	Add SynRM Sensorless control mode and PM Sensorless control	All manual				
	mode	All Illanual				
	Add keypad languages: Polski, Deutsch, Italiano and Svenska	Chapter 10				
	SynRM parameters:					
	Parameter group 00: 00-11, 00-17					
	• Parameter group 05: 05-00, 05-33, 05-34~05-41					
	Other new parameters:					
	Parameter group 00: 00-37					
	Parameter group 01: 01-50, 01-51	Chapter 11				
	Parameter group 06: 06-12	Section 12-1				
	• Parameter group 07: 07-21, 07-41–07-45					
	Parameter group 09: 09-49					
	• Parameter group 10: 10-08–10-15, 10-33, 10-35, 10-36, 10-					
	54–10-58					
	Parameter group 11: 11-00–11-23					
	Add Adjustment for SynRM	Section 12-2				
	Add summary of warning codes and fault codes	Chapter 13, 14				
	Add Warning code of CKx	Chapter 13				
	Add CANopen built-in PLC register D indexes	Chapter 15				
	Add PLC special M register: M1019 Motor drive warning indicator	Chapter 16				
	Add PLC special D register: D1560 Motor drive warning code	Chapter 10				
FW 1.09	Add information of CMC-EIP02	Chapter 8				
Manual V00	Add power supply capacity (kVA), certification download website	Chapter 9				
	and operation level information	Chapter 9				
	Add parameters:					
	• Parameter group 00: 00-04=54, 00-15, 00-33, 00-34					
	• Parameter group 03: 03-19 = 4					
	Parameter gropu 06: 06-88, 06-89	Chapter 11, 12				
	Parameter gropu 07: 07-62, 07-63	Onapioi 11, 12				
	Parameter gropu 09: 09-06, 09-74					
	Parameter group 11: 11-24, 11-25					
	• Parameter gropu 14: 14-10–14-11 = 4					

Manaian	Add Information		
Version	Description	Related Chapter	
	Add Fault code 113 (SWOC) and description	Chapter 14	
	Add Appendix A. Modbus Protocol (the original description in	Appendix A	
	Pr.09-04)	Appendix A	

\/avaiava	Updated Information					
Version	Description	Related Chapter				
FW V1.07	Update RFI jumper switch and sketch of each frame	Chapter 1				
Manual V01	Update wiring diagram of basic waterproof components	Chapter 4				
	Update specification of main circuit terminals, and add operation	Chantar F				
	conditions under ambient termperature 50°C	Chapter 5				
	Update the part number of zero phase reactors	Chapter 7				
	Adjust table format of 575V models AC reactors	Chapter 7				
	Update derating curve and certifications	Chapter 9				
	Update information of keypad function, Start Wizard and Warning	01 1 10				
	/ Fault codes	Chapter 10				
	Update parameter settings and descritpions:					
	• Parameter group 00: 00-00, 00-04, 00-06, 00-08, 00-11, 00-					
	17, 00-20, 00-24, 00-26, 00-30					
	• Parameter group 01: 01-01, 01-02, 01-10, 01-11, 01-23, 01-					
	35, 01-36, 01-49					
	• Parameter group 02: 02-01–02-08, 02-26–02-31, 02-10–02-					
	15, 02-36–02-46, 02-50, 02-51, 02-53, 02-73					
	• Parameter group 03: 03-20-03-25, 03-29, 03-57					
	<ul> <li>Parameter group 05: 05-24, 05-28-05-30</li> </ul>					
	• Parameter group 06: 06-03, 06-04, 06-16, 06-17-06-22, 06-	Chapter 11				
	23–06-26, 06-29, 06-46–06-48, 06-49, 06-53, 06-55, 06-73, 06-80–06-87	Section 12-1				
	<ul> <li>Parameter group 07: 07-08, 07-12, 07-19, 07-26, 07-27</li> </ul>					
	<ul> <li>Parameter group 08: 08-00, 08-06, 08-10, 08-11, 08-15</li> </ul>					
	(Reserved)					
	<ul> <li>Parameter group 09: 09-02, 09-04, 09-11-09-26, 09-30, 09-</li> </ul>					
	60, 09-75–09-92					
	<ul> <li>Parameter group 10: 10-34, 10-53</li> </ul>					
	• Parameter group 12: 12-00, 12-04, 12-09					
	• Parameter group 14: 14-10, 14-11, 14-16, 14-17					
	Update DO terminals	Chapter 15				
	Delete setting 4: Torque Profile Mode from 6060h	Chapter 15				
	Update the fault codes for CANopen	Chapter 15				

Version	Updated Information				
version	Description	Related Chapter			
	Correct the STO operating diagram	Chapter 18			
FW V1.09 Manual V00	Correct warnings before use	Warnings before use			
Wandar VOO	Correct Service link information and grounding description	Chapter 1			
	Update specification and description of main circuit temrinals	Chapter 5			
	Update brakint resistors selection, reactors information and	Onapter o			
	diagram correction, sine-wave filter description and information of	Chapter 7			
	EMC filters	Chapter 7			
	Correct information of CMC-EIP01 protocl and EMC-COP01				
	specification, update option card model name of eZVFD	Chapter 8			
	Modify information of general specification and the level marking				
	of certifications	Chapter 9			
	Update parameter settings and description:				
	Parameter group 00: 00-11				
	<ul> <li>Parameter group 01: 01-00, 01-34, 01-44, 01-49, 01-50</li> </ul>				
	<ul> <li>Parameter group 02: 02-00, 02-01-02-08/ 02-26-02-31, 02-</li> </ul>				
	12, 02-13-02-15/ 02-36-02-46				
	<ul> <li>Parameter group 03: 03-00-03-02, 03-07-03-09, 03-19, 03-</li> </ul>				
	68				
	<ul> <li>Parameter group 05: 05-28-05-30, 05-38</li> </ul>	Chapter 11			
	• Parameter group 06: 06-03-06-04, 06-08, 06-17-06-22, 06-	Section 12-1			
	23–06-26, 06-52, 06-55, 06-80, 06-83				
	<ul> <li>Parameter group 07: 07-13, 07-23</li> </ul>				
	<ul> <li>Parameter group 08: 08-00, 08-22</li> </ul>				
	<ul> <li>Parameter group 09: 09-00-09-04, 09-30, 09-75~09-92</li> </ul>				
	Parameter group 11: 11-00				
	• Parameter group 12: 12-00, 12-05				
	• Parameter group 14: 14-12–14-13				
	Correct description of adjustment	Section 12-2			
	Delete Warning code 19 (PHL) and 23 (dEb)				
	Modify description of warning code oSL and oSPd, and update	Chapter 13			
	the warning name of oH2				
	Delete Fault code 62 (dEb)				
	Modify description of fault code oL3, oSL, SdRv and SdOr	Chapter 14			
	Update Fault name of oH2				
	Update DS402 and CANopen index, update description of	Ob anti- 45			
	CANopen fault codes	Chapter 15			
	Update description of OS that supported by WPLSoft, and	Chapter 16			
	description of PLC commands (FPID, WPR)				

# Appendix B. Revision History | CFP2000

Version	Updated Information	
	Description	Related Chapter
	Update STO wiring	Chapter 18
	Update CANopen and Modbus command description and correct communication protocol	Appendix A



# **Industrial Automation Headquarters**

#### Delta Electronics, Inc.

Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District, Taoyuan City 330477, Taiwan TEL: +886-3-362-6301 / FAX: +886-3-371-6301

#### **Asia**

#### Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C. Post code: 201209

TEL: +86-21-6872-3988 / FAX: +86-21-6872-3996

Customer Service: 400-820-9595

#### Delta Electronics (Japan), Inc.

Industrial Automation Sales Department 4-11-25, Shibaura, Minato-ku, Tokyo 108-0023, Japan TEL: +81-3-6811-5470 / FAX: +81-3-6811-5802

#### Delta Electronics (Korea), Inc.

1511, 219, Gasan Digital 1-Ro., Geumcheon-gu, Seoul, 08501 South Korea TEL: +82-2-515-5305 / FAX: +82-2-515-5302

#### Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939 TEL: +65-6747-5155 / FAX: +65-6744-9228

#### Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: +91-124-4874900 / FAX: +91-124-4874945

#### Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z), Pattana 1 Rd., T.Phraksa, A.Muang, Samutprakarn 10280, Thailand TEL: +66-2709-2800 / FAX: +66-2709-2827

#### Delta Electronics (Australia) Pty Ltd.

Unit 2, Building A, 18-24 Ricketts Road, Mount Waverley, Victoria 3149 Australia Mail: IA.au@deltaww.com TEL: +61-1300-335-823 / +61-3-9543-3720

#### **Americas**

#### Delta Electronics (Americas) Ltd.

5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: +1-919-767-3813

#### Delta Electronics Brazil Ltd.

Estrada Velha Rio-São Paulo, 5300 Eugênio de Melo - São José dos Campos CEP: 12247-004 - SP - Brazil TEL: +55-12-3932-2300 / FAX: +55-12-3932-237

#### Delta Electronics International Mexico S.A. de C.V.

Gustavo Baz No. 309 Edificio E PB 103 Colonia La Loma, CP 54060 Tlalnepantla, Estado de México TEL: +52-55-3603-9200

#### **EMEA**

#### Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com
Marketing: Marketing.IA.EMEA@deltaww.com
Technical Support: iatechnicalsupport@deltaww.com
Customer Support: Customer-Support@deltaww.com
Service: Service.IA.emea@deltaww.com

TEL: +31(0)40 800 3900

#### Delta Electronics (Netherlands) B.V.

Automotive Campus 260, 5708 JZ Helmond, The Netherlands

Mail: Sales.IA.Benelux@deltaww.com

TEL: +31(0)40 800 3900

#### Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany Mail: Sales.IA.DACH@deltaww.com

TEL: +49 2921 987 238

#### Delta Electronics (France) S.A.

ZI du bois Challand 2,15 rue des Pyrénées, Lisses, 91090 Evry Cedex, France Mail: Sales.IA.FR@deltaww.com TEL: +33(0)1 69 77 82 60

#### Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed. Hormigueras – P.I. de Vallecas 28031 Madrid

TEL: +34(0)91 223 74 20

Carrer Llacuna 166, 08018 Barcelona, Spain Mail: Sales.IA.Iberia@deltaww.com

#### Delta Electronics (Italy) S.r.l.

Via Meda 2–22060 Novedrate(CO) Piazza Grazioli 18 00186 Roma Italy Mail: Sales.IA.Italy@deltaww.com TEL: +39 039 8900365

#### Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A

34775 Ümraniye – İstanbul

Mail: Sales.IA.Turkey@deltaww.com

TEL: + 90 216 499 9910

#### Eltek Dubai (Eltek MEA DMCC)

OFFICE 2504, 25th Floor, Saba Tower 1, Jumeirah Lakes Towers, Dubai, UAE Mail: Sales.IA.MEA@deltaww.com

TEL: +971(0)4 2690148